
See original or copy: <http://web.me.com/klaus.richter/GEE38/GEE38L0NA.TXT> / .PSS
 Technical information: <http://www.ps.ban.de> V 2.1, io=1, Cx=0, cfi=1.00, nt=0

IJB registration: 20091101-GE38/GE38L0NA.IX1/.ps IJB ma
 application for evaluation and measurement of printer or monitor systems

IOB material: code=rha4ta

[illegible]

TUB-test chart GE38; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

input: w *setgray*
output: no change compared to input

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE38/GE38L0NA.TXT> /PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

001717	002411	000724	0375	0000	0000	00625	1000	1000	0000	%0243	A10	\$	002120	003272	001345	0500	0000	0000	0500	1000	1000	0000	%0324	J10	\$	002591	004279	002099	0625	0000	0000	0375	1000	1000	0000	%0405	S10	\$
001819	003059	-01258	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$	002215	003822	-00726	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$	002677	004700	-00066	0625	0000	0125	0375	1000	0875	0000	%0406	S11	\$
001914	003600	-02423	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$	002280	004277	-01944	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$	002729	005062	-01332	0625	0000	0250	0375	1000	0750	0000	%0407	S12	\$
001984	004201	-03406	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$	002356	004754	-02942	0500	0000	0375	0500	1000	0625	0000	%0327	J13	\$	002783	005455	-02391	0625	0000	0375	0375	1000	0625	0000	%0408	S13	\$
002059	004786	-04301	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$	002411	005274	-03871	0500	0000	0500	0500	1000	0500	0000	%0328	J14	\$	002833	005889	-03339	0625	0000	0500	0375	1000	0500	0000	%0409	S14	\$
002122	005365	-05068	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$	002492	005792	-04666	0500	0000	0625	0500	1000	0375	0000	%0329	J15	\$	002900	006352	-04172	0625	0000	0625	0375	1000	0375	0000	%0410	S15	\$
002179	005798	-05591	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$	002555	006183	-05194	0500	0000	0750	0500	1000	0250	0000	%0330	J16	\$	002944	006685	-04714	0625	0000	0750	0375	1000	0250	0000	%0411	S16	\$
002202	006004	-05838	0375	0000	0875	0625	1000	0125	0000	%0250	A17	\$	002584	006370	-05455	0500	0000	0875	0500	1000	0125	0000	%0331	J17	\$	002943	006843	-04969	0625	0000	0875	0375	1000	0125	0000	%0412	S17	\$
002212	006025	-05839	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$	002595	006382	-05461	0500	0000	1000	0500	1000	0000	0000	%0332	J18	\$	002961	006860	-04978	0625	0000	1000	0375	1000	0000	0000	%0413	S18	\$
002453	001261	001609	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$	002829	002179	002186	0500	0125	0000	0500	0875	1000	0000	%0333	K10	\$	003305	003253	-00242	0625	0125	0000	0375	0875	1000	0000	%0414	T10	\$
002608	001797	-00496	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$	002962	002629	-00012	0500	0125	0125	0500	0875	0875	0000	%0334	K11	\$	003340	003592	000614	0625	0125	0125	0375	0875	0875	0000	%0415	T11	\$
002712	002315	-01784	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$	003057	003014	-01302	0500	0125	0250	0500	0875	0750	0000	%0335	K12	\$	003518	003912	-00738	0625	0125	0250	0375	0875	0750	0000	%0416	T12	\$
002809	002878	-02844	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$	003149	003507	-02422	0500	0125	0375	0500	0875	0625	0000	%0336	K13	\$	003594	004296	-01895	0625	0125	0375	0375	0875	0625	0000	%0417	T13	\$
002881	003497	-03859	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$	003218	004053	-03470	0500	0125	0500	0500	0875	0500	0000	%0337	K14	\$	003656	004758	-02960	0625	0125	0500	0375	0875	0500	0000	%0418	T14	\$
002958	004124	-04735	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$	003306	004625	-04380	0500	0125	0625	0500	0875	0375	0000	%0338	K15	\$	003723	005263	-03923	0625	0125	0625	0375	0875	0375	0000	%0419	T15	\$
003032	004632	-05370	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$	003364	005084	-05039	0500	0125	0750	0500	0875	0250	0000	%0339	K16	\$	003770	005663	-04590	0625	0125	0750	0375	0875	0250	0000	%0420	T16	\$
003051	004902	-05693	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$	003370	005339	-05375	0500	0125	0875	0500	0875	0125	0000	%0340	K17	\$	003778	005896	-04944	0625	0125	0875	0375	0875	0125	0000	%0421	T17	\$
003053	004937	-05712	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$	003384	005371	-05394	0500	0125	1000	0500	0875	0000	0000	%0341	K18	\$	003790	005915	-04965	0625	0125	1000	0375	0875	0000	0000	%0422	T18	\$
003268	-00099	002653	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$	003611	000864	003209	0500	0250	0000	0500	0750	1000	0000	%0342	L10	\$	004121	001990	003962	0625	0250	0000	0375	0750	1000	0000	%0423	U10	\$
003428	000337	000432	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$	003773	001812	000913	0500	0250	0125	0500	0750	0875	0000	%0343	L11	\$	004281	002223	001553	0625	0250	0125	0375	0750	0875	0000	%0424	U11	\$
003560	000794	-00964	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$	003808	001558	-00493	0500	0250	0250	0500	0750	0750	0000	%0344	L12	\$	004382	002500	000049	0625	0250	0250	0375	0750	0750	0000	%0425	U12	\$
003664	001295	-02039	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$	003878	001737	-00708	0500	0250	0375	0500	0875	0375	0000	%0345	L13	\$	004432	002700	-00500	0625	0250	0375	0375	0750	0750	0000	%0426	U13	\$
003738	001906	-03125	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$	004062	002513	-02738	0500	0250	0500	0500	0750	0500	0000	%0346	L14	\$	004532	003310	-02260	0625	0250	0500	0375	0750	0500	0000	%0427	U14	\$
003816	002575	-04132	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$	004158	003127	-03781	0500	0250	0625	0500	0750	0375	0000	%0347	L15	\$	004600	003855	-03347	0625	0250	0625	0375	0750	0375	0000	%0428	U15	\$
003895	003140	-04872	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$	004206	003662	-04700	0500	0250	0750	0500	0750	0250	0000	%0348	L16	\$	004651	004304	-04139	0625	0250	0500	0375	0750	0250	0000	%0429	U16	\$
003904	003464	-05270	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$	004210	003973	-04995	0500	0250	0875	0500	0750	0125	0000	%0349	L17	\$	004685	004558	-04567	0625	0250	0875	0375	0750	0125	0000	%0430	U17	\$
003907	003513	-05304	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$	004226	004010	-05027	0500	0250	1000	0500	0750	0000	0000	%0350	L18	\$	004689	004598	-04622	0625	0250	1000	0375	0750	0000	0000	%0431	U18	\$
004040	-01381	003645	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$	004389	-00393	004238	0500	0375	0000	0500	0625	1000	0000	%0351	M10	\$	004939	000738	005016	0625	0375	0000	0375	0625	1000	0000	%0432	V10	\$
004214	-01038	001387	0375	0375	0125	0625	0625	0875	0000	%0271	D11	\$	004551	-00154	000190	0500	0375	0125	0500	0625	0875	0000	%0352	M11	\$	005084	000900	002518										

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klau.s.richter/GE38/GE38L0NA.TXT> /PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

003105	005338	002985	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
003149	005632	000752	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
003181	005905	-000579	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
003224	006224	-01693	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
003260	006585	-02709	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
003299	006955	-03565	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
003340	007247	-04127	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
003339	007395	-04399	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$
003347	007416	-04418	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$
003389	004486	003807	0750	0125	0000	0250	0875	1000	0000	%0495	B19	\$
003918	004711	001400	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
003987	004948	-00031	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
004031	005261	-01235	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
004085	005629	-02359	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
004123	006052	-03358	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
004158	006393	-04047	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
004147	006621	-04428	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
004130	006668	-04467	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
004622	003335	-04077	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
004726	003478	-002778	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
004803	003681	000736	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
004866	003960	-00491	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
004915	004320	-01685	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
004958	004776	-02812	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
004982	005199	-03659	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
004981	005458	-04140	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
004969	005522	-04202	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
005405	002132	005780	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
005517	002240	003219	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005582	002429	001598	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
005607	002699	000327	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
005667	003065	-00952	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
005718	003522	-02183	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
005740	003963	-03134	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$
005730	004297	-03727	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$
005726	004360	-03804	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$
006198	000950	006817	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
006293	001002	004231	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
006355	001168	002570	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
006401	001409	001243	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006460	001725	-00067	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
006498	002167	-01376	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
006536	002640	-02476	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
006545	002975	-03169	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
006532	003044	-03269	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
006888	-00051	007768	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
006975	-00059	005172	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
007057	000030	003514	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
007115	000201	002209	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
007166	000495	000830	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
007223	000891	-00565	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
007275	001336	-01747	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
007277	001711	-02558	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$
007261	001788	-02680	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
007462	-00877	008575	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
007607	-01017	006026	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
007698	-01015	004407	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
007775	-00895	003077	0750	0750	0375	0250	0250	0625	0000	%0543	G22	\$
007851	-00680	001700	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007944	-00378	000302	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$
008002	000027	-00953	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$
008007	000401	-01858	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$
008010	000472	-01996	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$
007918	-01519	009262	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$
008136	-01832	006825	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$
008268	-01908	005191	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$
008364	-01872	003898	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$
008465	-01743	002534	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$
008560	-01540	001145	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$
008659	-01206	-00172	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$
008709	-00903	-01096	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$
008715	-00854	-01234	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$
007948	-01526	009319	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$
008169	-01858	006864	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$
008290	-01944	005254	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$
008402	-01910	003935	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$
008492	-01789	002578	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$
008603	-01590	001191	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$
008701	-01265	-00121	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$
008748	-00964	-01049	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$
008759	-00917	-01190	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$
003441	005971	003469	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$
003487	006260	001152	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$
003526	006527	-00201	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$
003559	006812											

See original or copy: <http://web.me.com/klaus.richter/GE38/GE38L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

009302	000000	-00599	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$	009247	000016	-00617	1000	1000	1000	0000	0000	0000	0000	0000	%0891	b10	\$
009252	-00080	-00649	0875	1000	1000	0000	0125	0000	0000	%0730	b02	\$	009209	000091	-00666	1000	0875	1000	0000	0125	0000	0000	0000	%0892	b09	\$
008838	00897	-01152	0750	1000	1000	0250	0000	0000	0000	%0731	b03	\$	008525	001299	-01424	1000	0675	1000	0000	0250	0000	0000	0000	%0893	b21	\$
008254	-01661	-01774	0625	1000	1000	0375	0000	0000	0000	%0732	b04	\$	007774	002563	-02148	1000	0250	1000	0000	0375	0000	0000	0000	%0894	b22	\$
007689	-02184	-02290	0500	1000	1000	0500	0000	0000	0000	%0733	b05	\$	007001	003808	-02780	1000	0500	1000	0000	0500	0000	0000	0000	%0895	b23	\$
007186	-02525	-02690	0375	1000	1000	0625	0000	0000	0000	%0734	b06	\$	006717	005073	-03330	1000	0375	1000	0000	0625	0000	0000	0000	%0896	b24	\$
006636	-02762	-03065	0250	1000	1000	0750	0000	0000	0000	%0735	b07	\$	005421	006148	-03718	1000	0250	1000	0000	0750	0000	0000	0000	%0897	b25	\$
005978	-02941	-03435	0125	1000	1000	0875	0000	0000	0000	%0736	b08	\$	004561	007243	-03999	1000	0125	1000	0000	0875	0000	0000	0000	%0898	b26	\$
005251	-02870	-03732	0000	1000	1000	1000	0000	0000	0000	%0737	b09	\$	003714	007928	-03950	1000	0000	1000	0000	1000	0000	0000	0000	%0899	b27	\$
009263	000032	-00523	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$	009204	-00115	-00529	0875	1000	0875	0125	0000	0125	0000	0000	%0900	c19	\$
009215	-00056	-00569	0875	0875	0875	0125	0125	0125	0000	%0739	c02	\$	009163	-00043	-00573	0875	0875	0875	0125	0125	0125	0125	0000	%0901	c20	\$
008798	-00877	-01081	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$	008499	001146	-01332	0875	0750	0875	0125	0250	0125	0250	0000	%0902	c21	\$
008218	-01656	-01702	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$	007747	002411	-02067	0875	0625	0875	0125	0375	0125	0000	%0903	c22	\$	
007663	-02184	-02217	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$	006978	003676	-02717	0875	0500	0875	0125	0500	0125	0000	%0904	c24	\$	
007156	-02540	-02636	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$	006157	004947	-03284	0875	0375	0875	0125	0625	0125	0000	%0905	c24	\$	
006615	-02805	-03011	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$	005387	006061	-03701	0875	0250	0875	0125	0750	0125	0000	%0906	c25	\$	
005965	-02970	-03376	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$	004534	007166	-03987	0875	0125	0875	0125	0875	0125	0000	%0907	c26	\$	
005241	-02908	-03675	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$	003691	007867	-03955	0875	0000	0875	0125	1000	0125	0000	%0908	c27	\$	
008544	000951	-00482	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$	008735	-01125	-00158	0750	1000	0750	0250	0000	0250	0000	%0909	d01	\$	
008504	000849	-00492	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$	006892	-01517	-00222	0750	0875	0750	0250	0125	0250	0000	%0910	d20	\$	
008106	000022	-00994	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$	007303	001250	-01722	0750	0375	0750	0250	0250	0375	0250	0000	%0911	d21	\$
007598	-00870	-01573	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$	007374	001270	-01722	0750	0625	0750	0250	0375	0250	0000	%0912	d22	\$	
007103	-01552	-02057	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$	006627	002574	-02452	0750	0500	0750	0250	0500	0250	0000	%0913	d23	\$	
006687	-02026	-02467	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$	005821	003928	-03112	0750	0375	0750	0250	0625	0250	0000	%0914	d24	\$	
006208	-02429	-02825	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$	005046	005167	-03646	0750	0250	0750	0250	0750	0250	0000	%0915	d25	\$	
005638	-02721	-03188	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$	004182	006417	-04049	0750	0125	0750	0250	0875	0250	0000	%0916	d26	\$	
004986	-02795	-03458	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$	003356	007270	-04107	0750	0000	0750	0250	1000	0250	0000	%0917	d27	\$	
007753	001835	-00156	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$	008703	-02431	-00381	0625	1000	0625	0375	0000	0375	0000	%0918	e19	\$	
007712	001740	-00160	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$	008044	-02374	-00340	0625	0875	0625	0375	0125	0375	0000	%0919	e20	\$	
007360	000845	-00589	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$	007481	-01350	-00338	0625	0750	0625	0375	0250	0375	0000	%0920	e21	\$	
006865	-00153	-01153	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$	006819	-00119	-01145	0625	0625	0625	0375	0375	0375	0000	%0921	e22	\$	
006414	-00935	-01651	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$	006107	001143	-01912	0625	0500	0625	0375	0500	0375	0000	%0922	e23	\$	
006048	-01529	-02061	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$	005304	002574	-02707	0625	0375	0625	0375	0625	0375	0000	%0923	e24	\$	
005638	-02056	-02410	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$	004513	003938	-03369	0625	0250	0625	0375	0750	0375	0000	%0924	e25	\$	
005116	-02482	-02769	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$	003655	005341	-03924	0625	0125	0625	0375	0875	0375	0000	%0925	e26	\$	
004564	-02694	-03032	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$	002875	006352	-04132	0625	0000	0625	0375	1000	0375	0000	%0926	e27	\$	
006947	002695	-008273	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$	007359	-03475	-01067	0500	1000	0500	0500	0000	0500	0000	%0927	f19	\$	
006929	002575	-008309	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$	007328	-03445	-00104	0500	0875	0500	0500	0125	0500	0000	%0928	f20	\$	
006576	001674	-00111	0750	0500	0500	0250	0500	0500	0000	%0767	f03	\$	006853	-02577	-00413	0500	0750	0500	0500	0250	0500	0000	%0929	f21	\$	
006090	000577	-00645	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$	006261	-01513	-00313	0500	0625	0500	0500	0375	0500	0000	%0930	f22	\$	
005563	-00309	-01131	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$	005584	-00291	-01105	0500	0500	0500	0500	0500	0500	0000	%0931	f23	\$	
005320	-01006	-01538	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$	004793	001619	-01995	0500	0375	0500	0500	0625	0500	0000	%0932	f24	\$	
004935	-01635	-01918	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$	004014	002615	-027											

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

%BEG GE28(7)_22_REM.TXT, Separation cmyn62*, D65, not adapted \$
%100 x LAB*
%#1000 x (r g b c m y 0) %nr. pos \$
%z003455 006029 003493 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008436 -00460 010064 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z004369 -06196 004029 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005222 -02845 -03739 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z001340 005229 -06400 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003694 007913 -03951 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z000823 000116 -00689 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009224 000014 -00616 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z003528 006057 003481 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008437 -00438 010001 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z004333 -06182 003905 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005251 -02870 -03732 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z001328 005239 -06402 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003714 007928 -03950 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z000812 000122 -00696 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009268 000013 -00612 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

TUB-test chart GE38; Relative Device Colour System G
1080 spectral reflexions R -> LAB* for D65 and D50

input: w *setgray*
output: -> *olv* setrgbcolor*

TUB registration: 20091101-GE38/GE38L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/GE38/GE38L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

TUB material: code=rh4ta

See original or copy: <http://web.me.com/klaus.richter/GE38/GE38L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cf1=1.00; nt=0.18; nx=1.0.

BEG GE22(7)_22.REM.TXT, Separation										cmycn62*, D65, not adapted \$										100% LAB*										100% LAB*									
00000 000000										00000 000000										00000 000000										00000 000000									
000077 000097										-00692 0000 0000										0000 1000 1000										0000 0000 0000									
0001984 000171										-01382 0125 0125										0125 0875 0875										0875 0000 0000									
0003268 000022										-01355 0250 0250										0250 0750 0750										0750 0000 0000									
0004488 000192										-01174 0375 0375										0375 0625 0625										0625 0000 0000									
0005070 000295										-01144 0500 0500										0500 0500 0500										0500 0000 0000									
0006910 000175										-01129 0625 0625										0625 0375 0375										0375 0000 0000									
0008132 000029										-00953 0750 0750										0750 0250 0250										0250 0000 0000									
0009189 000049										-00584 0875 0875										0875 0125 0125										0125 0000 0000									
0009267 000014										-00615 1000 1000										1000 0000 0000										0000 0000 0000									
0000873 000096										-00694 0000 0000										0000 1000 1000										0000 0000 0000									
0001985 000170										-01368 0125 0125										0125 0875 0875										0875 0000 0000									
0003266 000013										-01370 0250 0250										0250 0750 0750										0750 0000 0000									
0004488 000185										-01183 0375 0375										0375 0625 0625										0625 0000 0000									
0005070 000292										-01154 0500 0500										0500 0500 0500										0500 0000 0000									
0006915 000163										-01149 0625 0625										0625 0375 0375										0375 0000 0000									
0008130 000025										-00968 0750 0750										0750 0250 0250										0250 0000 0000									
0009190 000052										-00582 0875 0875										0875 0125 0125										0125 0000 0000									
0009266 000012										-00617 1000 1000										1000 0000 0000										0000 0000 0000									
0000861 000102										-00707 0000 0000										0000 1000 1000										0000 0000 0000									
0001962 000183										-01388 0125 0125										0125 0875 0875										0875 0000 0000									
0003224 000011										-01369 0250 0250										0250 0750 0750										0750 0000 0000									
0004449 000190										-01189 0375 0375										0375 0625 0625										0625 0000 0000									
0005668 000296										-01152 0500 0500										0500 0500 0500										0500 0000 0000									
0006915 000163										-01149 0625 0625										0625 0375 0375										0375 0000 0000									
0008114 000117										-00982 0750 0750										0750 0250 0250										0250 0000 0000									
0009187 000051										-00584 0875 0875										0875 0125 0125										0125 0000 0000									
0009266 000015										-00615 1000 1000										1000 0000 0000										0000 0000 0000									
0000864 000095										-00694 0000 0000										0000 1000 1000										0000 0000 0000									
0001948 000193										-01398 0125 0125										0125 0875 0875										0875 0000 0000									
0003224 000001										-01377 0250 0250										0250 0750 0750										0750 0000 0000									
0004433 000180										-01197 0375 0375										0375 0625 0625										0625 0000 0000									
0005662 000295										-01152 0500 0500										0500 0500 0500										0500 0000 0000									
0006885 000157										-01143 0625 0625										0625 0375 0375										0375 0000 0000									
0008108 000025										-00961 0750 0750										0750 0250 0250										0250 0000 0000									
0009186 000049										-00583 0875 0875										0875 0125 0125										0125 0000 0000									
0009266 000014										-00615 1000 1000										1000 0000 0000										0000 0000 0000									
0000820 000105										-00729 0000 0000										0000 1000 1000										0000 0000 0000									
0001349 000248										-01208 0066 0666										0666 0666 0666										0666 0000 0000									
0002032 000145										-01418 0133 0133										0133 0866 0866										0866 0000 0000									
0002723 000064										-01363 0260 0260										0260 0800 0800										0800 0000 0000									
0003429 000091										-01323 0266 0266										0266 0333 0333										0333 0000 0000									
0004091 000162										-01164 0333 0333										0333 0666 0666										0666 0000 0000									
0004745 000266										-01148 0400 0400										0400 0600 0600										0600 0000 0000									
0005383 000323										-01122 0466 0466										0466 0533 0533										0533 0000 0000									
0006021 000345										-01063 0533 0533										0533 0666 0666										0666 0000 0000									
0006635 000233										-01067 0600 0600										0600 0400 0400										0400 0000 0000									
0007075 000072										-01091 0666 0666										0666 0333 0333										0333 0000 0000									
0007597 000074										-00974 0734 0734										0734 0266 0266										0266 0000 0000									
0008532 000014										-00820 0800 0800										0800 0200 0200										0200 0000 0000									
0009119 000073										-00555 0866 0866										0866 0133 0133										0133 0000 0000									
0009245 000005										-00598 0933 0933										0933 0666 0666										0666 0000 0000									
0009241 000014										-00605 1000 1000										1000 0000 0000										0000 0000 0000									
0008027 000111										-00736 0000 0000										0000 1000 1000										0000 0000 0000									
0001339 000252										-01225 0066 0666										0666 0933 0933										0933 0000 0000									
0002020 000169										-01451 0133 0133										0133 0866 0866										0866 0000 0000									
0002706 000034										-01386 0200 0200										0200 0800 0800										0800 0000 0000									
0003417 000086										-01319 0266 0266										0266 0333 0333										0333 0000 0000									
0004083 000159										-01166 0333 0333										0333 0666 0666										0666 0000 0000									
0004743 000249										-01177 0400 0400										0400 0600 0600										0600 0000 0000									
0005374 000309										-01147 0466 0466										0466 0533 0533										0533 0000 0000									
0006024 000350										-01062 0533 0533										0533 0466 0466										0466 0000 0000									
0006644 000218										-01077 0600 0600										0600 0400 0400										0400 0000 0000									
0007270 000074										-01094 0666 0666										0666 0333 0333										0333 0000 0000									
0007933 000005										-00978 0734 0734										0734 0266 0266										0266 0000 0000									
0008528 000019										-00825 0800 0800										0800 0200 0200										0200 0000 0000									
0009112 000080										-00547 0866 0866										0866 0133 0133										0133 0000 0000									
0009248 000003										-00596 0933 0933										0933 0666 0666										0666 0000 0000									
0009240 000015										-00600 1000 1000										1000 0000 0000										0000 0000 0000									
0000820 000109										-00742 0000 0000										0000 1000 1000										0000 0000 0000									
0001323 000262										-01212 0066 0666										0666 0933 0933										0933 0000 0000									
0002002 000164										-01427 0133 0133										0133 0866 0866										0866 0000 0000									
0002084 000029										-01389 0200 0200										0200 0800 0800										0800 0000 0000									
0003089 000079										-01324 0266 0266										0266 0333 0333										0333 0000 0000									
0004062 000141										-01200 0333 0333										0333 0666 0666										0666 0000 0000									
0004698 000248										-01182 0400 0400										0400 0600 0600										0600 0000 0000									
0005353 000308										-01149 0466 0466										0466 0533 0533										0533 0000 0000									
0006015 000337										-01069 0533 0533										0533 0466 0466										0466 0000 0000									
0006607 000217										-01084 0600 0600										0600 0400 0400										0400 0000 0000									
0007266 000067										-01095 0666 0666										0666 0333 0333										0333 0000 0000									
0007925 000005										-00984 0734 0734										0734 0266 0266										0266 0000 0000									
0008521 000022										-00831 0800 0800										0800 0200 0200										0200 0000 0000									

See original or copy: <http://web.me.com/klaus.richter/GE38/GE38L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

11UB registration: 20091101-GE38/GE38L0NA.1X1/.PS 11UB material: code=rh4ta
application for evaluation and measurement of printer or monitor systems

[illegible]

TUB-test chart GE38; Relative Device Colour System
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolo
```

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klau.s.richter/GE38/GE38L0NA.TXT> /PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

001717	002395	001405	0375	0000	0000	0625	1000	1000	0000	%0243	A10 \$	002210	003171	002023	0500	0000	0000	0500	1000	1000	0000	%0324	J10 \$	002591	004183	002773	0625	0000	0000	0375	1000	1000	0000	%0405	S10 \$	
001819	002954	-00577	0375	0000	0125	0625	1000	0875	0000	%0244	A11 \$	002215	003722	-00049	0500	0000	0125	0500	1000	0875	0000	%0325	J11 \$	002677	004605	000666	0625	0000	0125	0375	1000	0875	0000	%0406	S11 \$	
001914	003497	-01743	0375	0000	0250	0625	1000	0750	0000	%0245	A12 \$	002280	004178	-01268	0500	0000	0250	0500	1000	0750	0000	%0326	J12 \$	002729	004968	-00659	0625	0000	0250	0375	1000	0750	0000	%0407	S12 \$	
001984	004099	-02727	0375	0000	0375	0625	1000	0625	0000	%0246	A13 \$	002356	004656	-02266	0500	0000	0375	0500	1000	0625	0000	%0327	J13 \$	002783	005362	-01719	0625	0000	0375	0375	1000	0625	0000	%0408	S13 \$	
002059	004684	-03622	0375	0000	0500	0625	1000	0500	0000	%0247	A14 \$	002411	005177	-03196	0500	0000	0500	0500	1000	0500	0000	%0328	J14 \$	002833	005796	-02667	0625	0000	0500	0375	1000	0500	0000	%0409	S14 \$	
002122	005264	-04390	0375	0000	0625	0625	1000	0375	0000	%0248	A15 \$	002492	005695	-03991	0500	0000	0625	0500	1000	0375	0000	%0329	J15 \$	002900	006260	-03501	0625	0000	0625	0375	1000	0375	0000	%0410	S15 \$	
002179	005698	-04913	0375	0000	0750	0625	1000	0250	0000	%0249	A16 \$	002555	006087	-04520	0500	0000	0750	0500	1000	0250	0000	%0330	J16 \$	002944	006593	-04043	0625	0000	0750	0375	1000	0250	0000	%0411	S16 \$	
002202	005904	-05161	0375	0000	0875	0625	1000	0125	0000	%0250	A17 \$	002584	006274	-04781	0500	0000	0875	0500	1000	0125	0000	%0331	J17 \$	002943	006752	-04298	0625	0000	0875	0375	1000	0125	0000	%0412	S17 \$	
002212	005925	-05162	0375	0000	1000	0625	1000	0000	0000	%0251	A18 \$	002658	006286	-04786	0500	0000	1000	0500	1000	0000	0000	%0332	J18 \$	002961	006769	-04307	0625	0000	1000	0375	1000	0000	0000	%0413	S18 \$	
002453	001164	002284	0375	0125	0000	0625	0875	1000	0000	%0252	B10 \$	002829	002086	002858	0500	0125	0000	0500	0875	1000	0000	%0333	K10 \$	003065	003167	003610	0625	0125	0000	0375	1000	0000	0000	%0414	T10 \$	
002608	001702	000177	0375	0125	0125	0625	0875	0875	0000	%0253	B11 \$	002962	002538	000658	0500	0125	0125	0500	0875	0875	0000	%0334	K11 \$	003340	003507	001281	0625	0125	0125	0375	0875	0875	0000	%0415	T11 \$	
002712	002222	-01111	0375	0125	0250	0625	0875	0750	0000	%0254	B12 \$	003057	002924	-00632	0500	0125	0250	0500	0875	0750	0000	%0335	K12 \$	003518	003828	-00072	0625	0125	0250	0375	0875	0750	0000	%0416	T12 \$	
002809	002786	-02172	0375	0125	0375	0625	0875	0625	0000	%0255	B13 \$	003149	003418	-01753	0500	0125	0375	0500	0875	0625	0000	%0336	K13 \$	003594	004213	-01229	0625	0125	0375	0375	0875	0625	0000	%0417	T13 \$	
002881	003405	-03179	0375	0125	0500	0625	0875	0500	0000	%0256	B14 \$	003218	003966	-02801	0500	0125	0500	0500	0875	0500	0000	%0337	K14 \$	003656	004676	-02295	0625	0125	0500	0375	0875	0500	0000	%0418	T14 \$	
002958	004033	-04065	0375	0125	0625	0625	0875	0375	0000	%0257	B15 \$	003306	004538	-03712	0500	0125	0625	0500	0875	0375	0000	%0338	K15 \$	003723	005182	-03259	0625	0125	0625	0375	0875	0375	0000	%0419	T15 \$	
003032	004542	-04700	0375	0125	0750	0625	0875	0250	0000	%0258	B16 \$	003364	004998	-04371	0500	0125	0750	0500	0875	0250	0000	%0339	K16 \$	003770	005818	-03296	0625	0125	0750	0375	0875	0250	0000	%0420	T16 \$	
003051	004812	-05023	0375	0125	0875	0625	0875	0125	0000	%0259	B17 \$	003370	005253	-04708	0500	0125	0875	0500	0875	0125	0000	%0340	K17 \$	003778	005815	-04280	0625	0125	0875	0375	0875	0125	0000	%0421	T17 \$	
003053	004847	-05042	0375	0125	1000	0625	0875	0000	0000	%0260	B18 \$	003384	005285	-04727	0500	0125	1000	0500	0875	0000	0000	%0341	K18 \$	003790	005834	-04301	0625	0125	1000	0375	0875	0000	0000	%0422	T18 \$	
003268	-00186	003321	0375	0250	0000	0625	0750	1000	0000	%0261	C10 \$	003611	000781	003874	0500	0250	0000	0500	0750	1000	0000	%0342	L10 \$	004121	006193	004622	0625	0250	0000	0000	0375	0750	1000	0000	%0423	U10 \$
003428	000252	001098	0375	0250	0125	0625	0750	0875	0000	%0262	C11 \$	003773	001131	001577	0500	0250	0125	0500	0750	0875	0000	%0343	L11 \$	004281	002148	002213	0625	0250	0125	0375	0750	0875	0000	%0424	U11 \$	
003560	000710	-00298	0375	0250	0250	0625	0750	0750	0000	%0263	C12 \$	003898	001479	000169	0500	0250	0250	0500	0750	0750	0000	%0344	L12 \$	004532	002266	000680	0625	0250	0250	0250	0750	0750	0000	%0425	U12 \$	
003664	001213	-01374	0375	0250	0375	0625	0750	0625	0000	%0264	C13 \$	003980	001891	-00953	0500	0250	0375	0500	0750	0625	0000	%0345	L13 \$	004447	003448	-01063	0625	0250	0375	0375	0750	0625	0000	%0426	U13 \$	
003738	001824	-02461	0375	0250	0500	0625	0750	0500	0000	%0265	C14 \$	004062	002435	-02076	0500	0250	0500	0500	0750	0500	0000	%0346	L14 \$	004592	003238	-01603	0625	0250	0500	0375	0750	0500	0000	%0427	U14 \$	
003816	002495	-03468	0375	0250	0625	0625	0750	0375	0000	%0266	C15 \$	004158	003051	-03121	0500	0250	0625	0500	0750	0375	0000	%0347	L15 \$	004600	003784	-02690	0625	0250	0625	0375	0750	0375	0000	%0428	U15 \$	
003895	003061	-04210	0375	0250	0750	0625	0750	0250	0000	%0267	C16 \$	004206	003586	-03910	0500	0250	0750	0500	0750	0250	0000	%0348	L16 \$	004651	004233	-03483	0625	0250	0750	0375	0750	0250	0000	%0429	U16 \$	
003904	003384	-04607	0375	0250	0875	0625	0750	0125	0000	%0268	C17 \$	004210	003898	-04335	0500	0250	0875	0500	0750	0125	0000	%0349	L17 \$	004685	004488	-03911	0625	0250	0875	0375	0750	0125	0000	%0430	U17 \$	
003907	003433	-04642	0375	0250	1000	0625	0750	0000	0000	%0269	C18 \$	004226	003935	-04367	0500	0250	1000	0500	0750	0000	0000	%0350	L18 \$	004669	004528	-03966	0625	0250	1000	0375	0750	0000	0000	%0431	U18 \$	
004040	-01459	004306	0375	0375	0000	0625	0625	1000	0000	%0270	D10 \$	004389	-00467	004897	0500	0375	0000	0500	0625	1000	0000	%0351	M10 \$	004939	006671	005670	0625	0375	0000	0375	0625	1000	0000	%0432	V10 \$	
004214	-01114	002047	0375	0375	0125	0625	0625	0875	0000	%0271	D11 \$	004551	-00225	002566	0500	0375	0125	0500	0625	0875	0000	%0352	M11 \$	005084	000835	003170	0625	0375	0125	0375	0625	0875	0000	%0433	V11 \$	
004435	-00712	006095	0375	0375	0250	0625	0625	0750	0000	%0272	D12 \$	004668	000101	001061	0500	0375	0250	0500	0625	0750	0000	%0353</														

See original or copy: <http://web.me.com/klau.s.richter/GE38/GE38L0NA.TXT> /PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

003105	005249	003655	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
003149	005543	001422	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
003181	005817	000089	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
003224	006136	-01024	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
003260	006497	-02041	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
003299	006868	-02898	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
003340	007160	-03460	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
003339	007309	-03731	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$
003347	007330	-03751	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$
003839	004406	004471	0750	0125	0000	0250	0875	1000	0000	%0495	B19	\$
003918	004632	002063	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
003987	004869	000630	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
004031	005183	-00573	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
004085	005552	-01698	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
004123	005976	-02697	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
004158	006317	-03387	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
004147	006545	-03768	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
004130	006591	-03806	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
004622	003265	005428	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
004726	003408	002933	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
004803	003613	001391	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
004866	003892	001622	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
004915	004252	-01031	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
004958	004709	-02159	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
004982	005133	-03006	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
004981	005392	-03487	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
004969	005455	-03548	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
005405	002071	006430	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
005517	002180	003867	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005582	002370	002246	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
005607	002641	000975	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
005667	003007	-00305	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
005710	003464	-01536	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
005740	003906	-02487	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$
005730	004239	-03081	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$
005726	004303	-03158	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$
006198	000898	007460	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
006293	000952	004873	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
006355	001118	003212	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
006401	001360	001884	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006460	001676	000573	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
006498	002119	-00736	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
006536	002593	-01836	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
006545	002928	-02529	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
006532	002997	-02629	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
006888	-00094	008404	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
006975	-00101	005808	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
007057	-00010	004150	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
007115	000160	002844	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
007166	000455	001465	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
007223	000852	000068	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
007275	001298	-01114	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
007277	001672	-01925	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$
007261	001750	-02046	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
007462	-00913	009207	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
007607	-01051	006656	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
007698	-01048	005937	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
007775	-00927	003706	0750	0750	0375	0250	0250	0625	0000	%0543	G22	\$
007851	-00712	002329	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007944	-00408	000930	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$
008002	-00001	-00326	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$
008007	000371	-01231	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$
008010	000443	-01368	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$
007918	-01549	009899	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$
008136	-01860	007451	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$
008268	-01934	005816	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$
008364	-01898	004523	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$
008465	-01767	003157	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$
008560	-01563	001768	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$
008659	-01228	000449	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$
008709	-00924	-00475	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$
008715	-00875	-00613	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$
007948	-01556	009946	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$
008169	-01886	007490	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$
008290	-01970	005879	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$
008402	-01934	004559	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$
008492	-01812	003201	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$
008603	-01613	001813	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$
008701	-01286	000499	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$
008748	-00985	-00428	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$
008759	-00937	-00569	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$
003441	005886	004135	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$
003487	006175	001818	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$
003526	006443	000464	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$
003559	006											

009302	-00013	000012	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009252	-00094	-00037	0875	1000	1000	0125	0000	0000	%0730	b02	\$
008838	-00916	-00535	0750	1000	1000	0250	0000	0000	%0731	b03	\$
008254	-01688	-01152	0625	1000	1000	0375	0000	0000	%0732	b04	\$
007689	-02218	-01661	0500	1000	1000	0500	0000	0000	%0733	b05	\$
007186	-02565	-02057	0375	1000	1000	0625	0000	0000	%0734	b06	\$
006636	-02830	-02426	0250	1000	1000	0750	0000	0000	%0735	b07	\$
005978	-02987	-02789	0125	1000	1000	0875	0000	0000	%0736	b08	\$
005251	-02385	-03079	0000	1000	1000	1000	0000	0000	%0737	b09	\$
009263	000019	000088	1000	0875	0875	0000	0125	0125	%0738	c01	\$
009215	-00070	000043	0875	0875	0875	0125	0125	0125	%0739	c02	\$
008798	-00897	-00464	0750	0875	0875	0250	0125	0125	%0740	c03	\$
008218	-01683	-01079	0625	0875	0875	0375	0125	0125	%0741	c04	\$
007663	-02218	-01588	0500	0875	0875	0500	0125	0125	%0742	c05	\$
007156	-02581	-02003	0375	0875	0875	0625	0125	0125	%0743	c06	\$
006615	-02853	-02372	0250	0875	0875	0750	0125	0125	%0744	c07	\$
005965	-03025	-02730	0125	0875	0875	0875	0125	0125	%0745	c08	\$
005241	-02973	-03022	0000	0875	0875	1000	0125	0125	%0746	c09	\$
008544	000928	000137	1000	0750	0750	0000	0250	0250	%0747	d01	\$
008504	000825	000127	0875	0750	0750	0125	0250	0250	%0748	d02	\$
008106	-00005	-00370	0750	0750	0750	0250	0250	0250	%0749	d03	\$
007598	-00905	-00944	0625	0750	0750	0375	0250	0250	%0750	d04	\$
007103	-01593	-01423	0500	0750	0750	0500	0250	0250	%0751	d05	\$
006687	-02072	-01829	0375	0750	0750	0625	0250	0250	%0752	d06	\$
006208	-02481	-02182	0250	0750	0750	0750	0250	0250	%0753	d07	\$
005638	-02781	-02539	0125	0750	0750	0875	0250	0250	%0754	d08	\$
004986	-02863	-02803	0000	0750	0750	1000	0250	0250	%0755	d09	\$
007753	001802	000470	1000	0625	0625	0000	0375	0375	%0756	e01	\$
007712	001706	000467	0875	0625	0625	0125	0375	0375	%0757	e02	\$
007369	000807	000042	0750	0625	0625	0250	0375	0375	%0758	e03	\$
006865	-00197	-00517	0625	0625	0625	0375	0375	0375	%0759	e04	\$
006414	-00985	-01010	0500	0625	0625	0500	0375	0375	%0760	e05	\$
006048	-01584	-01417	0375	0625	0625	0625	0375	0375	%0761	e06	\$
005638	-02116	-01768	0250	0625	0625	0750	0375	0375	%0762	e07	\$
005116	-02549	-02115	0125	0625	0625	0875	0375	0375	%0763	e08	\$
004564	-02768	-02373	0000	0625	0625	1000	0375	0375	%0764	e09	\$
006947	002652	000908	1000	0500	0500	0000	0500	0500	%0765	f01	\$
006929	002532	000945	0875	0500	0500	0125	0500	0500	%0766	f02	\$
006576	001626	000528	0750	0500	0500	0250	0500	0500	%0767	f03	\$
006090	000523	-00001	0625	0500	0500	0375	0500	0500	%0768	f04	\$
005630	-00368	-00483	0500	0500	0500	0500	0500	0500	%0769	f05	\$
005320	-01070	-00886	0375	0500	0500	0625	0500	0500	%0770	f06	\$
004935	-01704	-01262	0250	0500	0500	0750	0500	0500	%0771	f07	\$
004479	-02242	-01634	0125	0500	0500	0875	0500	0500	%0772	f08	\$
003989	-02584	-01842	0000	0500	0500	1000	0500	0500	%0773	f09	\$
006101	003571	001345	1000	0375	0375	0000	0625	0625	%0774	g01	\$
006060	003478	001350	0875	0375	0375	0125	0625	0625	%0775	g02	\$
005724	002586	000962	0750	0375	0375	0250	0625	0625	%0776	g03	\$
005224	001453	000387	0625	0375	0375	0375	0625	0625	%0777	g04	\$
004793	000513	-00113	0500	0375	0375	0500	0625	0625	%0778	g05	\$
004448	-00270	-00534	0375	0375	0375	0625	0625	0625	%0779	g06	\$
004086	-00986	-00936	0250	0375	0375	0750	0625	0625	%0780	g07	\$
003671	-01595	-01305	0125	0375	0375	0875	0625	0625	%0781	g08	\$
003241	-01996	-01541	0000	0375	0375	1000	0625	0625	%0782	g09	\$
002581	004494	001738	1000	0250	0250	0000	0750	0750	%0783	h01	\$
005256	004398	001759	0875	0250	0250	0125	0750	0750	%0784	h02	\$
004893	003579	001358	0750	0250	0250	0250	0750	0750	%0785	h03	\$
004393	002456	000737	0625	0250	0250	0375	0750	0750	%0786	h04	\$
003939	001485	000202	0500	0250	0250	0500	0750	0750	%0787	h05	\$
003580	000654	-00289	0375	0250	0250	0625	0750	0750	%0788	h06	\$
003231	-00132	-00715	0250	0250	0250	0750	0750	0750	%0789	h07	\$
002845	-00805	-01079	0125	0250	0250	0875	0750	0750	%0790	h08	\$
002465	-01245	-01348	0000	0250	0250	1000	0750	0750	%0791	h09	\$
004393	005395	002475	1000	0125	0125	0000	0875	0875	%0792	i01	\$
004363	005330	002473	0875	0125	0125	0125	0875	0875	%0793	i02	\$
004012	004584	002056	0750	0125	0125	0250	0875	0875	%0794	i03	\$
003476	003491	001370	0625	0125	0125	0375	0875	0875	%0795	i04	\$
003011	002517	000732	0500	0125	0125	0500	0875	0875	%0796	i05	\$
002637	001626	000165	0375	0125	0125	0625	0875	0875	%0797	i06	\$
002279	000803	-00322	0250	0125	0125	0750	0875	0875	%0798	i07	\$
001933	000078	-00718	0125	0125	0125	0875	0875	0875	%0799	i08	\$
001619	-00457	-01004	0000	0125	0125	1000	0875	0875	%0800	i09	\$
003528	005970	004150	1000	0000	0000	0000	1000	1000	%0801	j01	\$
003506	005921	004146	0875	0000	0000	0125	1000	1000	%0802	j02	\$
003177	005272	003656	0750	0000	0000	0250	1000	1000	%0803	j03	\$
002656	004223	002843	0625	0000	0000	0375	1000	1000	%0804	j04	\$
002171	003214	002071	0500	0000	0000	0500	1000	1000	%0805	j05	\$
001767	002320	001407	0375	0000	0000	0625	1000	1000	%0806	j06	\$
001549	001343	000807	0250	0000	0000	0750	1000	1000	%0807	j07	\$
001080	000638	000350	0125	0000	0000	0875	1000	1000	%0808	j08	\$
000926	-00007	-00035	0000	0000	0000	1000	1000	1000	%0809	j09	\$
009256	000010	-00008	1000	1000	1000	0000	0000	0000	%0810	b10	\$
009174	000001	-00112	0875	0875	0875	0125	0125	0125	%0811	b11	\$
008670	000340	-01246	0750	0750	0750	0250	0250	0250	%0812	b12	\$
008691	000698	-02380	0625	0625	0625	0375	0375	0375	%0813	b13	\$
008572	001207	-03301	0500	0500	0500	0500	0500	0500	%0814	b14	\$
008479	001993	-04128	0375	0375	0375	0625	0625	0625	%0815	b15	\$
008361	002867	-04875	0250	0250	0250	0750	0750	0750	%0816	b16	\$
008238	000460	-05512	0125	0250	0250	0875	0875	0875	%0817	b17	\$
008132	000514	-05719	0000	0250	0250	1000	1000	1000	%0818	b18	\$
009256	-00028	000105	1000	1000	0875	0000	0125	0000	%0819	c10	\$
009173	-00042	000011	0875	0875	0875	0125	0125	0125	%0820	c11	\$
008175	-000275	-01136	0750	0750	0750	0250	0250	0125	%0821	c12	\$
007904	000639	-02281	0625	0625	0875	0375	0375	0125	%0822	c13	\$
005877	001143	-03228	0500	0500	0875	0500	0500	0125	%0823	c14	\$
004746	001933	-04072	0375	0375	0875	0625	0625	0125	%0824	c15	\$
003620	002812	-04827	0250	0250	0875	0750	0750	0125	%0825	c16	\$
002409	003976	-05468	0125	0125	0875	0875	0125	0000	%0826	c17	\$
001331	005082	-05677	0000	0000	0750	1000	1000	0125	%0827	c18	\$
009199	-00276	000975	1000	1000	0750	0000	0250	0000	%0828	d10	\$
009121	-00296	000886	0875	0875	0750	0125	0125	0250	%0829	d11	\$
008131	-00028	-00357	0750	0750	0750	0250	0250	0000	%0830	d12	\$
006978	000284	-01599	0625	0625	0750	0375	0375	0250	%0831	d13	\$
005862	000772	-02663	0500	0500	0750	0500	0500	0000	%0832	d14	\$
004738	001574	-03616	0375	0375	0750	0625	0625	0250	%0833	d15	\$
003605	002492	-04474	0250	0250	0750	0750	0250	0000	%0834	d16	\$
002383	003694	-05199	0125	0125	0750	0875	0875	0250	%0835	d17	\$
001302	004851	-05471	0000	0000	0750	1000	1000	0250	%0836	d18	\$
009115	-00551	002249	1000	1000	0625	0000	0375	0000	%0837	e10	\$
009040	-0058										

%BEG GE28(7)_22_REM.TXT, Separation cmyn62*, D65, adapted \$
%100 x LAB*a %1000 x (r g b c m y 0) %nr. pos \$
%z003455 005944 004159 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008436 -00484 010687 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z004369 -06270 004687 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005222 -02908 -03087 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z001340 005118 -05715 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003694 007831 -03287 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z000823 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009224 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z003528 005970 004150 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008437 -00462 010622 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z004333 -06259 004657 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005251 -02935 -03079 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z001328 005124 -05710 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003714 007843 -03282 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z000812 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009268 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/GE38/GE38L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG GE28(7)_22_REM.TXT, Separation cmyn62*, D65, adapted $
%100 x LAB*a      1000 x (r g b      c m y 0)      %nrr. pos $
000877 -00032 -00028 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
001984 000057 -00727 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003268 -00118 -00711 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004488 -00270 -00540 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005707 -00355 -00521 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006910 -00218 -00516 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
008132 -00054 -00350 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
009189 -00059 000009 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009267 000006 -00023 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
008073 -00034 -00030 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
001985 000055 -00713 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003266 -00108 -00726 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004488 -00263 -00549 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005704 -00352 -00531 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006915 -00206 -00536 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
008130 -00050 -00365 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
009190 -00061 000011 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009266 000004 -00024 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
008061 -00027 -00043 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
001962 000068 -00733 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003224 -00108 -00725 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004449 -00268 -00555 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
005668 -00357 -00529 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006882 -00210 -00536 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
008114 -00042 -00380 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
009187 -00060 000009 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009266 000006 -00022 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
008064 -00035 -00030 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
001948 000078 -00742 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003224 -00097 -00733 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004433 -00258 -00563 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005682 -00355 -00528 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006885 -00200 -00530 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
008108 -00050 -00358 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
009186 -00059 000009 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009266 000006 -00023 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
008020 -00025 -00065 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
001349 000125 -00548 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002032 000031 -00764 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
002723 -00167 -00714 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
003429 -00184 -00680 0266 0266 0266 0333 0333 0333 0000 %1012 k14 $
004091 -00245 -00527 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
004745 -00340 -00517 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005383 -00388 -00497 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
006021 -00401 -00442 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006635 -00280 -00452 0600 0600 0600 0400 0400 0400 0000 %1017 k19 $
007275 -00109 -00481 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007925 -00033 -00367 0734 0734 0734 0266 0266 0266 0000 %1019 k21 $
008532 -00004 -00221 0800 0800 0800 0200 0200 0200 0000 %1020 k22 $
009119 -00083 000037 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
009245 -00003 -00006 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009241 000005 -00013 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
008027 -00019 -00072 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
001339 000129 -00564 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
002020 000055 -00796 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
002706 -00138 -00737 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
003417 -00179 -00677 0266 0266 0266 0333 0333 0333 0000 %1028 l14 $
004083 -00239 -00629 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
004743 -00323 -00546 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005374 -00374 -00521 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
006024 -00406 -00442 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006644 -00264 -00462 0600 0600 0600 0400 0400 0400 0000 %1033 l19 $
007270 -00112 -00485 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007933 -00033 -00374 0734 0734 0734 0266 0266 0266 0000 %1035 l21 $
008528 000000 -00227 0800 0800 0800 0200 0200 0200 0000 %1036 l22 $
009112 -00091 000045 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
009248 -00005 -00003 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009240 000006 -00007 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
008020 -00021 -00077 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
001323 000139 -00552 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002002 000050 -00772 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
002684 -00133 -00740 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
003388 -00173 -00681 0266 0266 0266 0333 0333 0333 0000 %1044 m14 $
004062 -00225 -00563 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
004698 -00323 -00551 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005353 -00373 -00523 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
006015 -00393 -00448 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006607 -00264 -00468 0600 0600 0600 0400 0400 0400 0000 %1049 m19 $
007266 -00104 -00485 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007925 -00022 -00380 0734 0734 0734 0266 0266 0266 0000 %1051 m21 $
008521 000003 -00232 0800 0800 0800 0200 0200 0200 0000 %1052 m22 $
```

%BEG GE28(7)_22.REM.TXT, Separation cmyn62*, D50, not adapted S																			
%100 x LAB*																			
1000 x (r g b																			
c m y θ)																			
nmr. pos \$																			
000810	000021	-00675	0000	0000	0000	1000	1000	1000	0000	%0000	A01	\$							
000879	000837	-02369	0000	0000	0125	1000	1000	0875	0000	%0001	A02	\$							
000939	001555	-03430	0000	0000	0250	1000	1000	0750	0000	%0002	A03	\$							
000999	002197	-04257	0000	0000	0375	1000	1000	0625	0000	%0003	A04	\$							
001067	002858	-05037	0000	0000	0500	1000	1000	0500	0000	%0004	A05	\$							
001159	003454	-05726	0000	0000	0625	1000	1000	0375	0000	%0005	A06	\$							
001205	003898	-06208	0000	0000	0750	1000	1000	0250	0000	%0006	A07	\$							
001244	004089	-06422	0000	0000	0875	1000	1000	0125	0000	%0007	A08	\$							
001236	004132	-06455	0000	0000	1000	1000	1000	0000	0000	%0008	A09	\$							
001451	-01279	000102	0000	0125	0000	1000	0875	1000	0000	%0009	B01	\$							
001558	-00615	001085	0000	0125	0125	1000	0875	0875	0000	%0010	B02	\$							
001632	000063	-02889	0000	0125	0250	1000	0875	0750	0000	%0011	B03	\$							
001708	000067	-03777	0000	0125	0375	1000	0875	0625	0000	%0012	B04	\$							
001784	001359	-04641	0000	0125	0500	1000	0875	0500	0000	%0013	B05	\$							
001876	002015	-05444	0000	0125	0625	1000	0875	0375	0000	%0014	B06	\$							
001933	002494	-05995	0000	0125	0750	1000	0875	0250	0000	%0015	B07	\$							
001964	002738	-06264	0000	0125	0875	1000	0875	0125	0000	%0016	B08	\$							
001958	002787	-06300	0000	0125	1000	1000	0875	0000	0000	%0017	B09	\$							
002181	-02646	001038	0000	0250	0000	1000	0750	1000	0000	%0018	C01	\$							
002294	-02147	-00862	0000	0250	0125	1000	0750	0875	0000	%0019	C02	\$							
002358	-01516	-02118	0000	0250	0250	1000	0750	0750	0000	%0020	C03	\$							
002433	-00945	-03086	0000	0250	0375	1000	0750	0625	0000	%0021	C04	\$							
002521	-00289	-04013	0000	0250	0500	1000	0750	0500	0000	%0022	C05	\$							
002604	000399	-04906	0000	0250	0625	1000	0750	0375	0000	%0023	C06	\$							
002677	000914	-05535	0000	0250	0750	1000	0750	0250	0000	%0024	C07	\$							
002700	001194	-05852	0000	0250	0875	1000	0750	0125	0000	%0025	C08	\$							
002697	001247	-05903	0000	0250	1000	1000	0750	0000	0000	%0026	C09	\$							
002829	-03765	001874	0000	0375	0000	1000	0625	1000	0000	%0027	D01	\$							
002957	-03409	-00068	0000	0375	0125	1000	0625	0875	0000	%0028	D02	\$							
003041	-02929	-01286	0000	0375	0250	1000	0625	0750	0000	%0029	D03	\$							
003114	-02385	-02338	0000	0375	0375	1000	0625	0625	0000	%0030	D04	\$							
003209	-01755	-03348	0000	0375	0500	1000	0625	0500	0000	%0031	D05	\$							
003305	-01098	-04318	0000	0375	0625	1000	0625	0375	0000	%0032	D06	\$							
003372	-00570	-05001	0000	0375	0750	1000	0625	0250	0000	%0033	D07	\$							
003390	-00267	-05362	0000	0375	0875	1000	0625	0125	0000	%0034	D08	\$							
003392	-00215	-05416	0000	0375	1000	1000	0625	0000	0000	%0035	D09	\$							
003435	-04733	-02653	0000	0500	0000	1000	0500	1000	0000	%0036	E01	\$							
003567	-04503	-00691	0000	0500	0125	1000	0500	0875	0000	%0037	E02	\$							
003653	-04113	-00562	0000	0500	0250	1000	0500	0750	0000	%0038	E03	\$							
003736	-03633	-01658	0000	0500	0375	1000	0500	0625	0000	%0039	E04	\$							
003832	-03074	-02686	0000	0500	0500	1000	0500	0500	0000	%0040	E05	\$							
003919	-02429	-03706	0000	0500	0625	1000	0500	0375	0000	%0041	E06	\$							
004010	-01919	-04454	0000	0500	0750	1000	0500	0250	0000	%0042	E07	\$							
004028	-01603	-04852	0000	0500	0875	1000	0500	0125	0000	%0043	E08	\$							
004032	-01548	-04911	0000	0500	1000	1000	0500	0000	0000	%0044	E09	\$							
003866	-05406	003195	0000	0625	0000	1000	0375	1000	0000	%0045	F01	\$							
004008	-05269	001277	0000	0625	0125	1000	0375	0875	0000	%0046	F02	\$							
004111	-04952	000013	0000	0625	0250	1000	0375	0750	0000	%0047	F03	\$							
004201	-04541	-01085	0000	0625	0375	1000	0375	0625	0000	%0048	F04	\$							
004289	-04009	-02176	0000	0625	0500	1000	0375	0500	0000	%0049	F05	\$							
004390	-03407	-03222	0000	0625	0625	1000	0375	0375	0000	%0050	F06	\$							
004465	-02890	-04015	0000	0625	0750	1000	0375	0250	0000	%0051	F07	\$							
004499	-02582	-04441	0000	0625	0875	1000	0375	0125	0000	%0052	F08	\$							
004502	-02533	-04510	0000	0625	1000	1000	0375	0000	0000	%0053	F09	\$							
004140	-05832	003559	0000	0750	0000	1000	0250	1000	0000	%0054	G01	\$							
004318	-05788	001680	0000	0750	0125	1000	0250	0875	0000	%0055	G02	\$							
004428	-05520	000414	0000	0750	0250	1000	0250	0750	0000	%0056	G03	\$							
004513	-05148	000714	0000	0750	0375	1000	0250	0625	0000	%0057	G04	\$							
004622	-04683	-01794	0000	0750	0500	1000	0250	0500	0000	%0058	G05	\$							
004723	-04102	-02879	0000	0750	0625	1000	0250	0375	0000	%0059	G06	\$							
004802	-03609	-03675	0000	0750	0750	1000	0250	0250	0000	%0060	G07	\$							
004847	-03315	-04126	0000	0750	0875	1000	0250	0125	0000	%0061	G08	\$							
004853	-03261	-04195	0000	0750	1000	1000	0250	0000	0000	%0062	G09	\$							
004302	-06068	003776	0000	0875	0000	1000	0125	1000	0000	%0063	H01	\$							
004496	-06092	001934	0000	0875	0125	1000	0125	0875	0000	%0064	H02	\$							
004629	-05881	000676	0000	0875	0250	1000	0125	0750	0000	%0065	H03	\$							
004721	-05543	-00453	0000	0875	0375	1000	0125	0625	0000	%0066	H04	\$							
004841	-05101	-01560	0000	0875	0500	1000	0125	0500	0000	%0067	H05	\$							
004944	-04564	-02626	0000	0875	0625	1000	0125	0375	0000	%0068	H06	\$							

See original or copy: <http://web.me.com/klaustrichter/GE38/GE38L0NA.TXT> /PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

001783	002523	000874	0375	0000	0000	0625	1000	1000	0000	%0243	A10 \$	002215	003427	001547	0500	0000	0000	0500	0500	1000	1000	0000	%0324	J10 \$	002721	004476	002363	0625	0000	0000	0375	1000	1000	0000	%0405	S10 \$
001871	002978	-01096	0375	0000	0125	0625	1000	0875	0000	%0244	A11 \$	002299	003819	-00507	0500	0000	0125	0500	1000	0875	0000	%0325	J11 \$	002797	004770	000214	0625	0000	0125	0375	1000	0875	0000	%0406	S11 \$	
001954	003357	-02265	0375	0000	0250	0625	1000	0750	0000	%0245	A12 \$	002353	004131	-01727	0500	0000	0250	0500	1000	0750	0000	%0326	J12 \$	002838	005010	-01050	0625	0000	0250	0375	1000	0750	0000	%0407	S12 \$	
002013	003802	-03253	0375	0000	0375	0625	1000	0625	0000	%0246	A13 \$	002419	004469	-02729	0500	0000	0375	0500	1000	0625	0000	%0327	J13 \$	002883	005278	-02113	0625	0000	0375	0375	1000	0625	0000	%0408	S13 \$	
002076	004230	-04156	0375	0000	0500	0625	1000	0500	0000	%0247	A14 \$	002462	004842	-03665	0500	0000	0500	0500	1000	0500	0000	%0328	J14 \$	002922	005508	-03065	0625	0000	0500	0375	1000	0500	0000	%0409	S14 \$	
002127	004669	-04932	0375	0000	0625	0625	1000	0375	0000	%0248	A15 \$	002533	005224	-04465	0500	0000	0625	0500	1000	0375	0000	%0329	J15 \$	002980	005914	-03901	0625	0000	0625	0375	1000	0375	0000	%0410	S15 \$	
002177	005006	-05458	0375	0000	0750	0625	1000	0250	0000	%0249	A16 \$	002590	005522	-04995	0500	0000	0750	0500	1000	0250	0000	%0330	J16 \$	003018	006157	-04445	0625	0000	0750	0375	1000	0250	0000	%0411	S16 \$	
002196	005165	-05708	0375	0000	0875	0625	1000	0125	0000	%0250	A17 \$	002585	005659	-05258	0500	0000	0875	0500	1000	0125	0000	%0331	J17 \$	003013	006271	-04701	0625	0000	0875	0375	1000	0125	0000	%0412	S17 \$	
002207	005106	-05707	0375	0000	1000	0625	1000	0000	0000	%0251	A18 \$	002599	005669	-05263	0500	0000	1000	0500	1000	0000	0000	%0332	J18 \$	003032	006286	-04709	0625	0000	1000	0375	1000	0000	0000	%0413	S18 \$	
002497	001444	001693	0375	0125	0000	0625	0875	1000	0000	%0252	B10 \$	002901	002405	-002318	0500	0125	0000	0500	0875	1000	0000	%0333	K10 \$	003410	003525	003131	0625	0125	0000	0375	0875	1000	0000	%0414	T10 \$	
002638	001806	-00399	0375	0125	0125	0625	0875	0875	0000	%0253	B11 \$	003021	002711	-001035	0500	0125	0125	0500	0875	0875	0000	%0334	K11 \$	003532	003746	-008020	0625	0125	0125	0375	0875	0875	0000	%0415	T11 \$	
002730	002160	-01690	0375	0125	0250	0625	0875	0750	0000	%0254	B12 \$	003104	002957	-01157	0500	0125	0250	0500	0875	0750	0000	%0335	K12 \$	003600	003947	-00534	0625	0125	0250	0375	0875	0750	0000	%0416	T12 \$	
002816	002566	-02756	0375	0125	0375	0625	0875	0625	0000	%0255	B13 \$	003184	003303	-02282	0500	0125	0375	0500	0875	0625	0000	%0336	K13 \$	003665	004020	-01695	0625	0125	0375	0375	0875	0625	0000	%0417	T13 \$	
002875	003016	-03770	0375	0125	0500	0625	0875	0500	0000	%0256	B14 \$	003242	003690	-03337	0500	0125	0500	0500	0875	0500	0000	%0337	K14 \$	003716	004521	-02764	0625	0125	0500	0375	0875	0500	0000	%0418	T14 \$	
002941	003485	-04662	0375	0125	0625	0625	0875	0375	0000	%0257	B15 \$	003319	004112	-04252	0500	0125	0625	0500	0875	0375	0000	%0338	K15 \$	003771	004882	-03731	0625	0125	0625	0375	0875	0375	0000	%0419	T15 \$	
003007	003879	-05300	0375	0125	0750	0625	0875	0250	0000	%0258	B16 \$	003369	004456	-04914	0500	0125	0750	0500	0875	0250	0000	%0339	K16 \$	003811	005172	-04401	0625	0125	0750	0375	0875	0250	0000	%0420	T16 \$	
003022	004089	-05626	0375	0125	0875	0625	0875	0125	0000	%0259	B17 \$	003371	004649	-05251	0500	0125	0875	0500	0875	0125	0000	%0340	K17 \$	003816	005344	-04755	0625	0125	0875	0375	0875	0125	0000	%0421	T17 \$	
003024	004120	-05643	0375	0125	1000	0625	0875	0000	0000	%0260	B18 \$	003386	004677	-05269	0500	0125	1000	0500	0875	0000	0000	%0341	K18 \$	003827	005359	-04775	0625	0125	1000	0375	0875	0000	0000	%0422	T18 \$	
003293	000135	002671	0375	0250	0000	0625	0750	1000	0000	%0261	C10 \$	003661	001145	-032369	0500	0250	0000	0500	0750	1000	0000	%0342	L10 \$	004203	002323	004074	0625	0250	0000	0375	0750	1000	0000	%0423	U10 \$	
003439	000413	000468	0375	0250	0125	0625	0750	0875	0000	%0262	C11 \$	003810	001363	-000994	0500	0250	0125	0500	0750	0875	0000	%0343	L11 \$	004348	002541	001687	0625	0250	0125	0375	0750	0875	0000	%0424	U11 \$	
003558	000708	-00930	0375	0250	0250	0625	0750	0750	0000	%0263	C12 \$	003922	001571	-00414	0500	0250	0250	0500	0750	0750	0000	%0344	L12 \$	004437	002606	000181	0625	0250	0250	0375	0750	0750	0000	%0425	U12 \$	
003651	001061	-02010	0375	0250	0375	0625	0750	0625	0000	%0264	C13 \$	003992	001844	-01541	0500	0250	0375	0500	0750	0625	0000	%0345	L13 \$	004519	002824	-00988	0625	0250	0375	0375	0750	0625	0000	%0426	U13 \$	
003714	001501	-03102	0375	0250	0500	0625	0750	0500	0000	%0265	C14 \$	004063	002227	-02669	0500	0250	0500	0500	0750	0500	0000	%0346	L14 \$	004565	003150	-02135	0625	0250	0500	0375	0750	0500	0000	%0427	U14 \$	
003779	001999	-04116	0375	0250	0625	0625	0750	0375	0000	%0266	C15 \$	004149	002677	-03717	0500	0250	0625	0500	0750	0375	0000	%0347	L15 \$	004656	003746	-02135	0625	0250	0500	0375	0750	0500	0000	%0428	U15 \$	
003851	002435	-04860	0375	0250	0750	0625	0750	0250	0000	%0267	C16 \$	004188	003079	-04508	0500	0250	0750	0500	0750	0250	0000	%0348	L16 \$	004663	003862	-04020	0625	0250	0750	0375	0750	0250	0000	%0429	U16 \$	
003855	002686	-05259	0375	0250	0875	0625	0750	0125	0000	%0268	C17 \$	004187	003315	-04935	0500	0250	0875	0500	0750	0125	0000	%0349	L17 \$	004695	004045	-04449	0625	0250	0875	0375	0750	0125	0000	%0430	U17 \$	
003858	002729	-05292	0375	0250	1000	0625	0750	0000	0000	%0269	C18 \$	004204	003346	-04966	0500	0250	1000	0500	0750	0000	0000	%0350	L18 \$	004698	004074	-04503	0625	0250	1000	0375	0750	0000	0000	%0431	U18 \$	
004049	-01119	003604	0375	0375	0000	0625	0625	1000	0000	%0270	D10 \$	004422	-00080	004237	0500	0375	0000	0500	0625	1000	0000	%0351	M10 \$	005091	001110	005061	0625	0375	0000	0375	0625	1000	0000	%0432	U19 \$	
004209	-00915	001371	0375	0375	0125	0625	0625	0875	0000	%0271	D11 \$	004570	000045	-001932	0500	0375	0125	0500	0625	0875	0000	%0352	M11 \$	005132	001177	002590	0625	0375	0125	0375	0625	0875	0000	%0433	V11 \$	
004328	-00664	-00609	0375	0375	0250	0625	0625	0750	0000	%0272	D12 \$	004675	000240	-004030	0500	0375	0250	0500	0																	

003273	005579	003313	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
003307	005774	001100	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
003330	005946	-00229	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
003363	006156	-01345	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
003389	006396	-02365	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
003419	006648	-03224	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
003454	006854	-03786	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
003450	006958	-04058	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$
003458	006975	-04076	0750	0000	0900	0250	1000	0000	0000	%0494	A27	\$
003484	007187	-04579	0750	0000	1000	0250	1000	0000	0000	%0495	A28	\$
003984	004803	-00462	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$
004051	004937	001675	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
004108	005075	000242	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
004142	005277	-00963	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
004184	005517	-02092	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
004212	005806	-03895	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
004240	006043	-03785	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
004256	006209	-04165	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
004216	006248	-04202	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
004743	003718	004949	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
004833	003779	002478	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
004897	003884	000937	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
004950	004056	-00293	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
004988	004287	-01491	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
005020	004599	-02622	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
005036	004899	-03469	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
005030	005083	-03950	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
005018	005136	-04010	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
005504	002560	005885	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
005602	002595	003355	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005655	002688	001738	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
005678	002856	000466	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
005720	003093	-00816	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
005751	003400	-02506	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
005772	003710	-03903	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$
005757	003955	-03596	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$
005753	004007	-03672	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$
006280	001403	006859	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
006360	001394	004309	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
006411	001473	002655	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
006447	001617	001328	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006495	001810	000014	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
006521	002105	-01299	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
006550	002435	-02401	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
006551	002671	-03097	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
006538	002726	-03195	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
006957	000413	007759	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
007029	000354	005205	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
007099	000366	003554	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
007148	000450	002248	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
007187	000628	000867	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
007232	000878	-00535	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
007272	001179	-01722	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
007267	001445	-02536	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$
007250	001506	-02657	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
007521	-00418	008528	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
007650	-00592	006020	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
007730	-00659	004408	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
007795	-00619	003378	0750	0750	0375	0250	0250	0500	0000	%0543	G22	\$
007860	-00512	001697	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007939	-00346	000290	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$
007986	-00082	-00973	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$
007983	000176	-01884	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$
007984	000230	-02022	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$
007971	-01054	009187	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$
008172	-01403	006790	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$
008291	-01541	005162	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$
008376	-01578	003868	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$
008464	-01548	002497	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$
008545	-01471	001098	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$
008631	-01277	-00232	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$
008671	-01084	-01165	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$
008676	-01052	-01305	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$
008002	-01061	009243	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$
008205	-01428	006827	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$
008312	-01575	005224	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$
008414	-01614	003903	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$
008491	-01592	002540	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$
008588	-01519	001142	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$
008673	-01332	-00183	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$
008710	-01142	-01120	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$
008720	-01112	-01263	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$
003631	006243	003834	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$
003669	006441	001541	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$
003699	006616	000191	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$
003724	006804	-00901	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$
003756	007021	-01916	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$
003779	007243	-02744	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$
003812	007420	-03294	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$
003805	007519	-03574	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$
003810	007532	-03597	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$
004375	005551	-004636	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$
004442	005692	-002180	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$
004487	005840	-000712	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$
004532	006019	-00480	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$
004557	006235	-01603	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$
004589	006496	-02582	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$
004616	006714	-03278	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$
004594	006870	-03678	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$
004598	006897	-03714	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$
005134	004573	005522	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$
005223	00											

009292	-00059	-00621	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009240	-00151	-00676	0875	1000	1000	0000	0125	0000	0000	%0730	b02	\$
008800	-01086	-01223	0750	1000	1000	0000	0250	0000	0000	%0731	b03	\$
008188	-01995	-01891	0625	1000	1000	0000	0375	0000	0000	%0732	b04	\$
007602	-02649	-02441	0500	1000	1000	0000	0500	0000	0000	%0733	b05	\$
007083	-03101	-02868	0375	1000	1000	0000	0625	0000	0000	%0734	b06	\$
006519	-03474	-03266	0250	1000	1000	0000	0750	0000	0000	%0735	b07	\$
005847	-03756	-03659	0125	1000	1000	0000	0875	0000	0000	%0736	b08	\$
005140	-03700	-03971	0000	1000	1000	0000	1000	0000	0000	%0737	b09	\$
009256	-00015	-00542	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
009204	-00115	-00593	0875	0875	0875	0000	0125	0125	0125	%0739	c02	\$
008761	-01056	-01149	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
008154	-01979	-01816	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
007578	-02636	-02366	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
007054	-03108	-02813	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
006498	-03488	-03211	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005835	-03774	-03599	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
005101	-03808	-03913	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
008556	-00059	-00455	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
008514	-00049	-00469	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
008090	-00093	-01016	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
007551	-01129	-01645	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
007033	-01942	-02170	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
006599	-02534	-02612	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
006102	-03056	-02999	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005516	-03475	-03389	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
004854	-03646	-03679	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007789	-001925	-00078	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007747	-001824	-00085	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
007367	-000826	-00561	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006841	-00307	-01180	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
006364	-01220	-01721	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
005977	-01935	-02169	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
005549	-02583	-02587	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
005008	-03140	-02941	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
004444	-03453	-03228	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
007009	-002866	-000403	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006990	-002744	-000434	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006609	-001753	-000333	0750	0500	0500	0250	0500	0500	0000	%0767	f03	\$
006090	-000534	-00624	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005635	-00473	-01159	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005270	-01286	-01605	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
004864	-02039	-02021	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004388	-02708	-02433	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
003885	-03140	-02671	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
006192	-003858	-000888	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
006149	-003761	-000888	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005786	-002800	-000450	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
005251	-001565	-00190	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
004790	-000521	-00747	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
004420	-00367	-01215	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
004036	-01203	-01661	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
003600	-01943	-02072	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003155	-02444	-02340	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
005403	-004822	-001326	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005376	-004725	-001350	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
004986	-003851	-000900	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
004642	-002642	-000210	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
003963	-001584	-00383	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
003577	-000654	-00926	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
003202	-00245	-01402	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
002793	-01044	-01810	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
002396	-01595	-02114	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
004551	-005749	-002133	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004520	-005682	-002126	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
004142	-004897	-001662	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
003570	-003740	-000906	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
003070	-002700	-000205	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
002665	-001731	-00419	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
002278	-000813	-01061	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
001907	-00024	-00495	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
001573	-00672	-01730	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
003720	-006338	-003852	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
003697	-006288	-003843	0875	0000	0000	0125	1000	1000	0000	%0802	j02	\$
003345	-005611	-003312	0750	0000	0000	0250	1000	1000	0000	%0803	j03	\$
002787	-004523	-002431	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
002268	-003477	-001593	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
001833	-002543	-000871	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
001502	-001513	-000208	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
001088	-000743	-00291	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
000912	-000012	-00719	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009247	-00036	-00643	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
009163	-00059	-00749	0875	1000	1000	0125	0125	0000	0000	%0811	b11	\$
008145	-000139	-01898	0750	0750	0750	0250	0250	0000	0000	%0812	b12	\$
008949	-000328	-03051	0625	1000	0375	0375	0000	0000	0000	%0813	b13	\$
005817	-000681	-03987	0500	0500	0500	0500	0000	0000	0000	%0814	b14	\$
004685	-001321	-04822	0375	0375	1000	0625	0625	0000	0000	%0815	b15	\$
003534	-002040	-05506	0250	0250	1000	0750	0750	0000	0000	%0816	b16	\$
002233	-003900	-06250	0125	0250	1000	0875	0875	0000	0000	%0817	b17	\$
001223	-004143	-06458	0000	1000	1000	1000	0000	0000	0000	%0818	b18	\$
009248	-00062	-00527	1000	1000	0875	0000	0125	0000	0000	%0819	c10	\$
009162	-00088	-00625	0875	0875	0875	0125	0125	0200	0000	%0820	c11	\$
008150	-000809	-01788	0750	0750	0750	0250	0250	0125	0000	%0821	c12	\$
006963	-002283	-02952	0625	0625	0875	0375	0375	0125	0000	%0822	c13	\$
005822	-00628	-03914	0500	0500	0875	0500	0500	0125	0000	%0823	c14	\$
004681	-001269	-04767	0375	0375	0875	0625	0625	0125	0000	%0824	c15	\$
003543	-001993	-05539	0250	0250	0875	0750	0750	0125	0000	%0825	c16	\$
002317	-003023	-06201	0125	0125	0875	0875	0125	0000	0000	%0826	c17	\$
001228	-004106	-06423	0000	0000	0875	1000	1000	0125	0000	%0827	c18	\$
009199	-00216	-009350	1000	1000	0750	0000	0250	0000	0000	%0828	d10	\$
009119	-00246	-002057	0875	0875	0750	0125	0125	0250	0000	%0829	d11	\$
008114	-00											

%BEG GE28(7)_22_REM.TXT, Separation cmyn62*, D50, not adapted \$
%100 x LAB*
%#1000 x (r g b c m y 0) %nr. pos \$
%z003647 006303 003862 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008515 000054 010030 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z004308 -06071 003807 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005081 -03755 -03977 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z001236 004132 -06455 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003837 007577 -03554 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z000810 000021 -00675 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009214 -00045 -00638 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z003720 006338 003852 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008517 000074 009972 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z004272 -06059 003775 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005110 -03780 -03971 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z001223 004143 -06458 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003858 007594 -03552 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z000799 000025 -00683 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009259 -00046 -00634 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

TUB-test chart GE38; Relative Device Colour System G
1080 spectral reflexions R -> LAB* for D65 and D50

input: w *setgray*
output: -> *olv* setrgbcolor*

TUB registration: 20091101-GE38/GE38L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

\$B00	LAB2(7)_22.REM.TXT,	Separation	cmy62*	D50,	not adapted	\$
100 x GE8	1000 x	r g b	c m y 0			
000864	000000	00679	0090	0090	1000	1000
001958	00035	01384	0125	0125	0875	0875
003240	00219	01367	0250	0250	0250	0250
004461	00361	01193	0375	0375	0625	0625
005679	00460	01172	0500	0500	0500	0500
006886	00327	01156	0625	0625	0375	0375
008115	00143	00976	0750	0750	0250	0250
009178	00189	00607	0875	0875	0125	0125
009257	00045	00637	1000	1000	0000	0000
000860	00001	00681	0000	0000	1000	1000
001959	00033	01369	0125	0125	0875	0875
003238	00212	01383	0250	0250	0750	0750
004461	00354	01202	0375	0375	0625	0625
005676	00458	01181	0500	0500	0500	0500
006891	00317	01176	0625	0625	0375	0375
008113	00141	00991	0750	0750	0250	0250
009179	00112	00605	0875	0875	0125	0125
009257	00047	00639	1000	1000	0000	0000
000848	000004	00694	0000	0000	1000	1000
001936	00023	01389	0125	0125	0875	0875
003240	00219	01383	0250	0250	0750	0750
004422	00361	01180	0375	0375	0625	0625
005640	00463	01208	0500	0500	0500	0500
006857	00321	01176	0625	0625	0375	0375
008096	00134	01006	0750	0750	0250	0250
009177	00111	00607	0875	0875	0125	0125
009257	00044	00637	1000	1000	0000	0000
000851	00001	00681	0000	0000	1000	1000
001922	00015	01399	0125	0125	0875	0875
003196	00201	01389	0250	0250	0750	0750
004406	00351	01216	0375	0375	0625	0625
005634	00461	01179	0500	0500	0500	0500
006861	00310	01170	0625	0625	0375	0375
008091	00140	00984	0750	0750	0250	0250
009175	00189	00606	0875	0875	0125	0125
009256	00045	00637	1000	1000	0000	0000
000806	000002	00717	0000	0000	1000	1000
001328	000069	01201	0066	0066	0933	0933
002005	00069	01423	0133	0133	0866	0866
002693	00271	01377	0200	0200	0800	0800
003400	00285	01338	0266	0266	0333	0333
004064	00329	01180	0333	0333	0666	0666
004717	00434	01171	0400	0400	0600	0600
005355	00488	01149	0466	0466	0533	0533
005994	00500	01091	0533	0533	0466	0466
006611	00380	01094	0600	0600	0400	0400
007008	00121	00903	0734	0734	0266	0266
008019	00076	00841	0800	0800	0200	0200
009158	00137	00579	0866	0866	0133	0133
009236	00053	00621	0933	0933	0066	0066
009232	00044	00627	1000	1000	0000	0000
000814	000008	00725	0000	0000	1000	1000
001318	000070	01218	0066	0066	0933	0933
001993	00050	01455	0133	0133	0866	0866
002676	00244	01399	0200	0200	0800	0800

TUB-test chart GE38; Relative Device Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

TUB registration: 20091101-GE38/GE38L0NA.TXT /.PS
- application for evaluation and measurement of printer or

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus-richter/GE38/GE38L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

TUB registration: 20091101-GE38/GE38L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

%BEG GE28(7)_22.REM.TXT, Separation cmyn62*, D50, adapted \$																			
%100 x LAB*a																			
1000 x (r g b																			
c m y 0)																			
%nrr. pos \$																			
000810	000000	000000	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
000879	000816	-01694	0000	0000	0125	1000	1000	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
000939	001534	-02755	0000	0000	0250	1000	1000	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
000999	002176	-03582	0000	0000	0375	1000	1000	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001067	002838	-04362	0000	0000	0500	1000	1000	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001159	003434	-05052	0000	0000	0625	1000	1000	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001205	003879	-05534	0000	0000	0750	1000	1000	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001244	004070	-05748	0000	0000	0875	1000	1000	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001236	004113	-05781	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001451	-01296	000775	0000	0125	0000	1000	0875	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001558	-00631	001033	0000	0125	0125	1000	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001632	000847	-02217	0000	0125	0250	1000	0875	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001708	000662	-03105	0000	0125	0375	1000	0875	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001784	001345	-03970	0000	0125	0500	1000	0875	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001876	002002	-04773	0000	0125	0625	1000	0875	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001933	002481	-05324	0000	0125	0750	1000	0875	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001964	002725	-05593	0000	0125	0875	1000	0875	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001958	-02774	-05629	0000	0125	1000	1000	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002181	-02657	001707	0000	0250	0000	1000	0750	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002294	-02157	-001493	0000	0250	0125	1000	0750	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002358	-01526	-01449	0000	0250	0250	1000	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002433	-00954	-02417	0000	0250	0375	1000	0750	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002521	-00297	-03345	0000	0250	0500	1000	0750	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002604	000392	-04239	0000	0250	0625	1000	0750	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002677	000907	-04867	0000	0250	0750	1000	0750	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002700	001188	-05185	0000	0250	0875	1000	0750	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002697	001240	-05236	0000	0250	1000	1000	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002829	-03771	002541	0000	0375	0000	1000	0625	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002957	-03413	000598	0000	0375	0125	1000	0625	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003041	-02933	-00620	0000	0375	0250	1000	0625	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003114	-02388	-01673	0000	0375	0375	1000	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003208	-01758	-02883	0000	0375	0500	1000	0625	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003305	-01100	-03653	0000	0375	0625	1000	0625	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003372	-00971	-04336	0000	0375	0750	1000	0625	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003390	-00268	-04698	0000	0375	0875	1000	0625	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003392	-00216	-04752	0000	0375	1000	1000	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003435	-04733	003317	0000	0500	0000	1000	0500	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003567	-04502	001355	0000	0500	0125	1000	0500	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003653	-04112	000100	0000	0500	0250	1000	0500	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003736	-03631	-00095	0000	0500	0375	1000	0500	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003832	-03071	-02023	0000	0500	0500	1000	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003919	-02426	-03044	0000	0500	0625	1000	0500	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004010	-01916	-03793	0000	0500	0750	1000	0500	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004028	-01599	-04190	0000	0500	0875	1000	0500	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004032	-01544	-04249	0000	0500	1000	1000	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003866	-05403	003857	0000	0625	0000	1000	0375	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004008	-05265	001939	0000	0625	0125	1000	0375	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004111	-04948	000674	0000	0625	0250	1000	0375	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004201	-04536	-00425	0000	0625	0375	1000	0375	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004289	-04003	-01515	0000	0625	0500	1000	0375	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004390	-03400	-02561	0000	0625	0625	1000	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004465	-02883	-03356	0000	0625	0750	1000	0375	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004499	-02575	-03781	0000	0625	0875	1000	0375	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004502	-02525	-03858	0000	0625	1000	1000	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004140	-05827</																		

See original or copy: <http://web.me.com/klau.s.richter/GE38/GE38L0NA.TXT> /.PS
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

001783	002509	001545	0375	0000	0000	0625	1000	1000	0000	%0243	A10	\$	002215	003416	002217	0500	0000	0000	0500	1000	1000	0000	%0324	J10	\$	002721	004469	003030	0625	0000	0000	0375	1000	1000	0000	%0405	S10	\$
001871	002965	-00424	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$	002299	003809	000161	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$	002797	004764	000881	0625	0000	0125	0375	1000	0875	0000	%0406	S11	\$
001954	003345	-01594	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$	002353	004121	-01058	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$	002838	005095	-00383	0625	0000	0250	0375	1000	0750	0000	%0407	S12	\$
002013	003790	-02583	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$	002419	004460	-02060	0500	0000	0375	0500	1000	0625	0000	%0327	J13	\$	002883	005273	-01446	0625	0000	0375	0375	1000	0625	0000	%0408	S13	\$
002076	004218	-03486	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$	002462	004833	-02996	0500	0000	0500	0500	1000	0500	0000	%0328	J14	\$	002922	005575	-02398	0625	0000	0500	0375	1000	0500	0000	%0409	S14	\$
002127	004658	-04261	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$	002533	005216	-03797	0500	0000	0625	0500	1000	0375	0000	%0329	J15	\$	002980	005910	-03235	0625	0000	0625	0375	1000	0375	0000	%0410	S15	\$
002177	004995	-04788	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$	002590	005514	-04327	0500	0000	0750	0500	1000	0250	0000	%0330	J16	\$	003018	006153	-03779	0625	0000	0750	0375	1000	0250	0000	%0411	S16	\$
002196	005154	-05039	0375	0000	0875	0625	1000	0125	0000	%0250	A17	\$	002585	005652	-04590	0500	0000	0875	0500	1000	0125	0000	%0331	J17	\$	003013	006266	-04035	0625	0000	0875	0375	1000	0125	0000	%0412	S17	\$
002207	005175	-05037	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$	002599	005662	-04595	0500	0000	1000	0500	1000	0000	0000	%0332	J18	\$	003032	006282	-04043	0625	0000	1000	0375	1000	0000	0000	%0413	S18	\$
002497	001436	002362	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$	002901	002400	002984	0500	0125	0000	0500	0875	1000	0000	%0333	K10	\$	003010	003524	003795	0625	0125	0000	0375	0875	1000	0000	%0414	T10	\$
002638	001799	002688	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$	003021	002706	000801	0500	0125	0125	0500	0875	0875	0000	%0334	K11	\$	003532	003746	001848	0625	0125	0125	0375	0875	0875	0000	%0415	T11	\$
002730	002154	-01022	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$	003104	002953	-00492	0500	0125	0250	0500	0875	0750	0000	%0335	K12	\$	003600	003948	000129	0625	0125	0250	0375	0875	0750	0000	%0416	T12	\$
002816	002560	-02089	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$	003184	003300	-01617	0500	0125	0375	0500	0875	0625	0000	%0336	K13	\$	003665	004203	-01031	0625	0125	0375	0375	0875	0625	0000	%0417	T13	\$
002875	003010	-03103	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$	003242	003688	-02671	0500	0125	0500	0500	0875	0500	0000	%0337	K14	\$	003716	004520	-02101	0625	0125	0500	0375	0875	0500	0000	%0418	T14	\$
002941	003480	-03996	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$	003319	004110	-03587	0500	0125	0625	0500	0875	0375	0000	%0338	K15	\$	003771	004883	-03069	0625	0125	0625	0375	0875	0375	0000	%0419	T15	\$
003007	003875	-04634	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$	003369	004454	-04249	0500	0125	0750	0500	0875	0250	0000	%0339	K16	\$	003811	005175	-03738	0625	0125	0750	0375	0875	0250	0000	%0420	T16	\$
003022	004085	-04960	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$	003371	004647	-04587	0500	0125	0875	0500	0875	0125	0000	%0340	K17	\$	003816	005346	-04093	0625	0125	0875	0375	0875	0125	0000	%0421	T17	\$
003024	004116	-04976	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$	003386	004676	-04604	0500	0125	1000	0500	0875	0000	0000	%0341	K18	\$	003827	005361	-04113	0625	0125	1000	0375	0875	0000	0000	%0422	T18	\$
003293	000133	003336	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$	003661	001146	003932	0500	0250	0000	0500	0750	1000	0000	%0342	L10	\$	004203	002328	004735	0625	0250	0000	0375	0750	1000	0000	%0423	T19	\$
003439	000412	001132	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$	003810	001365	001656	0500	0250	0125	0500	0750	0875	0000	%0343	L11	\$	004348	002457	002347	0625	0250	0125	0375	0750	0875	0000	%0424	T20	\$
003558	000708	-00267	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$	003922	001574	000247	0500	0250	0250	0500	0750	0750	0000	%0344	L12	\$	004437	002614	000841	0625	0250	0250	0375	0750	0750	0000	%0425	T21	\$
003651	001062	-01347	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$	003992	001848	-00079	0500	0250	0375	0500	0750	0625	0000	%0345	L13	\$	004519	002832	-00328	0625	0250	0375	0375	0750	0625	0000	%0426	T22	\$
003714	001502	-02439	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$	004063	002322	-02007	0500	0250	0500	0500	0750	0500	0000	%0346	L14	\$	004565	003581	-01475	0625	0250	0500	0375	0750	0500	0000	%0427	T23	\$
003779	002001	-03453	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$	004061	002001	-03453	0500	0250	0625	0500	0750	0375	0000	%0347	L15	\$	004666	003877	-01361	0625	0250	0500	0375	0750	0500	0000	%0428	T24	\$
003851	002438	-04197	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$	004188	003084	030847	0500	0250	0750	0500	0750	0250	0000	%0348	L16	\$	004655	003151	-01031	0625	0250	0500	0375	0750	0500	0000	%0429	T25	\$
003855	002689	-04597	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$	004187	003320	-04274	0500	0250	0875	0500	0750	0125	0000	%0349	L17	\$	004695	004054	-03791	0625	0250	0875	0375	0750	0125	0000	%0430	T26	\$
003858	002731	-04629	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$	004204	003351	-04305	0500	0250	1000	0500	0750	0000	0000	%0350	L18	\$	004678	004083	-03845	0625	0250	1000	0375	0750	0000	0000	%0431	T27	\$
004049	-01115	004266	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$	004422	-00073	004896	0500	0375	0000	0500	0625	1000	0000	%0351	M10	\$	005091	001122	005719	0625	0375	0000	0375	0625	1000	0000	%0432	T28	\$
004209	-00909	002032	0375	0375	0125	0625	0625	0875	0000	%0271	D11	\$	004570	000054	002592	0500	0375	0125	0500	0625	0875	0000																

See original or copy: <http://web.me.com/klaustrichter/GE38/GE38L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

003273	005577	003978	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$	003631	006244	004498	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$	003647	006303	004526	1000	0000	0000	0000	1000	1000	0000	%0648	S19	\$
003307	005772	001765	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$	003669	006442	002204	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$	003691	006504	002186	1000	0000	0125	0000	1000	0875	0000	%0649	S20	\$
003330	005944	000434	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$	003699	006618	000854	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$	003731	006685	000843	1000	0000	0250	0000	1000	0750	0000	%0650	S21	\$
003363	006155	-00680	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$	003724	006806	-00238	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$	003757	006876	-00251	1000	0000	0375	0000	1000	0625	0000	%0651	S22	\$
003389	006395	-01700	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$	003756	007023	-01253	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$	003789	007083	-01211	1000	0000	0500	0000	1000	0500	0000	%0652	S23	\$
003419	006647	-02560	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$	003779	007245	-02081	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$	003817	007304	-02039	1000	0000	0625	0000	1000	0375	0000	%0653	S24	\$
003454	006854	-03122	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$	003812	007422	-02631	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$	003836	007482	-02595	1000	0000	0750	0000	1000	0250	0000	%0654	S25	\$
003459	006957	-03393	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$	003805	007521	-02911	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$	003838	007572	-02869	1000	0000	0875	0000	1000	0125	0000	%0655	S26	\$
003458	006974	-03412	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$	003810	007536	-02935	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$	003837	007579	-02891	1000	0000	1000	0000	1000	0000	0000	%0656	S27	\$
003984	004807	004724	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$	004375	005558	%05296	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$	004401	005630	005341	1000	0125	0000	0000	0875	1000	0000	%0657	T19	\$
004051	004941	002377	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$	004442	005699	002840	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$	004472	005789	002821	1000	0125	0125	0000	0875	0875	0000	%0658	T20	\$
004108	005080	000903	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$	004487	005848	001372	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$	004522	005937	001357	1000	0125	0250	0000	0875	0750	0000	%0659	T21	\$
004142	005282	-00302	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$	004532	006027	000178	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$	004564	006113	000164	1000	0125	0375	0000	0875	0625	0000	%0660	T22	\$
004184	005523	-01431	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$	004557	006243	-00944	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$	004599	006334	-00920	1000	0125	0500	0000	0875	0500	0000	%0661	T23	\$
004212	005812	-02434	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$	004589	006504	-01923	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$	004625	006586	-01893	1000	0125	0625	0000	0875	0375	0000	%0662	T24	\$
004240	006049	-03125	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$	004616	006722	-02619	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$	004650	006795	-02592	1000	0125	0750	0000	0875	0250	0000	%0663	T25	\$
004258	006215	-03504	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$	004594	006878	-03019	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$	004646	006940	-02970	1000	0125	0875	0000	0875	0125	0000	%0664	T26	\$
004210	006254	-03541	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$	004598	006905	-03054	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$	004628	006968	-03012	1000	0125	1000	0000	0875	0000	0000	%0665	T27	\$
004743	003728	005607	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$	005134	004586	006178	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$	005210	004622	006273	1000	0250	0000	0000	0750	1000	0000	%0666	U19	\$
004833	003789	003136	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$	005223	004682	003625	0875	0250	0125	0125	0750	0875	0000	%0586	L20	\$	005292	004722	003634	1000	0250	0125	0000	0750	0875	0000	%0667	U20	\$
004897	003895	001594	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$	005280	004786	002957	0875	0250	0250	0125	0750	0750	0000	%0587	L21	\$	005363	004826	002961	1000	0250	0250	0000	0750	0750	0000	%0668	U21	\$
004950	004067	000364	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$	005333	004935	000838	0875	0250	0375	0125	0750	0625	0000	%0588	L22	\$	005398	004992	000830	1000	0250	0375	0000	0750	0625	0000	%0669	U22	\$
004988	004298	-00834	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$	005363	005154	-00344	0875	0250	0500	0125	0750	0500	0000	%0589	L23	\$	005423	005225	-00356	1000	0250	0500	0000	0750	0500	0000	%0670	U23	\$
005020	004611	-01964	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$	005381	005425	-01454	0875	0250	0625	0125	0750	0375	0000	%0590	L24	\$	005454	005480	-01432	1000	0250	0625	0000	0750	0375	0000	%0671	U24	\$
005036	004912	-02812	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$	005407	005680	-02304	0875	0250	0750	0125	0750	0250	0000	%0591	L25	\$	005468	005731	-02281	1000	0250	0750	0000	0750	0250	0000	%0672	U25	\$
005030	005095	-03293	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$	005402	005865	-02810	0875	0250	0875	0125	0750	0125	0000	%0592	L26	\$	005461	005914	-02761	1000	0250	0875	0000	0750	0125	0000	%0673	U26	\$
005018	005148	-03353	0750	0250	1000	0250	0750	0000	0000	%0513	C27	\$	005385	005912	-02876	0875	0250	1000	0125	0750	0000	0000	%0593	L27	\$	005450	005961	-02820	1000	0250	1000	0000	0750	0000	0000	%0674	U27	\$
005504	002576	006541	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$	005892	003544	007138	0875	0375	0000	0125	0625	1000	0000	%0594	M19	\$	005967	003588	007193	1000	0375	0000	0000	0625	1000	0000	%0675	V19	\$
005602	002612	004009	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$	005967	003606	004518	0875	0375	0125	0125</																			

See original or copy: <http://web.me.com/klaus.richter/GE38/GE38L0NA.TXT /.PS>
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

009292	-00012	000012	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009240	-00104	-00041	0875	1000	1000	0125	0000	0000	0000	%0730	b02	\$
008800	-01043	-00586	0750	1000	1000	0250	0000	0000	0000	%0731	b03	\$
008188	-01958	-01250	0625	1000	1000	0375	0000	0000	0000	%0732	b04	\$
007602	-02616	-01797	0500	1000	1000	0500	0000	0000	0000	%0733	b05	\$
007083	-03073	-02221	0375	1000	1000	0625	0000	0000	0000	%0734	b06	\$
006519	-03451	-02616	0250	1000	1000	0750	0000	0000	0000	%0735	b07	\$
005847	-03738	-03005	0125	1000	1000	0875	0000	0000	0000	%0736	b08	\$
005110	-03768	-03313	0000	1000	1000	1000	0000	0000	0000	%0737	b09	\$
009256	000031	000091	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
009204	000609	000041	0875	0875	0875	0125	0125	0125	0000	%0739	c02	\$
008761	-01063	-00512	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
008154	-01942	-01175	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
007578	-02604	-01722	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
007054	-03080	-02165	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
006498	-03465	-02561	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005835	-03756	-02944	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
005101	-03796	-03254	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
008556	000099	000183	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
008514	000889	000168	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
008090	-00057	-00375	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
007551	-01097	-01000	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
007033	-01915	-01522	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
006599	-02510	-01962	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
006102	-03037	-02346	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005516	-03460	-02733	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
004854	-03637	-03019	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007789	001959	000564	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007747	001858	000557	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
007367	000856	000083	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006841	-00281	-00531	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
006364	-01198	-01070	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
005977	-01916	-01515	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
005549	-02567	-01901	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
005008	-03129	-02282	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
004444	-03447	-02566	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
007099	002894	001050	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006990	002772	001082	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006609	001777	000616	0750	0500	0500	0250	0500	0500	0000	%0767	f03	\$
006090	000553	000028	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005635	-00457	-00503	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005270	-01273	-00947	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
004864	-02030	-01362	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004388	-02703	-01771	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
003885	-03139	-02006	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
006192	003878	001540	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
006149	003781	001541	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005786	002817	001105	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
005251	001577	000467	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
004790	000530	-00087	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
004420	-00361	-00552	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
004036	-01200	-00997	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
003600	-01944	-01405	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003155	-02450	-01671	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
005403	004836	001983	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005376	004739	002007	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
004986	003061	001559	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
004642	002648	000873	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
003963	001586	000281	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
003577	000652	-00259	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
003202	-00250	-00733	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
002793	-01053	-01139	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
002396	-01607	-01440	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
004551	005756	002795	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004520	005688	002788	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
004142	004900	002326	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
003570	003739	001573	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
003070	002694	000875	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
002665	001721	000253	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
002278	000800	-00207	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
001907	-00039	-00729	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
001573	-00691	-01052	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
003720	006338	004518	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
003697	006287	004509	0875	0000	0000	0125	1000	1000	0000	%0802	j02	\$
003345	005608	003980	0750	0000	0000	0250	1000	1000	0000	%0803	j03	\$
002787	004515	003102	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
002268	003464	002267	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
001833	002527	001548	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
001502	001495	000887	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
001088	000720	000390	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
000812	-00013	-00036	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009247	000009	-00008	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
009163	-00013	-00114	0875	0875	0875	0100	0125	0125	0000	%0811	b11	\$
008145	-000177	-01257	0750	0750	0750	0250	0250	0250	0000	%0812	b12	\$

%BEG GE28(7)_22_REM.TXT, Separation cmyn62*, D50, adapted \$
%100 x LAB*a %1000 x (r g b c m y 0) %nr. pos \$
%z003647 006303 004526 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008515 000094 010671 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z004308 -06064 004468 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005081 -03742 -03320 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z001236 004113 -05781 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003837 007579 -02891 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z000810 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009214 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z003720 006338 004518 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008517 000115 010611 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z004272 -06055 004438 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005110 -03768 -03313 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z001223 004121 -05777 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003858 007594 -02886 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z000799 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009259 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/GE38/GE38L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cf1=1.00; nt=0.18; nx=1.0.

TUB registration: 20091101-GE38/GE38L0NA.TXT /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

[illegible]

TUB-test chart GE38; Relative Device Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

input: w *setgray*
output: $\rightarrow$ *olv** *setrgbcolor*