

See original or copy: <http://web.me.com/klaus.richter/GE30/GE30L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

TUB registration: 20091101-GE30/GE30L0NP.PDF /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

B6E GE28 2D TXT, Separation (r l v g b c m y 0)										D65, not adapted s																										
%100 x LAB*	1000 x (r l v g b c m y 0)									%nR.	pos s																									
001465	000032	000132	0000	0000	0000	1000	1000	1000	0000	00000	A01	001691	000211	000229	0125	0000	0000	0875	1000	1000	0000	00001	J01	001955	001984	000779	0250	0000	0000	0750	1000	1000	0000	000162	S01	
001163	-00078	000054	0000	0000	0125	1000	1000	0875	0000	00001	A02	001737	000947	-002991	0125	0000	0125	0875	1000	0875	0000	00082	J02	001733	001738	-006761	0250	0000	0125	0750	1000	0875	0000	000163	S02	
002166	-00298	-00863	0000	0000	0250	1000	1000	0750	0000	00002	A03	002306	000710	-03174	0125	0000	0250	0875	1000	0750	0000	00083	J03	002112	002345	-02367	0250	0000	0250	0750	1000	0750	0000	000164	S03	
002262	-00075	-02488	0000	0000	0375	1000	1000	0625	0000	00003	A04	002608	000301	-03373	0125	0000	0375	0875	1000	0625	0000	00084	J04	002627	002447	-04298	0250	0000	0375	0750	1000	0625	0000	000165	S04	
002746	-00103	-03250	0000	0000	0500	1000	1000	0500	0000	00004	A05	002957	000223	-03839	0125	0000	0500	0875	1000	0500	0000	00085	J05	003152	001073	-04593	0250	0000	0500	0750	1000	0500	0000	000166	S05	
003135	-00324	-03624	0000	0000	0625	1000	1000	0375	0000	00005	A06	003266	-00001	-04057	0125	0000	0625	0875	1000	0375	0000	00086	J06	003329	000192	-04187	0250	0000	0625	0750	1000	0375	0000	000167	S06	
003417	-00407	-03970	0000	0000	0750	1000	1000	0250	0000	00006	A07	003508	-00179	-04264	0125	0000	0750	0875	1000	0250	0000	00087	J07	003478	000214	-04426	0250	0000	0750	0750	1000	0250	0000	000168	S07	
003620	-00455	-04278	0000	0000	0875	1000	1000	0125	0000	00007	A08	003723	-00311	-04442	0125	0000	0875	0875	1000	0125	0000	00088	J08	003692	-00012	-04608	0250	0000	0875	0750	1000	0125	0000	000169	S08	
003865	-00485	-04471	0000	0000	1000	1000	1000	0000	0000	00008	A09	003922	-00406	-04582	0125	0000	1000	0875	1000	0000	0000	00089	J09	003894	-00264	-04583	0250	0000	1000	0750	1000	0000	0000	000170	S09	
003568	-02784	-001306	0000	0125	0000	1000	0875	1000	0000	00009	B01	001978	-00218	-000363	0125	0125	0000	0875	0875	1000	0000	00090	K01	002040	-001087	-001234	0250	0125	0000	0750	1000	0875	1000	0000	000171	T01
002000	-01460	-00238	0000	0125	0125	1000	0875	0875	0000	00010	B02	001751	000032	000121	0125	0125	0125	0875	0875	0875	0000	00091	K02	002215	-001328	-000416	0250	0125	0125	0750	1000	0875	0875	0000	000172	T02
002518	-00654	-02381	0000	0125	0250	1000	0875	0750	0000	00011	B03	002593	-00099	-02413	0125	0125	0250	0875	0875	0750	0000	00092														

1	()	()	1 ()	()

TUB registration: 20091101-GE30/GE30L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

TUB-test chart GE30; Relative Device Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

input: w setgray
output: $->oly^*$ s

See original or copy: <http://web.me.com/klaus.richter/GE30/GE30LONP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=

See original or copy: <http://web.me.com/klaus.richter/GE30/GE30L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

003874	005099	003290	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
003832	005079	002827	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
003758	005178	001820	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
003717	005483	000467	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
003703	005876	-01029	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
003743	005746	-02079	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
003599	005405	-02541	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
003737	004493	-03075	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$
003896	003606	-03363	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$
004070	005319	003862	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$
003941	005118	002982	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
003883	005286	001751	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
003879	005690	000307	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
003897	005934	-01271	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
003851	005775	-02110	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
003742	005075	-02709	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
003866	004225	-03106	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
003985	003628	-03305	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
004308	005094	004323	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
004193	005383	004085	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
004122	005478	002419	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
004129	005770	000816	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
004132	006267	-01159	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
004131	005639	-02181	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
003990	004669	-02791	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
004055	003862	-03151	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
004228	003225	-03303	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
005217	003104	005256	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
005100	003504	005148	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005260	003413	003291	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
005295	003681	005141	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
005124	004355	-00306	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
004922	004763	-02025	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
004587	003917	-02750	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$
004610	002995	-03098	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$
004773	002483	-03198	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$
006182	001200	006270	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
006126	001408	006190	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
006200	001475	004656	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
006268	001590	002601	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006146	002095	000856	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
005906	002900	-01114	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
005598	003927	-02377	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
005436	002206	-02823	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
005384	001493	-03113	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
007193	-00420	007400	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
007160	-00360	007311	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
007091	-00241	006521	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
007088	-00040	004611	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
006968	000337	002431	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
006733	001122	000344	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
006773	001458	-01546	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
006505	001038	-02404	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$
006297	000517	-02749	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
008184	-01864	008428	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
008100	-01835	008298	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
008032	-01701	008055	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
008032	-01706	008522	0750	0750	0375	0250	0250	0500	0000	%0543	G22	\$
007913	-01452	004035	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007722	-00959	002249	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$
007481	-00936	000129	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$
007952	-00234	-01619	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$
007517	-00716	-02187	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$
007988	-03299	007537	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$
008018	-03296	007512	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$
008044	-03277	006992	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$
008181	-03953	005709	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$
008256	-02820	004305	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$
008372	-02572	003237	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$
008539	-02208	002121	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$
008563	-01688	000186	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$
008413	-01256	-01480	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$
007400	-03995	006596	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$
007417	-03987	006337	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$
007558	-03802	005728	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$
007714	-03465	004304	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$
007985	-03033	003505	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$
008184	-02721	002898	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$
008336	-02452	002245	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$
008482	-02111	001328	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$
008386	-01672	-00519	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$
004356	005820	000460	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$
004287	005763	003408	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$
004240	005809	002454	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$
004239	006041	001385	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$
004260	006397	000296	0875	0000	0500	0125	1000	0375	0000	%0571	J23	\$
004261	006791	-01014	0875	0000	0625	0125	1000	0500	0000	%0572	J24	\$
004225	006744	-01492	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$
004237	006748	-01907	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$
004106	005134	-02534	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$
004472	005984	004497	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$
004334	005750	003195	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$
004321	005897	002260	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$
004313	006112	001178	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$
004322	006577	-00104	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$
004402	006877	-01126	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$
004222	006458	-01657	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$
004220	005722	-02119	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$
004273	004903	-02545	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$
004715	005824	004930	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$
004639	006122	004415	0875	0250	0125	0125	0750	0875				

009742	-00093	000196	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009089	-00873	-00249	0875	1000	1000	0125	0000	0000	0000	%0730	b02	\$
008504	-01441	-00494	0750	1000	1000	0250	0000	0000	0000	%0731	b03	\$
008080	-01889	-00783	0625	1000	1000	0375	0000	0000	0000	%0732	b04	\$
007367	-02369	-01321	0500	1000	1000	0500	0000	0000	0000	%0733	b05	\$
006786	-03011	-01218	0375	1000	1000	0625	0000	0000	0000	%0734	b06	\$
006166	-03576	-01592	0250	1000	1000	0750	0000	0000	0000	%0735	b07	\$
005845	-03857	-01820	0125	1000	1000	0875	0000	0000	0000	%0736	b08	\$
005596	-03936	-01967	0000	1000	1000	1000	0000	0000	0000	%0737	b09	\$
008962	000850	000395	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
008771	-00072	000216	0875	0875	0875	0125	0125	0125	0000	%0739	c02	\$
008654	-01443	000019	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
008062	-01969	-00311	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
007448	-02563	-00468	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
007038	-02967	-00540	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
006406	-03564	-00847	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005841	-04147	-01120	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
005598	-04121	-01452	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
008171	001791	000641	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
008028	000947	000415	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
007689	-00046	000123	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
007563	-01427	-00178	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
007362	-02317	-00180	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
006999	-02945	-00283	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
006404	-03740	-00524	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005754	-04438	-00871	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
005394	-04540	-01229	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007308	002775	001303	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007009	001966	000741	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
006961	001036	000284	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006519	-00034	000080	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
006533	-01444	-00292	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
006286	-02513	-00277	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
006118	-03696	-00432	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
005413	-05080	-00747	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
004953	-05052	-01199	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
006223	004366	001844	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006447	003352	001478	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006208	002035	000875	0750	0500	0500	0250	0500	0500	0000	%0767	f03	\$
005784	001079	000299	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005209	-00018	000058	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005270	-01549	-00405	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
005157	-02696	-00437	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004841	-05164	-00700	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
004733	-05253	-00741	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
005294	000562	002614	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
005378	005454	002339	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005217	003813	001503	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
004907	002394	000781	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
004513	001266	000191	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
003937	-00001	000016	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
003987	-01647	-00371	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
004044	-03758	-00501	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003995	-04517	-00552	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
004856	006583	003226	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
004609	006230	003043	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
004078	005518	002443	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
003908	004065	001697	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
003646	002527	000871	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
003266	001327	000255	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
002783	000013	000031	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
003156	-02081	-00494	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
002943	-02985	-00607	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
004758	006614	004147	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004208	005748	003359	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
003759	005181	002918	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
003413	004583	002431	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
003004	003994	001747	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
002597	002903	000970	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
002288	001436	000356	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
001822	000039	000107	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
002204	-01379	-00295	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
004765	006556	004442	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
004224	005672	004031	0875	0000	0000	0125	1000	1000	0000	%0802	j02	\$
003715	004983	003220	0750	0000	0000	0250	1000	1000	0000	%0803	j03	\$
003315	004324	002965	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
002843	003433	002276	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
002413	002564	001537	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
002137	002142	000717	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
001755	000269	000200	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
001726	000046	000101	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009734	-00085	000195	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
008809	-00397	-00847	0875	0875	0875	0125	0125	0000	0000	%0811	b11	\$
007587	-00802	-02102	0750	0750	0750	0250	0250	0000	0000	%0812	b12	\$
006570												

%BEG GE20_22.TXT, Separation olv*, D65, not adapted \$
%100 x LAB*
%#1000 x (r g b c m y 0) %nr. pos \$
%z004819 006432 004348 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z009350 -01836 009724 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z006027 -05966 004588 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005633 -04121 -01890 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z003865 -00485 -04471 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z004824 007201 -00968 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z001465 000032 000132 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009731 -00096 000220 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004765 006556 004442 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z009355 -01842 009551 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z006043 -05782 004467 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005596 -03936 -01967 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003832 -00500 -04462 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z004797 007224 -00918 %#1000 0000 1000 0000 0000 0000 0000 %0899 b27 %M2 5 \$
%z001430 000044 000102 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009736 -00088 000196 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

[illegible]

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart GE30; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

TUB registration: 20091101-GE30/GE30L0NP.PDF /.PS TUB material: code=rh4ta
application for evaluation and measurement of printer or monitor systems

See original or copy: <http://web.me.com/klaus.richter/GE30/GE30L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

[illegible]

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klau.s.richter/GE30/GE30L0NP.PDF> /.PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

002624	002401	001290	0375	0000	0000	00625	1000	1000	0000	%0243	A10 \$	003110	003383	002060	0500	0000	0000	0500	1000	1000	0000	%0324	J10 \$	003545	004180	002486	0625	0000	0000	0375	1000	1000	0000	%0405	S10 \$
002460	002782	000503	0375	0000	0125	0625	1000	0875	0000	%0244	A11 \$	003044	003545	001533	0500	0000	0125	0500	1000	0875	0000	%0325	J11 \$	003504	004353	002370	0625	0000	0125	0375	1000	0875	0000	%0406	S11 \$
002426	003138	-01196	0375	0000	0250	0625	1000	0750	0000	%0245	A12 \$	002899	004018	-00253	0500	0000	0250	0500	1000	0750	0000	%0326	J12 \$	003432	004569	000918	0625	0000	0250	0375	1000	0750	0000	%0407	S12 \$
002605	003359	-03009	0375	0000	0375	0625	1000	0625	0000	%0246	A13 \$	003026	004188	-01890	0500	0000	0375	0500	1000	0625	0000	%0327	J13 \$	003396	005000	-00866	0625	0000	0375	0375	1000	0625	0000	%0408	S13 \$
002947	003173	-04124	0375	0000	0500	0625	1000	0500	0000	%0247	A14 \$	003115	004241	-03159	0500	0000	0500	0500	1000	0500	0000	%0328	J14 \$	003444	004878	-02262	0625	0000	0500	0375	1000	0500	0000	%0409	S14 \$
003300	001779	-04469	0375	0000	0625	0625	1000	0375	0000	%0248	A15 \$	003266	003546	-03755	0500	0000	0625	0500	1000	0375	0000	%0329	J15 \$	003424	004738	-02993	0625	0000	0625	0375	1000	0375	0000	%0410	S15 \$
003468	000713	-04776	0375	0000	0750	0625	1000	0250	0000	%0249	A16 \$	003478	002441	-04152	0500	0000	0750	0500	1000	0250	0000	%0330	J16 \$	003549	003889	-03489	0625	0000	0750	0375	1000	0250	0000	%0411	S16 \$
003603	000250	-04767	0375	0000	0875	0625	1000	0125	0000	%0250	A17 \$	003610	001312	-04464	0500	0000	0875	0500	1000	0125	0000	%0331	J17 \$	003639	002899	-03839	0625	0000	0875	0375	1000	0125	0000	%0412	S17 \$
003726	-00018	-04870	0375	0000	1000	0625	1000	0000	0000	%0251	A18 \$	003616	000836	-04633	0500	0000	1000	0500	1000	0000	0000	%0332	J18 \$	003683	002141	-04114	0625	0000	1000	0375	1000	0000	0000	%0413	S18 \$
002766	002360	001511	0375	0125	0000	0625	0875	1000	0000	%0252	B10 \$	003240	003637	002371	0500	0125	0000	0500	0875	1000	0000	%0333	K10 \$	003722	004439	002950	0625	0125	0000	0375	0875	1000	0000	%0414	T10 \$
002834	002893	000839	0375	0125	0125	0625	0875	0875	0000	%0253	B11 \$	003255	003949	001547	0500	0125	0125	0500	0875	0875	0000	%0334	K11 \$	003655	004458	002122	0625	0125	0125	0375	0875	0875	0000	%0415	T11 \$
002822	003524	-01149	0375	0125	0250	0625	0875	0750	0000	%0254	B12 \$	003071	004240	-00172	0500	0125	0250	0500	0875	0750	0000	%0335	K12 \$	003571	004680	000834	0625	0125	0250	0375	0875	0750	0000	%0416	T12 \$
002988	003472	-02924	0375	0125	0375	0625	0875	0625	0000	%0255	B13 \$	003180	004395	-01847	0500	0125	0375	0500	0875	0625	0000	%0336	K13 \$	003566	005179	-00924	0625	0125	0375	0375	0875	0625	0000	%0417	T13 \$
003144	003070	-04022	0375	0125	0500	0625	0875	0500	0000	%0256	B14 \$	003263	004349	-03098	0500	0125	0500	0875	0500	0000	%0337	K14 \$	003674	005118	-02299	0625	0125	0500	0375	0875	0500	0000	%0418	T14 \$	
003468	001938	-04271	0375	0125	0625	0625	0875	0375	0000	%0257	B15 \$	003403	003512	-03661	0500	0125	0625	0500	0875	0375	0000	%0338	K15 \$	003634	004602	-02960	0625	0125	0625	0375	0875	0375	0000	%0419	T15 \$
003573	000956	-04590	0375	0125	0750	0625	0875	0250	0000	%0258	B16 \$	003573	002479	-03997	0500	0125	0750	0500	0875	0250	0000	%0339	K16 \$	003739	003742	-03419	0625	0125	0750	0375	0875	0250	0000	%0420	T16 \$
003633	000318	-04765	0375	0125	0875	0625	0875	0125	0000	%0259	B17 \$	003686	001663	-04270	0500	0125	0875	0500	0875	0125	0000	%0340	K17 \$	003813	002856	-03733	0625	0125	0875	0375	0875	0125	0000	%0421	T17 \$
003877	-00207	-04797	0375	0125	1000	0625	0875	0000	0000	%0260	B18 \$	003791	000775	-04528	0500	0125	1000	0500	0875	0000	0000	%0341	K18 \$	003822	002141	-04009	0625	0125	1000	0375	0875	0000	0000	%0422	T18 \$
003388	000903	002441	0375	0250	0000	0625	0750	1000	0000	%0261	C10 \$	003603	002240	-02805	0500	0250	0000	0500	0750	1000	0000	%0342	L10 \$	003987	003715	003272	0625	0250	0000	0375	0750	1000	0000	%0423	U10 \$
003622	000795	002361	0375	0250	0125	0625	0750	0875	0000	%0262	C11 \$	003836	002206	002802	0500	0250	0125	0500	0750	0875	0000	%0343	L11 \$	003989	004115	003326	0625	0250	0125	0375	0750	0875	0000	%0424	U11 \$
003487	001346	000131	0375	0250	0250	0625	0750	0750	0000	%0263	C12 \$	003812	002631	000702	0500	0250	0250	0500	0750	0750	0000	%0344	L12 \$	004015	004508	002509	0625	0250	0250	0375	0750	0875	0000	%0425	U12 \$
003634	001653	-01987	0375	0250	0375	0625	0750	0625	0000	%0264	C13 \$	003806	003503	-01306	0500	0250	0375	0500	0750	0625	0000	%0345	L13 \$	003944	004803	-03734	0625	0250	0375	0375	0750	0875	0000	%0426	U13 \$
003944	001761	-03597	0375	0250	0500	0625	0750	0500	0000	%0265	C14 \$	003709	003805	-013139	0500	0250	0500	0750	0500	0000	%0346	L14 \$	003911	005141	-02302	0625	0250	0500	0375	0750	0500	0000	%0427	U14 \$	
003866	001311	-04301	0375	0250	0625	0625	0750	0375	0000	%0266	C15 \$	003774	002928	-03692	0500	0250	0625	0500	0750	0375	0000	%0347	L15 \$	003982	004209	-03092	0625	0250	0500	0375	0750	0375	0000	%0428	U15 \$
003873	000444	-04614	0375	0250	0750	0625	0750	0250	0000	%0267	C16 \$	003852	001999	-04053	0500	0250	0750	0500	0750	0250	0000	%0348	L16 \$	003987	003272	-03476	0625	0250	0625	0375	0750	0375	0000	%0429	U16 \$
003885	-00048	-04753	0375	0250	0875	0625	0750	0125	0000	%0268	C17 \$	003978	001159	-04281	0500	0250	0875	0500	0750	0125	0000	%0349	L17 \$	004029	002413	-03734	0625	0250	0875	0375	0750	0125	0000	%0430	U17 \$
004069	-00454	-04796	0375	0250	1000	0625	0750	0000	0000	%0269	C18 \$	004114	000454	-04467	0500	0250	1000	0500	0750	0000	0000	%0350	L18 \$	004208	001622	-03945	0625	0250	1000	0375	0750	0000	0000	%0431	U18 \$
004499	-01208	003975	0375	0375	0000	0625	0625	1000	0000	%0270	D10 \$	004568	000355	-004085	0500	0375	0000	0500	0625	1000	0000	%0351	M10 \$	004850	001749	004280	0625	0375	0000	0375	0625	1000	0000	%0432	V10 \$
004540	-01169	003967	0375	0375	0125	0625	0625	0875	0000	%0271	D11 \$	004681	000407	004325	0500	0375	0125	0500	0625	0875	0000	%0352	M11 \$	004913	001964	004552	0625	0375	0125	0375	0625	0875	0000	%0433	V11 \$
004429	-00758	001730	0375	0375	0250	0625	0625	0750	0000	%0272	D12 \$	004786	000587	002171	0500	0375	0250	0500	0625	0750	0000	%0353	M12 \$	005071	00										

See original or copy: <http://web.me.com/klaustrichter/GE30/GE30L0NP.PDF> /.PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

003874	005104	003131	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
003832	005083	002669	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
003758	005181	001663	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
003717	005485	000310	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
003703	005879	-01185	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
003743	005749	-02236	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
003599	005405	-02696	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
003737	003446	-03232	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$
003896	003701	-03522	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$
004070	005327	003801	0750	0125	0000	0250	0875	1000	0000	%0495	B19	\$
003941	005124	002722	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
003883	005291	001592	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
003879	005695	000149	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
003897	005940	-01439	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
003851	005779	-02268	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
003742	005078	-02866	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
003866	004230	-03264	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
003985	003635	-03464	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
004308	005105	004161	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
004193	005393	003923	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
004122	005486	002259	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
004129	005779	000655	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
004132	006276	-01320	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
004131	005648	-02342	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
003990	004675	-02950	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
004055	003869	-03311	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
004228	003236	-03465	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
005217	003130	005083	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
005100	003528	004976	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005269	003439	003118	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
005295	003708	001368	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
005124	004380	-00477	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
004922	004784	-02195	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
004587	003932	-02916	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$
004610	003911	-03264	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$
004773	002502	-03365	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$
006182	001241	006087	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
006126	001448	006008	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
006200	001516	004473	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
006268	001632	002417	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006146	002136	000674	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
005906	002937	-01294	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
005598	003959	-02554	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
005436	002235	-02997	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
005384	001521	-03287	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
007193	-00364	007206	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
007160	-00303	007118	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
007091	-00186	006328	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
007088	000015	003969	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
006968	000391	002240	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
006733	001172	000156	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
006773	001508	-01735	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
006505	001084	-02590	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$
006297	000560	-02932	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
008184	-01792	008225	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
008100	-01764	008095	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
008032	-01711	007853	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
008015	-01637	005621	0750	0750	0375	0250	0250	0625	0000	%0543	G22	\$
007913	-01384	003834	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007722	-00894	002051	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$
007481	-008024	-00066	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$
007952	-00165	-01820	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$
007517	-00654	-02383	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$
007988	-03230	007336	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$
008018	-03226	007310	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$
008044	-03207	006790	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$
008181	-02980	005506	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$
008256	-02747	004101	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$
008372	-02497	003032	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$
008539	-02130	001913	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$
008563	-01610	-00021	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$
008413	-01180	-01686	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$
007400	-03935	006400	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$
007417	-03926	006141	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$
007558	-03739	005531	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$
007714	-03400	004105	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$
007985	-02964	003304	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$
008184	-02649	002695	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$
008336	-02377	002040	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$
008482	-02034	001121	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$
008386	-01596	-00725	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$
004356	005832	003897	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$
004287	005775	003245	0875	0000	0000	0125	1000	0875	0000	%0568	J20	\$
004240	005820	002292	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$
004239												

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klau.s.richter/GE30/GE30L0NP.PDF> /.PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

009742	-00004	000000	1000	1000	1000	0000	0000	0000	%0729	b01 \$	009734	000002	000000	1000	1000	1000	0000	0000	0000	%0810	b10 \$	009731	000001	000000	1000	1000	1000	0000	0000	0000	0000	%0809	b19 \$							
009089	-00795	-00438	0875	1000	1000	0125	0000	0000	0000	%0730	b02 \$	008809	-00324	-01032	0875	0875	1000	0125	0125	0000	0000	%0811	b11 \$	008585	001422	-00691	1000	0875	1000	0000	0125	0000	0000	%0820	b20 \$					
008504	-01372	-00677	0750	1000	1000	0250	0000	0000	0000	0000	%0731	b03 \$	007587	-00748	-02274	0750	0750	1000	0250	0250	0000	0000	%0812	b12 \$	007571	002661	-01096	1000	0750	1000	0000	0250	0000	0000	%0893	b21 \$				
008008	-01828	-00960	0625	1000	1000	0375	0000	0000	0000	0000	0000	%0732	b04 \$	006570	-00880	-03109	0625	0625	1000	0375	0375	0000	0000	%0813	b13 \$	006604	004018	-01330	1000	0625	1000	0000	0375	0000	0000	%0894	b22 \$			
007367	-02319	-01490	0500	1000	1000	0500	0000	0000	0000	0000	0000	0000	%0733	b05 \$	005407	-00913	-03990	0500	0500	1000	0500	0500	0000	0000	%0814	b14 \$	006009	005034	-01339	1000	0500	1000	0000	0500	0000	0000	%0895	b23 \$		
006786	-02969	-01381	0375	1000	1000	0625	0000	0000	0000	0000	0000	0000	%0734	b06 \$	004534	-00917	-04570	0375	0375	1000	0625	0625	0000	0000	%0815	b15 \$	005387	006114	-01317	1000	0375	1000	0000	0625	0000	0000	%0896	b24 \$		
006166	-03545	-01748	0250	1000	1000	0750	0000	0000	0000	0000	0000	0000	0000	%0735	b07 \$	004112	-00685	-04728	0250	0250	1000	0750	0750	0000	0000	%0816	b16 \$	005071	006844	-01098	1000	0250	1000	0000	0750	0000	0000	%0897	b25 \$	
005819	-03832	-01972	0125	1000	1000	0875	0000	0000	0000	0000	0000	0000	0000	%0736	b08 \$	003955	-00489	-04778	0125	0125	1000	0875	0875	0000	0000	%0817	b17 \$	004853	007195	-01027	1000	0125	1000	0000	0875	0000	0000	%0898	b26 \$	
005596	-03914	-02116	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	%0737	b09 \$	003832	-00507	-04592	0000	0000	1000	1000	1000	0000	0000	%0818	b18 \$	004797	007233	-01058	1000	0000	1000	0000	1000	0000	0000	%0899	b27 \$
008962	000926	000207	1000	0875	0875	0000	0125	0125	0000	0000	0000	0000	0000	0000	%0738	c01 \$	009655	-00678	-001907	1000	1000	0875	0000	0000	0125	0000	%0819	c10 \$	009115	-01166	000951	0875	1000	0875	0125	0000	0125	0000	%0900	c19 \$
008771	000001	000031	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	%0739	c02 \$	008905	000012	000003	0875	0875	0875	0125	0125	0125	0000	%0820	c11 \$	008881	000007	000020	0875	0875	0875	0125	0125	0125	0000	%0901	c20 \$
008654	-01372	-00164	0750	0875	0875	0250	0125	0125	0000	0000	0000	0000	0000	0000	%0740	c03 \$	008078	-00273	-01691	0750	0750	0875	0250	0250	0125	0000	%0821	c12 \$	008050	001275	-01188	0875	0750	0875	0125	0250	0125	0000	%0902	c21 \$
008062	-01908	-00488	0625	0875	0875	0375	0125	0125	0000	0000	0000	0000	0000	0000	%0741	c04 \$	006754	-00487	-02842	0625	0625	0875	0375	0375	0125	0000	%0822	c13 \$	006698	002534	-01762	0875	0625	0875	0125	0375	0125	0000	%0903	c22 \$
007448	-02511	-00639	0500	0875	0875	0500	0125	0125	0000	0000	0000	0000	0000	0000	%0742	c05 \$	005495	-00459	-03728	0500	0500	0875	0500	0500	0125	0000	%0823	c14 \$	005686	003663	-02132	0875	0500	0875	0125	0500	0125	0000	%0904	c23 \$
007038	-02922	-00706	0375	0875	0875	0625	0125	0125	0000	0000	0000	0000	0000	0000	%0743	c06 \$	004480	-00511	-04444	0375	0375	0875	0625	0625	0125	0000	%0824	c15 \$	004916	004533	-02286	0875	0375	0875	0125	0625	0125	0000	%0905	c24 \$
006406	-03529	-01006	0250	0875	0875	0750	0125	0125	0000	0000	0000	0000	0000	0000	%0744	c07 \$	004049	-00522	-04714	0250	0250	0875	0750	0750	0125	0000	%0825	c16 \$	004371	005354	-02261	0875	0250	0875	0125	0750	0125	0000	%0906	c25 \$
005841	-04121	-01272	0125	0875	0875	0875	0125	0125	0000	0000	0000	0000	0000	0000	%0745	c08 \$	003871	-00384	-04604	0125	0125	0875	0875	0875	0125	0000	%0826	c17 \$	004207	005746	-02105	0875	0125	0875	0125	0875	0125	0000	%0907	c26 \$
005598	-04098	-01601	0000	0875	0875	1000	0125	0125	0000	0000	0000	0000	0000	0000	%0746	c09 \$	003606	-00372	-04299	0000	0000	0875	1000	1000	0125	0000	%0827	c18 \$	004128	006073	-01947	0875	0800	0875	0125	1000	0125	0000	%0908	c27 \$
008171	001854	000463	1000	0750	0750	0000	0250	0250	0000	0000	0000	0000	0000	0000	%0747	d01 \$	005950	-01073	-03353	1000	1000	0750	0000	0000	0250	0000	%0828	d10 \$	003831	-02152	001581	0750	1000	0750	0250	0000	0250	0000	%0909	d19 \$
008028	001008	000238	0875	0750	0750	0125	0250	0250	0000	0000	0000	0000	0000	0000	%0748	d02 \$	008932	-00697	-001715	0875	0875	0750	0125	0125	0250	0000	%0829	d11 \$	008565	-01895	-001406	0750	0875	0750	0250	0125	0250	0000	%0910	d20 \$
007689	000009	-00049	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	%0749	d03 \$	007840	000004	-00029	0750	0750	0750	0250	0250	0000	0000	%0830	d12 \$	007689	-00052	-00052	0750	0750	0750	0250	0250	0000	0000	%0911	d21 \$
007563	-01374	-00349	0625	0750	0750	0375	0250	0250	0000	0000	0000	0000	0000	0000	%0750	d04 \$	006825	-00039	-01885	0625	0625	0875	0375	0375	0125	0000	%0831	d13 \$	006988	001384	-01711	0750	0125	0750	0250	0500	0250	0000	%0912	d22 \$
007362	-02267	-00350	0500	0750	0750	0500	0250	0250	0000	0000	0000	0000	0000	0000	%0751	d05 \$	005676	-00112	-03381	0500	0500	0750	0500	0500	0250	0000	%0832	d14 \$	005712	002908	-02306	0750	0500	0500	0250	0500	0250	0000	%0913	d23 \$
006999	-02900	-00449	0375	0750	0750	0625	0250	0250	0000	0000	0000	0000	0000	0000	%0752	d06 \$	004555	-00339	-04318	0375	0375	0750	0625	0625	0250	0000	%0833	d15 \$	004685	003830	-02773	0750	0375	0750	0250	0625	0250	0000	%0914	d24 \$
006404	-03705	-00682	0250	0750	0750	0750	0250	0250	0000	0000	0000	0000	0000	0000	%0753	d07 \$	004004	-00427	-04711	0250	0250	0750	0750	0750	0250	0000	%0834	d16 \$	004027	004603	-02870	0750	0250	0750	0250	0500	0250	0000	%0915	d25 \$
005754	-04413	-01023	0125	0750	0750	0875	0250	0250	0000	0000	0000	0000	0000	0000	%0754	d08 \$	003684	-00317	-04476	0125	0125	0750	0875	0875	0250	0000	%0835	d17 \$	003740	005059	-02741	0750	0125	0750	0250	0875	0250	0000	%0916	d26 \$
005394	-04522	-01376	0000	0750	0750	1000	0250	0250	0000	0000	0000	0000	0000	0000	%0755	d09 \$	003378	-00378	-04040	0000	0000	0750	1000	1000	0250	0000	%0836	d18 \$	003591	005276	-02587	0750	0000	0750	0250	1000	0250	0000	%0	

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

%BEG GE20_22.TXT, Separation olv*, D65, adapted \$
%100 x LAB*a %1000 x (r g b c m y 0) %nr. pos \$
%z004819 006451 004180 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z009350 -01745 009508 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z006027 -05928 004407 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005633 -04089 -02066 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z003865 -00481 -04629 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z004824 007220 -01136 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z001465 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009731 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004765 006565 004302 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z009355 -01760 009359 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z006043 -05753 004313 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005596 -03914 -02116 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003832 -00507 -04592 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z004797 007233 -01058 %#1000 0000 1000 0000 0000 0000 0000 %0899 b27 %M2 5 \$
%z001430 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009736 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

TUB-test chart GE30; Relative Device Colour System G
1080 spectral reflexions R -> LAB* for D65 and D50

input: w *setgray*
output: -> *olv** *setrgbcolor*

TUB registration: 20091101-GE30/GE30L0NP.PDF /.PS
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/GE30/GE30L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

See original or copy: <http://web.me.com/klaus.richter/GE30/GE30L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG GE20_22.TXT, Separation olv*, D65 adapted \$		%100 x LAB*a		1000 x (r g b c m y 0)		%nr. pos \$																					
001351	-00005	000032	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$	008605	000024	-00015	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$		
001671	-00006	000013	0125	0125	0125	0875	0875	0875	0875	0000	%0973	k02	\$	009171	000019	-00001	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$	
002609	-00009	-00070	0250	0250	0250	0750	0750	0750	0750	0000	%0974	k03	\$	009720	000004	000000	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$	
003827	-00003	-00106	0375	0375	0375	0625	0625	0625	0625	0000	%0975	k04	\$	001626	000011	000003	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$	
005259	000001	-00108	0500	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$	001368	000009	000015	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$	
006576	000006	-00092	0625	0625	0625	0625	0625	0625	0625	0000	%0977	k06	\$	001804	000013	-00014	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$	
007716	000016	-00053	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$	002395	000008	-00066	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$		
008441	000017	-00012	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$	002903	000005	-00094	0266	0266	0266	0333	0333	0333	0000	%1060	n14	\$		
009741	000018	-00020	1000	1000	1000	1000	0000	0000	0000	%0980	k09	\$	003565	000008	-00098	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$		
001399	000000	000022	0000	0000	0000	1000	1000	1000	1000	0000	%0981	l01	\$	004210	000010	-00099	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$	
001752	000003	000029	0125	0125	0125	0875	0875	0875	0875	0000	%0982	l02	\$	004816	000015	-00074	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$	
002607	-00003	-00066	0250	0250	0250	0750	0750	0750	0750	0000	%0983	l03	\$	005567	000011	-00074	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$	
003833	000000	-00116	0375	0375	0375	0625	0625	0625	0625	0000	%0984	l04	\$	006378	000013	-00077	0600	0600	0600	0400	0400	0400	0000	%1065	n19	\$	
005243	000006	-00122	0500	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$	006975	000014	-00063	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$	
006590	000011	-00108	0625	0625	0625	0375	0375	0375	0375	0000	%0986	l06	\$	007523	000022	-00048	0734	0734	0734	0266	0266	0266	0000	%1067	n21	\$	
007742	000017	-00057	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$	008083	000025	-00016	0800	0800	0800	0200	0200	0200	0000	%1068	n22	\$		
008855	000019	-00016	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$	008614	000025	-00005	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$		
009739	000005	-00014	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$	009178	000021	-00004	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$		
001311	000000	000036	0000	0000	0000	1000	1000	1000	1000	0000	%0990	m01	\$	009705	000011	-00012	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$	
001679	000006	000022	0125	0125	0125	0875	0875	0875	0875	0000	%0991	m02	\$	001395	000000	000000	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$	
002581	-00001	-00062	0250	0250	0250	0750	0750	0750	0750	0000	%0992	m03	\$	009741	000000	000000	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$	
003777	000001	-00101	0375	0375	0375	0625	0625	0625	0625	0000	%0993	m04	\$	004759	000570	004377	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$	
005171	000006	-00110	0500	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$	005884	-04506	-01390	0000	1000	1000	0000	0000	0000	0000	%1075	l27	\$	
006588	000015	-00103	0625	0625	0625	0375	0375	0375	0375	0000	%0995	m06	\$	009349	-01754	009690	1000	1000	0000	0000	1000	1000	0000	%1076	m26	\$	
007697	000021	-00058	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$	003844	-00332	-04586	0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$		
008840	000014	000003	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$	006056	-05954	004520	0000	1000	0000	1000	0000	1000	0000	%1078	n26	\$		
009733	000005	-00010	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$	004786	007290	-01162	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$		
001293	000001	000048	0000	0000	0000	1000	1000	1000	1000	0000	%0999	n01	\$														
001672	-00001	000037	0125	0125	0125	0875	0875	0875	0875	0000	%1000	n02	\$														
002544	-00003	-00055	0250	0250	0250	0750	0750	0750	0750	0000	%1001	n03	\$														
003762	000000	-00086	0375	0375	0375	0625	0625	0625	0625	0000	%1002	n04	\$														
005183	000006	-00103	0500	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$														
006533	000015	-00092	0625	0625	0625	0375	0375	0375	0375	0000	%1004	n06	\$														
007715	000020	-00050	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$															
008848	000022	-00009	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$															
009728	000011	-00018	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$															
001804	000009	-00019	0000	0000	0000	1000	1000	1000	1000	0000	%1008	k10	\$														
001547	000013	-00003	0066	0066	0066	0933	0933	0933	0933	0000	%1009	k11	\$														
001925	000007	-00049	0133	0133	0133	0866	0866	0866	0866	0000	%1010	k12	\$														
002459	000006	-00089	0200	0200	0200	0800	0800	0800	0800	0000	%1011	k13	\$														
002976	000006	-00114	0266	0266	0266	0333	0333	0333	0333	0000	%1012	k14	\$														
003619	000006	-00120	0333	0333	0333	0666	0666	0666	0666	0000	%1013	k15	\$														
004231	000008	-00105	0400	0400	0400	0600	0600	0600	0600	0000	%1014	k16	\$														
004882	000013	-00097	0466	0466	0466	0533	0533	0533	0533	0000	%1015	k17	\$														
005634	000013	-00089	0533	0533	0533	0466	0466	0466	0466	0000	%1016	k18	\$														
006421	000014	-00100	0600	0600	0600	0400	0400	0400	0400	0000	%1017	k19	\$														
007054	000013	-00079	0666	0666	0666	0333	0333	0333	0333	0000	%1018	k20	\$														
007609	000014	-00042	0734	0734	0734	0266	0266	0266	0266	0000	%1019	k21	\$														
008163	000018	-00020	0800	0800	0800	0200	0200	0200	0200	0000	%1020	k22	\$														
008665	000015	000006	0866	0866	0866	0133	0133	0133	0133	0000	%1021	k23	\$														
009209	000011	000006	0933	0933	0933	0066	0066	0066	0066	0000	%1022	k24	\$														
009726	000006	-00011	1000	1000	1000	0000	0000	0000	0000	%1023	k25	\$															
001837	000011	-00016	0000	0000	0000	1000	1000	1000	1000	0000	%1024	l10	\$														
001601	000010	000007	0066	0066	0066	0933	0933	0933	0933	0000	%1025	l11	\$														
001981	000011	-00031	0133	0133	0133	0866	0866	0866	0866	0000	%1026	l12	\$														
002496	000002	-00086	0200	0200	0200	0800	0800	0800	0800	0000	%1027	l13	\$														
003011	000003	-00108	0266	0266	0266	0333	0333	0333	0333	0000	%1028	l14	\$														
003625	000007	-00118	0333	0333	0333	0666	0666	0666	0666	0000	%1029	l15	\$														
004253	000010	-00115	0400	0400	0400	0600	0600	0600	0600	0000	%1030	l16	\$														
004911	000019	-00111	0466	0466	0466	0533	0533	0533	0533	0000	%1031	l17	\$														
005620	000018	-00113	0533	0533	0533	0466	0466	0466	0466	0000	%1032	l18	\$														
006437	000016	-00112	0600	0600	0600	0400	0400	0400	0400	0000	%1033	l19	\$														
007042	000019	-00094	0666	0666	0666	0333	0333	0333	0333	0000	%1034	l20	\$														
007577	000021	-00068	0734	0734	0734	0266	0266	0266	0266	0000	%1035	l21	\$														
008109	000026	-00038	0800	0800	0800	0200	0200	0200	0200	0000	%1036	l22	\$														
008653	000025	-00020	0866	0866	0866	0133	0133	0133	0133	0000	%1037	l23	\$														
009199	000014	-00004	0933	0933	0933	0066	0066	0066	0066	0000	%1038	l24	\$														
009713	000011	-00023	1000	1000	1000	0000	0000	0000	0000	0000	%1039	l25	\$														
001754	000010	-00003	0800	0800	0800	1000	1000	1000	1000	0000	%1040	m10	\$														
001392	00																										

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

%BEG	GE20.22.TXT	Separation	olv*	D50	not	adapted	\$	%LAB*	1000 x (r g b c m y θ)	%nrr.	pos	\$	%BEG	GE20.22.TXT	Separation	olv*	D50	not	adapted	\$	%LAB*	1000 x (r g b c m y θ)	%nrr.	pos	\$		
000168	000051	000036	0000	0000	0000	0000	0000	000000	A01	%	001	\$	002010	002125	000873	0250	0000	0000	0000	0000	0000	0000	0000	0000	%0162	S01	\$
001632	-00065	000048	0000	0000	0125	1000	1000	0000	0000	0000	0000	0000	001769	001760	-000176	0250	0000	0125	0750	1000	0000	0000	0000	0000	%0163	S02	\$
002143	-00391	-00908	0000	0000	0250	1000	1000	0000	0000	0000	0000	0000	002218	002161	-02315	0250	0000	0250	0750	1000	0000	0000	0000	0000	%0164	S03	\$
002200	-00417	-02602	0000	0000	0375	1000	1000	0000	0000	0000	0000	0000	002571	001872	-04356	0250	0000	0375	0750	1000	0000	0000	0000	0000	%0165	S04	\$
002681	-00583	-03407	0000	0000	0500	1000	1000	0000	0000	0000	0000	0000	003050	009387	-04760	0250	0000	0500	0750	1000	0000	0000	0000	0000	%0166	S05	\$
003034	-00884	-03813	0000	0000	0625	1000	1000	0000	0000	0000	0000	0000	003222	-00447	-04379	0250	0000	0625	0750	1000	0000	0000	0000	0000	%0167	S06	\$
003304	-01037	-04182	0000	0000	0750	1000	1000	0000	0000	0000	0000	0000	003364	-00469	-04631	0250	0000	0750	0750	1000	0000	0000	0000	0000	%0168	S07	\$
003492	-01151	-04510	0000	0000	0875	1000	1000	0000	0000	0000	0000	0000	003567	-00744	-04836	0250	0000	0875	0750	1000	0000	0000	0000	0000	%0169	S08	\$
003735	-01212	-04714	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	003766	-00995	-04822	0250	0000	1000	0750	1000	0000	0000	0000	0000	%0170	S09	\$
005258	-02594	001141	0000	0125	0000	0000	0000	0000	0000	0000	0000	0000	002077	001265	001275	0250	0125	0000	0750	0875	1000	0000	0000	0000	%0171	T01	\$
001964	-01460	-00341	0000	0125	0125	1000	0000	0000	0000	0000	0000	0000	002249	001433	000478	0250	0125	0125	0750	0875	0875	0000	0000	0000	%0172	T02	\$
002447	-00995	-02521	0000	0125	0250	1000	0000	0000	0000	0000	0000	0000	002532	001750	-01875	0250	0125	0250	0750	0875	0750	0000	0000	0000	%0173	T03	\$
002777	-00711	-03416	0000	0125	0375	1000	0000	0000	0000	0000	0000	0000	003167	001362	-03706	0250	0125	0375	0750	0875	0625	0000	0000	0000	%0174	T04	\$
003066	-00849	-03774	0000	0125	0500	1000	0000	0000	0000	0000	0000	0000	003311	000535	-04524	0250	0125	0500	0750	0875	0500	0000	0000	0000	%0175	T05	\$
003294	-00969	-04121	0000	0125	0625	1000	0000	0000	0000	0000	0000	0000	003445	-00181	-04706	0250	0125	0625	0750	0875	0375	0000	0000	0000	%0176	T06	\$
003522	-01135	-04367	0000	0125	0750	1000	0000	0000	0000	0000	0000	0000	003609	-00661	-04753	0250	0125	0750	0750	0875	0250	0000	0000	0000	%0177	T07	\$
003668	-01153	-04669	0000	0125	0875	1000	0000	0000	0000	0000	0000	0000	003750	-00953	-04827	0250	0125	0875	0750	0875	0125	0000	0000	0000	%0178	T08	\$
003852	-01180	-04834	0000	0125	1000	1000	0000	0000	0000	0000	0000	0000	003854	-01022	-04776	0250	0125	1000	0750	0875	0000	0000	0000	0000	%0179	T09	\$
003408	-03973	002060	0000	0250	0000	0000	0000	0000	0000	0000	0000	0000	002978	-00605	002453	0250	0250	0000	0750	0750	1000	0000	0000	0000	%0180	U01	\$
003350	-04465	001809	0000	0250	0125	1000	0000	0000	0000	0000	0000	0000	003079	-00460	002071	0250	0250	0125	0750	0750	0875	0000	0000	0000	%0181	U02	\$
002824	-03133	-00723	0000	0250	0250	1000	0000	0000	0000	0000	0000	0000	002735	000017	000064	0250	0250	0250	0750	0750	0750	0000	0000	0000	%0182	U03	\$
003236	-01892	-03445	0000	0250	0375	1000	0000	0000	0000	0000	0000	0000	003419	-00344	-02331	0250	0250	0375	0750	0750	0625	0000	0000	0000	%0183	U04	\$
003426	-01235	-04216	0000	0250	0500	1000	0000	0000	0000	0000	0000	0000	003797	-00561	-03875	0250	0250	0500	0750	0750	0500	0000	0000	0000	%0184	U05	\$
003641	-01248	-04456	0000	0250	0625	1000	0000	0000	0000	0000	0000	0000	003755	-00854	-04714	0250	0250	0625	0750	0750	0375	0000	0000	0000	%0185	U06	\$
003816	-01357	-04737	0000	0250	0750	1000	0000	0000	0000	0000	0000	0000	003858	-01122	-04825	0250	0250	0750	0750	0750	0250	0000	0000	0000	%0186	U07	\$
003987	-01304	-04917	0000	0250	0875	1000	0000	0000	0000	0000	0000	0000	003868	-01282	-04897	0250	0250	0875	0750	0750	0125	0000	0000	0000	%0187	U08	\$
003978	-01409	-04876	0000	0250	1000	1000	0000	0000	0000	0000	0000	0000	003974	-01306	-04825	0250	0250	1000	0750	0750	0000	0000	0000	0000	%0188	U09	\$
004295	-04625	002847	0000	0375	0000	0000	0000	0000	0000	0000	0000	0000	004244	-03317	003105	0250	0375	0000	0750	0625	1000	0000	0000	0000	%0189	V01	\$
004228	-04924	002657	0000	0375	0125	1000	0000	0000	0000	0000	0000	0000	004293	-02972	003021	0250	0375	0125	0750	0625	0875	0000	0000	0000	%0190	V02	\$
004123	-06313	002138	0000	0375	0250	1000	0000	0000	0000	0000	0000	0000	004306	-02179	001424	0250	0375	0250	0750	0625	0750	0000	0000	0000	%0191	V03	\$
003918	-04850	-00828	0000	0375	0375	1000	0000	0000	0000	0000	0000	0000	003900	-01649	-00433	0250	0375	0375	0750	0625	0625	0000	0000	0000	%0192	V04	\$
004101	-02987	-03907	0000	0375	0500	1000	0000	0000	0000	0000	0000	0000	004310	-01371	-02511	0250	0375	0500	0750	0625	0500	0000	0000	0000	%0193	V05	\$
004159	-02085	-04775	0000	0375	0625	1000	0000	0000	0000	0000	0000	0000	004308	-01576	-04043	0250	0375	0625	0750	0625	0375	0000	0000	0000	%0194	V06	\$
004123	-01703	-04925	0000	0375	0750	1000	0000	0000	0000	0000	0000	0000	004253	-01662	-04793	0250	0375	0750	0750	0625	0250	0000	0000	0000	%0195	V07	\$
004106	-01784	-04962	0000	0375	0875	1000	0000	0000	0000	0000	0000	0000	004190	-01716	-04861	0250	0375	0875	0750	0625	0125	0000	0000	0000	%0196	V08	\$
004162	-01855	-04923	0000	0375	1000	1000	0000	0000	0000	0000	0000	0000	004264	-01791	-04846	0250	0375	1000	0750	0625	0000	0000	0000	0000	%0197	V09	\$
004880	-04979	003227	0000	0500	0000	0000	0000	0000	0000	0000	0000	0000	005004	-04516	003526	0250	0500	0000	0750	0500	1000	0000	0000	0000	%0198	W01	\$
004850	-05110	003185	0000	0500	0125	1000	0000	0000	0000	0000	0000	0000	005063	-04391	003590	0250	0500	0125	0750	0500	0875	0000	0000	0000	%0199	W02	\$
004790	-05734	002944	0000	0500	0250	1000	0000	0000	0000	0000	0000	0000	005156	-04139	003027	0250	0500	0250	0750	0500	0750	0000	0000	0000	%0200	W03	\$
004642	-07309	002141	0000	0500	0375	1000	0000	0000	0000	0000	0000	0000	005231	-03231	001266	0250	0500	0375	0750	0500	0625	0000	0000	0000	%0201	W04	\$
004711	-05846	-01037	0000	0500	0500	1000	0000	0000	0000	0000	0000	0000	005055	-02668	-00624	0250	0500	0500	0750	0500	0500	0000	0000	0000	%0202	W05	\$
004795	-04055	-03825	0000	0500	0625	1000	0000	0000	0000	0000	0000	0000	004978	-02238	-02660	0250	0500	0625	0750	0500	0375	0000	0000	0000	%0203	W06	\$
004556	-02633	-04964	0000	0500	0750	1000	0000	0000	0000	0000	0000	0000	004821	-02125	-04129	0250	0500	0750	0750	0500	0250	0000	0000	0000	%0204	W07	\$
004406	-02320	-04970	0000	0500	0875	1000	0000	0000	0000	0000	0000	0000	004697	-02138	-04681	0250	0500	0875	0750	0500	0125	0000	0000	0000	%0205	W08	\$
004392	-02290	-04955	0000	0500	1000	1000	0000	0000	0000	0000	0000	0000	004869	-02316	-04652	0250	0500	1000	0750	0500	0000	0000	0000	0000	%0206	W09	\$
005295	-05165	003581	0000	0625	0000	0000	0000	0000	0000	0000	0000	0000	005397	-04944	003770	0250	0625	0000	0750	0375	1000	0000	0000	0000	%0207	X01	\$
005259	-05335	003492	0000	0625																							

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-GE30/GE30L0NP.PDF /.PS
 application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

002696	002629	001541	0375	0000	0000	0625	1000	1000	0000	%0243	A10	\$
002535	002942	000786	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$
002485	003130	-00908	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$
002685	003128	-02778	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$
002927	002760	-03963	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$
003229	001239	-04416	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$
003358	000020	-04806	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$
003484	-04073	-04822	0375	0000	0875	0625	1000	0125	0000	%0250	A17	\$
003598	-00705	-04845	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$
002838	002606	001759	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$
002914	003088	001127	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$
002891	003529	-00836	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$
003014	003270	-02681	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$
003125	002684	-03861	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$
003410	001459	-04191	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$
003479	000338	-04588	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$
003516	-00396	-04814	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$
003749	-00961	-04874	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$
003434	001197	-02616	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$
003665	001086	-002533	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$
003520	001453	000347	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$
003635	001536	-01808	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$
003905	001421	-03484	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$
003792	000804	-04253	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$
003767	-00208	-04637	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$
003761	-00776	-04817	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$
003937	-01219	-04882	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$
004515	-00868	-04040	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$
004557	-00828	-04031	0375	0375	0125	0625	0625	0875	0000	%0271	D11	\$
004427	-00563	-001852	0375	0375	0250	0625	0625	0750	0000	%0272	D12	\$
004023	000001	000006	0375	0375	0375	0625	0625	0625	0000	%0273	D13	\$
004565	-00308	-02124	0375	0375	0500	0625	0625	0500	0000	%0274	D14	\$
004625	-00404	-03508	0375	0375	0625	0625	0625	0375	0000	%0275	D15	\$
004471	-00990	-04475	0375	0375	0750	0625	0625	0250	0000	%0276	D16	\$
004349	-01244	-04629	0375	0375	0875	0625	0625	0125	0000	%0277	D17	\$
004391	-01651	-04754	0375	0375	1000	0625	0625	0000	0000	%0278	D18	\$
005337	-03162	-04087	0375	0500	0000	0625	0500	1000	0000	%0279	D19	\$
005452	-03181	-04285	0375	0500	0125	0625	0500	0875	0000	%0280	E11	\$
005490	-02897	-003271	0375	0500	0250	0625	0500	0750	0000	%0281	E12	\$
005422	-02183	-001309	0375	0500	0375	0625	0500	0625	0000	%0282	E13	\$
005263	-01646	-00591	0375	0500	0500	0625	0500	0500	0000	%0283	E14	\$
005274	-01421	-02299	0375	0500	0625	0625	0500	0375	0000	%0284	E15	\$
005259	-01537	-03750	0375	0500	0750	0625	0500	0250	0000	%0285	E16	\$
005113	-01763	-04293	0375	0500	0875	0625	0500	0125	0000	%0286	E17	\$
005109	-01930	-04371	0375	0500	1000	0625	0500	0000	0000	%0287	E18	\$
005763	-04255	-004140	0375	0625	0000	0625	0375	1000	0000	%0288	F10	\$
005994	-04354	-004434	0375	0625	0125	0625	0375	0875	0000	%0289	F11	\$
006164	-04637	-004261	0375	0625	0250	0625	0375	0750	0000	%0290	F12	\$
006302	-03847	-002730	0375	0625	0375	0625	0375	0625	0000	%0291	F13	\$
006361	-03060	-001136	0375	0625	0500	0625	0375	0500	0000	%0292	F14	\$
006242	-02626	-00466	0375	0625	0625	0625	0375	0375	0000	%0293	F15	\$
005955	-02121	-02610	0375	0625	0750	0625	0375	0250	0000	%0294	F16	\$
006054	-02271	-03822	0375	0625	0875	0625	0375	0125	0000	%0295	F17	\$
006085	-02259	-03841	0375	0625	1000	0625	0375	0000	0000	%0296	F18	\$
005960	-04868	-004142	0375	0750	0000	0625	0250	1000	0000	%0297	G10	\$
006189	-04899	-004374	0375	0750	0125	0625	0250	0875	0000	%0298	G11	\$
006328	-04804	-004038	0375	0750	0250	0625	0250	0750	0000	%0299	G12	\$
006325	-04366	-003243	0375	0750	0375	0625	0250	0500	0000	%0300	G13	\$
006816	-03872	-002228	0375	0750	0500	0625	0250	0500	0000	%0301	G14	\$
007039	-03405	-001047	0375	0750	0625	0250	0250	0375	0000	%0302	G15	\$
006888	-03196	-00457	0375	0750	0750	0625	0250	0250	0000	%0303	G16	\$
006700	-02937	-02458	0375	0750	0875	0625	0250	0125	0000	%0304	G17	\$
006687	-02603	-03431	0375	0750	1000	0625	0250	0000	0000	%0305	G18	\$
006078	-05063	-004236	0375	0875	0000	0625	0125	1000	0000	%0306	H10	\$
006101	-05109	-004253	0375	0875	0125	0625	0125	0875	0000	%0307	H11	\$
006269	-04854	-003845	0375	0875	0250	0625	0125	0750	0000	%0308	H12	\$
006419	-04513	-003254	0375	0875	0375	0625	0125	0625	0000	%0309	H13	\$
006680	-04071	-002579	0375	0875	0500	0625	0125	0500	0000	%0310	H14	\$
006889	-03714	-001870	0375	0875	0625	0625	0125	0375	0000	%0311	H15	\$
006976	-03438	-000704	0375	0875	0750	0625	0125	0250	0000	%0312	H16	\$
006865	-03235	-00769	0375	0875	0875	0625	0125	0125	0000	%0313	H17	\$
006678	-02936	-02611	0375	0875	1000	0625	0125	0000	0000	%0314	H18	\$
006059	-05038	-004162	0375	1000	0000	0625	0000	1000	0000	%0315	I10	\$
006163	-04995	-004281	0375	1000	0125	0625	0000	0875	0000	%0316	I11	\$
006347	-04728	-003875	0375	1000	0250	0625	0000	0750	0000	%0317	I12	\$
006559	-04331	-003281	0375	1000	0375	0625	0000	0625	0000	%0318	I13	\$
006682	-04127	-002804	0375	1000	0500	0625	0000	0500	0000	%0319	I14	\$
006742	-03923	-002180	0375	1000	0625	0000	0000	0375	0000	%0320	I15	\$
006881	-03685	-001549	0375	1000	0750	0625	0000	0250	0000	%0321	I16	\$
006841	-03458	-000038	0375	1000	0875	0625	0000	0125	0000	%0322	I17	\$
006676	-03359	-01316	0375	1000	1000	0625	0000	0000	0000	%0323	I18	\$
003214	003656	002359	0500	0000	0000	0500	1000	1000	0000	%0324	J10	\$
003148	003785	001852	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$
002997	004107	-00105	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$
003098	004121	-01558	0500	0000	0375	0500	1000	0625	0000	%0327	J13	\$
003158	004022	-02876	0500	0000	0500	0500	1000	0500	0000	%0328	J14	\$
003270	003232	-03547	0500	0000	0625	0500	1000	0375	0000	%0329	J15	\$
003437	003020	-04035	0500	0000	0750	0500	1000	0250	0000	%0330	J16	\$
003529	003055	-04331	0500	0000	1000	0500	1000	0125	0000	%0331	J17	\$
003517	000290	-04574	0500	0000	1000	0500	1000	0000	0000	%0332	J18	\$
003353	003924	-02683	0500	0125	0000	0500	0875	1000	0000	%0333	K10	\$
003370	004188	-001892	0500	0125	0125	0500	0875	0075	0000	%0334	K11	\$
003176	004337	-002001	0500	0125	0250	0500	0875	0750	0000	%0335	K12	\$
003260	004336	-01501	0500	0125	0375	0500	0875	0625	0000	%0336	K13	\$
003310	004143	-02803	0500	0125	0500	0500	0875	0500	0000	%0337	K14	\$
003409	003217	-03450	0500	0125	0625	0500	0875	0375	0000	%0338	K15	\$
003540	002092	-03866	0500	0125	0750	0500	0875	0250	0000	%0339	K16	\$
003622	001179	-04203	0500	0125	0875	0500	0875	0125	0000	%0340	K17	\$
003696	000168	-04528	0500	0125	1000	0500	0875	0000	0000	%0341	K18	\$
003682	002569	-003937	0500	0250	0000	0500	0750	1000	0000	%0342	L10	\$
003915	002											

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

004032	005413	003521	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
003986	005373	003069	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
003907	005415	002085	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
003862	005619	000762	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
003838	005874	-00720	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
003853	005656	-01814	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
003689	005263	-02314	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
003784	005423	-02935	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$
003911	005448	-03287	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$
004237	005660	004192	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$
004097	005420	003125	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
004034	005523	002023	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
004028	005817	000614	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
004028	005920	-00968	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
003961	005686	-01845	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
003817	004924	-02514	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
003904	004023	-02985	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
004000	003391	-03230	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
004471	005467	004527	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
004363	005735	004314	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
004285	005760	002693	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
004284	005947	001123	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
004275	006266	-00834	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
004233	005558	-01933	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
004049	004517	-02629	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
004081	003653	-03055	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
004233	002982	-03253	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
005332	003588	005318	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
005225	003977	005234	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005372	003824	003424	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
005398	003977	001712	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
005224	004476	-00097	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
004090	004719	-01833	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
004625	003776	-02636	0750	0375	0875	0250	0625	0250	0000	%0519	D25	\$
004615	002783	-03052	0750	0375	1000	0250	0625	0125	0000	%0520	D26	\$
004761	002240	-03185	0750	0375	0875	0250	0625	0000	0000	%0521	D27	\$
006262	001748	006217	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
006210	001955	006149	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
006278	001972	004669	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
006332	001960	006269	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006202	002312	000948	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
005951	002915	-01000	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
005621	002920	-02301	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
005428	002013	-02809	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
005351	001226	-03151	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
007249	000167	007248	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
007217	000225	007166	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
007146	000325	006408	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
007133	000411	004126	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
007004	000661	004234	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
006761	001240	000389	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
006776	001386	-01523	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
006480	000851	-02434	0750	0625	1000	0250	0375	0125	0000	%0538	F26	\$
006252	000256	-02820	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
008221	-01244	008192	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
008137	-01222	008067	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
008069	-01175	007834	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
008041	-01183	007804	0750	0750	0375	0250	0250	0500	0000	%0543	G22	\$
007930	-01039	003941	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007730	-00699	002196	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$
007483	-00917	000127	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$
007917	-00388	-01685	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$
007459	-00967	-02297	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$
007992	-02666	007234	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$
008022	-02663	007212	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$
008045	-02658	006709	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$
008179	-02493	005484	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$
008247	-02350	004120	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$
008357	-02188	003078	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$
008520	-01932	001986	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$
008528	-01641	000073	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$
008359	-01444	-01592	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$
007384	-03392	006271	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$
007399	-03391	006021	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$
007540	-03232	005442	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$
007691	-02984	004075	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$
007963	-02619	003315	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$
008163	-02363	002730	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$
008313	-02159	002094	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$
008454	-01921	001197	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$
008340	-01718	-00641	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$
004538	006170	003481	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$
004464	006080	003619	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$
004412	006090	002749	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$
004408	006255	001706	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$
004428	006524	000644	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$
004422	006797	-00652	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$
004376	006713	-01146	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$
004240	006831	-01717	0875	0000	1000	0125	1000	0125	0000	%0574	J26	\$
004274	005019	-02333	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$
004661	006350	004756	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$
004509	006072	003473	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$
004464	006169	002563	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$
004482	006315	001506	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$
004489	006670	000254	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$
004563	006882	-00763	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$
004361	006420	-01336	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$
004326	005651	-01864	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$
004344	004789	-02359	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$
004901	006223	005164	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$
004831	006495	004683	0875	0250	0125	0125	0750					

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009743	-00064	000189	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009905	-00891	-00314	0875	1000	1000	0000	0000	0000	0000	%0730	b02	\$
008464	-01481	-00602	0750	1000	1000	0000	0000	0000	0000	%0731	b03	\$
009952	-01963	-00927	0625	1000	1000	0000	0000	0000	0000	%0732	b04	\$
007291	-02519	-01509	0500	1000	1000	0000	0000	0000	0000	%0733	b05	\$
006697	-03144	-01444	0375	1000	1000	0000	0000	0000	0000	%0734	b06	\$
006858	-03785	-01862	0250	1000	1000	0000	0000	0000	0000	%0735	b07	\$
005701	-04121	-02113	0125	1000	1000	0000	0000	0000	0000	%0736	b08	\$
005472	-04232	-02271	0000	1000	1000	0000	0000	0000	0000	%0737	b09	\$
008985	-00695	-00425	1000	0875	0875	0000	0000	0000	0000	%0738	c01	\$
008773	-00641	-00211	0875	0875	0875	0000	0000	0000	0000	%0739	c02	\$
008621	-01417	-00801	0750	0875	0875	0000	0000	0000	0000	%0740	c03	\$
008012	-01976	-00451	0625	0875	0875	0000	0000	0000	0000	%0741	c04	\$
007383	-02584	-00651	0500	0875	0875	0000	0000	0000	0000	%0742	c05	\$
006963	-02995	-00750	0375	0875	0875	0000	0000	0000	0000	%0743	c06	\$
006313	-03642	-01099	0250	0875	0875	0000	0000	0000	0000	%0744	c07	\$
005732	-04284	-01411	0125	0875	0875	0000	0000	0000	0000	%0745	c08	\$
005482	-04317	-01751	0000	0875	0875	0000	0000	0000	0000	%0746	c09	\$
008217	001983	000716	1000	0750	0750	0000	0000	0000	0000	%0747	d01	\$
008053	001068	000452	0875	0750	0750	0000	0000	0000	0000	%0748	d02	\$
007690	-00028	000120	0750	0750	0750	0000	0000	0000	0000	%0749	d03	\$
007528	-01426	-00279	0625	0750	0750	0000	0000	0000	0000	%0750	d04	\$
007308	-02303	-00341	0500	0750	0750	0000	0000	0000	0000	%0751	d05	\$
006929	-02937	-00487	0375	0750	0750	0000	0000	0000	0000	%0752	d06	\$
006314	-03768	-00779	0250	0750	0750	0000	0000	0000	0000	%0753	d07	\$
005644	-04539	-01172	0125	0750	0750	0000	0000	0000	0000	%0754	d08	\$
005275	-04710	-01544	0000	0750	0750	0000	0000	0000	0000	%0755	d09	\$
007385	003070	001426	1000	0625	0625	0000	0000	0000	0000	%0756	e01	\$
007452	002173	000826	0875	0625	0625	0000	0000	0000	0000	%0757	e02	\$
006987	001142	000378	0750	0625	0625	0000	0000	0000	0000	%0758	e03	\$
006519	-00022	000026	0625	0625	0625	0000	0000	0000	0000	%0759	e04	\$
006498	-01456	-00396	0500	0625	0625	0000	0000	0000	0000	%0760	e05	\$
006225	-02511	-00451	0375	0625	0625	0000	0000	0000	0000	%0761	e06	\$
006032	-03625	-00676	0250	0625	0625	0000	0000	0000	0000	%0762	e07	\$
005294	-05183	-01077	0125	0625	0625	0000	0000	0000	0000	%0763	e08	\$
004825	-05237	-01541	0000	0625	0625	0000	0000	0000	0000	%0764	e09	\$
006346	004715	002049	1000	0500	0500	0000	0000	0000	0000	%0765	f01	\$
006541	003664	001631	0875	0500	0500	0000	0000	0000	0000	%0766	f02	\$
006263	002251	000966	0750	0500	0500	0000	0000	0000	0000	%0767	f03	\$
005811	001186	000345	0625	0500	0500	0000	0000	0000	0000	%0768	f04	\$
005210	-00009	000058	0500	0500	0500	0000	0000	0000	0000	%0769	f05	\$
005228	-01577	-00517	0375	0500	0500	0000	0000	0000	0000	%0770	f06	\$
005091	-02721	-00623	0250	0500	0500	0000	0000	0000	0000	%0771	f07	\$
004723	-05278	-01030	0125	0500	0500	0000	0000	0000	0000	%0772	f08	\$
004611	-05360	-01081	0000	0500	0500	0000	0000	0000	0000	%0773	f09	\$
005466	006214	002900	1000	0375	0375	0000	0000	0000	0000	%0774	g01	\$
005536	005801	002603	0875	0375	0375	0000	0000	0000	0000	%0775	g02	\$
005322	004104	001682	0750	0375	0375	0000	0000	0000	0000	%0776	g03	\$
004970	002597	000890	0625	0375	0375	0000	0000	0000	0000	%0777	g04	\$
004542	001363	000247	0500	0375	0375	0000	0000	0000	0000	%0778	g05	\$
003937	000001	000016	0375	0375	0375	0000	0000	0000	0000	%0779	g06	\$
003944	-01672	-00488	0250	0375	0375	0000	0000	0000	0000	%0780	g07	\$
003956	-03816	-00746	0125	0375	0375	0000	0000	0000	0000	%0781	g08	\$
003983	-04589	-00843	0000	0375	0375	0000	0000	0000	0000	%0782	g09	\$
005054	006918	003551	1000	0250	0250	0000	0000	0000	0000	%0783	h01	\$
004796	006549	003349	0875	0250	0250	0000	0000	0000	0000	%0784	h02	\$
004241	005796	002717	0750	0250	0250	0000	0000	0000	0000	%0785	h03	\$
004024	004325	001818	0625	0250	0250	0000	0000	0000	0000	%0786	h04	\$
003714	002721	000988	0500	0250	0250	0000	0000	0000	0000	%0787	h05	\$
003298	001427	000315	0375	0250	0250	0000	0000	0000	0000	%0788	h06	\$
002784	000018	000033	0250	0250	0250	0000	0000	0000	0000	%0789	h07	\$
003102	-02124	-00641	0125	0250	0250	0000	0000	0000	0000	%0790	h08	\$
002869	-03043	-00812	0000	0250	0250	0000	0000	0000	0000	%0791	h09	\$
004964	006973	004355	1000	0125	0125	0000	0000	0000	0000	%0792	i01	\$
004384	006066	003630	0875	0125	0125	0000	0000	0000	0000	%0793	i02	\$
003917	005469	003165	0750	0125	0125	0000	0000	0000	0000	%0794	i03	\$
003551	004847	002650	0625	0125	0125	0000	0000	0000	0000	%0795	i04	\$
003121	004216	001943	0500	0125	0125	0000	0000	0000	0000	%0796	i05	\$
002677	003077	001111	0375	0125	0125	0000	0000	0000	0000	%0797	i06	\$
002324	001540	000423	0250	0125	0125	0000	0000	0000	0000	%0798	i07	\$
001824	000055	000111	0125	0125	0125	0000	0000	0000	0000	%0799	i08	\$
002167	-01383	-00396	0000	0125	0125	0000	0000	0000	0000	%0800	i09	\$
004970	006927	004739	1000	0000	0000	0000	0000	0000	0000	%0801	j01	\$
004402	006015	004278	0750	0000	0000	0000	0000	0000	0000	%0802	j02	\$
003869	005286	003446	0875	0000	0000	0000	0000	0000	0000	%0803	j03	\$
003449	004610	003155	0625	0000	0000	0000	0000	0000	0000	%0804	j04	\$
002948	003687	002426	0500	0000	0000	0000	0000	0000	0000	%0805	j05	\$
002490	002774	001651	0375	0000	0000	0000	0000	0000	0000	%0806	j06	\$
002195	002284	000820	0250	0000	0000	0000	0000	0000	0000	%0807	j07	\$
001764	000311	000123	0125	0000	0000	0000	0000	0000	0000	%0808	j08	\$
001722	000055	000014	0000	0000	0000	0000	0000	0000	0000	%0809	j09	\$
009735	-00056	000188	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
008785	-00476	-00897	0875	0875	0875	0000	0000	0000	0000	%0811	b11	\$
007529	-01041	-02217	0750	0750	0750	0000	0000	0000	0000	%0812	b12	\$
006489	-01283	-03107	0625	0625	0625	0000	0000	0000	0000	%0813	b13	\$
005298	-01477	-04051	0500	0500	0500	0000	0000	0000	0000	%0814	b14	\$
004482	-01638	-04684	0375	0375	0375	0000	0000	0000	0000	%0815	b15	\$
003976	-01440	-04855	0250	0250	0250	0000	0000	0000	0000	%0816	b16	\$
003919	-01247	-04121	0125	0125	0125	0000	0000	0000	0000	%0817	b17	\$
003702	-01229	-04706	0000	0000	0000	0000	0000	0000	0000	%0818	b18	\$
009666	-00520	002065	1000	1000	1000	0000	0000	0000	0000	%0819	c10	\$
008907	-00035	000185	0875	0875	0875	0000	0000	0000	0000	%0820	c11	\$
008043	-00479	-01582	0750	0750	0750	0000	0000	0000	0000	%0821	c12	\$
006688	-00829	-02805	0625	0625	0625	0000	0000	0000	0000	%0822	c13	\$
005404	-00936	-03750	0500	0500	0500	0000	0000	0000	0000	%0823	c14	\$
004361	-01168	-04528	0375	0375	0375	0000	0000	0000	0000	%0824	c15	\$
003917	-01264	-04832	0250	0250	0250	0000	0000	0000	0000	%0825	c16	\$
003744	-01095	-04712	0125	0125	0125	0000	0000	0000	0000	%0826	c17	\$
003488	-01023	-04392	0000	0000	0000	0000	0000	0000	0000	%0827	c18	\$
005959	-00780	003485	1000	1000	1000	0000	0000	0000	0000	%0828	d10	\$
008941	-00546	001862	0875	0875	0875	0000	0000	0000	0000	%0829	d11	

%BEG GE20_22.TXT, Separation olv*, D50, not adapted \$
%100 x LAB*
%#1000 x (r g b c m y 0) %nr. pos \$
%z005020 006809 004642 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z009398 -01150 009473 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005961 -05450 004193 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005508 -04412 -02200 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z003735 -01212 -04714 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z004995 007230 -00586 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z001468 000051 000136 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009732 -00065 000212 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004970 006927 004739 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z009402 -01160 009310 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005979 -05272 004084 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005472 -04232 -02271 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003702 -01229 -04706 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z004970 007255 -00532 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z001432 000059 000106 %#0000 0000 1000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009737 -00059 000189 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/GE30/GE30L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG GE20_22.TXT, Separation olv*, D50, not adapted \$																									
%100 x LAB*			1000 x (r g b c m y θ)			%nr.	pos	\$																	
001353	000048	000131	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$	008606	-00029	000169	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$
001673	000040	000117	0125	0125	0125	0875	0875	0875	0000	%0973	k02	\$	009172	-00040	000189	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$
002610	000012	000043	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$	009721	-00062	000195	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$
003827	-00003	000021	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$	001628	000058	000107	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$
005259	-00018	000036	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$	001370	000061	000116	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$
006576	-00030	000068	0625	0625	0625	0625	0625	0625	0000	%0977	k06	\$	001806	000054	000091	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$
007717	-00030	000120	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$	002397	000034	000045	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$
008845	-00039	000174	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$	002904	000020	000023	0266	0266	0266	0333	0333	0333	0000	%1060	n14	\$
009741	-00061	000175	1000	1000	1000	1000	1000	1000	0000	%0980	k09	\$	003566	000013	000027	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$
014402	000051	000123	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$	004210	000005	000034	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$
001754	000051	000134	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$	004817	000006	000066	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$
002608	000019	000047	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$	005568	-00008	000075	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$
003833	000000	000012	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$	006379	-00018	000081	0600	0600	0600	0400	0400	0400	0000	%1065	n19	\$
005243	-00015	000022	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$	006976	-00023	000102	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$
006590	-00027	000052	0625	0625	0625	0625	0625	0625	0000	%0986	l06	\$	007524	-00021	000124	0734	0734	0734	0266	0266	0266	0000	%1067	n21	\$
007743	-00030	000117	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$	008085	-00021	000162	0800	0800	0800	0200	0200	0200	0000	%1068	n22	\$
008857	-00038	000170	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$	008616	-00026	000179	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$
009739	-00063	000181	1000	1000	1000	1000	1000	1000	0000	%0989	l09	\$	009179	-00039	000186	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$
013134	000054	000136	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$	009706	-00057	000183	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$
001681	000054	000127	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$	001308	000050	000099	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$
002582	000022	000052	0250	0250	0250	0750	0750	0750	0000	%0992	m03	\$	009742	-00067	000196	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$
003777	000002	000026	0375	0375	0375	0625	0625	0625	0000	%0993	m04	\$	004965	006923	004815	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$
005171	-00012	000033	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$	005765	-04732	-01545	0000	1000	1000	1000	0000	0000	0000	%1075	l27	\$
006589	-00022	000058	0625	0625	0625	0625	0625	0625	0000	%0995	m06	\$	009398	-01156	009626	1000	1000	1000	0000	0000	1000	0000	%1076	m26	\$
007697	-00025	000116	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$	003719	-01062	-04684	0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$
008841	-00040	000190	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$	005990	-05475	004280	0000	1000	0000	1000	0000	1000	0000	%1078	n26	\$
009734	-00063	000185	1000	1000	1000	1000	1000	1000	0000	%0998	m09	\$	004959	007291	-00635	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$
011296	000057	000147	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$	\$												
001675	000048	000141	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$	%z004965 006923 004815 ##1000 0000 0000 0000 1000 1000 0000 %1074 126 %03 0 \$												
002545	000021	000058	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$	%z009398 -01156 009626 ##1000 1000 0000 0000 0000 1000 0000 %1076 m26 %Y3 1 \$												
003763	000003	000041	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$	%z005990 -05475 004280 ##0000 1000 0000 1000 0000 1000 0000 %1078 n26 %L3 2 \$												
005184	-00012	000041	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$	%z005765 -04732 -01545 ##0000 1000 1000 0000 0000 0000 0000 %1075 127 %C3 3 \$												
006533	-00019	000058	0625	0625	0625	0625	0625	0625	0000	%1004	n06	\$	%z003719 -01062 -04684 ##0000 0000 1000 1000 1000 0000 0000 %1077 m27 %V3 4 \$												
007716	-00025	000124	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$	%z004959 007291 -00635 ##1000 0000 1000 0000 1000 0000 0000 %1079 n27 %W3 5 \$												
008849	-00034	000177	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$	%z001308 000050 000099 ##0000 0000 0000 1000 1000 1000 0000 %1072 k26 %W3 6 \$												
009729	-00058	000178	1000	1000	1000	1000	1000	1000	0000	%1007	n09	\$	%z009742 -00067 000196 ##1000 1000 1000 0000 0000 0000 0000 %1073 k27 %W3 7 \$												
001806	000049	000086	0000	0000	0000	1000	1000	1000	0000	%1008	k10	\$	\$												
001550	000060	000099	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$	%z001580 000049 000109 ##0000 0000 0000 1000 1000 1000 0000 %0972 k01 %N4 6 \$												
001926	000042	000057	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$	%z009734 -00062 000179 ##1000 1000 1000 0000 0000 0000 0000 %0980 k09 %W4 7 \$												
002460	000027	000023	0200	0200	0200	0800	0800	0800	0000	%1011	k13	\$	\$												
002977	000018	000005	0266	0266	0266	0333	0333	0333	0000	%1012	k14	\$	%z001621 000051 000106 ##0000 0000 0000 1000 1000 1000 0000 %0981 l01 %N5 6 \$												
003619	000007	000006	0333	0333	0333	0666	0666	0666	0000	%1013	k15	\$	%z009727 -00060 000176 ##1000 1000 1000 0000 0000 0000 0000 %0989 l09 %W5 7 \$												
004232	000003	000028	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$	\$												
004882	000000	000044	0466	0466	0466	0533	0533	0533	0000	%1015	k17	\$	%z001535 000054 000119 ##0000 0000 0000 1000 1000 1000 0000 %0990 m01 %N6 6 \$												
005635	-00009	000061	0533	0533	0533	0666	0666	0666	0000	%1016	k18	\$	%z009728 -00063 000190 ##1000 1000 1000 0000 0000 0000 0000 %0998 m09 %W6 7 \$												
006422	-00020	000058	0600	0600	0600	0800	0800	0800	0000	%1017	k19	\$	\$												
007717	-00027	000067	0666	0666	0666	0733	0733	0733	0000	%1018	k20	\$	%z001462 000057 000127 ##0000 0000 0000 1000 1000 1000 0000 %0999 n01 %N7 6 \$												
007610	-00029	000130	0734	0734	0734	0266	0266	0266	0000	%1019	k21	\$	%z009717 -00057 000180 ##1000 1000 1000 0000 0000 0000 0000 %1007 n09 %W7 7 \$												
008165	-00030	000159	0800	0800	0800	0200	0200	0200	0000	%1020	k22	\$	\$												
008666	-00036	000191	0866	0866	0866	0133	0133	0133	0000	%1021	k23	\$													
009211	-00048	000197	0933	0933	0933	0066	0066	0066	0000	%1022	k24	\$													
009727	-00062	000184	1000	1000	1000	1000	1000	1000	0000	%1023	k25	\$													
001840	000051	000090	0000	0000	0000	1000	1000	1000	0000	%1024	l10	\$													
001604	000057	000110	0066	0066	0066	0933	0933	0933	0000	%1025	l11	\$													
001982	000048	000076	0133	0133	0133	0866	0866	0866	0000	%1026	l12	\$													
002497	000024	000027	0200	0200	0200	0800	0800	0800	0000	%1027	l13	\$													
003011	000015	000010	0266	0266	0266	0333	0333	0333	0000	%1028	l14	\$													
003626	000009	000008	0333	0333	0333	0666	0666	0666	0000	%1029	l15	\$													
004254	000003	000018	0400	0400	0400	0600	0600	0600	0000	%1030	l16	\$													
004912	000003	000030	0466	0466	0466	0533	0533	0533	0000	%1031	l17	\$													
005620	-00006	000037	0533	0533	0533	0666	0666	0666	0000	%1032	l18	\$													
006437	-00020	000047	0600	0600	0600	0800	0800	0800	0000	%1033	l19	\$													
007042	-00023	000072	0666	0666	0666	0333	0333	0333	0000	%1034	l20	\$													
007578	-00025	000104	0734	0734	0734	0266	0266	0266	0000	%1035	l21	\$													

See original or copy: <http://web.me.com/klaus.richter/GE30/GE30L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfl=1.00; nt=0.18; nx=1.00

XREG GE28 2D.TT, Separation (r l v, D50, adapted s																									
#100 x LAB*	1000 x c m y 0				%nr.	pos \$																			
001468	000000	000000	0000	0000	0000	1000	1000	1000	0000	000000	A01	\$	001699	000205	000102	0125	0000	0000	00875	1000	1000	0000	000081	J01	\$
0014632	-00114	-00089	0000	0000	0125	1000	1000	0875	0000	000001	A02	\$	001739	000836	-01114	0125	0000	0125	0875	1000	0875	0000	000802	J02	\$
002143	-00433	-01051	0000	0000	0250	1000	1000	0750	0000	000002	A03	\$	002241	000828	-03424	0125	0000	0250	0875	1000	0750	0000	000083	J03	\$
002200	-00458	-02745	0000	0000	0375	1000	1000	0625	0000	000003	A04	\$	002527	-00225	-03660	0125	0000	0375	0875	1000	0625	0000	000084	J04	\$
002661	-00618	-03554	0000	0000	0500	1000	1000	0500	0000	000004	A05	\$	002860	-00387	-04160	0125	0000	0500	0875	1000	0500	0000	000085	J05	\$
003034	-00913	-03963	0000	0000	0625	1000	1000	0375	0000	000005	A06	\$	003158	-00657	-04405	0125	0000	0625	0875	1000	0375	0000	000086	J06	\$
003304	-01062	-04335	0000	0000	0750	1000	1000	0250	0000	000006	A07	\$	003390	-00880	-04634	0125	0000	0750	0875	1000	0250	0000	000087	J07	\$
003496	-01174	-04665	0000	0000	0875	1000	1000	0125	0000	000007	A08	\$	003597	-01048	-04830	0125	0000	0875	0875	1000	0125	0000	000088	J08	\$
003735	-02323	-04871	0000	0000	1000	1000	1000	0000	0000	000008	A09	\$	003791	-01168	-04985	0125	0000	1000	0875	1000	0000	0000	000089	J09	\$
002528	-01261	-000995	0000	0125	0000	1000	0875	1000	0000	000009	B01	\$	001978	-00214	000211	0125	0125	0000	0875	0875	1000	0000	000090	K01	\$
001964	-01504	-00482	0000	0125	0125	1000	0875	0875	0000	000010	B02	\$	001753	000002	-00014	0125	0125	0125	0875	0875	0875	0000	000091	K02	\$
002447	-01033	-02666	0000	0125	0250	1000	0875	0750	0000	000011	B03	\$	002535	-00447	-02665	0125	0125	0250	0875	0875	0750	0000	000092	K03	\$
002777	-00744	-03564	0000	0125	0375	1000	0875	0625	0000	000012	B04	\$	003000	-00705	-03928	0125	0125	0375	0875	0875	0625	0000	000093	K04	\$
003066	-00877	-03925	0000	0125	0500	1000	0875	0500	0000	000013	B05	\$	003248	-00738	-04425	0125	0125	0500	0875	0875	0500	0000	000094	K05	\$
003294	-00995	-04275	0000	0125	0625	1000	0875	0375	0000	000014	B06	\$	003427	-00916	-04581	0125	0125	0625	0875	0875	0375	0000	000095	K06	\$
003522	-01158	-04522	0000	0125	0750	1000	0875	0250	0000	000015	B07	\$	003589	-01052	-04754	0125	0125	0750	0875	0875	0250	0000	000096	K07	\$
003668	-01174	-04826	0000	0125	0875	1000	0875	0125	0000	000016	B08	\$	003741	-01187	-04946	0125	0125	0875							

TUB-test chart GE30; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```

TUB registration: 20091101-GE30/GE30L0NP.PDF /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

002696	002595	001394	0375	0000	0000	0025	1000	1000	0000	%0243	A10 \$
002535	002906	000640	0375	0000	0125	0625	1000	0875	0000	%0244	A11 \$
002485	003093	-01054	0375	0000	0250	0625	1000	0750	0000	%0245	A12 \$
002685	003094	-02926	0375	0000	0375	0625	1000	0625	0000	%0246	A13 \$
002927	002729	-04113	0375	0000	0500	0625	1000	0500	0000	%0247	A14 \$
003229	001213	-04568	0375	0000	0625	0625	1000	0375	0000	%0248	A15 \$
003358	-00004	-04960	0375	0000	0750	0625	1000	0250	0000	%0249	A16 \$
003484	-00496	-04976	0375	0000	0875	0625	1000	0125	0000	%0250	A17 \$
003598	-00806	-05101	0375	0000	1000	0625	1000	0000	0000	%0251	A18 \$
002838	002574	001610	0375	0125	0000	0625	0875	1000	0000	%0252	B10 \$
002914	003057	000977	0375	0125	0125	0625	0875	0875	0000	%0253	B11 \$
002891	003497	-00985	0375	0125	0250	0625	0875	0750	0000	%0254	B12 \$
003014	003240	-02831	0375	0125	0375	0625	0875	0625	0000	%0255	B13 \$
003125	002656	-04013	0375	0125	0500	0625	0875	0500	0000	%0256	B14 \$
003410	001435	-04345	0375	0125	0625	0625	0875	0375	0000	%0257	B15 \$
003479	000315	-04743	0375	0125	0750	0625	0875	0250	0000	%0258	B16 \$
003516	-00418	-04969	0375	0125	0875	0625	0875	0125	0000	%0259	B17 \$
003749	-00980	-05031	0375	0125	1000	0625	0875	0000	0000	%0260	B18 \$
003434	001173	-02462	0375	0250	0000	0625	0750	1000	0000	%0261	C10 \$
003665	001066	002377	0375	0250	0125	0625	0750	0875	0000	%0262	C11 \$
003520	001430	000192	0375	0250	0250	0625	0750	0750	0000	%0263	C12 \$
003635	001515	-01965	0375	0250	0375	0625	0750	0625	0000	%0264	C13 \$
003905	001404	-03643	0375	0250	0500	0625	0750	0500	0000	%0265	C14 \$
003792	000785	-04411	0375	0250	0625	0625	0750	0375	0000	%0266	C15 \$
003767	-00227	-04795	0375	0250	0750	0625	0750	0250	0000	%0267	C16 \$
003761	-00795	-04975	0375	0250	0875	0625	0750	0125	0000	%0268	C17 \$
003937	-01236	-05041	0375	0250	1000	0625	0750	0000	0000	%0269	C18 \$
004515	-00877	-003875	0375	0375	0000	0625	0625	1000	0000	%0270	D10 \$
004557	-00836	-003866	0375	0375	0125	0625	0625	0875	0000	%0271	D11 \$
004427	-00573	-001688	0375	0375	0250	0625	0625	0750	0000	%0272	D12 \$
004023	-00014	-00153	0375	0375	0375	0625	0625	0625	0000	%0273	D13 \$
004565	-00388	-02289	0375	0375	0500	0625	0625	0500	0000	%0274	D14 \$
004625	-00501	-03763	0375	0375	0625	0625	0625	0375	0000	%0275	D15 \$
004471	-00999	-04639	0375	0375	0750	0625	0625	0250	0000	%0276	D16 \$
004349	-01254	-04791	0375	0375	0875	0625	0625	0125	0000	%0277	D17 \$
004391	-01662	-04917	0375	0375	1000	0625	0625	0000	0000	%0278	D18 \$
005337	-03159	-003915	0375	0500	0000	0625	0500	1000	0000	%0279	D19 \$
005452	-03176	-04111	0375	0500	0125	0625	0500	0875	0000	%0280	E11 \$
005490	-02891	-003097	0375	0500	0250	0625	0500	0750	0000	%0281	E12 \$
005422	-02179	-001137	0375	0500	0375	0625	0500	0625	0000	%0282	E13 \$
005263	-01643	-00763	0375	0500	0500	0625	0500	0500	0000	%0283	E14 \$
005274	-01419	-02471	0375	0500	0625	0625	0500	0375	0000	%0284	E15 \$
005259	-01535	-03921	0375	0500	0750	0625	0500	0250	0000	%0285	E16 \$
005113	-01763	-04463	0375	0500	0875	0625	0500	0125	0000	%0286	E17 \$
005109	-01930	-04541	0375	0500	1000	0625	0500	0000	0000	%0287	E18 \$
005763	-04246	-003964	0375	0625	0000	0625	0375	1000	0000	%0288	F10 \$
005994	-04341	-004256	0375	0625	0125	0625	0375	0875	0000	%0289	F11 \$
006164	-04623	-004082	0375	0625	0250	0625	0375	0750	0000	%0290	F12 \$
006302	-03830	-002549	0375	0625	0375	0625	0375	0625	0000	%0291	F13 \$
006361	-03043	-000954	0375	0625	0500	0625	0375	0500	0000	%0292	F14 \$
006242	-02610	-00647	0375	0625	0625	0625	0375	0375	0000	%0293	F15 \$
005955	-02110	-02787	0375	0625	0750	0625	0375	0250	0000	%0294	F16 \$
006054	-02257	-04001	0375	0625	0875	0625	0375	0125	0000	%0295	F17 \$
005985	-02246	-04019	0375	0625	1000	0625	0375	0000	0000	%0296	F18 \$
005960	-04856	-003964	0375	0750	0000	0625	0250	1000	0000	%0297	G10 \$
006189	-04884	-004194	0375	0750	0125	0625	0250	0875	0000	%0298	G11 \$
006328	-04787	-003857	0375	0750	0250	0625	0250	0750	0000	%0299	G12 \$
006325	-04346	-00376	0375	0750	0375	0625	0250	0625	0000	%0300	G13 \$
006816	-03848	-002042	0375	0750	0500	0625	0250	0500	0000	%0301	G14 \$
007039	-03378	-000859	0375	0750	0625	0250	0250	0375	0000	%0302	G15 \$
006888	-03171	-00643	0375	0750	0750	0625	0250	0250	0000	%0303	G16 \$
006709	-02915	-02642	0375	0750	0875	0625	0250	0125	0000	%0304	G17 \$
006687	-02581	-03616	0375	0750	1000	0625	0250	0000	0000	%0305	G18 \$
006078	-05050	-004057	0375	0875	0000	0625	0125	1000	0000	%0306	H10 \$
006101	-05095	-004074	0375	0875	0125	0625	0125	0875	0000	%0307	H11 \$
006269	-04837	-003664	0375	0875	0250	0625	0125	0750	0000	%0308	H12 \$
006419	-04495	-003072	0375	0875	0375	0625	0125	0625	0000	%0309	H13 \$
006680	-04049	-002394	0375	0875	0500	0625	0125	0500	0000	%0310	H14 \$
006889	-03689	-001684	0375	0875	0625	0625	0125	0375	0000	%0311	H15 \$
006976	-03411	-000517	0375	0875	0750	0625	0125	0250	0000	%0312	H16 \$
006865	-03210	-00955	0375	0875	0875	0625	0125	0125	0000	%0313	H17 \$
006678	-02914	-02795	0375	0875	1000	0625	0125	0000	0000	%0314	H18 \$
006059	-05025	-003983	0375	1000	0000	0625	0000	1000	0000	%0315	I10 \$
006163	-04980	-004102	0375	1000	0125	0625	0000	0875	0000	%0316	I11 \$
006347	-04711	-003693	0375	1000	0250	0625	0000	0750	0000	%0317	I12 \$
006559	-04311	-003098	0375	1000	0375	0625	0000	0625	0000	%0318	I13 \$
006682	-04105	-002619	0375	1000	0500	0625	0000	0500	0000	%0319	I14 \$
006742	-03900	-001995	0375	1000	0625	0000	0000	0375	0000	%0320	I15 \$
006881	-03660	-001353	0375	1000	0750	0625	0000	0250	0000	%0321	I16 \$
006841	-03433	-00147	0375	1000	0875	0625	0000	0125	0000	%0322	I17 \$
006676	-03336	-01500	0375	1000	1000	0625	0000	0000	0000	%0323	I18 \$
003214	003629	002207	0500	0000	0000	0500	1000	1000	0000	%0324	J10 \$
003148	003757	001709	0500	0000	0125	0500	1000	0875	0000	%0325	J11 \$
002997	004077	-00044	0500	0000	0250	0500	1000	0750	0000	%0326	J12 \$
003098	004093	-01709	0500	0000	0375	0500	1000	0625	0000	%0327	J13 \$
003158	003994	-03028	0500	0000	0500	0500	1000	0500	0000	%0328	J14 \$
003270	003206	-03709	0500	0000	0625	0500	1000	0375	0000	%0329	J15 \$
003437	001996	-04189	0500	0000	0750	0500	1000	0250	0000	%0330	J16 \$
003529	000733	-04587	0500	0000	0875	0500	1000	0125	0000	%0331	J17 \$
003517	000177	-04785	0500	0000	1000	0500	1000	0000	0000	%0332	J18 \$
003353	003000	002529	0500	0125	0000	0500	0875	1000	0000	%0333	K10 \$
003370	004164	001738	0500	0125	0125	0500	0875	0075	0000	%0334	K11 \$
003176	004309	000049	0500	0125	0250	0500	0875	0750	0000	%0335	K12 \$
003260	004310	-01653	0500	0125	0375	0500	0875	0625	0000	%0336	K13 \$
003310	004117	-02956	0500	0125	0500	0500	0875	0500	0000	%0337	K14 \$
003409	003193	-03604	0500	0125	0625	0500	0875	0375	0000	%0338	K15 \$
003540	002070	-04022	0500	0125	0750	0500	0875	0250	0000	%0339	K16 \$
003622	001158	-04359	0500	0125	0875	0500	0875	0125	0000	%0340	K17 \$
003696	000148	-04684	0500	0125	1000	0500	0875	0000	0000	%0341	K18 \$
003682	002548	-002880	0500	0250	0000	0500	0750	1000	0000	%0342	L10 \$
003915	002525	002874	0500	0250	0125	0500	0750	0875	0000	%0343	L11 \$
003882	002806	000825	0500	0250	0250	0500	0750	0750	0000	%0344	L12 \$
003869	003481	-01153	0500	0250	0375	0500	0750	0625	0000	%0345	L13 \$
003738	003586	-03040	0500	0250	0500	0500	0750	0500	0000	%0346	L14 \$
003763	002603	-03673	0500	0250	0625	050					

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

004032	005397	003361	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
003986	005357	002909	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
003907	005398	001926	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
003862	005601	006064	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
003838	005556	-00878	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
003853	005638	-01972	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
003689	005243	-02471	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
003784	005427	-03092	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$
003911	005431	-03446	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$
004237	005648	004030	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$
004097	005406	002965	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
004034	005508	001863	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
004028	005801	000454	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
004028	005905	-01128	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
003961	005670	-02005	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
003817	004905	-02672	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
003904	004006	-03144	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
004000	003376	-03390	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
004471	005458	004363	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
004363	005724	004151	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
004285	005748	002531	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
004284	005935	-00960	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
004275	006255	-00996	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
004233	005545	-02095	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
004049	004502	-02789	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
004081	003639	-03215	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
004233	002970	-03414	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
005332	003591	005146	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
005225	003979	005063	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005372	003828	003252	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
005398	003981	001539	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
005224	004477	-02688	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
004090	004717	-02902	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
004625	003769	-02801	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$
004615	002776	-03217	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$
004761	002235	-03352	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$
006262	001764	006836	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
006210	001970	005969	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
006278	001988	004488	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
006332	001977	002477	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006202	002327	000768	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
005951	002927	-01177	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
005621	002927	-02476	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
005428	002017	-02982	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
005351	001229	-03323	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
007249	000198	007058	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
007217	000255	006977	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
007146	000353	006219	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
007133	000439	003937	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
007004	000687	002246	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
006761	001263	000204	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
006776	001410	-01709	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
006480	000871	-02617	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$
006252	000272	-03001	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
008221	-01200	007993	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
008137	-01179	007869	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
008069	-01133	007637	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
008041	-01142	007587	0750	0750	0375	0250	0250	0500	0000	%0543	G22	\$
007930	-01000	003745	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007730	-00662	002002	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$
007483	000015	-00064	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$
007917	-00349	-01881	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$
007459	-00934	-02489	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$
007992	-02625	007038	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$
008022	-02622	007015	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$
008045	-02616	006512	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$
008179	-02450	005285	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$
008247	-02306	003921	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$
008357	-02142	002878	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$
008520	-01884	001784	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$
008528	-01593	-00128	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$
008359	-01398	-01792	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$
007384	-03360	006080	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$
007399	-03359	005830	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$
007540	-03197	005250	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$
007691	-02947	003881	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$
007963	-02579	003118	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$
008163	-02320	002532	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$
008313	-02114	001895	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$
008454	-01874	000996	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$
008340	-01672	-00841	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$
004538	006162	004154	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$
004464	006080	003517	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$
004412	006080	002585	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$
004408	006246	001543	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$
004428	006515	000480	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$
004422	006787	-00815	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$
004376	006703	-01309	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$
004240	006027	-01810	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$
004274	005007	-02495	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$
004661	006343	004590	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$
004509	006064	003308	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$
004464	006160	002400	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$
004482	006306	001342	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$
004489	006661	000090	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$
004563	006874	-00927	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$
004361	006409	-01499	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$
004326	005640	-02027	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$
004344	004778	-02522	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$
004901	006220	004996	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$
004831	006491	004516	0875	0250	0125	0125	0750	08				

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009743	-00004	000000	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009905	-00841	-00496	0875	1000	1000	0000	0000	0000	0000	%0730	b02	\$
008464	-01439	-00779	0750	1000	1000	0000	0000	0000	0000	%0731	b03	\$
007952	-01929	-01098	0625	1000	1000	0000	0000	0000	0000	%0732	b04	\$
007291	-02495	-01673	0500	1000	1000	0000	0000	0000	0000	%0733	b05	\$
006697	-03128	-01603	0375	1000	1000	0000	0000	0000	0000	%0734	b06	\$
006058	-03778	-02014	0250	1000	1000	0000	0000	0000	0000	%0735	b07	\$
005701	-04119	-02262	0125	1000	1000	0000	0000	0000	0000	%0736	b08	\$
005472	-04234	-02417	0000	1000	1000	0000	0000	0000	0000	%0737	b09	\$
008985	-001014	000243	1000	0875	0875	0000	0000	0000	0000	%0738	c01	\$
008773	000004	000032	0875	0875	0875	0000	0000	0000	0000	%0739	c02	\$
008621	-01373	-00259	0750	0875	0875	0000	0000	0000	0000	%0740	c03	\$
008012	-01941	-00623	0625	0875	0875	0000	0000	0000	0000	%0741	c04	\$
007383	-02558	-00817	0500	0875	0875	0000	0000	0000	0000	%0742	c05	\$
006963	-02975	-00911	0375	0875	0875	0000	0000	0000	0000	%0743	c06	\$
006313	-03631	-01254	0250	0875	0875	0000	0000	0000	0000	%0744	c07	\$
005732	-04282	-01560	0125	0875	0875	0000	0000	0000	0000	%0745	c08	\$
005482	-04318	-01897	0000	0875	0875	0000	0000	0000	0000	%0746	c09	\$
008217	002021	000542	1000	0750	0750	0000	0000	0000	0000	%0747	d01	\$
008053	001104	000279	0875	0750	0750	0000	0000	0000	0000	%0748	d02	\$
007690	000002	-00048	0750	0750	0750	0000	0000	0000	0000	%0749	d03	\$
007528	-01398	-00446	0625	0750	0750	0000	0000	0000	0000	%0750	d04	\$
007308	-02278	-00506	0500	0750	0750	0000	0000	0000	0000	%0751	d05	\$
006929	-02917	-00648	0375	0750	0750	0000	0000	0000	0000	%0752	d06	\$
006314	-03758	-00934	0250	0750	0750	0000	0000	0000	0000	%0753	d07	\$
005644	-04538	-01320	0125	0750	0750	0000	0000	0000	0000	%0754	d08	\$
005275	-04714	-01689	0000	0750	0750	0000	0000	0000	0000	%0755	d09	\$
007385	003096	001260	1000	0625	0625	0000	0000	0000	0000	%0756	e01	\$
007452	002200	000660	0875	0625	0625	0000	0000	0000	0000	%0757	e02	\$
006987	001162	000164	0750	0625	0625	0000	0000	0000	0000	%0758	e03	\$
006519	-00009	-00078	0625	0625	0625	0000	0000	0000	0000	%0759	e04	\$
006498	-01443	-00553	0500	0625	0625	0000	0000	0000	0000	%0760	e05	\$
006225	-02502	-00895	0375	0625	0625	0000	0000	0000	0000	%0761	e06	\$
006032	-03618	-00828	0250	0625	0625	0000	0000	0000	0000	%0762	e07	\$
005294	-05187	-01222	0125	0625	0625	0000	0000	0000	0000	%0763	e08	\$
004825	-05248	-01681	0000	0625	0625	0000	0000	0000	0000	%0764	e09	\$
006346	-004726	-001894	1000	0500	0500	0000	0000	0000	0000	%0765	f01	\$
006541	-003677	-001474	0875	0500	0500	0000	0000	0000	0000	%0766	f02	\$
006263	-002261	-000811	0750	0500	0500	0000	0000	0000	0000	%0767	f03	\$
005811	001189	000195	0625	0500	0500	0000	0000	0000	0000	%0768	f04	\$
005210	-00014	-00085	0500	0500	0500	0000	0000	0000	0000	%0769	f05	\$
005228	-01582	-00661	0375	0500	0500	0000	0000	0000	0000	%0770	f06	\$
005091	-02729	-00766	0250	0500	0500	0000	0000	0000	0000	%0771	f07	\$
004723	-05290	-01169	0125	0500	0500	0000	0000	0000	0000	%0772	f08	\$
004611	-05374	-01219	0000	0500	0500	0000	0000	0000	0000	%0773	f09	\$
005466	006212	002753	1000	0375	0375	0000	0000	0000	0000	%0774	g01	\$
005536	005800	002456	0875	0375	0375	0000	0000	0000	0000	%0775	g02	\$
005322	-004100	-001537	0750	0375	0375	0000	0000	0000	0000	%0776	g03	\$
004970	002588	000749	0625	0375	0375	0000	0000	0000	0000	%0777	g04	\$
004542	001348	000110	0500	0375	0375	0000	0000	0000	0000	%0778	g05	\$
003937	-00021	-00114	0375	0375	0375	0000	0000	0000	0000	%0779	g06	\$
003944	-01695	-00619	0250	0375	0375	0000	0000	0000	0000	%0780	g07	\$
003956	-03839	-00878	0125	0375	0375	0000	0000	0000	0000	%0781	g08	\$
003983	-04613	-00973	0000	0375	0375	0000	0000	0000	0000	%0782	g09	\$
005054	006919	003409	1000	0250	0250	0000	0000	0000	0000	%0783	h01	\$
004796	006538	003209	0875	0250	0250	0000	0000	0000	0000	%0784	h02	\$
004241	005777	002583	0750	0250	0250	0000	0000	0000	0000	%0785	h03	\$
004024	004303	001758	0625	0250	0250	0000	0000	0000	0000	%0786	h04	\$
003714	002695	000859	0500	0250	0250	0000	0000	0000	0000	%0787	h05	\$
003298	001394	000191	0375	0250	0250	0000	0000	0000	0000	%0788	h06	\$
002784	-00021	-00086	0250	0250	0250	0000	0000	0000	0000	%0789	h07	\$
003102	-02160	-00764	0125	0250	0250	0000	0000	0000	0000	%0790	h08	\$
002869	-03082	-00933	0000	0250	0250	0000	0000	0000	0000	%0791	h09	\$
004364	006965	004313	1000	0125	0125	0000	0000	0000	0000	%0792	i01	\$
004984	006049	003494	0875	0125	0125	0000	0000	0000	0000	%0793	i02	\$
003917	005445	003034	0750	0125	0125	0000	0000	0000	0000	%0794	i03	\$
003551	004817	002522	0625	0125	0125	0000	0000	0000	0000	%0795	i04	\$
003211	004181	001820	0500	0125	0125	0000	0000	0000	0000	%0796	i05	\$
002677	003035	000992	0375	0125	0125	0000	0000	0000	0000	%0797	i06	\$
002324	001493	000308	0250	0125	0125	0000	0000	0000	0000	%0798	i07	\$
001824	000001	000001	0125	0125	0125	0000	0000	0000	0000	%0799	i08	\$
002167	-01432	-00510	0000	0125	0125	0000	0000	0000	0000	%0800	i09	\$
004970	006918	004597	1000	0000	0000	0000	0000	0000	0000	%0801	j01	\$
004402	005998	004142	0875	0000	0000	0000	0000	0000	0000	%0802	j02	\$
003869	005261	003315	0750	0000	0000	0000	0000	0000	0000	%0803	j03	\$
003449	004579	003028	0625	0000	0000	0000	0000	0000	0000	%0804	j04	\$
002948	003649	002305	0500	0000	0000	0000	0000	0000	0000	%0805	j05	\$
002490	002729	001535	0375	0000	0000	0000	0000	0000	0000	%0806	j06	\$
002195	002235	000706	0250	0000	0000	0000	0000	0000	0000	%0807	j07	\$
001764	000256	000103	0125	0000	0000	0000	0000	0000	0000	%0808	j08	\$
001722	000000	-00004	0000	0000	0000	0000	0000	0000	0000	%0809	j09	\$
009735	000002	000000	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
008785	-00430	-01076	0875	0875	0875	0000	0000	0000	0000	%0811	b11	\$
007529	-01013	-02384	0750	0750	0750	0000	0000	0000	0000	%0812	b12	\$
006489	-01270	-03263	0625	0625	0625	0000	0000	0000	0000	%0813	b13	\$
005298	-01481	-04195	0500	0500	0500	0000	0000	0000	0000	%0814	b14	\$
004402	-01655	-04829	0375	0375	0375	0000	0000	0000	0000	%0815	b15	\$
003976	-01463	-04986	0250	0250	0250	0000	0000	0000	0000	%0816	b16	\$
003919	-01272	-05031	0125	0125	0125	0000	0000	0000	0000	%0817	b17	\$
003702	-01255	-04835	0000	1000	1000	0000	0000	0000	0000	%0818	b18	\$
009666	-00461	-001876	1000	0875	0875	0000	0000	0000	0000	%0819	c10	\$
008907	000012	000004	0875	0875	0875	0000	0000	0000	0000	%0820	c11	\$
008043	-00444	-01755	0750	0750	0750	0000	0000	0000	0000	%0821	c12	\$
006688	-00813	-02964	0625	0625	0625	0000	0000	0000	0000	%0822	c13	\$
005404	-00939	-03896	0500	0500	0500	0000	0000	0000	0000	%0823	c14	\$
004361	-01186	-04664	0375	0375	0375	0000	0000	0000	0000	%0824	c15	\$
003917	-01288	-04963	0250	0250	0250	0000	0000	0000	0000	%0825	c16	\$
003744	-01122	-04841	0125	0125	0125	0000	0000	0000	0000	%0826	c17	\$
003488	-01053	-04519	0000	0875	0875	0000	0000	0000	0000	%0827	c18	\$
005959	-00722	-003297	1000	1000	1000	0000	0000	0000	0000	%0828	d10	\$
008941	-00498	-001681	0875	0875	0875	0000	0000	0000	0000	%0829	d11	

%BEG GE20_22.TXT, Separation olv*, D50, adapted \$
%100 x LAB*a %1000 x (r g b c m y 0) %nr. pos \$
%z005020 006808 004473 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z009398 -01090 009263 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005961 -05438 004015 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005508 -04407 -02373 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z003735 -01232 -04871 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z004995 007228 -00754 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z001468 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009732 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004970 006918 004597 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z009402 -01106 009124 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005979 -05266 003933 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005472 -04234 -02417 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003702 -01256 -04835 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z004970 007246 -00674 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z001432 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009737 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

TUB-test chart GE30; Relative Device Colour System G
1080 spectral reflexions R -> LAB* for D65 and D50

input: w *setgray*
output: -> *olv** *setrgbcolor*

TUB registration: 20091101-GE30/GE30L0NP.PDF /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

See original or copy: <http://web.me.com/klaus.richter/GE30/GE30L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG GE20_22.TXT, Separation olv*, D50, adapted \$																								
%100 x LAB*a										1000 x (r g b c m y θ)														
										%nr.	pos \$													
001353	-00001	000031	0000	0000	0000	1000	1000	1000	0000	%0972	k01 \$	000806	000022	-00013	0866	0866	0866	0133	0133	0133	0000	%1053	m23 \$	
001673	-00004	000013	0125	0125	0125	0875	0875	0875	0000	%0973	k02 \$	0009172	000019	000000	0933	0933	0933	0066	0066	0066	0000	%1054	m24 \$	
002610	-00019	000070	0250	0250	0250	0750	0750	0750	0000	%0974	k03 \$	0009721	000004	000000	1000	1000	1000	0000	0000	0000	0000	%1055	m25 \$	
003822	-00018	000106	0375	0375	0375	0625	0625	0625	0000	%0975	k04 \$	001628	000012	000000	0000	0000	0000	0000	1000	1000	0000	%1056	n10 \$	
005259	-00013	000108	0500	0500	0500	0500	0500	0500	0000	%0976	k05 \$	001370	000011	000016	0066	0066	0066	0933	0933	0933	0000	%1057	n11 \$	
006576	-00006	000090	0625	0625	0625	0375	0375	0375	0000	%0977	k06 \$	001806	000011	-00013	0133	0133	0133	0866	0866	0866	0000	%1058	n12 \$	
007717	000009	000051	0750	0750	0750	0250	0250	0250	0000	%0978	k07 \$	002397	000000	-00066	0200	0200	0200	0800	0800	0800	0000	%1059	n13 \$	
008845	000015	000100	0875	0875	0875	0125	0125	0125	0000	%0979	k08 \$	002904	-00007	-00094	0266	0266	0266	0333	0333	0333	0000	%1060	n14 \$	
009741	000005	000020	1000	1000	1000	0000	0000	0000	0000	%0980	k09 \$	003566	-00005	-00097	0333	0333	0333	0666	0666	0666	0000	%1061	n15 \$	
001402	000002	000022	0000	0000	0000	0000	0000	0000	0000	%0981	l01 \$	004210	-00003	-00098	0400	0400	0400	0600	0600	0600	0000	%1062	n16 \$	
001754	000007	000029	0125	0125	0125	0875	0875	0875	0000	%0982	l02 \$	004817	000004	-00072	0466	0466	0466	0533	0533	0533	0000	%1063	n17 \$	
002608	-00012	000066	0250	0250	0250	0750	0750	0750	0000	%0983	l03 \$	005568	000000	-00072	0533	0533	0533	0466	0466	0466	0000	%1064	n18 \$	
003233	-00015	000116	0375	0375	0375	0625	0625	0625	0000	%0984	l04 \$	006379	000002	-00076	0600	0600	0600	0600	0400	0400	0000	%1065	n19 \$	
005443	-00010	000121	0500	0500	0500	0500	0500	0500	0000	%0985	l05 \$	006976	000000	-00062	0666	0666	0666	0333	0333	0333	0000	%1066	n20 \$	
006590	-00003	000107	0625	0625	0625	0375	0375	0375	0000	%0986	l06 \$	007524	000015	-00046	0734	0734	0734	0266	0266	0266	0000	%1067	n21 \$	
007743	000008	000055	0750	0750	0750	0250	0250	0250	0000	%0987	l07 \$	008085	000023	-00014	0800	0800	0800	0200	0200	0200	0000	%1068	n22 \$	
008857	000017	000015	0875	0875	0875	0125	0125	0125	0000	%0988	l08 \$	008616	000025	-00003	0866	0866	0866	0133	0133	0133	0000	%1069	n23 \$	
009739	000003	000114	1000	1000	1000	0000	0000	0000	0000	%0989	l09 \$	009179	000020	-00002	0933	0933	0933	0066	0066	0066	0000	%1070	n24 \$	
001314	000003	000036	0000	0000	0000	0000	0000	0000	0000	%0990	m01 \$	009706	000010	-00012	1000	1000	1000	0000	0000	0000	0000	%1071	n25 \$	
001681	000009	000023	0125	0125	0125	0875	0875	0875	0000	%0991	m02 \$	001308	000000	000000	0000	0000	0000	1000	1000	1000	0000	%1072	k26 \$	
002502	-00009	000101	0250	0250	0250	0750	0750	0750	0000	%0992	m03 \$	009742	000000	000000	1000	1000	1000	0000	0000	0000	0000	%1073	k27 \$	
003018	-00013	000104	0375	0375	0375	0625	0625	0625	0000	%0993	m04 \$	004965	000024	004673	1000	0000	0000	0000	1000	1000	0000	%1074	l26 \$	
005171	-00009	000109	0500	0500	0500	0500	0500	0500	0000	%0994	m05 \$	005765	-04720	-01695	0000	1000	1000	1000	0000	0000	0000	%1075	l27 \$	
006589	000001	000101	0625	0625	0625	0375	0375	0375	0000	%0995	m06 \$	009398	-01093	009434	1000	1000	0000	0000	0000	1000	0000	%1076	m26 \$	
007697	000013	000056	0750	0750	0750	0250	0250	0250	0000	%0996	m07 \$	003719	-01079	-04811	0000	0000	1000	1000	1000	0000	0000	%1077	m27 \$	
008841	000014	000004	0875	0875	0875	0125	0125	0125	0000	%0997	m08 \$	005990	-05460	004127	0000	0000	0000	1000	0000	0000	0000	%1078	n26 \$	
009734	000004	000110	1000	1000	1000	0000	0000	0000	0000	%0998	m09 \$	004959	007292	-00776	1000	0000	1000	0000	1000	0000	0000	%1079	n27 \$	
001296	000007	000048	0000	0000	0000	0000	0000	0000	0000	%0999	n01 \$	%												
001675	000003	000038	0125	0125	0125	0875	0875	0875	0000	%1000	n02 \$	%004965	006924	004673	%#1000	0000	0000	0000	0000	1000	1000	0000	%1074	l26 %03 0 \$
002545	-00011	000055	0250	0250	0250	0750	0750	0750	0000	%1001	n03 \$	%009398	-01093	009434	%#1000	1000	0000	0000	0000	1000	0000	0000	%1076	m26 %Y3 1 \$
003763	-00012	000085	0375	0375	0375	0625	0625	0625	0000	%1002	n04 \$	%005990	-05460	004127	%#0000	1000	0000	1000	0000	1000	0000	0000	%1078	n26 %L3 2 \$
005184	-00008	000102	0500	0500	0500	0500	0500	0500	0000	%1003	n05 \$	%005765	-04720	-01695	%#0000	1000	1000	1000	0000	0000	0000	0000	%1075	l27 %C3 3 \$
006533	000003	000090	0625	0625	0625	0375	0375	0375	0000	%1004	n06 \$	%003719	-01079	-04811	%#0000	0000	1000	1000	1000	0000	0000	0000	%1077	m27 %W3 4 \$
007716	000013	000048	0750	0750	0750	0250	0250	0250	0000	%1005	n07 \$	%004959	007292	-00776	%#1000	0000	1000	0000	1000	0000	0000	0000	%1079	n27 %M3 5 \$
008849	000020	000008	0875	0875	0875	0125	0125	0125	0000	%1006	n08 \$	%001308	000000	000000	%#0000	0000	0000	1000	1000	1000	0000	0000	%1072	k26 %M3 6 \$
009729	000009	000017	1000	1000	1000	0000	0000	0000	0000	%1007	n09 \$	%009742	000000	000000	%#1000	1000	1000	0000	0000	0000	0000	0000	%1073	k27 %W3 7 \$
001806	000006	000010	0000	0000	0000	0000	0000	0000	0000	%1008	k10 \$	%												
001550	000013	000002	0066	0066	0066	0933	0933	0933	0000	%1009	k11 \$	%001353	-00001	000031	%#0000	0000	0000	1000	1000	1000	0000	0000	%0972	k01 %N4 6 \$
001926	000000	000048	0133	0133	0133	0866	0866	0866	0000	%1010	k12 \$	%009741	000005	-00020	%#1000	1000	1000	0000	0000	0000	0000	0000	%0980	k09 %M4 7 \$
002460	-00006	000089	0200	0200	0200	0800	0800	0800	0000	%1011	k13 \$	%												
002977	-00008	000113	0266	0266	0266	0333	0333	0333	0000	%1012	k14 \$	%001402	000002	000022	%#0000	0000	0000	1000	1000	1000	0000	0000	%0981	l01 %N5 6 \$
003619	-00010	000119	0333	0333	0333	0666	0666	0666	0000	%1013	k15 \$	%009739	000003	-00014	%#1000	1000	1000	0000	0000	0000	0000	0000	%0989	l09 %M5 7 \$
004232	-00006	000104	0400	0400	0400	0600	0600	0600	0000	%1014	k16 \$	%												
004882	000000	000095	0466	0466	0466	0533	0533	0533	0000	%1015	k17 \$	%001314	000003	000036	%#0000	0000	0000	1000	1000	1000	0000	0000	%0990	m01 %M6 6 \$
005635	000000	000087	0533	0533	0533	0466	0466	0466	0000	%1016	k18 \$	%009734	000004	-00010	%#1000	1000	1000	0000	0000	0000	0000	0000	%0998	m09 %M6 7 \$
006222	000000	000099	0600	0600	0600	0400	0400	0400	0000	%1017	k19 \$	%												
007040	000008	000092	0666	0666	0666	0333	0333	0333	0000	%1018	k20 \$	%001296	000007	000048	%#0000	0000	0000	1000	1000	1000	0000	0000	%0999	n01 %M7 6 \$
007610	000008	000040	0734	0734	0734	0266	0266	0266	0000	%1019	k21 \$	%009729	000009	-00017	%#1000	1000	1000	0000	0000	0000	0000	0000	%1007	n09 %M7 7 \$
008165	000015	000108	0800	0800	0800	0200	0200	0200	0000	%1020	k22 \$	%												
008666	000016	000007	0866	0866	0866	0133	0133	0133	0000	%1021	k23 \$	%												
009211	000012	000007	0933	0933	0933	0066	0066	0066	0000	%1022	k24 \$	%												
009727	000005	000110	1000	1000	1000	0000	0000	0000	0000	%1023	k25 \$	%												
001840	000008	000015	0000	0000	0000	0000	0000	0000	0000	%1024	l10 \$	%												
001604	000011	000007	0066	0066	0066	0933	0933	0933	0000	%1025	l11 \$	%												
001982	000007	000300	0133	0133	0133	0866	0866	0866	0000	%1026	l12 \$	%												
002497	-00009	000085	0200	0200	0200	0800	0800	0800	0000	%1027	l13 \$	%												
003011	-00011	000108	0266	0266	0266	0333	0333	0333	0000	%1028	l14 \$	%												
003626	-00008	000117	0333	0333	0333	0666	0666	0666	0000	%1029	l15 \$	%												
004254	-00005	000114	0400	0400	0400	0600	0600	0600	0000	%1030	l16 \$	%												
004912	000003	000109	0466	0466	0466	0533	0533	0533																