

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE34/GE34L0NA.TXT> /PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

002707	003005	001727	0375	0000	0000	0625	1000	1000	0000	%0243	A10	\$
002657	003111	000960	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$
002613	003305	000232	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$
002726	003784	-00716	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$
002792	003771	-01369	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$
002880	003845	-01818	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$
002934	004071	-02342	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$
003146	004273	-02774	0375	0000	0875	0625	1000	0125	0000	%0250	A17	\$
003274	004467	-03002	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$
003112	001987	002632	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$
003598	001985	001951	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$
003509	002447	000514	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$
003559	003075	-00924	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$
003474	003218	-01642	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$
003518	003345	-02247	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$
003619	003669	-02787	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$
003557	003992	-03180	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$
003619	003819	-03236	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$
003667	000441	003485	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$
004450	000314	002773	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$
004366	000858	000962	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$
004447	001332	-00751	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$
004328	001642	-01673	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$
004301	002009	-02312	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$
004415	002085	-02740	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$
004121	002873	-03381	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$
004022	002859	-03495	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$
004789	-00827	004710	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$
005432	-00987	003768	0375	0375	0125	0625	0625	0875	0000	%0271	D11	\$
005348	-00656	001648	0375	0375	0250	0625	0625	0750	0000	%0272	D12	\$
005190	-00014	000903	0375	0375	0375	0625	0625	0625	0000	%0273	D13	\$
004931	000234	-01455	0375	0375	0500	0625	0625	0500	0000	%0274	D14	\$
004967	000660	-02110	0375	0375	0625	0625	0625	0375	0000	%0275	D15	\$
004978	000948	-02607	0375	0375	0750	0625	0625	0250	0000	%0276	D16	\$
004884	001637	-03357	0375	0375	0875	0625	0625	0125	0000	%0277	D17	\$
004595	001858	-03487	0375	0375	1000	0625	0625	0000	0000	%0278	D18	\$
004834	-01590	004624	0375	0500	0000	0625	0500	1000	0000	%0279	E10	\$
005679	-01792	004001	0375	0500	0125	0625	0500	0875	0000	%0280	E11	\$
005704	-01589	001998	0375	0500	0250	0625	0500	0750	0000	%0281	E12	\$
005684	-01301	000567	0375	0500	0375	0625	0500	0625	0000	%0282	E13	\$
005612	-00899	-01145	0375	0500	0500	0625	0500	0500	0000	%0283	E14	\$
005470	-00455	-01957	0375	0500	0625	0625	0500	0375	0000	%0284	E15	\$
005491	-00265	-02425	0375	0500	0750	0625	0500	0250	0000	%0285	E16	\$
005607	000204	-03149	0375	0500	0875	0625	0500	0125	0000	%0286	E17	\$
005200	000787	-03427	0375	0500	1000	0625	0500	0000	0000	%0287	E18	\$
005315	-02572	004783	0375	0625	0000	0625	0375	1000	0000	%0288	F10	\$
006020	-02664	004237	0375	0625	0125	0625	0375	0875	0000	%0289	F11	\$
006078	-02459	002307	0375	0625	0250	0625	0375	0750	0000	%0290	F12	\$
006048	-02182	000813	0375	0625	0375	0625	0375	0625	0000	%0291	F13	\$
006155	-01804	-00337	0375	0625	0500	0625	0375	0500	0000	%0292	F14	\$
006103	-01496	-01620	0375	0625	0625	0625	0375	0375	0000	%0293	F15	\$
006006	-01116	-02402	0375	0625	0750	0625	0375	0250	0000	%0294	F16	\$
006073	-00838	-02844	0375	0625	0875	0625	0375	0125	0000	%0295	F17	\$
005673	-00475	-03508	0375	0625	1000	0625	0375	0000	0000	%0296	F18	\$
006124	-03306	005367	0375	0750	0000	0625	0250	1000	0000	%0297	G10	\$
006486	-03451	004580	0375	0750	0125	0625	0250	0875	0000	%0298	G11	\$
006523	-03138	002658	0375	0750	0250	0625	0250	0750	0000	%0299	G12	\$
006475	-02921	001442	0375	0750	0375	0625	0250	0625	0000	%0300	G13	\$
006606	-02534	000404	0375	0750	0500	0625	0250	0500	0000	%0301	G14	\$
006519	-02258	-00948	0375	0750	0625	0625	0250	0375	0000	%0302	G15	\$
006538	-01975	-02085	0375	0750	0750	0625	0250	0250	0000	%0303	G16	\$
006535	-01562	-02749	0375	0750	0875	0625	0250	0125	0000	%0304	G17	\$
006492	-01431	-03223	0375	0750	1000	0625	0250	0000	0000	%0305	G18	\$
006669	-04128	005631	0375	0875	0000	0625	0125	1000	0000	%0306	H10	\$
007029	-04134	004930	0375	0875	0125	0625	0125	0875	0000	%0307	H11	\$
006984	-03801	002888	0375	0875	0250	0625	0125	0750	0000	%0308	H12	\$
007074	-03649	001980	0375	0875	0375	0625	0125	0625	0000	%0309	H13	\$
007168	-03377	000877	0375	0875	0500	0625	0125	0500	0000	%0310	H14	\$
007104	-03041	-00015	0375	0875	0625	0625	0125	0375	0000	%0311	H15	\$
007012	-02706	-01182	0375	0875	0750	0625	0125	0250	0000	%0312	H16	\$
006920	-02236	-02537	0375	0875	0875	0625	0125	0125	0000	%0313	H17	\$
006920	-01864	-03027	0375	0875	1000	0625	0125	0000	0000	%0314	H18	\$
006920	-04507	005757	0375	1000	0000	0625	0000	1000	0000	%0315	I10	\$
006952	-04372	004762	0375	1000	0125	0625	0000	0875	0000	%0316	I11	\$
007088	-03980	003032	0375	1000	0250	0625	0000	0750	0000	%0317	I12	\$
007016	-03882	002228	0375	1000	0375	0625	0000	0625	0000	%0318	I13	\$
007038	-03673	001344	0375	1000	0500	0625	0000	0500	0000	%0319	I14	\$
007076	-03274	000226	0375	1000	0625	0000	0000	0375	0000	%0320	I15	\$
007046	-02960	-00826	0375	1000	0750	0625	0000	0250	0000	%0321	I16	\$
007031	-02577	-01698	0375	1000	0875	0625	0000	0125	0000	%0322	I17	\$
006916	-02241	-02680	0375	1000	1000	0625	0000	0000	0000	%0323	I18	\$
003102	003805	002285	0500	0000	0000	0500	1000	1000	0000	%0324	J10	\$
003103	003779	001757	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$
003035	003880	000940	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$
003024	004129	-00129	0									

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

003885	004933	002781	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$	004301	005548	003414	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$	004653	006103	003873	1000	0000	0000	0000	1000	1000	0000	%0648	S19	\$
003796	004922	002450	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$	004259	005557	003052	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$	004591	006100	003424	1000	0000	0125	0000	1000	0875	0000	%0649	S20	\$
003756	005027	001887	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$	004166	005620	002405	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$	004523	006145	002753	1000	0000	0250	0000	1000	0750	0000	%0650	S21	\$
003681	005144	001183	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$	004127	005728	001729	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$	004464	006217	002126	1000	0000	0375	0000	1000	0625	0000	%0651	S22	\$
003612	005314	000368	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$	004108	005876	001833	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$	004461	006369	001509	1000	0000	0500	0000	1000	0500	0000	%0652	S23	\$
003605	005495	-00538	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$	004080	006090	001688	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$	004491	006585	000863	1000	0000	0625	0000	1000	0375	0000	%0653	S24	\$
003590	005559	-01130	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$	004048	006338	-00704	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$	004509	006839	000047	1000	0000	0750	0000	1000	0250	0000	%0654	S25	\$
003739	-01687	0750	0000	0875	0250	1000	0875	0000	0000	%0493	A26	\$	004018	006386	-01309	0875	0000	1000	0125	1000	0125	0000	%0574	J26	\$	004592	007029	-00725	1000	0000	0875	0000	1000	0125	0000	%0655	S26	\$
003837	005918	-01992	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$	004102	006422	-01595	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$	004544	007025	-01032	1000	0000	1000	0000	1000	0000	%0656	S27	\$	
004385	005024	004326	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$	004976	005108	005032	0875	0125	0000	0125	0875	1000	0000	%0576	K10	\$	005262	005566	005397	1000	0125	0000	0875	1000	0000	%0657	T10	\$	
004451	004265	003405	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$	004937	005139	004197	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$	005126	005844	004741	1000	0125	0125	0000	0875	0875	0000	%0658	T20	\$
004393	004326	002341	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$	004832	005197	003006	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$	005050	006111	003678	1000	0125	0250	0000	0875	0750	0000	%0659	T21	\$
004248	004558	001567	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$	004744	005356	002212	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$	004959	006408	002726	1000	0125	0375	0000	0875	0625	0000	%0660	T22	\$
004268	004645	000710	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$	004644	005569	001390	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$	004942	006595	002020	1000	0125	0500	0000	0875	0500	0000	%0661	T23	\$
004178	005171	-00371	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$	004690	005869	000554	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$	004889	006912	001093	1000	0125	0625	0000	0875	0375	0000	%0662	T24	\$
004127	005537	-01277	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$	004618	006213	-00608	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$	004905	007153	000151	1000	0125	0750	0000	0875	0250	0000	%0663	T25	\$
004259	005493	-01846	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$	004671	006154	-01509	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$	004951	007372	-00636	1000	0125	0875	0000	0875	0125	0000	%0664	T26	\$
004345	005426	-02210	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$	004660	005891	-01774	0875	0125	1000	0125	0875	1000	0000	%0584	K27	\$	004957	006826	-01050	1000	0125	1000	0000	0875	0000	0000	%0665	T27	\$
005317	002744	005344	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$	005892	003233	005947	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$	006024	004035	006159	1000	0250	0000	0000	0750	1000	0000	%0666	U19	\$
005254	002787	004418	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$	005698	003440	004968	0875	0250	0125	0125	0750	0875	0000	%0586	L20	\$	005901	004290	005559	1000	0250	0125	0000	0750	0875	0000	%0667	U20	\$
005234	002871	002768	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$	005645	003577	003368	0875	0250	0250	0125	0750	0750	0000	%0587	L21	\$	005880	004429	004519	1000	0250	0250	0000	0750	0750	0000	%0668	U21	\$
005158	003062	001882	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$	005584	003784	002533	0875	0250	0375	0125	0750	0625	0000	%0588	L22	\$	005750	004874	003229	1000	0250	0375	0000	0750	0625	0000	%0669	U22	\$
005164	003239	000950	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$	005521	003922	001715	0875	0250	0500	0125	0750	0500	0000	%0589	L23	\$	005654	005228	002400	1000	0250	0500	0000	0750	0500	0000	%0670	U23	\$
005122	003707	-00111	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$	005522	004263	000826	0875	0250	0625	0125	0750	0375	0000	%0590	L24	\$	005672	005417	001457	1000	0250	0625	0000	0750	0375	0000	%0671	U24	\$
004977	004060	-01202	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$	005511	004636	-00226	0875	0250	0750	0125	0750	0250	0000	%0591	L25	\$	005683	005729	000378	1000	0250	0750	0000	0750	0250	0000	%0672	U25	\$
005075	004341	-01772	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$	005464	004830	-01358	0875	0250	0875	0125	0750	0125	0000	%0592	L26	\$	005788	005961	-00725	1000	0250	0875	0000	0750	0125	0000	%0673	U26	\$
004915	004504	-02267	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$	005375	004950	-01706	0875	0250	1000	0125	0750	0000	0000	%0593	L27	\$	005802	005595	-01138	1000	0250	1000	0000	0750	0000	0000	%0674	U27	\$
005773	001541	005847	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$	006495	002337	006510	0875	0375	0000	0125	0625	1000	0000	%0594	M19	\$	006526	002881	006709	1000	0375	0000	0000	0625	1000	0000	%0675	V19	\$
005898	001655	005318	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$	006298	002386	005314	0875	0375	0125	0125	0625	0875	0000	%0595	M20	\$	006628	003107	005973	1000	0375	0125	0000	0625	0875	0000	%0676	V20	\$
005974	001677	003284	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$	006295	002483	003675	0875	0375	0250	0125	0625	0750	0000	%0596	M21	\$	006465	003316	005002	1000	0375	0250	0000	0625	0750	0000	%0677	V21	\$
005935	001857	002236	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$	006234	002650	002689	0875	0375	0375	0125	0625	0625	0000	%0597	M22	\$	006462	003534	003579	1000	0375	0375	0000	0625	0625	0000	%0678	V22	\$
005886	002068	001356	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$	006220	002890	001958	0875	0375	0500	0125	0625	0500	0000	%0598	M23	\$	006459	003741	002718	1000	0375	0500	0000	0625	0500	0000	%0679	V23	\$
005847	002508	000134	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$	006215	003075	001122	0875	0375	0625	0125	0625	0375	0000	%0599	M24	\$	006424	004037	001781	1000	0375	0625	0000	0625	0375	0000	%0680	V24	\$
005702	002909	-01079	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$	006124	003681	-00063	0875	0375	0750	0125	0625	0250	0000	%0600	M25	\$	006448	004316	000747	1000	0375	0750	0000	0625	0250	0000	%0681	V25	\$
005701	003605	-01719	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$	006101	003926	-01292	08																						

009748	-00097	000194	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009081	-00768	-00521	0875	1000	1000	0000	0000	0000	0000	%0730	b02	\$
008540	-01121	-01203	0750	1000	1000	0000	0000	0000	0000	%0731	b03	\$
008056	-01435	-01728	0625	1000	1000	0000	0000	0000	0000	%0732	b04	\$
007517	-01735	-02287	0500	1000	1000	0000	0000	0000	0000	%0733	b05	\$
006953	-02093	-02677	0375	1000	1000	0000	0000	0000	0000	%0734	b06	\$
006129	-02673	-03168	0250	1000	1000	0000	0000	0000	0000	%0735	b07	\$
005556	-03161	-03440	0125	1000	1000	0000	0000	0000	0000	%0736	b08	\$
005168	-03287	-03761	0000	1000	1000	0000	0000	0000	0000	%0737	b09	\$
009162	000284	001074	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
008928	-00076	000200	0875	0875	0875	0000	0125	0125	0000	%0739	c02	\$
008575	-00857	-00839	0750	0875	0875	0000	0125	0125	0000	%0740	c03	\$
008209	-01351	-01394	0625	0875	0875	0000	0125	0125	0000	%0741	c04	\$
007650	-01735	-01948	0500	0875	0875	0000	0125	0125	0000	%0742	c05	\$
007064	-02044	-02518	0375	0875	0875	0000	0625	0125	0000	%0743	c06	\$
006447	-02333	-02787	0250	0875	0875	0000	0750	0125	0000	%0744	c07	\$
005773	-03053	-03210	0125	0875	0875	0000	0875	0125	0000	%0745	c08	\$
005046	-03453	-03625	0000	0875	0875	0000	1000	0125	0000	%0746	c09	\$
008678	000734	001562	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
008174	000497	000896	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
007918	-00050	000139	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
007572	-00835	-00954	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
007153	-01365	-01514	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
006609	-01793	-02091	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
006043	-02060	-02491	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005578	-02800	-02961	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
004998	-03794	-03328	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007993	001438	002243	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007624	000851	001770	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
007375	000568	000764	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
007080	-00041	000085	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
006714	-00798	-01113	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
006182	-01305	-01584	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
005595	-01710	-02210	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
005217	-02350	-02761	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
004800	-03584	-03294	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
007277	002313	002932	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006990	001626	002264	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006732	001012	001690	0750	0500	0500	0000	0250	0500	0000	%0767	f03	\$
006416	000609	000721	0625	0500	0500	0000	0375	0500	0000	%0768	f04	\$
006126	-00031	000065	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005694	-00829	-01128	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
005217	-01438	-01869	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004819	-01897	-02586	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
004432	-02872	-03384	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
006462	003556	003471	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
006246	002607	002679	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005927	001898	002073	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
005605	001301	001538	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
005315	000687	000754	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
005113	-00014	000049	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
004713	-01013	-01452	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
004513	-01579	-02083	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003874	-02639	-03012	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
005931	004337	004400	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005636	003493	003446	0875	0250	0250	0500	0125	0750	0000	%0784	h02	\$
005209	002843	002798	0750	0250	0250	0500	0250	0750	0000	%0785	h03	\$
004858	002214	002367	0625	0250	0250	0750	0375	0750	0000	%0786	h04	\$
004531	001482	001758	0500	0250	0250	0500	0500	0750	0000	%0787	h05	\$
004280	000895	000958	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
003964	000081	000035	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
003944	-01133	-01571	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
003397	-02069	-02726	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
005148	005839	004599	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004911	005015	004039	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
004465	004166	003333	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
003967	004034	003390	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
003733	002985	002640	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
003583	001961	001959	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
003365	001138	001302	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
002496	000024	000042	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
002876	-01558	-02199	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
004582	006095	003741	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
004141	005423	003305	0875	0000	0000	0125	1000	1000	0000	%0802	j02	\$
003801	004837	002739	0750	0000	0000	0250	1000	1000	0000	%0803	j03	\$
003378	004239	002481	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
003059	003589	001994	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
002726	002904	001604	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
002401	002351	001959	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
002151	001609	000867	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
001461	000042	000115	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009730	-00094	000190	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
008865	000057	-00660	0875	0875	1000	0125	0125	0000	0000	%0811	b11	\$
007932	000192	-01479	0750	0750	0750	0250	0250	0000	0000	%0812	b12	\$
006837	000614	-02175	0625	0625	1000	0375	0375	0000	0000	%0813	b13	\$
006567	001178	-02895	0500	0500	0500	0500	0500	0000	0000	%0814	b14	\$
004698	001804	-03344	0375	0375	1000	0625	0625	0000	0000	%0815	b15	\$
003795	002302	-03750	0250	0250	1000	0750	0750	0000	0000	%0816	b16	\$
003428	-03085	-03805	0125	0250	1000	0875	0875	0000	0000	%0817	b17	\$
003119	002484	-03859	0000	1000	1000	1000	1000	0000	0000	%0818	b18	\$
009659	-00682	001778	1000	1000	0875	0000	0125	0000	0000	%0819	c10	\$
009022	-00067	000175	0875	0875	0875	0125	0125	0250	0000	%0820	c11	\$
008807	000028	-00998	0750	0750	0875	0250	0250	0125	0000	%0821	c12	\$
007956	000449	-01757	0625	0625	0875	0375	0375	0125	0000	%0822	c13	\$
006010	001009	-02634	0500	0500	0875	0500	0500	0125	0000	%0823	c14	\$
004880	001656	-03257	0375	0375	0875	0625	0625	0125	0000	%0824	c15	\$
003899	002161	-03729	0250	0250	0875	0750	0750	0125	0000	%0825	c16	\$
003383	002380	-03897	0125	0125	0875	0875	0875	0125	0000	%0826	c17	\$
002868	002502	-04000	0000	0000	0750	1000	1000	0125	0000	%0827	c18	\$
005953	-01067	003130	1000	1000	0750	0000	0250	0000	0000	%0828	d10	\$
009004	-00516	000153	0875	0875	0750	0125	0125	0250	0000</			

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

%BEG GE24_22_REM.TXT, Separation cmyn5*, D65, not adapted \$
%100 x LAB*
%#1000 x (r g b c m y 0) %nr. pos \$
%z004653 006103 003873 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z009172 -01489 008585 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005674 -06397 003651 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005166 -03398 -03712 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z003145 002329 -04174 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z004544 007025 -01032 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z001537 000030 000141 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009713 -00086 000197 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004582 006095 003741 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z009159 -01496 008613 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005670 -06134 003467 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005169 -03287 -03761 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003119 002484 -03959 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z004514 006991 -00967 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z001589 000043 000096 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009737 -00097 000195 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

TUB-test chart GE34; Relative Device Colour System G
1080 spectral reflexions R -> LAB* for D65 and D50

input: w *setgray*
output: -> *olv* setrgbcolor*

TUB registration: 20091101-GE34/GE34L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems

TUB material: code=rh4ta

See original or copy: <http://web.me.com/klaus.richter/GE34/GE34L0NA.TXT /.PS>
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

See original or copy: <http://web.me.com/klaus.richter/GE34/GE34L0NA.TXT> / PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.0

TUB material: code=rh4ta
r systems

KBEG GE24_22_REM.TXT, Separation cmyrn's, D65, not adapted S																
%100 x LAB*	1000 x (r g b c m y)	%nr.	pos	\$												
001525	000023	000113	0000	0000	1000	1000	1000	0000	0000	00972	k01	\$				
002201	000017	000068	0125	0125	0125	0875	0875	0800	0000	00973	k02	\$				
003841	-00013	000014	0250	0250	0250	0750	0750	0750	0000	00974	k03	\$				
005045	-00025	000030	0375	0375	0375	0625	0625	0625	0000	00975	k04	\$				
006137	-00036	000042	0500	0500	0500	0500	0500	0500	0000	00976	k05	\$				
007156	-00043	000079	0625	0625	0625	0375	0375	0375	0000	00977	k06	\$				
008024	-00048	000128	0750	0750	0750	0250	0250	0250	0000	00978	k07	\$				
000910	-00069	000177	0875	0875	0875	0125	0125	0125	0000	00979	k08	\$				
009724	-00100	000178	1000	1000	1000	0000	0000	0000	0000	00980	k09	\$				
001516	000026	000113	0000	0000	0000	0000	0000	0000	0000	00981	l01	\$				
002189	000021	000066	0125	0125	0125	0875	0875	0875	0000	00982	l02	\$				
003281	-00010	000013	0250	0250	0250	0750	0750	0750	0000	00983	l03	\$				
004975	-00017	000032	0375	0375	0375	0625	0625	0625	0000	00984	l04	\$				
006057	-00028	000046	0500	0500	0500	0500	0500	0500	0000	00985	l05	\$				
007885	-00040	000081	0625	0625	0625	0375	0375	0375	0000	00986	l06	\$				
007903	-00046	000134	0750	0750	0750	0250	0250	0250	0000	00987	l07	\$				
009024	-00072	000187	0875	0875	0875	0125	0125	0125	0000	00988	l08	\$				
009720	-00105	000200	1000	1000	1000	0000	0000	0000	0000	00989	l09	\$				
000150	000000	000108	0000	0000	0000	1000	1000	1000	0000	00990	m01	\$				
002121	000018	000055	0125	0125	0125	0875	0875	0875	0000	00991	m02	\$				
003825	-00003	000018	0250	0250	0250	0750	0750	0750	0000	00992	m03	\$				
004993	-00017	000040	0375	0375	0375	0625	0625	0625	0000	00993	m04	\$				
006052	-00030	000051	0500	0500	0500	0500	0500	0500	0000	00994	m05	\$				
007079	-00042	000089	0625	0625	0625	0375	0375	0375	0000	00995	m06	\$				
007986	-00049	000142	0750	0750	0750	0250	0250	0250	0000	00996	m07	\$				
009021	-00074	000195	0875	0875	0875	0125	0125	0125	0000	00997	m08	\$				
009727	-00103	000202	1000	1000	1000	0000	0000	0000	0000	00998	m09	\$				
001305	000031	000120	0000	0000	0000	1000	1000	1000	0000	00999	n01	\$				
002114	000019	000067	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$				
003756	-00005	000032	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$				
004960	-00016	000054	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$				
005996																

TUB-test chart GE34; Relative Device Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

1. $\frac{1}{2}$ 2. $\frac{1}{3}$ 3. $\frac{1}{4}$ 4. $\frac{1}{5}$ 5. $\frac{1}{6}$ 6. $\frac{1}{7}$ 7. $\frac{1}{8}$ 8. $\frac{1}{9}$ 9. $\frac{1}{10}$ 10. $\frac{1}{11}$ 11. $\frac{1}{12}$ 12. $\frac{1}{13}$ 13. $\frac{1}{14}$ 14. $\frac{1}{15}$ 15. $\frac{1}{16}$ 16. $\frac{1}{17}$ 17. $\frac{1}{18}$ 18. $\frac{1}{19}$ 19. $\frac{1}{20}$ 20. $\frac{1}{21}$ 21. $\frac{1}{22}$ 22. $\frac{1}{23}$ 23. $\frac{1}{24}$ 24. $\frac{1}{25}$ 25. $\frac{1}{26}$ 26. $\frac{1}{27}$ 27. $\frac{1}{28}$ 28. $\frac{1}{29}$ 29. $\frac{1}{30}$ 30. $\frac{1}{31}$ 31. $\frac{1}{32}$ 32. $\frac{1}{33}$ 33. $\frac{1}{34}$ 34. $\frac{1}{35}$ 35. $\frac{1}{36}$ 36. $\frac{1}{37}$ 37. $\frac{1}{38}$ 38. $\frac{1}{39}$ 39. $\frac{1}{40}$ 40. $\frac{1}{41}$ 41. $\frac{1}{42}$ 42. $\frac{1}{43}$ 43. $\frac{1}{44}$ 44. $\frac{1}{45}$ 45. $\frac{1}{46}$ 46. $\frac{1}{47}$ 47. $\frac{1}{48}$ 48. $\frac{1}{49}$ 49. $\frac{1}{50}$ 50. $\frac{1}{51}$ 51. $\frac{1}{52}$ 52. $\frac{1}{53}$ 53. $\frac{1}{54}$ 54. $\frac{1}{55}$ 55. $\frac{1}{56}$ 56. $\frac{1}{57}$ 57. $\frac{1}{58}$ 58. $\frac{1}{59}$ 59. $\frac{1}{60}$ 60. $\frac{1}{61}$ 61. $\frac{1}{62}$ 62. $\frac{1}{63}$ 63. $\frac{1}{64}$ 64. $\frac{1}{65}$ 65. $\frac{1}{66}$ 66. $\frac{1}{67}$ 67. $\frac{1}{68}$ 68. $\frac{1}{69}$ 69. $\frac{1}{70}$ 70. $\frac{1}{71}$ 71. $\frac{1}{72}$ 72. $\frac{1}{73}$ 73. $\frac{1}{74}$ 74. $\frac{1}{75}$ 75. $\frac{1}{76}$ 76. $\frac{1}{77}$ 77. $\frac{1}{78}$ 78. $\frac{1}{79}$ 79. $\frac{1}{80}$ 80. $\frac{1}{81}$ 81. $\frac{1}{82}$ 82. $\frac{1}{83}$ 83. $\frac{1}{84}$ 84. $\frac{1}{85}$ 85. $\frac{1}{86}$ 86. $\frac{1}{87}$ 87. $\frac{1}{88}$ 88. $\frac{1}{89}$ 89. $\frac{1}{90}$ 90. $\frac{1}{91}$ 91. $\frac{1}{92}$ 92. $\frac{1}{93}$ 93. $\frac{1}{94}$ 94. $\frac{1}{95}$ 95. $\frac{1}{96}$ 96. $\frac{1}{97}$ 97. $\frac{1}{98}$ 98. $\frac{1}{99}$ 99. $\frac{1}{100}$ 100. $\frac{1}{101}$ 101. $\frac{1}{102}$ 102. $\frac{1}{103}$ 103. $\frac{1}{104}$ 104. $\frac{1}{105}$ 105. $\frac{1}{106}$ 106. $\frac{1}{107}$ 107. $\frac{1}{108}$ 108. $\frac{1}{109}$ 109. $\frac{1}{110}$ 110. $\frac{1}{111}$ 111. $\frac{1}{112}$ 112. $\frac{1}{113}$ 113. $\frac{1}{114}$ 114. $\frac{1}{115}$ 115. $\frac{1}{116}$ 116. $\frac{1}{117}$ 117. $\frac{1}{118}$ 118. $\frac{1}{119}$ 119. $\frac{1}{120}$ 120. $\frac{1}{121}$ 121. $\frac{1}{122}$ 122. $\frac{1}{123}$ 123. $\frac{1}{124}$ 124. $\frac{1}{125}$ 125. $\frac{1}{126}$ 126. $\frac{1}{127}$ 127. $\frac{1}{128}$ 128. $\frac{1}{129}$ 129. $\frac{1}{130}$ 130. $\frac{1}{131}$ 131. $\frac{1}{132}$ 132. $\frac{1}{133}$ 133. $\frac{1}{134}$ 134. $\frac{1}{135}$ 135. $\frac{1}{136}$ 136. $\frac{1}{137}$ 137. $\frac{1}{138}$ 138. $\frac{1}{139}$ 139. $\frac{1}{140}$ 140. $\frac{1}{141}$ 141. $\frac{1}{142}$ 142. $\frac{1}{143}$ 143. $\frac{1}{144}$ 144. $\frac{1}{145}$ 145. $\frac{1}{146}$ 146. $\frac{1}{147}$ 147. $\frac{1}{148}$ 148. $\frac{1}{149}$ 149. $\frac{1}{150}$ 150. $\frac{1}{151}$ 151. $\frac{1}{152}$ 152. $\frac{1}{153}$ 153. $\frac{1}{154}$ 154. $\frac{1}{155}$ 155. $\frac{1}{156}$ 156. $\frac{1}{157}$ 157. $\frac{1}{158}$ 158. $\frac{1}{159}$ 159. $\frac{1}{160}$ 160. $\frac{1}{161}$ 161. $\frac{1}{162}$ 162. $\frac{1}{163}$ 163. $\frac{1}{164}$ 164. $\frac{1}{165}$ 165. $\frac{1}{166}$ 166. $\frac{1}{167}$ 167. $\frac{1}{168}$ 168. $\frac{1}{169}$ 169. $\frac{1}{170}$ 170. $\frac{1}{171}$ 171. $\frac{1}{172}$ 172. $\frac{1}{173}$ 173. $\frac{1}{174}$ 174. $\frac{1}{175}$ 175. $\frac{1}{176}$ 176. $\frac{1}{177}$ 177. $\frac{1}{178}$ 178. $\frac{1}{179}$ 179. $\frac{1}{180}$ 180. $\frac{1}{181}$ 181. $\frac{1}{182}$ 182. $\frac{1}{183}$ 183. $\frac{1}{184}$ 184. $\frac{1}{185}$ 185. $\frac{1}{186}$ 186. $\frac{1}{187}$ 187. $\frac{1}{188}$ 188. $\frac{1}{189}$ 189. $\frac{1}{190}$ 190. $\frac{1}{191}$ 191. $\frac{1}{192}$ 192. $\frac{1}{193}$ 193. $\frac{1}{194}$ 194. $\frac{1}{195}$ 195. $\frac{1}{196}$ 196. $\frac{1}{197}$ 197. $\frac{1}{198}$ 198. $\frac{1}{199}$ 199. $\frac{1}{200}$ 200. $\frac{1}{201}$ 201. $\frac{1}{202}$ 202. $\frac{1}{203}$ 203. $\frac{1}{204}$ 204. $\frac{1}{205}$ 205. $\frac{1}{206}$ 206. $\frac{1}{207}$ 207. $\frac{1}{208}$ 208. $\frac{1}{209}$ 209. $\frac{1}{210}$ 210. $\frac{1}{211}$ 211. $\frac{1}{212}$ 212. $\frac{1}{213}$ 213. $\frac{1}{214}$ 214. $\frac{1}{215}$ 215. $\frac{1}{216}$ 216. $\frac{1}{217}$ 217. $\frac{1}{218}$ 218. $\frac{1}{219}$ 219. $\frac{1}{220}$ 220. $\frac{1}{221}$ 221. $\frac{1}{222}$ 222. $\frac{1}{223}$ 223. $\frac{1}{224}$ 224. $\frac{1}{225}$ 225. $\frac{1}{226}$ 226. $\frac{1}{227}$ 227. $\frac{1}{228}$ 228. $\frac{1}{229}$ 229. $\frac{1}{230}$ 230. $\frac{1}{231}$ 231. $\frac{1}{232}$ 232. $\frac{1}{233}$ 233. $\frac{1}{234}$ 234. $\frac{1}{235}$ 235. $\frac{1}{236}$ 236. $\frac{1}{237}$ 237. $\frac{1}{238}$ 238. $\frac{1}{239}$ 239. $\frac{1}{240}$ 240.

See original or copy: <http://web.me.com/klaus.riecher/GEE34/GEE34L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1.1, Cx=0, cfl=1.00, nt=0.18; nx=1.0

1UB registration: 20091101-GE34/GE34L0NA.1X1/.PS 1UB material: code=rha4ta
 application for evaluation and measurement of printer or monitor systems

[illegible]

TUB-test chart GE34; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klau.s.richter/GE34/GE34L0NA.TXT> /PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

002657	002991	001578	0375	0000	0000	0060	0625	1000	1000	0000	%0243	A10 \$	003012	003797	002133	0500	0000	0000	0500	1000	1000	0000	%0324	J10 \$	003425	004374	002559	0625	0000	0000	0375	1000	1000	0000	%0405	S10
002787	003097	000811	0375	0000	0125	0625	1000	0875	0000	%0244	A11 \$	003103	003771	001605	0500	0000	0125	0500	1000	0875	0000	%0325	J11 \$	003476	004361	002166	0625	0000	0125	0375	1000	0875	0000	%0406	S11	
002613	003290	000803	0375	0000	0250	0625	1000	0750	0000	%0245	A12 \$	003035	003871	000788	0500	0000	0250	0500	1000	0750	0000	%0326	J12 \$	003440	004457	001450	0625	0000	0250	0375	1000	0750	0000	%0407	S12	
002726	003770	000866	0375	0000	0375	0625	1000	0625	0000	%0246	A13 \$	003024	004120	002811	0500	0000	0375	0500	1000	0625	0000	%0327	J13 \$	003397	004560	000401	0625	0000	0375	0375	1000	0625	0000	%0408	S13	
002792	003758	001519	0375	0000	0500	0625	1000	0500	0000	%0247	A14 \$	003115	004497	001850	0500	0000	0500	0500	1000	0500	0000	%0328	J14 \$	003400	004918	000451	0625	0000	0500	0375	1000	0500	0000	%0409	S14	
002880	003834	001969	0375	0000	0625	0625	1000	0375	0000	%0248	A15 \$	003181	004559	001612	0500	0000	0625	0500	1000	0375	0000	%0329	J15 \$	003458	005156	001121	0625	0000	0625	0375	1000	0375	0000	%0410	S15	
002934	004060	002493	0375	0000	0750	0625	1000	0250	0000	%0249	A16 \$	003245	004655	002176	0500	0000	0750	0500	1000	0250	0000	%0330	J16 \$	003542	005250	001690	0625	0000	0750	0375	1000	0250	0000	%0411	S16	
003146	004266	002927	0375	0000	0875	0625	1000	0125	0000	%0250	A17 \$	003394	004756	002592	0500	0000	0875	0500	1000	0125	0000	%0331	J17 \$	003652	005246	002208	0625	0000	0875	0375	1000	0125	0000	%0412	S17	
003274	004462	003156	0375	0000	1000	0625	1000	0000	0000	%0251	A18 \$	003501	004879	002833	0500	0000	1000	0500	1000	0000	0000	%0332	J18 \$	003744	005389	002462	0625	0000	1000	0375	1000	0000	0000	%0413	S18	
003112	001979	002480	0375	0125	0000	0625	0875	1000	0000	%0252	B10 \$	003471	002813	003076	0500	0125	0000	0500	0875	1000	0000	%0333	K10 \$	003761	003877	003512	0625	0125	0000	0375	0875	1000	0000	%0414	T10	
003598	001984	001795	0375	0125	0125	0625	0875	0875	0000	%0253	B11 \$	003744	003098	002677	0500	0125	0125	0500	0875	0875	0000	%0334	K11 \$	004017	004116	003396	0625	0125	0125	0375	0875	0875	0000	%0415	T11	
003509	002445	000359	0375	0125	0250	0625	0875	0750	0000	%0254	B12 \$	003785	002951	001132	0500	0125	0250	0500	0875	0750	0000	%0335	K12 \$	004115	003542	001730	0625	0125	0250	0375	0875	0750	0000	%0416	T12	
003559	003074	001079	0375	0125	0375	0625	0875	0625	0000	%0255	B13 \$	003784	003477	000878	0500	0125	0375	0500	0875	0625	0000	%0336	K13 \$	004056	003901	000704	0625	0125	0375	0375	0875	0625	0000	%0417	T13	
003474	003215	001797	0375	0125	0500	0625	0875	0500	0000	%0256	B14 \$	003746	004014	001134	0500	0125	0500	0500	0875	0500	0000	%0337	K14 \$	004016	004387	000368	0625	0125	0500	0375	0875	0500	0000	%0418	T14	
003518	003343	002402	0375	0125	0625	0625	0875	0375	0000	%0257	B15 \$	003737	004220	001782	0500	0125	0625	0500	0875	0375	0000	%0338	K15 \$	003987	004790	001198	0625	0125	0625	0375	0875	0375	0000	%0419	T15	
003619	003668	002943	0375	0125	0750	0625	0875	0250	0000	%0258	B16 \$	003855	004287	002392	0500	0125	0750	0500	0875	0250	0000	%0339	K16 \$	004063	004869	001909	0625	0125	0750	0375	0875	0250	0000	%0420	T16	
003557	003990	003335	0375	0125	0875	0625	0875	0125	0000	%0259	B17 \$	003833	004589	002965	0500	0125	0875	0500	0875	0125	0000	%0340	K17 \$	004153	005017	002396	0625	0125	0875	0375	0875	0125	0000	%0421	T17	
003619	003819	003392	0375	0125	1000	0625	0875	0000	0000	%0260	B18 \$	003796	004269	003135	0500	0125	1000	0500	0875	0000	0000	%0341	K18 \$	004107	004694	002774	0625	0125	1000	0375	0875	0000	0000	%0422	T18	
003667	000441	003329	0375	0250	0000	0625	0750	1000	0000	%0261	C10 \$	003998	001198	003736	0500	0250	0000	0500	0750	1000	0000	%0342	L10 \$	004457	002102	004264	0625	0250	0000	0375	0750	1000	0000	%0423	U10	
004450	000325	002612	0375	0250	0125	0625	0750	0875	0000	%0262	C11 \$	004723	001176	003235	0500	0250	0125	0500	0750	0875	0000	%0343	L11 \$	004897	002109	003924	0625	0250	0125	0375	0750	0875	0000	%0424	U11	
004366	000868	000801	0375	0250	0250	0625	0750	0750	0000	%0263	C12 \$	004608	001510	001530	0500	0250	0250	0500	0750	0750	0000	%0344	L12 \$	004959	002220	002046	0625	0250	0250	0375	0750	0750	0000	%0425	U12	
004447	001343	000912	0375	0250	0375	0625	0750	0625	0000	%0264	C13 \$	004646	001941	001959	0500	0250	0375	0500	0750	0625	0000	%0345	L13 \$	004894	002567	000936	0625	0250	0375	0375	0750	0625	0000	%0426	U13	
004328	001652	001833	0375	0250	0500	0625	0750	0500	0000	%0265	C14 \$	004647	002472	001944	0500	0250	0500	0500	0750	0625	0000	%0346	L14 \$	004865	002603	000808	0625	0250	0375	0375	0750	0625	0000	%0427	U14	
004301	002018	002473	0375	0250	0625	0625	0750	0375	0000	%0266	C15 \$	004560	002765	001818	0500	0250	0625	0500	0750	0375	0000	%0347	L15 \$	004862	003345	001243	0625	0250	0500	0625	0750	0375	0000	%0428	U15	
004415	002096	002902	0375	0250	0750	0625	0750	0250	0000	%0267	C16 \$	004614	002802	002432	0500	0250	0750	0500	0750	0250	0000	%0348	L16 \$	004945	003451	001733	0625	0250	0750	0375	0750	0250	0000	%0429	U16	
004121	002880	003540	0375	0250	0875	0625	0750	0125	0000	%0268	C17 \$	004430	003400	003153	0500	0250	0875	0500	0750	0125	0000	%0349	L17 \$	004884	003929	002593	0625	0250	0875	0375	0750	0125	0000	%0430	U17	
004022	002864	003654	0375	0250	1000	0625	0750	0000	0000	%0269	C18 \$	004278	003430	003246	0500	0250	1000	0500	0750	0000	0000	%0350	L18 \$	004549	003982	002806	0625	0250	1000	0375	0750	0000	0000	%0431	U18	
004789	000811	004546	0375	0375	0000	0625	0625	1000	0000	%0270	D10 \$	004701	000902	004468	0500	0375	0000	0500	0625	1000	0000	%0351	M10 \$	004962	000858	004747	0625	0375	0000	0375	0625	1000	0000	%0432	V10	
005432	000962	003599	0375	0375	0125	0625	0625	0875	0000	%0271	D11 \$	005372	000910	004098	0500	0375	0125	0500	0625	0875	0000	%0352	M11 \$	005092	000394	004463	0625	0375	0125	0375	0625	0875	0000	%0433	V11	
005348	000632	001480	0375	0375	0250	0625	0625	0750	0000	%0272	D12 \$	005530	000226	002141	0500	0375	0250	0500	0625	0750	0000	%0353														

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klau.s.richter/GE34/GE34L0NA.TXT> /PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

003885	004936	002623	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
003890	004924	002293	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
003756	005028	001730	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
003681	005144	001026	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
003612	005313	000212	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
003605	005494	-00693	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
003590	005558	-01286	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
003739	005733	-01844	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$
003937	005922	-02151	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$
004385	005935	004165	0750	0125	0000	0250	0875	1000	0000	%0495	B19	\$
004451	004276	003244	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
004393	004337	002179	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
004248	004567	001406	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
004268	004653	000549	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
004178	005179	-00477	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
004127	005544	-01437	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
004259	005501	-02006	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
004345	005436	-02371	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
005317	002767	005177	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
005254	002810	004251	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
005234	002893	002601	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
005158	003083	001716	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
005164	003261	000783	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
005122	003728	-00277	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
004977	004079	-01367	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
005075	004361	-01937	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
004915	004522	-02432	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
005773	001571	005676	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
005898	001687	005146	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005974	001710	003112	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
005935	001899	002065	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
005886	002100	001184	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
005847	002620	-00037	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
005702	003028	-01249	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$
005701	003634	-01889	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$
005471	003744	-02329	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$
006283	000674	006208	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
006460	000694	005854	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
006616	000681	003714	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
006591	000850	002734	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006528	001116	001625	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
006482	001600	000310	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
006291	002126	-01088	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
006396	002494	-01718	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
006263	002884	-02086	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
007242	-00284	007223	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
007262	-00294	006575	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
007301	-00249	004491	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
007282	-00049	003432	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
007199	000229	002345	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
007140	000665	000752	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
006981	001048	-00864	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
007073	001426	-01609	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$
006976	001772	-01967	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
008304	-01248	008366	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
008055	-01161	007510	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
008030	-01062	005296	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
007960	-00805	004172	0750	0750	0375	0250	0250	0625	0000	%0543	G22	\$
007911	-00796	003125	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007864	-00486	001509	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$
007701	000016	-00015	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$
007725	000183	-01286	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$
007709	000420	-01875	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$
008871	-01700	008063	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$
008595	-01865	008010	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$
008423	-01778	005451	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$
008355	-01745	004384	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$
008390	-01689	003523	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$
008347	-01461	002399	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$
008437	-01343	000841	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$
008447	-00904	-01093	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$
008396	-00960	-01635	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$
008864	-02324	008610	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$
008737	-02330	007281	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$
008721	-02377	005743	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$
008647	-02400	004835	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$
008596	-02348	003857	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$
008602	-02156	002636	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$
008719	-01852	001671	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$
008578	-01588	000026	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$
008447	-01178	-01469	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$
004301	005557	003254	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$
004259	005566											

See original or copy: <http://web.me.com/klaustrichter/GE34/GE34L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

009794	000000	000000	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009081	-00682	-00708	0875	1000	1000	0125	0000	0000	0000	%0730	b02	\$
008540	-01045	-01384	0750	1000	1000	0250	0000	0000	0000	%0731	b03	\$
008056	-01367	-01903	0625	1000	1000	0375	0000	0000	0000	%0732	b04	\$
007517	-01676	-02455	0500	1000	1000	0500	0000	0000	0000	%0733	b05	\$
006953	-02044	-02838	0375	1000	1000	0625	0000	0000	0000	%0734	b06	\$
006129	-02639	-03319	0250	1000	1000	0750	0000	0000	0000	%0735	b07	\$
005556	-03136	-03584	0125	1000	1000	0875	0000	0000	0000	%0736	b08	\$
005169	-03269	-03901	0000	1000	1000	1000	0000	0000	0000	%0737	b09	\$
009162	000371	000886	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
008928	000007	000014	0875	0875	0875	0125	0125	0125	0000	%0739	c02	\$
008575	-00780	-01020	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
008200	-01280	-01570	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
007650	-01674	-02118	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
007064	-01993	-02681	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
006447	-02293	-02943	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005773	-03025	-03357	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
005046	-03437	-03763	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
008678	000813	001380	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
008174	000567	000720	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
007918	000015	-00033	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
007572	-00775	-01123	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
007153	-01313	-01678	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
006609	-01750	-02248	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
006043	-02027	-02641	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005578	-02775	-03105	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
004998	-03778	-03466	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007993	001505	002069	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007624	000911	001600	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
007375	000625	000598	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
007080	000009	-00077	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
006714	-00753	-01271	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
006192	-01349	-01736	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
005595	-01693	-02355	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
005217	-02332	-02902	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
004800	-03572	-03429	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
007277	002367	002767	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006990	001676	002102	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006732	001057	001531	0750	0500	0500	0250	0500	0500	0000	%0767	f03	\$
006416	000649	000566	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
006126	000003	-00085	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005694	-00801	-01274	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
005217	-01419	-02009	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004819	-01885	-02722	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
004332	-02869	-03514	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
006462	003596	003315	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
006246	002644	002527	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005927	001930	001924	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
005605	001326	001393	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
005315	000708	000613	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
005113	000002	-00089	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
004713	-01003	-01587	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
004513	-01572	-02214	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003874	-02644	-03136	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
005931	004368	004251	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005636	003520	003301	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
005200	002862	002658	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
004850	002153	002231	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
004531	001489	001626	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
004280	000897	000829	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
003964	000000	-00090	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
003944	-01136	-01696	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
003397	-02081	-02844	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
005148	005857	004460	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004911	005028	003903	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
004465	004172	003292	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
003967	004032	003265	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
003733	002978	002518	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
003583	001952	001838	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
003365	001125	001184	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
002496	-00003	-00064	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
002876	-01579	-02311	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
004582	006103	003608	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
004141	005423	003177	0875	0000	0000	0125	1000	1000	0000	%0802	j02	\$
003801	004832	002616	0750	0000	0000	0250	1000	1000	0000	%0803	j03	\$
003378	004226	002363	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
003050	003570	001881	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
002701	002879	001494	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
002426	002322	000953	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
002151	001574	000464	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
001461	-00003	000021	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009730	000002	-00004	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
008865	000139	-00844	0875	0875	0875	0100	0125	0125	0000	%0811	b11	\$
007932	000258	-01652	0750	0750	0750	0200	0250	0250	0000	%0812		

%BEG GE24_22_REM.TXT, Separation cmyn5*, D65, adapted \$
%100 x LAB*a %#1000 x (r g b c m y 0) %nr. pos \$
%z004653 006117 003710 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z009172 -01411 008392 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005674 -06368 003481 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005166 -03377 -03878 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z003145 002322 -04327 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z004544 007038 -01195 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z001537 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009713 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004582 006103 003608 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z009159 -01409 008425 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005670 -06107 003321 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005169 -03269 -03901 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003119 002467 -04074 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z004514 006998 -01099 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z001589 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009737 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/GE34/GE34L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG GE24_22_REM.TXT, Separation cmyn5*, D65, adapted $
%100 x LAB*a      1000 x (r g b   c m y 0)      %nr. pos $
001525 -00008 000041 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002201 -00004 -00013 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003841 -00011 -00091 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
005045 -00006 -00093 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
006137 -00001 -00097 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
007156 000005 -00075 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
008024 000012 -00039 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
009010 000005 -00005 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009724 000014 -00015 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
001516 -00005 000041 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002189 000000 -00014 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003821 -00009 -00091 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004975 000000 -00090 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
006057 000004 -00092 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
007085 000007 -00072 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
007983 000014 -00033 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
009024 000003 -00004 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009720 -00019 000006 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
001450 000001 000037 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002171 -00004 -00015 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003825 -00002 -00086 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004993 000000 -00082 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
006052 000003 -00087 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
007079 000005 -00064 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
007986 000011 -00025 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
009021 000001 000011 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009727 -00017 000008 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
001305 -00003 000051 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002114 -00004 -00012 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003756 -00005 -00071 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004960 000000 -00068 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005985 000005 -00070 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
007042 000008 -00055 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
007965 000014 -00025 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008986 000004 000011 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009718 -00010 -00008 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
001450 000010 000028 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
001737 000011 000012 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002475 000000 -00071 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
003316 000000 -00104 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
004203 000000 -00107 0266 0266 0266 0333 0333 0333 0000 %1012 k14 $
004737 000004 -00102 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
005382 000007 -00109 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005919 000005 -00087 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
006511 000003 -00087 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
007018 000000 -00068 0600 0600 0600 0400 0400 0400 0000 %1017 k19 $
007475 000006 -00056 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007917 000009 -00019 0734 0734 0734 0266 0266 0266 0000 %1019 k21 $
008365 000012 -00012 0800 0800 0800 0200 0200 0200 0000 %1020 k22 $
008808 000008 000005 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
009303 000000 000009 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009698 000004 -00007 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
001398 000010 000037 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
001700 000016 000037 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
002479 000002 -00043 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
003302 000003 -00082 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
004122 000003 -00090 0266 0266 0266 0333 0333 0333 0000 %1028 l14 $
004692 000003 000037 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
005325 000010 -00099 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005891 000013 -00090 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
006503 000012 -00098 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006986 000012 -00081 0600 0600 0600 0400 0400 0400 0000 %1033 l19 $
007430 000014 -00065 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007901 000016 -00033 0734 0734 0734 0266 0266 0266 0000 %1035 l21 $
008330 000016 -00013 0800 0800 0800 0200 0200 0200 0000 %1036 l22 $
008796 000012 -00004 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
009307 000002 000001 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009692 000007 -00015 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
001330 000013 000040 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
001653 000019 000038 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002465 000003 -00050 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
003288 000004 -00078 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
004123 000007 -00088 0266 0266 0266 0333 0333 0333 0000 %1044 m14 $
004691 000008 -00075 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
005332 000011 -00097 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005868 000011 -00069 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
006402 000014 -00088 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006913 000010 -00058 0600 0600 0600 0400 0400 0400 0000 %1049 m19 $
007400 000015 -00054 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007876 000014 -00021 0734 0734 0734 0266 0266 0266 0000 %1051 m21 $
008315 000017 -00008 0800 0800 0800 0200 0200 0200 0000 %1052 m22 $
```

%BEG GE24_22.REM.TXT, Separation cmyn5*, D50, not adapted \$																				
%100 x LAB*																				
1000 x (r g b c m y θ)																				
xnmr. pos \$																				
001539	000050	000144	0000	0000	0000	0000	1000	1000	0000	00000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002320	0000579	-01402	0000	0000	0125	1000	1000	0875	0000	00000	0001	A02	\$	001970	001658	000710	0125	0000	0000	0875
002219	0000719	-02788	0000	0000	0250	1000	1000	0750	0000	00000	0002	A03	\$	001853	001827	-00116	0125	0000	0125	0875
002366	0000650	-03486	0000	0000	0375	1000	1000	0625	0000	00003	0003	A04	\$	002020	001817	-01431	0125	0000	0250	0875
002538	001221	-04154	0000	0000	0500	1000	1000	0500	0000	00004	0004	A05	\$	002240	002186	-02331	0125	0000	0375	0875
002582	001680	-04351	0000	0000	0625	1000	1000	0375	0000	00005	0005	A06	\$	002435	002355	-02839	0125	0000	0500	0875
002726	001745	-04240	0000	0000	0750	1000	1000	0250	0000	00006	0006	A07	\$	002620	002647	-03098	0125	0000	0625	0875
002869	001921	-04219	0000	0000	0875	1000	1000	0125	0000	00007	0007	A08	\$	002701	002781	-03516	0125	0000	0750	0875
003093	001851	-04234	0000	0000	1000	1000	1000	0000	0000	00008	0008	A09	\$	002859	002801	-03680	0125	0000	0875	0875
003018	-03382	001157	0000	0125	0000	1000	0875	1000	0000	00009	0009	B01	\$	003066	002691	-03868	0125	0000	1000	0875
002604	-01837	-02244	0000	0125	0125	1000	0875	0875	0000	00010	0010	B02	\$	002671	-00117	001978	0125	0125	0000	0875
002517	-00864	-02901	0000	0125	0250	1000	0875	0750	0000	00011	0011	B03	\$	002229	000029	000074	0125	0125	0125	0875
002437	-00521	-02948	0000	0125	0375	1000	0875	0625	0000	00012	0012	B04	\$	002803	000414	-01745	0125	0125	0250	0875
002614	-00116	-03487	0000	0125	0500	1000	0875	0500	0000	00013	0013	B05	\$	002977	000513	-02451	0125	0125	0375	0875
002837	000238	-04207	0000	0125	0625	1000	0875	0375	0000	00014	0014	B06	\$	003391	001054	-02906	0125	0125	0500	0875
002951	000817	-04602	0000	0125	0750	1000	0875	0250	0000	00015	0015	B07	\$	003399	001471	-03474	0125	0125	0625	0875
003121	000869	-04537	0000	0125	0875	1000	0875	0125	0000	00016	0016	B08	\$	003559	001567	-03835	0125	0125	0750	0875
003268	000893	-04495	0000	0125	1000	1000	0875	0000	0000	00017	0017	B09	\$	003433	001822	-04048	0125	0125	0875	0875
003473	-04680	001752	0000	0250	0000	1000	0750	1000	0000	00018	0018	C01	\$	003363	001880	-04088	0125	0125	1000	0875
003220	-04162	-00425	0000	0250	0125	1000	0750	0875	0000	00019	0019	C02	\$	003248	-01767	002106	0125	0250	0000	0875
003200	-02432	-02924	0000	0250	0250	1000	0750	0750	0000	00020	0020	C03	\$	003849	-01507	000679	0125	0250	0125	0875
003080	-01369	-03711	0000	0250	0375	1000	0750	0625	0000	00021	0021	C04	\$	003675	-01294	-01582	0125	0250	0250	0875
003011	-00895	-03845	0000	0250	0500	1000	0750	0500	0000	00022	0022	C05	\$	003741	-00889	-02438	0125	0250	0375	0875
002968	-00802	-03853	0000	0250	0625	1000	0750	0375	0000	00023	0023	C06	\$	003859	-00423	-02926	0125	0250	0500	0875
003129	-00585	-04371	0000	0250	0750	1000	0750	0250	0000	00024	0024	C07	\$	004086	-00108	-03245	0125	0250	0625	0875
003204	-00439	-04717	0000	0250	0875	1000	0750	0125	0000	00025	0025	C08	\$	004081	000089	-03757	0125	0250	0750	0875
003274	-00306	-04926	0000	0250	1000	1000	0750	0000	0000	00026	0026	C09	\$	003720	000581	-04386	0125	0250	0875	0875
003967	-00598	-052196	0000	0375	0000	1000	0625	1000	0000	00027	0027	D01	\$	003601	001042	-04283	0125	0250	1000	0875
003909	-00610	000939	0000	0375	0125	1000	0625	0875	0000	00028	0028	D02	\$	003782	-03458	002471	0125	0375	0000	0875
003876	-04578	-01326	0000	0375	0250	1000	0625	0750	0000	00029	0029	D03	\$	004167	-02508	000109	0125	0375	0125	0875
003713	-03077	-03222	0000	0375	0375	1000	0625	0625	0000	00030	0030	D04	\$	004009	-02243	-00459	0125	0375	0250	0875
003596	-02132	-03960	0000	0375	0500	1000	0625	0500	0000	00031	0031	D05	\$	004308	-01866	-02212	0125	0375	0375	0875
003647	-01604	-04450	0000	0375	0625	1000	0625	0375	0000	00032	0032	D06	\$	004267	-01454	-02900	0125	0375	0500	0875
003715	-01385	-04718	0000	0375	0750	1000	0625	0250	0000	00033	0033	D07	\$	004373	-01169	-03267	0125	0375	0625	0875
003832	-01381	-04865	0000	0375	0875	1000	0625	0125	0000	00034	0034	D08	\$	004422	-01065	-03638	0125	0375	0750	0875
003774	-01311	-04959	0000	0375	1000	1000	0625	0000	0000	00035	0035	D09	\$	004208	-00933	-04566	0125	0375	0875	0875
004347	-06118	002467	0000	0500	0000	1000	0500	1000	0000	00036	0036	E01	\$	003705	-00413	-04690	0125	0375	1000	0875
004384	-07028	001551	0000	0500	0125	1000	0500	0875	0000	00037	0037	E02	\$	004315	-04523	002801	0125	0500	0000	0875
004370	-05842	-00474	0000	0500	0250	1000	0500	0750	0000	00038	0038	E03	\$	004615	-03302	001584	0125	0500	0125	0875
004413	-04938	-02119	0000	0500	0375	1000	0500	0625	0000	00039	0039	E04	\$	004559	-03100	000267	0125	0500	0250	0875
004226	-03520	-03613	0000	0500	0500	1000	0500	0500	0000	00040	0040	E05	\$	004503	-02735	-01238	0125	0500	0375	0875
004166	-02909	-04183	0000	0500	0625	1000	0500	0375	0000	00041	0041	E06	\$	004656	-02326	-02758	0125	0500	0500	0875
004309	-02590	-04685	0000	0500	0750	1000	0500	0250	0000	00042	0042	E07	\$	004729	-01957	-03245	0125	0500	0625	0875
004329	-02262	-04995	0000	0500	0875	1000	0500	0125	0000	00043	0043	E08	\$	004776	-01740	-03538	0125	0500	0750	0875
004236	-02188	-05004	0000	0500	1000	1000	0500	0000	0000	00044	0044	E09	\$	004734	-01764	-04256	0125	0500	0875	0875
004715	-06471	002706	0000	0625	0000	1000	0375	1000	0000	00045	F01	\$	004382	-01639	-04758	0125	0500	1000	0875	0875
004643	-07588	002193	0000	0625	0125	1000	0375	0875	0000	00046	F02	\$	004040	-05160	003110	0125	0625	0000	0875	0375
004756	-06904	000550	0000	0625	0250	1000	0375	0750	0000	00047	F03	\$	004989	-03982	002110	0125	0625	0125	0875	0375
004753	-05991	-01195	0000	0625	0375	1000	0375	0625	0000	00048	F04	\$	004989	-03982	002110	0125	0625	0125		

See original or copy: <http://web.me.com/klau.s.richter/GE34/GE34L0NA.TXT> /.PS
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

002797	003232	001864	0375	0000	0000	0625	1000	1000	0000	%0243	A10 \$	003217	004065	002459	0500	0000	0000	0500	1000	1000	0000	%0324	J10 \$	003559	004660	002915	0625	0000	0000	0375	1000	1000	0000	%0405	S10 \$	
002742	003284	001114	0375	0000	0125	0625	1000	0875	0000	%0244	A11 \$	003213	004012	001939	0500	0000	0125	0500	1000	0875	0000	%0325	J11 \$	003607	004633	002529	0625	0000	0125	0375	1000	0875	0000	%0406	S11 \$	
002696	003411	000404	0375	0000	0250	0625	1000	0750	0000	%0245	A12 \$	003141	004055	001139	0500	0000	0250	0500	1000	0750	0000	%0326	J12 \$	003568	004687	001830	0625	0000	0250	0375	1000	0750	0000	%0407	S12 \$	
002808	003799	-009525	0375	0000	0375	0625	1000	0625	0000	%0246	A13 \$	003125	004208	000087	0500	0000	0375	0500	1000	0625	0000	%0327	J13 \$	003520	004800	0000801	0625	0000	0375	0375	1000	0625	0000	%0408	S13 \$	
002861	003725	-01198	0375	0000	0500	0625	1000	0500	0000	%0247	A14 \$	003213	004511	-00669	0500	0000	0500	0500	1000	0500	0000	%0328	J14 \$	003520	004990	-00935	0625	0000	0500	0375	1000	0500	0000	%0409	S14 \$	
002941	003753	-01658	0375	0000	0625	0625	1000	0375	0000	%0248	A15 \$	003271	004523	-01244	0500	0000	0625	0500	1000	0375	0000	%0329	J15 \$	003574	005166	-00701	0625	0000	0625	0375	1000	0375	0000	%0410	S15 \$	
002989	003920	-02189	0375	0000	0750	0625	1000	0250	0000	%0249	A16 \$	003325	004563	-01822	0500	0000	0750	0500	1000	0250	0000	%0330	J16 \$	003650	005210	-01280	0625	0000	0750	0375	1000	0250	0000	%0411	S16 \$	
003196	004077	-02627	0375	0000	0875	0625	1000	0125	0000	%0250	A17 \$	003467	004621	-02247	0500	0000	0875	0500	1000	0125	0000	%0331	J17 \$	003748	005159	-01817	0625	0000	0875	0375	1000	0125	0000	%0412	S17 \$	
003323	004247	-02853	0375	0000	1000	0625	1000	0000	0000	%0251	A18 \$	003571	004718	-02490	0500	0000	1000	0500	1000	0000	0000	%0332	J18 \$	003838	005276	-02071	0625	0000	1000	0375	1000	0000	0000	%0413	S18 \$	
003183	002284	002697	0375	0125	0000	0625	0875	1000	0000	%0252	B10 \$	003566	003149	003326	0500	0125	0000	0500	0875	1000	0000	%0333	K10 \$	003886	004222	003813	0625	0125	0000	0375	0875	1000	0000	%0414	T10 \$	
003663	002258	002031	0375	0125	0125	0625	0875	0875	0000	%0253	B11 \$	003843	003424	002954	0500	0125	0125	0500	0875	0875	0000	%0334	K11 \$	004148	004466	003715	0625	0125	0125	0375	0875	0875	0000	%0415	T11 \$	
003571	002602	000630	0375	0125	0250	0625	0875	0750	0000	%0254	B12 \$	003868	003183	001427	0500	0125	0250	0500	0875	0750	0000	%0335	K12 \$	004219	003822	002053	0625	0125	0250	0375	0875	0750	0000	%0416	T12 \$	
003615	003088	-00787	0375	0125	0375	0625	0875	0625	0000	%0255	B13 \$	003866	003601	000248	0500	0125	0375	0500	0875	0625	0000	%0336	K13 \$	004159	004101	001055	0625	0125	0375	0375	0875	0625	0000	%0417	T13 \$	
003520	003165	-01522	0375	0125	0500	0625	0875	0500	0000	%0256	B14 \$	003826	004038	-00791	0500	0125	0500	0500	0875	0500	0000	%0337	K14 \$	004119	004487	000090	0625	0125	0500	0375	0875	0500	0000	%0418	T14 \$	
003553	003230	-02143	0375	0125	0625	0625	0875	0375	0000	%0257	B15 \$	003811	004183	-01445	0500	0125	0625	0625	0500	0875	0375	0000	%0338	K15 \$	004088	004809	-00008	0625	0125	0625	0375	0875	0375	0000	%0419	T15 \$
003649	003494	-02687	0375	0125	0750	0625	0875	0250	0000	%0258	B16 \$	003917	004189	-02074	0500	0125	0750	0500	0875	0250	0000	%0339	K16 \$	004152	004824	-01537	0625	0125	0750	0375	0875	0250	0000	%0420	T16 \$	
003587	003764	-03075	0375	0125	0875	0625	0875	0125	0000	%0259	B17 \$	003890	004426	-02650	0500	0125	0875	0500	0875	0125	0000	%0340	K17 \$	004235	004928	-02032	0625	0125	0875	0375	0875	0125	0000	%0421	T17 \$	
003642	003581	-03145	0375	0125	1000	0625	0875	0000	0000	%0260	B18 \$	003839	004081	-02848	0500	0125	1000	0500	0875	0000	0000	%0341	K18 \$	004170	004561	-02445	0625	0125	1000	0375	0875	0000	0000	%0422	T18 \$	
003710	000777	003465	0375	0250	0000	0625	0750	1000	0000	%0261	C10 \$	004060	001569	003897	0500	0250	0000	0500	0750	1000	0000	%0342	L10 \$	004543	002512	004457	0625	0250	0000	0375	0750	1000	0000	%0423	U10 \$	
004486	000631	002767	0375	0250	0125	0625	0750	0875	0000	%0262	C11 \$	004783	001542	003417	0500	0250	0125	0500	0750	0875	0000	%0343	L11 \$	004982	002522	004134	0625	0250	0125	0375	0750	0875	0000	%0424	U11 \$	
004396	001030	000999	0375	0250	0250	0625	0750	0750	0000	%0263	C12 \$	004661	001761	001754	0500	0250	0250	0500	0750	0750	0000	%0344	L12 \$	005033	002528	002301	0625	0250	0250	0375	0750	0750	0000	%0425	U12 \$	
004463	001326	-00707	0375	0250	0375	0625	0750	0625	0000	%0264	C13 \$	004692	002067	000401	0500	0250	0375	0500	0750	0625	0000	%0345	L13 \$	004964	002786	001216	0625	0250	0375	0375	0750	0625	0000	%0426	U13 \$	
004332	001555	-01645	0375	0250	0500	0625	0750	0500	0000	%0265	C14 \$	004752	002487	-00860	0500	0250	0500	0500	0750	0500	0000	%0346	L14 \$	005029	003113	000114	0625	0250	0500	0375	0750	0500	0000	%0427	U14 \$	
004300	001865	-02291	0375	0250	0625	0625	0750	0375	0000	%0266	C15 \$	004592	002703	-01583	0500	0250	0625	0500	0750	0375	0000	%0347	L15 \$	004990	003352	-00935	0625	0250	0625	0375	0750	0375	0000	%0428	U15 \$	
004404	001889	-02733	0375	0250	0750	0625	0750	0250	0000	%0267	C16 \$	004636	002688	-02109	0500	0250	0750	0500	0750	0250	0000	%0348	L16 \$	004997	003418	-01438	0625	0250	0750	0375	0750	0250	0000	%0429	U16 \$	
004113	002607	-03357	0375	0250	0875	0625	0750	0125	0000	%0268	C17 \$	004447	003203	-02919	0500	0250	0875	0500	0750	0125	0000	%0349	L17 \$	004929	003815	-02303	0625	0250	0875	0375	0750	0125	0000	%0430	U17 \$	
004011	002572	-03479	0375	0250	1000	0625	0750	0000	0000	%0269	C18 \$	004294	003220	-038015	0500	0250	1000	0500	0750	0000	0000	%0350	L18 \$	004591	003845	-02522	0625	0250	1000	0375	0750	0000	0000	%0431	U18 \$	
004817	-00433	004608	0375	0375	0000	0625	0625	1000	0000	%0270	D10 \$	004744	000388	004568	0500	0375	0000	0500	0625	1000	0000	%0351	M10 \$	005024	001286	004878	0625	0375	0000	0375	0625	1000	0000	%0432	V10 \$	
005452	-00621	003687	0375	0375	0125	0625	0625	0875	0000	%0271	D11 \$	005413	000383	004215	0500	0375	0125	0500	0625	0875	0000	%0352	M11 \$	005656	001371	004614	0625	0375								

See original or copy: <http://web.me.com/klaustrichter/GE34/GE34L0NA.TXT> /PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

004035	005233	003015	0750	0000	0000	0250	0000	1000	1000	0000	0000	%0486	A19	\$
003943	005201	002691	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$		
003901	005272	002142	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$		
003824	005339	001454	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$		
003751	005441	000655	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$		
003737	005539	000242	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$		
003715	005558	000843	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$		
003588	005677	001408	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$		
004053	005842	001714	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$		
004545	005405	004525	0750	0125	0000	0250	0875	1000	0000	%0495	B19	\$		
004586	004638	003581	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$		
004521	004643	002541	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$		
004376	004818	001792	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$		
004389	004839	000944	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$		
004301	005267	000537	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$		
004245	005538	001005	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$		
004364	005448	001596	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$		
004439	005350	001978	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$		
005424	003237	005385	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$		
005358	003250	004489	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$		
005329	003250	002882	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$		
005249	003378	002018	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$		
005249	003478	001100	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$		
005205	004084	001025	0750	0250	0750	0250	0750	0250	0000	%0509	C24	\$		
005052	004078	001025	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$		
005146	004318	001596	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$		
004980	004432	002099	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$		
005588	002064	005817	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$		
005982	002172	005311	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$		
006045	002094	003334	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$		
006002	002199	002309	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$		
005948	002334	001444	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$		
005905	002734	000249	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$		
005751	003018	000958	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$		
005753	003580	001586	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$		
005517	003653	002037	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$		
006352	001184	006299	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$		
006529	001202	005961	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$		
006671	001086	003885	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$		
006641	001188	002928	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$		
006573	001361	001841	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$		
006521	001715	000550	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$		
006321	002095	000836	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$		
006422	002420	001468	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$		
006291	002789	001829	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$		
007301	000259	007255	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$		
007316	000233	006631	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$		
007344	000181	004613	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$		
007321	000313	003581	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$		
007233	000509	002518	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$		
007165	000786	000953	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$		
006990	000989	000658	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$		
007076	001313	001407	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$		
006981	001639	001760	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$		
008352	000674	008339	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$		
008100	000610	007512	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$		
008064	000604	005374	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$		
007989	000494	004279	0750	0750	0375	0250	0250	0625	0000	%0543	G22	\$		
007933	000487	003249	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$		
007874	000333	001661	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$		
007703	000816	000165	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$		
007708	000940	001332	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$		
007676	000226	001729	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$		
008915	001112	008912	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$		
008631	001304	007979	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$		
008445	001320	005499	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$		
008369	001348	004450	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$		
008397	001353	003600	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$		
008347	001223	002496	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$		
008421	001266	000942	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$		
008410	001079	000985	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$		
008348	001202	001546	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$		
008895	001733	008537	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$		
008761	001776	007251	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$		
008734	001887	005750	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$		
008651	001959	004857	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$		
008593	001974	003892	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$		
008591	001883	002690	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$		
008702	001680	001745	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$		
008536	001606	000104	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$		
008397	001402	001388	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$		
004472	005882	003672	0875	0000	0000	0125	1000	1000	0000	%0567				

009749	-00069	000187	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009905	-00823	-00582	0875	1000	1000	0125	0000	0000	%0730	b02	\$
008494	-01263	-01303	0750	1000	1000	0250	0000	0000	%0731	b03	\$
007993	-01651	-01863	0625	1000	1000	0375	0000	0000	%0732	b04	\$
007435	-02038	-02460	0500	1000	1000	0500	0000	0000	%0733	b05	\$
006853	-02468	-02899	0375	1000	1000	0625	0000	0000	%0734	b06	\$
006004	-03168	-03440	0250	1000	1000	0750	0000	0000	%0735	b07	\$
005411	-03756	-03757	0125	1000	1000	0875	0000	0000	%0736	b08	\$
005010	-03924	-04107	0000	1000	1000	1000	0000	0000	%0737	b09	\$
009182	000460	001080	1000	0875	0875	0000	0125	0125	%0738	c01	\$
008930	-00947	000194	0875	0875	0875	0125	0125	0125	%0739	c02	\$
008542	-00953	-00912	0750	0875	0875	0250	0125	0125	%0740	c03	\$
008145	-01516	-01515	0625	0875	0875	0375	0125	0125	%0741	c04	\$
007575	-01982	-02111	0500	0875	0875	0500	0125	0125	%0742	c05	\$
006969	-02388	-02722	0375	0875	0875	0625	0125	0125	%0743	c06	\$
006339	-02735	-03022	0250	0875	0875	0750	0125	0125	%0744	c07	\$
005637	-03581	-03509	0125	0875	0875	0875	0125	0125	%0745	c08	\$
004887	-04126	-03976	0000	0875	0875	1000	0125	0125	%0746	c09	\$
008714	000092	001587	1000	0750	0750	0000	0250	0250	%0747	d01	\$
008196	000659	000912	0875	0750	0750	0125	0250	0250	%0748	d02	\$
007919	-00029	000136	0750	0750	0750	0250	0250	0250	%0749	d03	\$
007537	-00947	-01028	0625	0750	0750	0375	0250	0250	%0750	d04	\$
007096	-01549	-01639	0500	0750	0750	0500	0250	0250	%0751	d05	\$
006529	-02069	-02263	0375	0750	0750	0625	0250	0250	%0752	d06	\$
005948	-02415	-02695	0250	0750	0750	0750	0250	0250	%0753	d07	\$
005454	-03275	-03232	0125	0750	0750	0875	0250	0250	%0754	d08	\$
004841	-04418	-03684	0000	0750	0750	1000	0250	0250	%0755	d09	\$
008052	001793	002298	1000	0625	0625	0000	0375	0375	%0756	e01	\$
007664	001131	001801	0875	0625	0625	0125	0375	0375	%0757	e02	\$
007397	000715	000786	0750	0625	0625	0250	0375	0375	%0758	e03	\$
007081	-00028	000062	0625	0625	0625	0375	0375	0375	%0759	e04	\$
006677	-00927	-01190	0500	0625	0625	0500	0375	0375	%0760	e05	\$
006131	-01575	-01716	0375	0625	0625	0625	0375	0375	%0761	e06	\$
005514	-02029	-02382	0250	0625	0625	0750	0375	0375	%0762	e07	\$
005107	-02783	-02997	0125	0625	0625	0875	0375	0375	%0763	e08	\$
004648	-04201	-03636	0000	0625	0625	1000	0375	0375	%0764	e09	\$
007362	002743	003023	1000	0500	0500	0000	0500	0500	%0765	f01	\$
007052	001978	002327	0875	0500	0500	0125	0500	0500	%0766	f02	\$
006774	001284	001729	0750	0500	0500	0250	0500	0500	%0767	f03	\$
006438	000750	000745	0625	0500	0500	0375	0500	0500	%0768	f04	\$
006126	-00021	-00063	0500	0500	0500	0500	0500	0500	%0769	f05	\$
005654	-00950	-01211	0375	0500	0500	0625	0500	0500	%0770	f06	\$
005149	-01675	-02016	0250	0500	0500	0750	0500	0500	%0771	f07	\$
004723	-02294	-02787	0125	0500	0500	0875	0500	0500	%0772	f08	\$
004190	-03500	-03692	0000	0500	0500	1000	0500	0500	%0773	f09	\$
006580	004021	003613	1000	0375	0375	0000	0625	0625	%0774	g01	\$
006334	003004	002783	0875	0375	0375	0125	0625	0625	%0775	g02	\$
005993	002226	002150	0750	0375	0375	0250	0625	0625	%0776	g03	\$
005652	001559	001591	0625	0375	0375	0375	0625	0625	%0777	g04	\$
005340	000833	000783	0500	0375	0375	0500	0625	0625	%0778	g05	\$
005113	-00007	000049	0375	0375	0375	0625	0625	0625	%0779	g06	\$
004663	-01186	-01558	0250	0375	0375	0750	0625	0625	%0780	g07	\$
004436	-01867	-02246	0125	0375	0375	0875	0625	0625	%0781	g08	\$
004348	-03185	-03289	0000	0375	0375	1000	0625	0625	%0782	g09	\$
006074	004828	004561	1000	0250	0250	0000	0750	0750	%0783	h01	\$
005751	003928	003500	0875	0250	0250	0125	0750	0750	%0784	h02	\$
005294	003223	002911	0750	0250	0250	0250	0750	0750	%0785	h03	\$
004815	002475	002450	0625	0250	0250	0375	0750	0750	%0786	h04	\$
004584	001751	001818	0500	0250	0250	0500	0750	0750	%0787	h05	\$
004311	001066	000997	0375	0250	0250	0625	0750	0750	%0788	h06	\$
003964	000807	000835	0250	0250	0250	0750	0750	0750	%0789	h07	\$
003888	-01330	-01691	0125	0250	0250	0875	0750	0750	%0790	h08	\$
003288	-02532	-02959	0000	0250	0250	1000	0750	0750	%0791	h09	\$
005373	006266	004441	1000	0125	0125	0000	0875	0875	%0792	i01	\$
005070	005424	004284	0875	0125	0125	0125	0875	0875	%0793	i02	\$
004596	004538	003504	0750	0125	0125	0250	0875	0875	%0794	i03	\$
004095	004383	003551	0625	0125	0125	0375	0875	0875	%0795	i04	\$
003829	003304	002759	0500	0125	0125	0500	0875	0875	%0796	i05	\$
003648	002234	002038	0375	0125	0125	0625	0875	0875	%0797	i06	\$
003405	001342	001350	0250	0125	0125	0750	0875	0875	%0798	i07	\$
002497	000031	000044	0125	0125	0125	0875	0875	0875	%0799	i08	\$
002792	-01893	-02380	0000	0125	0125	1000	0875	0875	%0800	i09	\$
004771	006447	004027	1000	0000	0000	0000	1000	1000	%0801	j01	\$
004308	005747	003558	0875	0000	0000	0125	1000	1000	%0802	j02	\$
003947	005133	002968	0750	0000	0000	0250	1000	1000	%0803	j03	\$
003507	004514	002678	0625	0000	0000	0375	1000	1000	%0804	j04	\$
003158	003837	002161	0500	0000	0000	0500	1000	1000	%0805	j05	\$
002812	003127	001737	0375	0000	0000	0625	1000	1000	%0806	j06	\$
002468	002530	001169	0250	0000	0000	0750	1000	1000	%0807	j07	\$
002194	001734	000642	0125	0000	0000	0875	1000	1000	%0808	j08	\$
001464	000059	000119	0000	0000	0000	1000	1000	1000	%0809	j09	\$
009730	-00067	000183	1000	1000	1000	0000	0000	0000	%0810	b10	\$
008855	000015	-00681	0875	0875	1000	0125	0125	0000	%0811	b11	\$
007909	000075	-01520	0750	0750	1000	0250	0250	0000	%0812	b12	\$
006808	000442	-02221	0625	0625	1000	0375	0375	0000	%0813	b13	\$
005622	000935	-02942	0500	0500	1000	0500	0500	0000	%0814	b14	\$
004665	001510	-03389	0375	0375	1000	0625	0625	0000	%0815	b15	\$
003761	001937	-03780	0250	0250	1000	0750	0750	0000	%0816	b16	\$
003000	000022	-03890	0125	0125	1000	0875	0875	0000	%0817	b17	\$
002377	002032	-03991	0000	1000	1000	1000	1000	0000	%0818	b18	\$
009668	-00468	001742	1000	1000	0875	0000	0125	0000	%0819	c10	\$
009023	-00041	000169	0875	0875	0875	0125	0125	0125	%0820	c11	\$
009789	-00048	-01031	0750	0750	0875	0250	0250	0125	%0821	c12	\$
007932	000315	-01796	0625	0625	0875	0375	0375	0125	%0822	c13	\$
005978	000796	-02679	0500	0500	0875	0500	0500	0125	%0823	c14	\$
004846	001373	-03296	0375	0375	0875	0625	0625	0125	%0824	c15	\$
003861	001797	-03767	0250	0250	0875	0750	0750	0125	%0825	c16	\$
003344	001967	-03932	0125	0125	0875	0875	0125	0000	%0826	c17	\$
002827	002022	-04033	0000	0000	0875	1000	1000	0125	%0827	c18	\$
009610	-00719	003069	1000	1000	0750	0000	0250	0000	%0828	d10	\$
009014	-00324	001508	0875	0875	0750	0125	0125	0250	%0829	d11	\$
008042	-00031	000149	0750	0750	0750	0250	0250	0000	%0830	d12	\$
006991	000108	-01173	0625	0625	0750	0375	0375	0250	%0831	d13	\$
005930	000395	-01857	0500	0500	0750	0500	0500	0250	%0832	d14	\$
004953	000791	-02588	0375	0375	0750	0625	0625	0250	%0833	d15	\$
004272	001291	-03137	0250	0250	0750	0750	0250	0000	%0834	d16	\$
003460	001748	-03794	0125	0125	0750	0875	0875	0250	%0835	d17	\$
002602	000987	-04243	0000	0000	0750	1000	1000	0250	%0836	d18	\$
009434	-00611	003848	1000	1000	0625	0000	0375	0000	%0837	e10	\$
0089											

%BEG GE24_22_REM.TXT, Separation cmyn5*, D50, not adapted \$
%100 x LAB*
%#1000 x (r g b c m y 0) %nr. pos \$
%z004842 006462 004158 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z009221 -00823 008391 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005593 -05939 003251 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005907 -04094 -04060 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z003993 001851 -04234 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z004710 007041 -00658 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z001539 000050 000144 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009714 -00057 000190 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004771 006447 004027 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z009208 -00826 008411 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005592 -05692 003087 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005010 -03984 -04107 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003079 002038 -03991 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z004680 007011 -00592 %#1000 0000 1000 0000 0000 0000 0000 %0899 b27 %M2 5 \$
%z001592 000057 000099 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009738 -00068 000187 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

BEBG GE24.22 REM.TXT, Separation cmyn5*, D50, not adapted \$		1000 x (r g b c m y o)		%nr.	pos \$																				
%100 x LAB*	000000	000116	0000	0000	0000	1000	1000	0000	0000	%0972	k01	\$	000790	-00037	000183	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$
0021527	0000308	000116	0000	0000	0000	1000	1000	0000	0000	%0973	k02	\$	0009339	-00051	000193	0933	0933	0933	0666	0666	0666	0000	%1054	m24	\$
0022083	000027	000070	0125	0125	0125	0875	0875	0875	0875	%0974	k03	\$	0009719	-00065	000188	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$
0030441	-00011	000014	0250	0250	0250	0750	0750	0750	0750	%0975	k04	\$	0012227	000061	000114	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$
0061337	-00029	000040	0500	0500	0500	0500	0500	0500	0500	%0976	k05	\$	0016200	000068	000122	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$
007156	-00031	000076	0625	0625	0625	0375	0375	0375	0375	%0977	k06	\$	0024448	000029	000044	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$
008025	-00030	000125	0750	0750	0750	0250	0250	0250	0250	%0978	k07	\$	0032443	000021	000032	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$
009012	-00044	000172	0875	0875	0875	0125	0125	0125	0125	%0979	k08	\$	0040999	000007	000038	0266	0266	0266	0333	0333	0333	0000	%1060	n14	\$
009724	-00047	000170	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$	004678	000007	000060	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$
001518	000042	000115	0000	0000	0000	1000	1000	0000	0000	%0981	101	\$	005291	-00004	000057	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$
002191	000031	000069	0125	0125	0125	0875	0875	0875	0875	%0982	102	\$	005817	-00005	000091	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$
003821	-00007	000164	0250	0250	0250	0750	0750	0750	0750	%0983	103	\$	006409	-00017	000086	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$
004975	-00012	000032	0375	0375	0375	0625	0625	0625	0625	%0984	104	\$	006892	-00018	000114	0600	0600	0600	0400	0400	0400	0000	%1065	n19	\$
006057	-00021	000044	0500	0500	0500	0500	0500	0500	0500	%0985	105	\$	007360	-00021	000113	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$
007084	-00027	000078	0625	0625	0625	0375	0375	0375	0375	%0986	106	\$	007844	-00023	000155	0734	0734	0734	0266	0266	0266	0000	%1067	n21	\$
007986	-00027	000131	0750	0750	0750	0250	0250	0250	0250	%0987	107	\$	008282	-00026	000184	0800	0800	0800	0200	0200	0200	0000	%1068	n22	\$
009025	-00045	000182	0875	0875	0875	0125	0125	0125	0125	%0988	108	\$	008732	-00034	000195	0866	0866	0866	0133	0133	0133	00			

TUB-test chart GE34; Relative Device Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

TUB registration: 20091101-GE34/GE34L0NA.TXT / PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/GE34/GE34L0NA.TXT> / PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.0

TUB registration: 20091101-GE34/GE34L0NA.TXT/.PS TUB material: code=tna4ta
application for evaluation and measurement of printer or monitor systems

[illegible]

002266	002321	001060	0250	0000	0000	0750	1000	1000	0000	%0162	S01	S
002216	002215	000480	0250	0000	0125	0750	1000	0875	0000	%0163	S02	S
002320	002818	-00343	0250	0000	0250	0750	1000	0750	0000	%0164	S03	S
002361	002813	-01263	0250	0000	0375	0750	1000	0625	0000	%0165	S04	S
002530	002888	-01938	0250	0000	0500	0750	1000	0500	0000	%0166	S05	S
002649	003078	-02361	0250	0000	0625	0750	1000	0375	0000	%0167	S06	S
002826	003288	-02879	0250	0000	0750	0750	1000	0250	0000	%0168	S07	S
002980	003558	-03237	0250	0000	0875	0750	1000	0125	0000	%0169	S08	S
003111	003634	-03482	0250	0000	1000	0750	1000	0000	0000	%0170	S09	S
002560	001293	001662	0250	0125	0000	0750	0875	1000	0000	%0171	T01	S
003113	001324	001213	0250	0125	0125	0750	0875	0875	0000	%0172	T02	S
003218	001895	-00759	0250	0125	0250	0750	0875	0750	0000	%0173	T03	S
003215	001874	-01849	0250	0125	0375	0750	0875	0625	0000	%0174	T04	S
003341	002098	-02447	0250	0125	0500	0750	0875	0500	0000	%0175	T05	S
003467	002442	-02898	0250	0125	0625	0750	0875	0375	0000	%0176	T06	S
003569	002645	-03467	0250	0125	0750	0750	0875	0250	0000	%0177	T07	S
003469	002877	-03741	0250	0125	0875	0750	0875	0125	0000	%0178	T08	S
003468	002750	-03819	0250	0125	1000	0750	0875	0000	0000	%0179	T09	S
003554	-00337	00049	0250	0250	0000	0750	0750	1000	0000	%0180	U01	S
004104	00418	002110	0250	0250	0125	0750	0750	0875	0000	%0181	U02	S
003809	-00019	00127	0250	0250	0250	0750	0750	0750	0000	%0182	U03	S
003834	000213	-01792	0250	0250	0375	0750	0750	0625	0000	%0183	U04	S
004061	000514	-02386	0250	0250	0500	0750	0750	0500	0000	%0184	U05	S
004270	000934	-02861	0250	0250	0625	0750	0750	0375	0000	%0185	U06	S
004383	001138	-03266	0250	0250	0750	0750	0750	0250	0000	%0186	U07	S
003910	001726	-03995	0250	0250	0875	0750	0750	0125	0000	%0187	U08	S
003724	001844	-04069	0250	0250	1000	0750	0750	0000	0000	%0188	U09	S
003691	-01224	002951	0250	0375	0000	0750	0625	1000	0000	%0189	V01	S
004635	-01474	002084	0250	0375	0125	0750	0625	0875	0000	%0190	V02	S
004614	-01236	000442	0250	0375	0250	0750	0625	0750	0000	%0191	V03	S
004604	-01130	-01599	0250	0375	0375	0750	0625	0625	0000	%0192	V04	S
004642	-00749	-02341	0250	0375	0500	0750	0625	0500	0000	%0193	V05	S
004747	-00410	-02724	0250	0375	0625	0750	0625	0375	0000	%0194	V06	S
004813	-00226	-03104	0250	0375	0750	0750	0625	0250	0000	%0195	V07	S
004												

TUB-test chart GE34; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```

See original or copy: <http://web.me.com/klaustrichter/GE34/GE34L0NA.TXT> /PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

002797	003199	001712	0375	0000	0000	00625	1000	1000	0000	%0243	A10 \$	003217	004036	002305	0500	0000	0000	0500	1000	1000	0000	%0324	J10 \$	003559	004637	002759	0625	0000	0000	0375	1000	1000	0000	%0405	S10 \$
002742	003249	000963	0375	0000	0125	0625	1000	0875	0000	%0244	A11 \$	003213	003984	001785	0500	0000	0125	0500	1000	0875	0000	%0325	J11 \$	003607	004610	002373	0625	0000	0125	0375	1000	0875	0000	%0406	S11 \$
002696	003376	000253	0375	0000	0250	0625	1000	0750	0000	%0245	A12 \$	003141	004026	000985	0500	0000	0250	0500	1000	0750	0000	%0326	J12 \$	003568	004663	001674	0625	0000	0250	0375	1000	0750	0000	%0407	S12 \$
002808	003766	-00677	0375	0000	0375	0625	1000	0625	0000	%0246	A13 \$	003125	004179	-00065	0500	0000	0375	0500	1000	0625	0000	%0327	J13 \$	003520	004776	000646	0625	0000	0375	0375	1000	0625	0000	%0408	S13 \$
002861	003692	-01350	0375	0000	0500	0625	1000	0500	0000	%0247	A14 \$	003213	004483	-00823	0500	0000	0500	0500	1000	0500	0000	%0328	J14 \$	003520	004966	-00191	0625	0000	0500	0375	1000	0500	0000	%0409	S14 \$
002941	003721	-01810	0375	0000	0625	0625	1000	0375	0000	%0248	A15 \$	003271	004496	-01398	0500	0000	0625	0500	1000	0375	0000	%0329	J15 \$	003574	005142	-00857	0625	0000	0625	0375	1000	0375	0000	%0410	S15 \$
002989	003889	-02341	0375	0000	0750	0625	1000	0250	0000	%0249	A16 \$	003325	004536	-01977	0500	0000	0750	0500	1000	0250	0000	%0330	J16 \$	003650	005188	-01437	0625	0000	0750	0375	1000	0250	0000	%0411	S16 \$
003196	004049	-02781	0375	0000	0875	0625	1000	0125	0000	%0250	A17 \$	003467	004596	-02402	0500	0000	0875	0500	1000	0125	0000	%0331	J17 \$	003748	005138	-01974	0625	0000	0875	0375	1000	0125	0000	%0412	S17 \$
003323	004221	-03008	0375	0000	1000	0625	1000	0000	0000	%0251	A18 \$	003571	004695	-02646	0500	0000	1000	0500	1000	0000	0000	%0332	J18 \$	003838	005257	-02229	0625	0000	1000	0375	1000	0000	0000	%0413	S18 \$
003183	002256	002544	0375	0125	0000	0625	0875	1000	0000	%0252	B10 \$	003566	003125	003170	0500	0125	0000	0500	0875	1000	0000	%0333	K10 \$	003886	004203	003655	0625	0125	0000	0375	0875	1000	0000	%0414	T10 \$
003663	002236	001875	0375	0125	0125	0625	0875	0875	0000	%0253	B11 \$	003843	003404	002797	0500	0125	0125	0500	0875	0875	0000	%0334	K11 \$	004148	004451	003556	0625	0125	0125	0375	0875	0875	0000	%0415	T11 \$
003571	002579	000474	0375	0125	0250	0625	0875	0750	0000	%0254	B12 \$	003868	003163	001270	0500	0125	0250	0500	0875	0750	0000	%0335	K12 \$	004219	003807	001893	0625	0125	0250	0375	0875	0750	0000	%0416	T12 \$
003615	003965	-00944	0375	0125	0375	0625	0875	0625	0000	%0255	B13 \$	003866	003582	000090	0500	0125	0375	0500	0875	0625	0000	%0336	K13 \$	004159	004085	000896	0625	0125	0375	0375	0875	0625	0000	%0417	T13 \$
003520	003140	-01678	0375	0125	0500	0625	0875	0500	0000	%0256	B14 \$	003826	004018	-00948	0500	0125	0500	0500	0875	0500	0000	%0337	K14 \$	004119	004471	-00149	0625	0125	0500	0375	0875	0500	0000	%0418	T14 \$
003553	003206	-02299	0375	0125	0625	0625	0875	0375	0000	%0257	B15 \$	003811	004162	-01603	0500	0125	0625	0500	0875	0375	0000	%0338	K15 \$	004088	004792	-00967	0625	0125	0625	0375	0875	0375	0000	%0419	T15 \$
003649	003471	-02843	0375	0125	0750	0625	0875	0250	0000	%0258	B16 \$	003917	004170	-02232	0500	0125	0750	0500	0875	0250	0000	%0339	K16 \$	004152	004808	-01696	0625	0125	0750	0375	0875	0250	0000	%0420	T16 \$
003587	003741	-03231	0375	0125	0875	0625	0875	0125	0000	%0259	B17 \$	003890	004406	-02808	0500	0125	0875	0500	0875	0125	0000	%0340	K17 \$	004235	004913	-02192	0625	0125	0875	0375	0875	0125	0000	%0421	T17 \$
003642	003559	-03302	0375	0125	1000	0625	0875	0000	0000	%0260	B18 \$	003839	004061	-03006	0500	0125	1000	0500	0875	0000	0000	%0341	K18 \$	004170	004545	-02604	0625	0125	1000	0375	0875	0000	0000	%0422	T18 \$
003710	000755	003308	0375	0250	0000	0625	0750	1000	0000	%0261	C10 \$	004060	001552	003739	0500	0250	0000	0500	0750	1000	0000	%0342	L10 \$	004543	002502	004296	0625	0250	0000	0375	0750	1000	0000	%0423	U10 \$
004486	000619	002606	0375	0250	0125	0625	0750	0875	0000	%0262	C11 \$	004783	001534	003255	0500	0250	0125	0500	0750	0875	0000	%0343	L11 \$	004982	002517	003970	0625	0250	0125	0375	0750	0875	0000	%0424	U11 \$
004396	001017	000838	0375	0250	0250	0625	0750	0750	0000	%0263	C12 \$	004661	001752	001592	0500	0250	0250	0500	0750	0750	0000	%0344	L12 \$	005033	002524	002137	0625	0250	0250	0375	0750	0750	0000	%0425	U12 \$
004463	001315	-00868	0375	0250	0375	0625	0750	0625	0000	%0264	C13 \$	004692	002058	002038	0500	0250	0375	0500	0750	0625	0000	%0345	L13 \$	004964	002781	001052	0625	0250	0375	0375	0750	0625	0000	%0426	U13 \$
004332	001542	-01805	0375	0250	0500	0625	0750	0500	0000	%0265	C14 \$	004752	002479	-01822	0500	0250	0500	0500	0750	0500	0000	%0346	L14 \$	005029	003109	-00049	0625	0250	0500	0375	0750	0500	0000	%0427	U14 \$
004300	001851	-02452	0375	0250	0625	0625	0750	0375	0000	%0266	C15 \$	004592	002693	-01744	0500	0250	0625	0500	0750	0375	0000	%0347	L15 \$	004990	003347	-01099	0625	0250	0750	0375	0750	0375	0000	%0428	U15 \$
004404	001876	-02894	0375	0250	0750	0625	0750	0250	0000	%0267	C16 \$	004636	002679	-02271	0500	0250	0750	0500	0750	0250	0000	%0348	L16 \$	004997	003413	-01602	0625	0250	0750	0375	0750	0250	0000	%0429	U16 \$
004113	002591	-03516	0375	0250	0875	0625	0750	0125	0000	%0268	C17 \$	004447	003191	-03080	0500	0250	0875	0500	0750	0125	0000	%0349	L17 \$	004929	003810	-02467	0625	0250	0875	0375	0750	0125	0000	%0430	U17 \$
004011	002555	-03637	0375	0250	1000	0625	0750	0000	0000	%0269	C18 \$	004294	003206	-03175	0500	0250	1000	0500	0750	0000	0000	%0350	L18 \$	004591	003835	-02684	0625	0250	1000	0375	0750	0000	0000	%0431	U18 \$
004817	-00440	004445	0375	0375	0000	0625	0625	1000	0000	%0270	D10 \$	004744	003830	004405	0500	0375	0000	0500	0625	1000	0000	%0351	M10 \$	005024	001281	004713	0625	0375	0000	0375	0625	1000	0000	%0432	V10 \$
005452	-00619	003520	0375	0375	0125	0625	0625	0875	0000	%0271	D11 \$	005413	003833	004049	0500	0375	0125	0500	0625	0875	0000	%0352	M11 \$	005656	001375	004446	0625	0375	0125	0375	0625	0875			

See original or copy: <http://web.me.com/klaus.richter/GE34/GE34L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

004035	005215	002856	0750	0000	0000	0250	0000	1000	1000	0000	0000	%0486	A19	\$
003943	005183	002532	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$		
003901	005253	001984	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$		
003824	005319	001297	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$		
003751	005420	000498	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$		
003737	005518	000399	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$		
003715	005528	001000	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$		
003658	005658	001566	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$		
004053	005825	001872	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$		
004545	005394	004364	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$		
004586	004628	003419	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$		
004521	004632	002380	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$		
004376	004805	001631	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$		
004389	004827	000783	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$		
004301	005254	000213	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$		
004245	005523	001165	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$		
004364	005435	001757	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$		
004439	005338	002139	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$		
005424	002328	005218	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$		
005358	003251	004233	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$		
005329	003250	002716	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$		
005249	003376	001853	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$		
005249	003476	000935	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$		
005205	003839	001013	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$		
005052	004080	001189	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$		
005146	004315	001761	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$		
004980	004428	002263	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$		
005588	002071	005648	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$		
005982	002181	005142	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$		
006045	002103	003164	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$		
006002	002207	002140	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$		
005948	002342	001275	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$		
005905	002741	000000	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$		
005751	003023	001126	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$		
005753	003586	001754	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$		
005517	003655	002204	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$		
006352	001197	006128	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$		
006529	001217	005788	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$		
006671	001103	003712	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$		
006641	001205	002755	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$		
006573	001377	001668	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$		
006521	001731	000378	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$		
006321	002108	001008	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$		
006422	002434	001640	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$		
006291	002801	002000	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$		
007301	000285	007078	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$		
007316	000258	006454	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$		
007344	000207	004436	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$		
007321	000339	003404	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$		
007233	000533	002342	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$		
007165	000810	000777	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$		
006990	001011	000833	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$		
007076	001336	001583	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$		
006981	001661	001935	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$		
008352	000634	008156	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$		
008100	000574	007331	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$		
008064	000458	005193	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$		
007985	000458	004089	0750	0750	0375	0250	0250	0625	0000	%0543	G22	\$		
007933	000453	003068	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$		
007874	000300	001480	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$		
007703	000814	000814	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$		
007708	000971	001312	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$		
007676	000256	001908	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$		
008915	001065	008726	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$		
008631	001261	007794	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$		
008445	001280	005315	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$		
008369	001309	004266	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$		
008397	001313	003417	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$		
008347	001183	002313	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$		
008421	001225	000759	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$		
008410	001039	001168	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$		
008348	001163	001729	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$		
008895	001686	008351	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$		
008761	001731	007065	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$		
008734	001842	005565	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$		
008651	001916	004672	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$		
008593	001931	003708	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$		
008591	001841	002505	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$		
008702	001636	001560	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$		
008536	001564	000079	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$		
008397	001362	001572	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$		
004472	005871	003511	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$		
004428	005861	003158	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$		
004332	005886	002529	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$		
004291	005952	001869	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$		
004269	006049	001188	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$		
004238	006190	000340	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$		
004201	006354	000522	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$		
004262	006355	001139	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$		
004321	006372	001433	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$		
005145	005631	005059	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$		
005100	005549	004242	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$		
004989	005550	003083	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$		
004899	005658	002312	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$		
004798	005808	001513	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$		
004843	006043	000697	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$		
004765	006277	000449	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$		
004801	006140	001373	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$		
004776	005856	001663	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$		
006019	003870	005836	0875	0250	0000	0125	0750	1000	00					

0097949	0000000	000000	1000	1000	1000	0000	0000	0000	0000	0000	%0729	b01	\$
0099055	-00765	-00762	0875	1000	1000	0000	0125	0000	0000	0000	%0730	b02	\$
0084894	-01214	-01477	0750	1000	1000	0000	0250	0000	0000	0000	%0731	b03	\$
0079993	-01609	-02032	0625	1000	1000	0000	0375	0000	0000	0000	%0732	b04	\$
0074735	-02005	-02623	0500	1000	1000	0000	0500	0000	0000	0000	%0733	b05	\$
0068553	-02444	-03046	0375	1000	1000	0000	0625	0000	0000	0000	%0734	b06	\$
0060004	-03157	-03588	0250	1000	1000	0000	0750	0000	0000	0000	%0735	b07	\$
0054111	-03754	-03998	0125	1000	1000	0000	0875	0000	0000	0000	%0736	b08	\$
0050410	-03900	-04242	0000	1000	1000	0000	1000	0000	0000	0000	%0737	b09	\$
0091812	0005020	000899	1000	0875	0875	0000	0125	0125	0000	0000	%0738	c01	\$
0090930	0000008	000015	0875	0875	0875	0000	0125	0125	0000	0000	%0739	c02	\$
0085422	-00903	-01087	0750	0875	0875	0000	0250	0125	0125	0000	%0740	c03	\$
0081451	-01472	-01685	0625	0875	0875	0000	0375	0125	0125	0000	%0741	c04	\$
0075755	-01947	-02276	0500	0875	0875	0000	0500	0125	0125	0000	%0742	c05	\$
0096969	-02362	-02880	0375	0875	0875	0000	0625	0125	0125	0000	%0743	c06	\$
0063393	-02719	-03173	0250	0875	0875	0000	0750	0125	0125	0000	%0744	c07	\$
0056377	-03576	-03653	0125	0875	0875	0000	0875	0125	0125	0000	%0745	c08	\$
0048877	-04133	-04111	0000	0875	0875	0000	1000	0125	0125	0000	%0746	c09	\$
0087141	001045	001410	1000	0750	0750	0000	0250	0250	0000	0000	%0747	d01	\$
008196	000704	000741	0875	0750	0750	0125	0250	0250	0000	0000	%0748	d02	\$
007919	000010	-00031	0750	0750	0750	0250	0250	0250	0000	0000	%0749	d03	\$
0075737	-00913	-01192	0625	0750	0750	0375	0250	0250	0000	0000	%0750	d04	\$
007096	-01521	-01799	0500	0750	0750	0500	0250	0250	0000	0000	%0751	d05	\$
0065529	-02050	-02416	0375	0750	0750	0625	0250	0250	0000	0000	%0752	d06	\$
005948	-02405	-02842	0250	0750	0750	0750	0250	0250	0000	0000	%0753	d07	\$
005454	-03273	-03374	0125	0750	0750	0875	0250	0250	0000	0000	%0754	d08	\$
004841	-04425	-03819	0000	0750	0750	1000	0250	0250	0000	0000	%0755	d09	\$
0080052	001836	002129	1000	0625	0625	0000	0375	0375	0000	0000	%0756	e01	\$
007664	001168	001635	0875	0625	0625	0125	0375	0375	0000	0000	%0757	e02	\$
007397	000747	000623	0750	0625	0625	0250	0375	0375	0000	0000	%0758	e03	\$
007081	-00001	-00076	0625	0625	0625	0375	0375	0375	0000	0000	%0759	e04	\$
006677	-00006	-01345	0500	0625	0625	0500	0375	0375	0000	0000	%0760	e05	\$
006131	-01562	-01865	0375	0625	0625	0625	0375	0375	0000	0000	%0761	e06	\$
005514	-02026	-02524	0250	0625	0625	0750	0375	0375	0000	0000	%0762	e07	\$
005107	-02786	-03135	0125	0625	0625	0875	0375	0375	0000	0000	%0763	e08	\$
004648	-04212	-03769	0000	0625	0625	1000	0375	0375	0000	0000	%0764	e09	\$
007362	002775	002861	1000	0500	0500	0000	0500	0500	0000	0000	%0765	f01	\$
007052	002006	002168	0875	0500	0500	0125	0500	0500	0000	0000	%0766	f02	\$
006774	001307	001573	0750	0500	0500	0000	0250	0500	0000	0000	%0767	f03	\$
006438	000767	000593	0625	0500	0500	0500	0375	0500	0000	0000	%0768	f04	\$
006126	-00008	-00084	0500	0500	0500	0500	0500	0500	0000	0000	%0769	f05	\$
005654	-00944	-01355	0375	0500	0500	0625	0500	0500	0000	0000	%0770	f06	\$
005149	-01678	-02154	0250	0500	0500	0750	0500	0500	0000	0000	%0771	f07	\$
004723	-02303	-02920	0125	0500	0500	0875	0500	0500	0000	0000	%0772	f08	\$
004190	-03517	-03820	0000	0500	0500	1000	0500	0500	0000	0000	%0773	f09	\$
006580	0004041	003459	1000	0375	0375	0000	0625	0625	0000	0000	%0774	g01	\$
006334	003020	002632	0875	0375	0375	0125	0625	0625	0000	0000	%0775	g02	\$
005993	002237	002002	0750	0375	0375	0250	0625	0625	0000	0000	%0776	g03	\$
005652	001564	001447	0625	0375	0375	0375	0625	0625	0000	0000	%0777	g04	\$
005340	000833	000642	0500	0375	0375	0500	0625	0625	0000	0000	%0778	g05	\$
005113	-00010	-00088	0375	0375	0375	0625	0625	0625	0000	0000	%0779	g06	\$
004663	-01196	-01691	0250	0375	0375	0750	0625	0625	0000	0000	%0780	g07	\$
004436	-01881	-02377	0125	0375	0375	0875	0625	0625	0000	0000	%0781	g08	\$
003748	-03209	-03412	0000	0375	0375	1000	0625	0625	0000	0000	%0782	g09	\$
006074	004840	004413	1000	0250	0250	0000	0750	0750	0000	0000	%0783	h01	\$
005751	003935	003435	0875	0250	0250	0500	0125	0750	0000	0000	%0784	h02	\$
005294	003222	002771	0750	0250	0250	0500	0250	0750	0000	0000	%0785	h03	\$
004815	002460	002214	0625	0250	0250	0625	0375	0750	0000	0000	%0786	h04	\$
004584	001740	001686	0500	0250	0250	0500	0750	0750	0000	0000	%0787	h05	\$
004311	001051	000868	0375	0250	0250	0625	0750	0750	0000	0000	%0788	h06	\$
003964	-00013	-00089	0250	0250	0250	0750	0750	0750	0000	0000	%0789	h07	\$
003888	-01353	-01815	0125	0250	0250	0875	0750	0750	0000	0000	%0790	h08	\$
003288	-02563	-03077	0000	0250	0250	1000	0750	0750	0000	0000	%0791	h09	\$
005333	006266	004700	1000	0125	0125	0000	0875	0875	0000	0000	%0792	i01	\$
005070	005421	004107	0875	0125	0125	0125	0125	0875	0000	0000	%0793	i02	\$
004596	004527	003372	0750	0125	0125	0250	0875	0875	0000	0000	%0794	i03	\$
004095	004364	003424	0625	0125	0125	0375	0875	0875	0000	0000	%0795	i04	\$
003829	003281	002635	0500	0125	0125	0500	0875	0875	0000	0000	%0796	i05	\$
003648	002208	001916	0375	0125	0125	0625	0875	0875	0000	0000	%0797	i06	\$
003405	001312	001231	0250	0125	0125	0750	0875	0875	0000	0000	%0798	i07	\$
002497	-00011	-00064	0125	0125	0125	0875	0875	0875	0000	0000	%0799	i08	\$
002792	-01932	-02493	0000	0125	0125	1000	0875	0875	0000	0000	%0800	i09	\$
004771	006438	003893	1000	0000	0000	0000	1000	1000	0000	0000	%0801	j01	\$
004308	005731	003429	0875	0000	0000	0125	1000	1000	0000	0000	%0802	j02	\$
003947	005112	002843	0750	0000	0000	0250	1000	1000	0000	0000	%0803	j03	\$
003507	004486	002558	0625	0000	0000	0375	1000	1000	0000	0000	%0804	j04	\$
003158	003804	002044	0500	0000	0000	0500	1000	1000	0000	0000	%0805	j05	\$
002812	003088	001624	0375	0000	0000	0625	1000	1000	0000	0000	%0806	j06	\$
002468	002486	001606	0250	0000	0000	0750	1000	1000	0000	0000	%0807	j07	\$
002194	001685	000536	0125	0000	0000	0875	1000	1000	0000	0000	%0808	j08	\$
001464	000000	000020	0000	0000	0000	1000	1000	1000	0000	0000	%0809	j09	\$
009730	000001	-00004	1000	1000	1000	0000	0000	0000	0000	0000	%0810	b10	\$
008855	000070	-00060	0875	1000	1000	0125	0125	0000	0000	0000	%0811	b11	\$
007909	000116	-01688	0750	0750	0750	0250	0250	0000	0000	0000	%0812	b12	\$
006980	000466	-02377	0625	0625	1000	0375	0375	0000	0000	0000	%0813	b13	\$
005622	000940	-03086	0500	0500	0500	0500	0500	0000	0000	0000	%0814	b14	\$
004665	001500	-03513	0375	0375	1000	0625	0625	0000	0000	0000	%0815	b15	\$
003761	001813	-03903	0250	0250	1000	0750	0750	0000	0000	0000	%0816	b16	\$
003370	000923	-04037	0125	0250	1000	0875	0875	0000	0000	0000	%0817	b17	\$
003077	000434	-04135	0000	1000	1000	1000	1000	0000	0000	0000	%0818	b18	\$
009668	-00400	001555	1000	1000	0875	0000	0125	0000	0000	0000	%0819	c10	\$
009023	000015	-00010	0875	0875	0875	0125	0125	0125	0000	0000	%0820	c11	\$
009789	-00006	-01200	0750	0750	0750	0250	0250	0125	0000	0000	%0821	c12	\$
007932	000342	-01954	0625	0625	0875	0375	0375	0125					

%BEG GE24_22_REM.TXT, Separation cmyn5*, D50, adapted \$
%100 x LAB*a %1000 x (r g b c m y 0) %nr. pos \$
%z004842 006456 003995 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z009221 -00772 008203 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005593 -05936 003084 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005007 -04098 -04224 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z003093 001822 -04388 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z004710 007032 -00821 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z001539 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009714 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004771 006438 003893 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z009208 -00766 008229 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005592 -05687 002944 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005010 -03989 -04243 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003079 002004 -04106 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z004680 007002 -00726 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z001592 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009738 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/GE34/GE34L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

TUB registration: 20091101-GE34/GE34L0NA.TXT /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

KBEG GE24_22 REM.TXT, Separation cmvyr, D50, adapted \$									
%100 x LAB'a	1000 x (r g b c m y e)	%nr.	pos	\$					
001527	-00003	000041	0000	0000	1000	1000	1000	0000	%0972 k01
002203	-00006	-00012	0125	0125	0125	0875	0875	0000	%0973 k02
003041	-00025	-00091	0250	0250	0250	0750	0750	0000	%0974 k03
005045	-00020	-00093	0375	0375	0375	0625	0625	0000	%0975 k04
006137	-00016	-00074	0500	0500	0500	0500	0500	0000	%0976 k05
007156	-00005	-00074	0625	0625	0625	0375	0375	0000	%0977 k06
008025	-00006	-00037	0750	0750	0750	0250	0250	0000	%0978 k07
009012	000004	-00003	0875	0875	0875	0125	0125	0000	%0979 k08
009724	-00016	-00015	1000	1000	1000	0000	0000	0000	%0980 k09
001518	000000	000041	0000	0000	0000	1000	1000	0000	%0981 l01
002191	-00002	-00014	0125	0125	0125	0875	0875	0000	%0982 l02
003021	-00022	-00091	0250	0250	0250	0750	0750	0000	%0983 l03
004975	-00013	-00089	0375	0375	0375	0625	0625	0000	%0984 l04
006057	-00008	-00091	0500	0500	0500	0500	0500	0000	%0985 l05
007086	-00002	-00071	0625	0625	0625	0375	0375	0000	%0986 l06
007984	-00008	-00031	0750	0750	0750	0250	0250	0000	%0987 l07
009025	-00002	000005	0875	0875	0875	0125	0125	0000	%0988 l08
009720	-00019	-00005	1000	1000	1000	0000	0000	0000	%0989 l09
001452	000006	000038	0000	0000	0000	1000	1000	0000	%0990 m01
002172	-00006	-00015	0125	0125	0125	0875	0875	0000	%0991 m02
003021	-00015	-00066	0250	0250	0250	0750	0750	0000	%0992 m03
004903	-00011	-00081	0375	0375	0375	0625	0625	0000	%0993 m04
006052	-00009	-00086	0500	0500	0500	0500	0500	0000	%0994 m05
007080	-00004	-00063	0625	0625	0625	0375	0375	0000	%0995 m06
007988	-00007	-00023	0750	0750	0750	0250	0250	0000	%0996 m07
009022	-00002	000012	0875	0875	0875	0125	0125	0000	%0997 m08
009728	-00017	-00008	1000	1000	1000	0000	0000	0000	%0998 m09
001308	000003	000051	0000	0000	0000	1000	1000	0000	%0999 n01
002115	-00005	-00012	0125	0125	0125	0875	0875	0000	%1000 n02
003756	-00015	-00071	0250	0250	0250	0750	0750	0000	%1001 n03
004960	-00009	-00067	0375	0375	0375	0625	0625	0000	%1002 n04
005996	-00004	-00069	0500	0500	0500	0500	0500	0000	%1003 n05
007042	-00000	-00054	0625	0625	0625	0375	0375	0000	%1004 n06
007966	-00010	-00023	0750	0750	0750	0250	0250	0000	%1005 n07
008988	000005	000012	0875	0875	0875	0125	0125	0000	%1006 n08
009719	-00012	-00008	1000	1000	1000	0000	0000	0000	%1007 n09
001452	000014	000028	0000	0000	0000	1000	1000	0000	%1008 k10
001739	000013	000013	0006	0066	0066	0033	0933	0933	%1009 k11
002476	-00010	-00071	0133	0133	0133	0866	0866	0000	%1010 k12
003316	-00013	-00103							

TUB-test chart GE34; Relative Device Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```