

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE52/GE52L0NA.TXT/.PS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cf1=0.90; nt=0.18; nx=1.00

TUB registration: 20091101-GE52/GE52L0NA.TXT /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

SBEQ GE42.22.TXT, Separation cmy6n*, cf1=0.90, D65, not adapted \$									
\$100x	\$ LAB*	\$1000	\$ x (r	\$ g b	\$ c m y 0)	\$xnr	\$ pos \$		
000000	-00082	000291	1000	0000	0000	0000	0000	0000	0000
000826	-000523	000591	0875	1000	0125	0000	0000	0000	0000
000845	-000675	000803	0750	1000	0250	0000	0000	0000	0000
000784	-01172	-011446	0625	1000	0375	0000	0000	0000	0000
0007305	-01489	-01586	0500	1000	0500	0000	0000	0000	0000
0006794	-01827	-02181	0375	1000	0625	0000	0000	0000	0000
0006265	-02325	-02753	0250	1000	0750	0000	0000	0000	0000
0005759	-02677	-03038	0125	1000	0875	0000	0000	0000	0000
0005324	-03033	-03693	0000	1000	1000	0000	0000	0000	0000
0000721	000709	000614	1000	0875	0875	0000	0125	0125	0000
0000482	-00067	000206	0875	0875	0875	0125	0125	0125	0000
0008094	-00621	-00502	0750	0875	0875	0250	0125	0125	0000
0007297	-00790	-00802	0625	0875	0875	0375	0125	0125	0000
0006834	-01149	-01303	0500	0875	0875	0500	0125	0125	0000
0006315	-01490	-01807	0375	0875	0875	0625	0125	0125	0000
0005727	-01866	-02407	0250	0875	0875	0750	0125	0125	0000
0005280	-02276	-02729	0125	0875	0875	0875	0125	0125	0000
0004820	-02347	-03128	0000	0875	0875	1000	0125	0125	0000
0003900	001334	000899	1000	0750	0750	0000	0250	0250	0000
0007910	000565	000490	0875	0750	0750	0125	0250	0250	0000
0007488	000010	000163	0750	0750	0750	0250	0250	0250	0000
0006384	-0494	-0425	0625	0750	0750	0375	0250	0250	0000
0006385	-06742	-06841	0500	0750	0750	0500	0250	0250	0000
0005870	-0132	-01567	0375	0750	0750	0625	0250	0250	0000
0005437	-01559	-01833	0250	0750	0750	0750	0250	0250	0000
0004469	-02021	-02275	0125	0750	0750	0875	0250	0250	0000
0004452	-02087	-02760	0000	0750	0750	1000	0250	0250	0000
0007806	001964	001513	1000	0625	0625	0000	0375	0375	0000
0007324	001277	000896	0875	0625	0625	0125	0375	0375	0000
0006827	000672	000575	0750	0625	0625	0250	0375	0375	0000
0006402	000056	000176	0625	0625	0625	0375	0375	0375	0000
0006059	-00550	-00404	0500	0625	0625	0500	0375	0375	0000
0005482	-00900	-00935	0375	0625	0625	0625	0375	0375	0000
0004955	-01237	-01616	0250	0625	0625	0750	0375	0375	0000
0004500	-01534	-01857	0125	0625	0625	0875	0375	0375	0000
0004103	-01763	-02323	0000	0625	0625	1000	0375	0375	0000
0007150	002806	001958	1000	0500	0500	0000	0500	0500	0000
0006681	001944	001463	0875	0500	0500	0125	0500	0500	0000
0006272	001309	001220	0750	0500	0500	0250	0500	0500	0000
0005729	000760	000630	0625	0500	0500	0375	0500	0500	

TUB-test chart GE52; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

input: w *setgray*
output: no change compared to input

```
input: w setgray
output: ->oly* setrgbcolor
```

[illegible]

009662	-00093	000206	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
009583	-00036	-00336	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
008082	000053	-00790	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
007278	000269	-01220	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
006557	000347	-01645	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
005928	000446	-02107	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$
005251	000456	-02672	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
004469	000664	-03342	0125	0343	1000	0875	0656	0000	0000	%0250	b08	\$
003984	000664	-03500	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
009022	000193	000852	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
008484	-00070	000282	0875	0875	0875	0000	0125	0125	0000	%0253	c02	\$
007900	-00072	-00333	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
007013	000926	-00877	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
006360	000278	-01320	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
005625	000337	-01819	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
004931	000444	-02350	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
004209	000690	-02887	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
003732	000636	-03045	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
008867	000267	-001617	1000	0937	0750	0000	0662	0250	0000	%0261	d01	\$
008271	000063	000743	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
007492	000009	000096	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$
006642	000043	-00264	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
006069	000085	-00943	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
005338	000231	-01381	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
004600	000339	-01871	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
004073	000377	-02310	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
003495	000527	-02618	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
008078	000246	002535	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
008029	000102	001509	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
007224	000064	000816	0750	0718	0875	0625	0250	0281	0375	%0272	e03	\$
006433	000043	000159	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
005852	000065	-00411	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
005225	000143	-01039	0375	0437	0625	0625	0562	0375	0000	%0275	e06	\$
004337	000175	-01486	0250	0343	0625	0750	0656	0375	0000	%0276	e07	\$
003798	000314	-01886	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
003071	000494	-02302	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
008529	000347	003377	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
007814	000151	002616	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
006956	000140	001932	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
006217	000042	000926	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
005390	000062	000142	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
004994	000023	-000465	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
004371	000189	-01109	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
003504	000306	-01586	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
002828	000320	-01924	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
002821	000497	004282	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
007463	000318	003239	0875	0750	0375	0125	0250	0625	0000	%0289	g02	\$
006765	000218	002703	0750	0656	0375	0250	0343	0625	0000	%0290	g03	\$
005930	000123	002017	0625	0562	0375	0375	0437	0625	0000	%0291	g04	\$
005095	000038	001066	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
004454	000066	000102	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
004157	000098	-00075	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
003445	000157	-01110	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
002586	000473	-01463	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
007985	000769	005118	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
007122	000456	004231	0875	0718	0875	0500	0125	0812	0500	%0298	h02	\$
006207	000308	003425	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
005490	000321	002670	0625	0531	0250	0375	0437	0750	0000	%0300	h04	\$
004847	000242	-001786	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
004335	000027	000965	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
003658	000309	000027	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
003186	000243	-00713	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
002664	000318	-01126	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
007789	000851	005916	1000	0781	0125	0000	0218	0875	0000	%0306	i01	\$
006906	000509	004778	0875	0687	0125	0125	0312	0875	0000	%0307	i02	\$
006072	000455	004060	0750	0593	0125	0250	0406	0875	0000	%0308	i03	\$
005222	000531	003320	0625	0500	0125	0375	0500	0875	0000	%0309	i04	\$
004611	000357	002612	0500	0406	0125	0500	0593	0875	0000	%0310	i05	\$
004188	000196	001784	0375	0312	0125	0625	0687	0875	0000	%0311	i06	\$
003663	-00027	000949	0250	0218	0125	0750	0781	0875	0000	%0312	i07	\$
002743	000015	000055	0125	0125	0125	0875	0875	0875	0000	%0313	i08	\$
002747	000170	-00698	0000	0031	0125	1000	0968	0875	0000	%0314	i09	\$
007465	000963	006585	1000	0750	0000	0000	0250	1000	0000	%0315	j01	\$
006653	000662	005794	0875	0656	0000	0125	0343	1000	0000	%0316	j02	\$
005780	000741	005081	0750	0562	0000	0250	0437	1000	0000	%0317	j03	\$
005079	000568	004374	0625	0468	0000	0375	0531	1000	0000	%0318	j04	\$
004435	000550	003275	0500	0375	0000	0500	0625	1000	0000	%0319	j05	\$
003974	000161	002574	0375	0281	0000	0625	0718	1000	0000	%0320	j06	\$
003550	000008	002021	0250	0187	0000	0750	0812	1000	0000	%0321	j07	\$
002804	-00136	001253	0125	0093	0000	0875	0906	1000	0000	%0322	j08	\$
002475	-00213	000070	0000	0000	0000	1000	1000	1000	0000	%0323	j09	\$
009695	-00091	000194	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
008798	-000493	-00452	0800	0875	1000	0031	0125	0000	0000	%0568	b11	\$
008214	001208	-00319	0037	0750	1000	0062	0250	0000	0000	%0569	b12	\$
007742	001666	-00536	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$
006963	002182	-00853	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$
006369	002783	-00965	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$
005656	003461	-01241	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$
004948	004023	-01495	0781	0250	1000	0248	0875	0000	0000	%0574	b17	\$
004132	004968	-01529	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$
009027	-00672	000537	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$
008655	-00064	000188	0875	0875	0125	0125	0125	0000	0000	%0577	c11	\$
008110	000486	-00414	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$
007407	001119	-00389	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$
006773	001756	-00565	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$
006038	002463	-00897	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$
005154	003151	-01126	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$
004467	003688	-01402	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$
003644	004561	-01740	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$
008698	-01094	000838	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$
008223	-00629	000513	0781	0875	0750	0218						

See original or copy: <http://web.me.com/klaus.richter/GE52/GE52L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG GE42 22.TXT, Separation cmyn6*, cfi=0.90, D65, not adapted $
%100 x LAB*      %1000 x (r g b c m y o)      %nr.      pos $
%z004582 006175 003877 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008742 -01294 007378 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z005613 -05647 003067 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005324 -03033 -03963 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z003414 002156 -03926 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z004606 006535 -01065 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z002423 -00214 000089 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009677 -00084 000192 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%z004582 006175 003877 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008742 -01294 007378 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z005613 -05647 003067 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005324 -03033 -03963 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z003414 002156 -03926 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z004606 006535 -01065 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z002423 -00214 000089 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009677 -00084 000192 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%z004582 006175 003877 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008742 -01294 007378 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z005613 -05647 003067 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005324 -03033 -03963 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z003414 002156 -03926 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z004606 006535 -01065 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z002423 -00214 000089 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009677 -00084 000192 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%z005507 004121 004556 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z007814 -02774 006774 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z005514 -04913 000647 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z004684 -01247 -03599 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003462 003184 -03451 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z004682 006211 000447 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z002467 -00209 000089 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009677 -00091 000211 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%z006503 002762 005740 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z007042 -03977 005587 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z005608 -04399 -00548 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z004344 -00321 -03567 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z003816 003721 -02730 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z004679 006072 001681 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z002441 -00209 000068 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009683 -00089 000199 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%z007465 000963 006585 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z006439 -05179 004534 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005413 -03926 -01937 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z003984 000664 -03509 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z004132 004908 -01920 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z004630 006039 002833 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z002331 -00217 000080 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009678 -00093 000204 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE52/GE52L0NA.TXT> / PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=

TUB registration: 20091101-GE52/GE52L0NA.TXT /.PS
application for evaluation and measurement of printer or

TUB material: code=rha4ta

XBD	GEAB	22.TXT,	separation	cm yb	cfl=0.90,	D65	not	adapted	
#100	x	LAB	1000	x	(r g b	c m y	0 0)	%nr.	pos \$
0022114	-00213	000122	0009	0090	0090	1000	1000	0000	%0972 k01 \$
0022464	-00018	000188	0125	0125	0125	0875	0875	0875	%0973 k02 \$
0034350	000016	000045	0250	0250	0250	0750	0750	0750	%0974 k03 \$
0034503	000072	000110	0375	0375	0375	0625	0625	0625	%0975 k04 \$
0053330	000067	000125	0500	0500	0500	0500	0500	0500	%0976 k05 \$
006494	000039	000134	0625	0625	0625	0375	0375	0375	%0977 k06 \$
007614	000000	000091	0750	0750	0750	0250	0250	0250	%0978 k07 \$
008577	-00054	000169	0875	0875	0875	0125	0125	0125	%0979 k08 \$
009700	-00079	000187	1000	1000	1000	0000	0000	0000	%0980 k09 \$
002086	-00209	000098	0000	0000	0000	1000	1000	0000	%0981 k01 \$
002426	000010	000072	0125	0125	0125	0875	0875	0875	%0982 k02 \$
003419	000023	000041	0250	0250	0250	0750	0750	0750	%0983 k03 \$
004249	000073	000098	0375	0375	0375	0625	0625	0625	%0984 k04 \$
005317	000088	000103	0500	0500	0500	0500	0500	0500	%0985 k05 \$
006506	000039	000134	0625	0625	0625	0375	0375	0375	%0986 k06 \$
007609	-00001	000094	0750	0750	0750	0250	0250	0250	%0987 k07 \$
008613	-00058	000181	0875	0875	0875	0125	0125	0125	%0988 k08 \$
009702	-00083	000186	1000	1000	1000	0000	0000	0000	%0989 k09 \$
002062	000199	000126	0000	0000	0000	1000	1000	0000	%0990 m01 \$
002427	000013	000081	0125	0125	0125	0875	0875	0875	%0991 m02 \$
002428	000013	000081	0125	0125	0125	0875	0875	0875	%0992 m03 \$
002417	000077	000111	0375	0375	0375	0625	0625	0625	%0993 m04 \$
005255	000092	000120	0500	0500	0500	0500	0500	0500	%0994 m05 \$
006423	000044	000180	0625	0625	0625	0375	0375	0375	%0995 m06 \$
007596	000002	000108	0750	0750	0750	0250	0250	0250	%0996 m07 \$
008587	-00061	000197	0875	0875	0875	0125	0125	0125	%0997 m08 \$
009703	00085	000195	1000	1000	1000	0000	0000	0000	%0998 m09 \$
002061	000199	000090	0000	0000	0000	1000	1000	0000	%0999 n01 \$
002418	000096	000094	0125	0125	0125	0875	0875	0875	%1000 n02 \$
003464	000023	000046	0250	0250	0250	0750	0750	0750	%1001 n03 \$
004327	000071	000121	0375	0375	0375	0625	0625	0625	%1002 n04 \$
0053338	000075	000128	0500	0500	0500	0500	0500	0500	%1003 n05 \$
006482	000041	000163	0625	0625	0625	0375	0375	0375	%1004 n06 \$
007608	000009	000107	0750	0750	0750	0250	0250	0250	%1005 n07 \$
008575	-00060	000193	0875	0875	0875	0125	0125	0125	%1006 n08 \$
009699	-00086	000188	1000	1000	1000	0000	0000	0000	%1007 n09 \$
002375	-00215	000047	0000	0000	0000	1000	1000	0000	%1008 k10 \$
002304	-00151	000057	0006	0066					

008422	-00020	000176	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$
008712	-00061	000201	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$
009659	-00083	000200	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$
002359	-00206	000042	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$
002273	-00139	000067	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$
002820	-00004	000116	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$
033196	000025	000080	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$
003959	000021	000103	0266	0266	0266	0733	0733	0733	0000	%1060	n14	\$
004331	000061	000141	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$
004653	000029	000129	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$
005250	-00003	000182	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$
005839	000032	000193	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$
006314	-00042	000210	0600	0600	0600	0399	0399	0399	0000	%1065	n19	\$
006687	-00024	000239	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$
007349	000014	000110	0733	0733	0733	0266	0266	0266	0000	%1067	n21	\$
007965	-00044	000178	0800	0800	0800	0199	0199	0199	0000	%1068	n22	\$
008375	-00009	000185	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$
008686	-00056	000190	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$
009644	-00081	000187	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$
002130	-00230	000084	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$
009620	-00079	000190	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$
004527	006211	004207	0000	0000	0000	1000	1000	1000	0000	%1074	l26	\$
005330	-03512	-03720	0000	1000	1000	1000	0000	0000	0000	%1075	l27	\$
008601	-01256	007800	1000	0000	0000	0000	0000	1000	0000	%1076	m26	\$
003225	002263	-03973	0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$
005453	-05987	003346	0000	1000	0000	1000	0000	1000	0000	%1078	n26	\$
004555	006538	-01110	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$
%\$												
%z004527	006211	004207	%#1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$
%z008601	-01256	007800	%#1000	1000	0000	0000	0000	1000	0000	%1076	m26	\$
%z005453	-05987	003346	%#0000	1000	0000	1000	0000	1000	0000	%1078	n26	\$
%z005330	-03512	-03720	%#0000	1000	1000	1000	0000	0000	0000	%1075	l26	\$
%z003225	002263	-03973	%#0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$
%z004555	006538	-01110	%#1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$
%z002130	-00230	000094	%#0000	0000								

26	%03	0	\$
26	%Y3	1	\$
26	%L3	2	\$
27	%C3	3	\$
27	%V3	4	\$
27	%M3	5	\$
26	%N3	6	\$
27	%W3	7	\$
01	%N4	6	\$
09	%W4	7	\$
01	%N5	6	\$
09	%W5	7	\$
01	%N6	6	\$
09	%W6	7	\$
01	%N7	6	\$
09	%W7	7	\$

TUB-test chart GE52; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

%BEG GE42 22.TXT, Separation cmykn6*, cfi=0.90, D65, adapted S																										
%100 x LAB*a																										
1000 x (r g b c m y o)																										
%nrr. pos \$																										
0099705	-00001	-00007	1000	1000	1000	0000	0000	0000	0000	%0324	A10	\$	0099669	-00001	0000000	1000	1000	0000	0000	0000	0000	0000	%0648	A19	\$	
0086649	000236	-00540	0875	0875	1000	0125	0125	0000	0000	%0325	A11	\$	0088805	000958	-00553	1000	0875	1000	0000	0125	0000	0000	0000	0000	0000	0000
0081403	000500	-00944	0750	0750	1000	0250	0250	0000	0000	%0326	A12	\$	0083322	001586	-00200	1000	0750	1000	0000	0250	0000	0000	0000	0000	0000	
007231	000743	-01332	0625	0625	1000	0375	0375	0000	0000	%0327	A13	\$	007911	002505	-00348	1000	0625	1000	0000	0375	0000	0000	0000	0000	0000	
006384	001129	-01784	0500	0500	1000	0500	0500	0000	0000	%0328	A14	\$	007285	003441	-00627	1000	0500	1000	0000	0500	0000	0000	0000	0000	0000	
005636	001364	-02357	0375	0375	1000	0625	0625	0000	0000	%0329	A15	\$	006599	004339	-00788	1000	0375	1000	0000	0625	0000	0000	0000	0000	0000	
004885	001628	-02978	0250	0250	1000	0750	0750	0000	0000	%0330	A16	\$	005871	004852	-00761	1000	0250	1000	0000	0750	0000	0000	0000	0000	0000	
004037	001807	-03570	0125	0125	1000	0875	0875	0000	0000	%0331	A17	\$	005210	005931	-01008	1000	0125	1000	0000	0875	0000	0000	0000	0000	0000	
003414	002353	-04339	0000	0000	1000	1000	1000	0000	0000	%0332	A18	\$	004658	006710	-01136	1000	0000	1000	0000	1000	0000	0000	0000	0000	0000	
009428	-00068	000590	1000	1000	0875	0000	0125	0000	0000	%0333	B10	\$	008976	-00826	000263	0875	1000	0875	0125	0000	0125	0000	0000	0000	0000	
008649	000036	000022	0875	0875	0125	0125	0125	0000	0000	%0334	B11	\$	008555	000044	000017	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	
007945	000257	-00577	0750	0750	0875	0250	0250	0125	0000	%0335	B12	\$	008033	001017	-00298	0875	0750	0875	0125	0250	0125	0000	0000	0000	0000	
006900	000531	-01013	0625	0625	0875	0375	0375	0125	0000	%0336	B13	\$	007366	001754	-00348	0875	0625	0875	0125	0375	0125	0000	0000	0000	0000	
006191	000880	-01382	0500	0500	0875	0500	0500	0125	0000	%0337	B14	\$	006729	002400	-00348	0875	0500	0875	0125	0500	0125	0000	0000	0000	0000	
005397	001151	-01888	0375	0375	0875	0625	0625	0125	0000	%0338	B15	\$	006065	003279	-00512	0875	0375	0875	0125	0625	0125	0000	0000	0000	0000	
004605	001492	-02444	0250	0250	0875	0750	0750	0125	0000	%0339	B16	\$	005300	004105	-00609	0875	0250	0875	0125	0750	0125	0000	0000	0000	0000	
003804	001963	-03059	0125	0125	0875	0875	0875	0125	0000	%0340	B17	\$	004751	004734	-00778	0875	0125	0875	0125	0875	0125	0000	0000	0000	0000	
003195	002066	-03408	0000	0000	0875	1000	1000	0125	0000	%0341	B18	\$	004140	005916	-00934	0875	0000	0875	0125	1000	0125	0000	0000	0000	0000	
002926	-00059	001523	1000	1000	0750	0000	0250	0000	0000	%0342	C10	\$	008428	-01381	000521	0750	1000	0750	0250	0000	0250	0000	0000	0000	0000	
008598	-00077	000675	0875	0875	0750	0125	0125	0250	0000	%0343	C11	\$	008024	-00722	000368	0750	0875	0750	0250	0125	0250	0000	0000	0000	0000	
007648	000103	-00038	0750	0750	0250	0250	0250	0000	0000	%0344	C12	\$	007602	000131	-00062	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	
006723	000257	-00389	0625	0625	0750	0375	0375	0250	0000	%0345	C13	\$	006875	001036	-00295	0750	0625	0750	0250	0375	0250	0000	0000	0000	0000	
005951	000650	-01106	0500	0500	0750	0500	0500	0250	0000	%0346	C14	\$	006167	001858	-00282	0750	0500	0750	0250	0500	0250	0000	0000	0000	0000	
005183	000950	-01380	0375	0375	0750	0625	0625	0250	0000	%0347	C15	\$	005514	002616	-00332	0750	0375	0750	0250	0625	0250	0000	0000	0000	0000	
004397	001299	-01998	0250	0250	0750	0750	0750	0250	0000	%0348	C16	\$	004761	003442	-00304	0750	0250	0750	0250	0750	0250	0000	0000	0000	0000	
003685	001568	-02576	0125	0125	0750	0875	0875	0250	0000	%0349	C17	\$	004089	004127	-00525	0750	0125	0750	0250	0875	0250	0000	0000	0000	0000	
002932	001856	-03810	0000	0000	0750	1000	1000	0250	0000	%0350	C18	\$	003436	005026	-00679	0750	0000	0750	0250	1000	0250	0000	0000	0000	0000	
009222	-00357	002639	1000	1000	0625	0000	0000	0375	0000	%0351	D10	\$	007938	-02212	001224	0625	1000	0625	0375	0000	0375	0000	0000	0000	0000	
008486	-00202	001644	0875	0875	0625	0125	0125	0375	0000	%0352	D11	\$	007385	-01462	000929	0625	0875	0625	0375	0125	0375	0000	0000	0000	0000	
007518	-00120	000728	0750	0750	0625	0250	0250	0375	0000	%0353	D12	\$	006924	-00656	000535	0625	0750	0625	0375	0250	0375	0000	0000	0000	0000	
006539	000180	000011	0625	0625	0625	0375	0375	0375	0000	%0354	D13	\$	006445	-000177	000108	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	
005833	000306	-00548	0500	0500	0625	0500	0500	0375	0000	%0355	D14	\$	005643	000990	-00143	0625	0500	0625	0375	0500	0375	0000	0000	0000	0000	
004994	000935	-01117	0375	0375	0625	0625	0625	0375	0000	%0356	D15	\$	005022	-001823	000100	0625	0375	0625	0375	0625	0375	0000	0000	0000	0000	
004263	000916	-01436	0250	0250	0625	0750	0750	0375	0000	%0357	D16	\$	004338	-002560	-00171	0625	0250	0625	0375	0750	0375	0000	0000	0000	0000	
003605	001112	-02043	0125	0125	0625	0875	0875	0375	0000	%0358	D17	\$	003734	003734	-00329	0625	0125	0625	0375	0875	0375	0000	0000	0000	0000	
002658	001525	-02686	0000	0000	0625	1000	1000	0375	0000	%0359	D18	\$	003143	003963	-00459	0625	0000	0625	0375	1000	0375	0000	0000	0000	0000	
009197	-00599	003609	1000	1000	0500	0000	0000	0500	0000	%0360	E10	\$	007418	-03097	001632	0500	1000	0500	0500	0000	0500	0000	0000	0000	0000	
008374	-00475	002778	0875	0875	0500	0125	0125	0500	0000	%0361	E11	\$	006887	-00200	001239	0500	0875	0500	0500	0125	0500	0000	0000	0000	0000	
007361	-00262	002059	0750	0750	0500	0250	0250	0500	0000	%0362	E12	\$	006486	-01503	001022	0500	0750	0500	0500	0250	0500	0000	0000	0000	0000	
006438	-00057	000859	0625	0625	0500	0375	0375	0500	0000	%0363	E13	\$	005942	-00689	000463	0500	0625	0500	0500	0375	0500	0000	0000	0000	0000	
005444	000245	-000009	0500	0500	0500	0500	0500	0500	0000	%0364	E14	\$	005335	000249	-000666	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	
004960	000402	-00601	0375	0375	0500	0625	0625	0500	0000	%0365	E15	\$	004599	001013	-00037	0500	0375	0500	0500	0625	0500	0000	0000	0000	0000	
004301	000670	-01154	0250	0250	0500	0750	0750	0500	0000	%0366	E16	\$	003914	001996	-00192	0500	0250	0500	0500	0750	0500	0000	0000	0000	0000	
003477	000966	-01526	0125	0125	0500	0875	0875	0500	0000	%0367	E17	\$	003306	002519	-00355	0500	0125	0500	0500	0875	0500	0000	0000	0000	0000	
002566	001305	-02144	0000	0000	0500	1000	1000	0500	0000	%0368	E18	\$	002783	003260	-00449	0500	0000	0500	0500	1000	0500	0000	0000	0000	0000	
009132	-00788	004748	1000	1000	0375	0000	0000	0625	0000	%0369	F10	\$	006888	-03760	001927	0375	1000	0375	0625	0000	0625	0000	0000	0000	0000	
008268	-00640	003685	0875	0875	0375	0125	0125	0625	0000	%0370	F11	\$	006353	-03017	001615	0375	0875	0375	0625	0125	0625	0000	0000	0000	0000	
007249	-00320	002801	0750	0750	0375	0250	0250																			

```
input: w setgray
output: ->oly* setrgbcolor
```

TUB registration: 20091101-GE52/GE52L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

TUB-test chart GE52; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE52/GE52L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.00

See original or copy: <http://web.me.com/klaus.richter/GE52/GE52L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.00

See original or copy: <http://web.me.com/klaus.richter/GE52/GE52L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cf1=0.90; nt=0.18; nx=1.00

IJB registration: 20091101-GE52/GE52LUNA.1X1/.PS
 IJB material: code=rh4ta
 application for evaluation and measurement of printer or monitor systems

[illegible]

TUB-test chart GE52; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> oly* setrgbcolor
```

10B Material: Code-1144

See original or copy: <http://web.me.com/klaus.richter/GE52/GE52L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG GE42 22.TXT, Separation cmyn6*, cfi=0.90, D65, adapted S
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr.   pos $
%Z004582 006351 003757 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008742 -01193 007198 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005613 -05490 002931 %1000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005324 -02870 -04094 %1000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003414 002353 -04030 %1000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004606 006710 -01186 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z002423 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009677 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004582 006351 003757 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008742 -01193 007198 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005613 -05490 002931 %1000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005324 -02870 -04094 %1000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003414 002353 -04030 %1000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004606 006710 -01186 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z002423 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009677 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004582 006351 003757 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008742 -01193 007198 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005613 -05490 002931 %1000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005324 -02870 -04094 %1000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003414 002353 -04030 %1000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004606 006710 -01186 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z002423 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009677 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005507 004280 004415 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z007814 -02652 006594 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005514 -04754 000506 %1000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004684 -01874 -03726 %1000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003462 003377 -03558 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004682 006384 000320 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z002467 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009677 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z006503 002904 005598 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007042 -03843 005435 %1000 0000 0500 0000 1000 0000 0000 %0558 a10 %Y50L 1 $
%Z005608 -04242 -00674 %1000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004344 -00143 -03670 %1000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003816 003908 -02823 %1000 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004679 006245 001571 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z002441 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009683 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z007465 001094 006419 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006439 -05031 004384 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005413 -03761 -02069 %1000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003984 000853 -03617 %1000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004132 005095 -02030 %1000 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004630 006217 002715 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z002331 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009678 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE52/GE52L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

%BEG GE42 22.TXT, Separation cmy6*, cfi=0.90, D65, adapted S													
%100 x LAB*a		1000 x (r g b c m y θ)										%nrr. pos \$	
002114	000018	000027	0000	0000	0000	0000	1000	1000	1000	0000	0000	%0972	k01 \$
002464	000225	-00012	0125	0125	0125	0125	0875	0875	0875	0000	0000	%0972	k02 \$
003450	000221	-00065	0250	0250	0250	0250	0750	0750	0750	0000	0000	%0974	k03 \$
004303	000259	-00012	0375	0375	0375	0625	0625	0625	0625	0000	0000	%0975	k04 \$
005330	000234	-00010	0500	0500	0500	0500	0500	0500	0500	0000	0000	%0976	k05 \$
006494	000182	-00016	0625	0625	0625	0625	0375	0375	0375	0000	0000	%0977	k06 \$
007614	000119	-00074	0750	0750	0750	0250	0250	0250	0250	0000	0000	%0978	k07 \$
008570	000046	-00007	0875	0875	0875	0125	0125	0125	0125	0000	0000	%0978	k08 \$
009707	000000	-00004	1000	1000	1000	1000	0000	0000	0000	0000	0000	%0980	k09 \$
002086	000031	000004	0000	0000	0000	0000	1000	1000	1000	0000	0000	%0981	l01 \$
002426	000235	-00025	0125	0125	0125	0875	0875	0875	0875	0000	0000	%0982	l02 \$
003419	000228	-00069	0250	0250	0250	0750	0750	0750	0750	0000	0000	%0983	l03 \$
004249	000262	-00023	0375	0375	0375	0625	0625	0625	0625	0000	0000	%0984	l04 \$
005317	000255	-00032	0500	0500	0500	0500	0500	0500	0500	0000	0000	%0985	l05 \$
006506	000182	-00016	0625	0625	0625	0625	0375	0375	0375	0000	0000	%0986	l06 \$
007609	000119	-00070	0750	0750	0750	0250	0250	0250	0250	0000	0000	%0987	l07 \$
008613	000041	000003	0875	0875	0875	0125	0125	0125	0125	0000	0000	%0988	l08 \$
009702	-00005	-00005	1000	1000	1000	0000	0000	0000	0000	0000	0000	%0989	l09 \$
002062	000032	000032	0000	0000	0000	0000	1000	1000	1000	0000	0000	%0990	m01 \$
002427	000238	-00016	0125	0125	0125	0875	0875	0875	0875	0000	0000	%0991	m02 \$
003400	000233	-00075	0250	0250	0250	0750	0750	0750	0750	0000	0000	%0992	m03 \$
004217	000266	-00010	0375	0375	0375	0625	0625	0625	0625	0000	0000	%0993	m04 \$
005255	000260	-00013	0500	0500	0500	0500	0500	0500	0500	0000	0000	%0994	m05 \$
006423	000189	000030	0625	0625	0625	0375	0375	0375	0375	0000	0000	%0995	m06 \$
007596	000122	-00055	0750	0750	0750	0250	0250	0250	0250	0000	0000	%0996	m07 \$
008587	000039	000020	0875	0875	0875	0125	0125	0125	0125	0000	0000	%0997	m08 \$
009703	-00007	000003	1000	1000	1000	0000	0000	0000	0000	0000	0000	%0998	m09 \$
002061	000033	-00003	0000	0000	0000	0000	1000	1000	1000	0000	0000	%0999	n01 \$
002418	000232	-00003	0125	0125	0125	0875	0875	0875	0875	0000	0000	%1000	n02 \$
003464	000227	-00065	0250	0250	0250	0750	0750	0750	0750	0000	0000	%1001	n03 \$
004327	000258	-00001	0375	0375	0375	0625	0625	0625	0625	0000	0000	%1002	n04 \$
005338	000244	-00007	0500	0500	0500	0500	0500	0500	0500	0000	0000	%1003	n05 \$
006482	000184	000012	0625	0625	0625	0375	0375	0375	0375	0000	0000	%1004	n06 \$
007608	000130	000057	0750	0750	0750	0250	0250	0250	0250	0000	0000	%1005	n07 \$
008575	000040	000016	0875	0875	0875	0125	0125	0125	0125	0000	0000	%1006	n08 \$
009699	-00007	-00003	1000	1000	1000	0000	0000	0000	0000	0000	0000	%1007	n09 \$
002375	000010	-00049	0000	0000	0000	0000	1000	1000	1000	0000	0000	%1008	k10 \$
002304	000075	-00039	0066	0066	0066	0933	0933	0933	0933	0000	0000	%1009	k11 \$
002802	000207	-00013	0133	0133	0133	0866	0866	0866	0866	0000	0000	%1010	k12 \$
003151	000233	-00058	0200	0200	0200	0800	0800	0800	0800	0000	0000	%1011	k13 \$
003983	000217	-00072	0266	0266	0266	0733	0733	0733	0733	0000	0000	%1012	k14 \$
004379	000250	-00013	0333	0333	0333	0666	0666	0666	0666	0000	0000	%1013	k15 \$
004653	000207	-00035	0400	0400	0400	0600	0600	0600	0600	0000	0000	%1014	k16 \$
005292	000161	000009	0466	0466	0466	0533	0533	0533	0533	0000	0000	%1015	k17 \$
005873	000191	000019	0533	0533	0533	0466	0466	0466	0466	0000	0000	%1016	k18 \$
006389	000095	000036	0600	0600	0600	0399	0399	0399	0399	0000	0000	%1017	k19 \$
006752	000116	000055	0666	0666	0666	0333	0333	0333	0333	0000	0000	%1018	k20 \$
007385	000133	-00049	0733	0733	0733	0266	0266	0266	0266	0000	0000	%1019	k21 \$
007993	000066	000003	0800	0800	0800	0199	0199	0199	0199	0000	0000	%1020	k22 \$
008374	000084	-00002	0866	0866	0866	0133	0133	0133	0133	0000	0000	%1021	k23 \$
008654	000043	000012	0933	0933	0933	0066	0066	0066	0066	0000	0000	%1022	k24 \$
009616	000001	-00004	1000	1000	1000	0000	0000	0000	0000	0000	0000	%1023	k25 \$
002347	000016	-00032	0000	0000	0000	0000	1000	1000	1000	0000	0000	%1024	l10 \$
002258	000086	-00009	0066	0066	0066	0933	0933	0933	0933	0000	0000	%1025	l11 \$
002805	000213	000021	0133	0133	0133	0866	0866	0866	0866	0000	0000	%1026	l12 \$
003126	000237	-00028	0200	0200	0200	0800	0800	0800	0800	0000	0000	%1027	l13 \$
003936	000219	-00044	0266	0266	0266	0733	0733	0733	0733	0000	0000	%1028	l14 \$
004351	000258	-00003	0333	0333	0333	0666	0666	0666	0666	0000	0000	%1029	l15 \$
004587	000224	-00038	0400	0400	0400	0600	0600	0600	0600	0000	0000	%1030	l16 \$
005282	000179	000002	0466	0466	0466	0533	0533	0533	0533	0000	0000	%1031	l17 \$
005845	000215	-00012	0533	0533	0533	0466	0466	0466	0466	0000	0000	%1032	l18 \$
006349	000124	-00018	0600	0600	0600	0399	0399	0399	0399	0000	0000	%1033	l19 \$
006724	000131	000017	0666	0666	0666	0333	0333	0333	0333	0000	0000	%1034	l20 \$
007392	000142	-00063	0733	0733	0733	0266	0266	0266	0266	0000	0000	%1035	l21 \$
008006	000071	-00006	0800	0800	0800	0199	0199	0199	0199	0000	0000	%1036	l22 \$
008416	000078	-00010	0866	0866	0866	0133	0133	0133	0133	0000	0000	%1037	l23 \$
008714	000041	000007	0933	0933	0933	0066	0066	0066	0066	0000	0000	%1038	l24 \$
009651	000000	-00003	1000	1000	1000	0000	0000	0000	0000	0000	0000	%1039	l25 \$
002309	000018	-00041	0000	0000	0000	0000	1000	1000	1000	0000	0000	%1040	m10 \$
002236	000088	-00007	0066	0066	0066	0933	0933	0933	0933	0000	0000	%1041	m11 \$
002766	000212	000026	0133	0133	0133	0866	0866	0866	0866	0000	0000	%1042	m12 \$
003134	000248	-00025	0200	0200	0200	0800	0800	0800	0800	0000	0000	%1043	m13 \$
003908	000222	-00038	0266	0266	0266	0733	0733	0733	0733	0000	0000	%1044	m14 \$
004313	000257	000024	0333	0333	0333	0666	0666	0666	0666	0000	0000	%1045	m15 \$
004580	000217	-00021	0400	0400	0400	0600	0600	0600	0600	0000	0000	%1046	m16 \$
005252	000171	000042	0466	0466	0466	0533	0533	0533	0533	0000	0000	%1047	m17 \$
005827	000209	000023	0533	0533	0533	0466	0466	0466	0466	0000	0000	%1048	m18 \$
006294	000109	000048	0600	0600	0600	0399	0399	0399	0399	0000	0000	%1049	m19 \$
006707	000131	000034	0666	0666	0666	0333	0333	0333	0333	0000	0000	%1050	m20 \$
007363	000139	-00045	0733	0733	0733	0266	0266	0266	0266	0000	0000	%1051	m21 \$
007982	000074	-00005	0800	0800	0800	0199	0199	0199	0199	0000	0000	%1052	m22 \$

TUB-test chart GE52; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrabcnclor
```

TUB registration: 20091101-GE52/GE52L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/GE52/GE52L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.00

See original or copy: <http://web.me.com/klaus.richter/GE52/GE52L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cf1=0.90; nt=0.18; nx=1.00

TUB registration: 20091101-GE52/GE52L0NA.TXT /.PS TUB material: code=rha4ta
 application for evaluation and measurement of printer or monitor systems

[illegible]

TUB-test chart GE52; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50


```
input: w setgray
output: -> oly* setrgbcolor
```

009673	-00061	000187	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
009583	-00220	-00380	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
008081	-00240	-00843	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
007362	-00360	-01254	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
006127	-00318	-01672	0500	0787	1000	0500	0250	0000	0000	%0166	S05	\$
006732	-00416	-02171	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
005499	-00601	-02683	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
004857	-00760	-03273	0125	0562	1000	0875	0500	0000	0000	%0169	S08	\$
004253	-00917	-03731	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$
008916	-00967	-000771	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
008500	-00037	000197	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
007903	-00243	-00413	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
007051	-00224	-00908	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
006477	-00265	-01366	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
005852	-00416	-01844	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
005203	-00665	-02301	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
004508	-00696	-02888	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
003958	-00610	-03242	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
008707	-00905	-001379	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
008175	-00034	-000707	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
007526	-00016	-000111	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$
006702	-00131	-00292	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
006158	-00267	-00952	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
005524	-00416	-01448	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
004851	-00605	-01949	0250	0500	0875	0750	0500	0250	0000	%0186	U07	\$
004307	-00651	-02438	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
003802	-00751	-02752	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
008527	-001072	-002413	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
007786	-000736	-001439	0875	0750	0625	0125	0250	0375	0000	%0190	V02	\$
007040	-000319	-000810	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
006408	-000061	-000199	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
005897	-00143	-00408	0500	0562	0625	0500	0437	0375	0000	%0193	V05	\$
005275	-00257	-01064	0375	0500	0625	0625	0625	0375	0000	%0194	V06	\$
004566	-00409	-01577	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
003972	-00533	-01915	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
003468	-00676	-02401	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
008160	-001493	-003058	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
007474	-001047	-002278	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
006765	-000762	-001710	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
006032	-000515	-000754	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
005401	-000106	-000134	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
004975	-00156	-00567	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$
004438	-00281	-01093	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
003771	-00415	-01677	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
003159	-00560	-01957	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
007785	-001944	-003710	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
007059	-001448	-002770	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
006351	-001141	-002310	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
005679	-000851	-001743	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
005027	-000451	-000851	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
004529	-000087	-000091	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
004241	-00076	-00669	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
003541	-00224	-01174	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
003021	-00478	-01597	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
007357	-002577	-004334	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
006669	-001829	-003744	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
005973	-001546	-003103	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
005292	-001165	-002406	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$
004717	-000892	-001558	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
004320	-000364	-000898	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
003689	-000028	-000021	0250	0250	0250	0500	0750	0750	0000	%0222	Y07	\$
003298	-00955	-00740	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
002756	-00027	-01002	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
007057	-002953	-004963	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
006333	-001235	-004001	0875	0500	0125	0125	0125	0500	0875	%0226	Z02	\$
005622	-001844	-003534	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
004947	-001547	-002813	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
004303	-001282	-002143	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
004027	-000869	-001479	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
003587	-000335	-000824	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
002849	-000021	-000048	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
002806	-00016	-00602	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$
006617	-003329	-005784	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$
005801	-002678	-004900	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$
005231	-002419	-004303	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$
004647	-001957	-003553	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
004106	-001528	-002617	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
003646	-001250	-002083	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
003348	-000909	-001615	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$
002744	-000349	-001097	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$
002625	-001188	-000550	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
009701	-00062	-000204	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
008693	-000351	-000404	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$
008218	-000870	-00536	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
007577	-001162	-00775	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
006803	-001662	-01016	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
006043	-002103	-01346	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
005291	-002727	-01673	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
004584	-000933	-01273	0562	025	1000	0437	0875	0000	0000	%0493	S17	\$
003819	-003561	-012624	0000	1000	0500	1000	0000	0000	0000	%0494	S18	\$
009100	-00422	-00622	0937	1000	0875	0062	0000	0125	0000	%0495	T10	\$
008634	-00036	-000187	0875	0875	0125	0125	0125	0125	0000	%0496	T11	\$
008023	-000335	-003080	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
007322	-000845	-00514	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
006485	-001400	-00819	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
005657	-001940	-01140	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
004901	-002445	-01565	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
004189	-002859	-01917	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
003500	-003316	-02222	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
008843	-00766	-001805	0875	1000	0750	0125	0000	0250	0000	%0504	T19	\$
008333	-004428	-000537	0812	0875	0750	0187	0125	0250	0000			


009663	-00064	000199	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$	009695	-00063	000187	1000	1000	1000	0000	0000	0000	%0567	b10	\$	009677	-00063	000203	1000	1000	1000	0000	0000	0000	0000	%0891	b19	\$		
009876	-00054	-00353	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$	009880	000487	-00446	0886	0875	1000	0031	0125	0000	0000	%0568	b11	\$	008776	000841	000415	1000	0875	0906	0000	0125	0093	0000	%0892	b20	\$	
008069	-00004	-00815	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$	008234	001246	-00275	0937	0750	1000	0062	0250	0000	0000	%0569	b12	\$	008415	001473	000824	1000	0750	0812	0000	0250	0187	0000	%0893	b21	\$	
007261	000178	-01247	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$	007769	001697	-00471	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$	007871	002344	001073	1000	0625	0718	0000	0375	0281	0000	%0894	b22	\$	
006534	000212	-01682	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$	007096	002203	-00770	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$	007315	003098	001613	1000	0500	0625	0000	0500	0375	0000	%0895	b23	\$	
005896	000262	-02157	0375	0531	1000	0625	0478	0000	0000	%0248	b06	\$	006415	002812	-00854	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$	006684	004117	001990	1000	0375	0531	0000	0625	0468	0000	%0896	b24	\$	
005205	000192	-02746	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$	005714	003477	-01699	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$	005996	004891	002374	1000	0250	0437	0000	0750	0562	0000	%0897	b25	\$	
004408	000204	-03440	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$	005217	004923	-01318	0781	0125	1000	0210	0875	0000	0000	%0574	b17	\$	005401	005515	002828	1000	0125	0343	0000	0875	0562	0000	%0898	b26	\$	
003916	000245	-03619	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$	004218	004856	-01710	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$	004811	006356	003137	1000	0000	0250	0000	1000	0750	0000	%0899	b27	\$	
009037	000334	-000854	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$	009020	-00596	000496	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$	008989	-00720	-00372	0875	1000	0968	0125	0000	0031	0000	%0900	c19	\$	
008486	-00042	000197	0875	0875	0875	0000	0125	0125	0000	%0253	c02	\$	008657	-00037	000183	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$	008583	-00030	000190	0875	0875	0875	0125	0125	0125	0000	%0901	c20	\$	
007893	-00093	-00350	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$	008113	000482	-00406	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$	008011	000729	000402	0875	0750	0781	0125	0250	0218	0000	%0902	c21	\$	
006997	-00045	-00904	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$	007424	001144	-00350	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$	007416	001504	000909	0875	0625	0687	0125	0375	0312	0000	%0903	c22	\$	
006341	000173	-01349	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$	006802	001784	-00495	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$	006717	002251	001088	0875	0500	0593	0125	0500	0406	0000	%0904	c23	\$	
005597	000178	-01863	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$	006077	002486	-00799	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$	006075	000309	001540	0875	0375	0500	0125	0625	0500	0000	%0905	c24	\$	
004893	000219	-02411	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$	005206	003165	-00997	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$	005376	003803	001965	0875	0250	0406	0125	0750	0593	0000	%0906	c25	\$	
004160	000393	-02962	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$	004529	003683	-01250	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$	004825	004437	002274	0875	0125	0312	0125	0875	0687	0000	%0907	c26	\$	
003677	000296	-03134	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$	003725	004514	-01542	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$	004222	005496	002804	0875	0000	0218	0125	1000	0781	0000	%0908	c27	\$	
008893	000511	-001619	1000	0937	0750	0000	0602	0250	0000	%0261	d01	\$	008686	-00976	000771	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$	008399	-01055	-00500	0750	1000	0937	0250	0000	0062	0000	%0909	d19	\$	
008282	000181	-00741	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$	008217	-00557	000474	0781	0875	0750	0218	0125	0250	0000	%0586	d11	\$	008038	-00671	-00444	0750	0875	0843	0250	0125	0156	0000	%0910	d20	\$	
007494	000027	-000905	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$	007623	000014	000119	0750	0750	0750	0250	0250	0250	0000	%0587	d12	\$	007568	000027	000098	0750	0750	0750	0250	0250	0250	0000	%0911	d21	\$	
006638	000028	-00271	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$	006828	000501	-00279	0718	0625	0750	0281	0375	0250	0000	%0588	d13	\$	006838	000873	000490	0750	0625	0656	0250	0375	0343	0000	%0912	d22	\$	
006053	000008	-00968	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$	006141	001215	-00373	0687	0500	0750	0312	0500	0250	0000	%0589	d14	\$	006232	001606	000883	0750	0500	0562	0250	0500	0437	0000	%0913	d23	\$	
005317	000115	-01414	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$	005544	001883	-00591	0656	0375	0750	0343	0625	0250	0000	%0590	d15	\$	005565	002343	001285	0750	0375	0468	0250	0625	0531	0000	%0914	d24	\$	
004570	000168	-01918	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$	004929	002461	-00745	0625	0250	0750	0375	0750	0250	0000	%0591	d16	\$	004838	003153	001631	0750	0250	0375	0250	0750	0625	0000	%0915	d25	\$	
004032	000141	-02374	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$	004210	003153	-01048	0593	0125	0750	0406	0875	0250	0000	%0592	d17	\$	004260	003844	002925	0750	0125	0281	0250	0875	0718	0000	%0916	d26	\$	
003448	000238	-02690	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$	003515	003780	-01236	0562	0000	0750	0437	1000	0250	0000	%0593	d18	\$	003629	004645	002327	0750	0000	0187	0250	1000	0812	0000	%0917	d27	\$	
008815	000591	-002533	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$	008291	-01556	0001491	0718	1000	0625	0281	0000	0375	0000	%0594	e10	\$	007730	-01392	-00598	0625	1000	0906	0375	0000	0093	0000	%0918	e19	\$	
008041	000321	-001506	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$	007684	-01081	-00818	0687	0875	0625	0312	0125	0375	0000	%0595	e11	\$	007325	-01034	-00489	0625	0875	0812	0375	0125	0187	0000	%0919	e20	\$	
007236	000198	-000815	0750	0718	0875	0625	0250	0281	0375	0000	%0272	e03	\$	007089	-00555	000613	0656	0750	0625	0343	0250	0375	0000	%0596	e12	\$	006847	-00411	-00135	0625	0750	0718	0375	0250	0281	0000	%0920	e21	\$
006436	000073	-000160	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$	006557	000053	-000165	0625	0625	0625	0375	0375	0375	0000	%0597	e13	\$	006427	000088	000206	0625	0625	0625	0375	0375	0375	0000	%0921	e22	\$	
005846	000036	-00420	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$	005825	000005	-00228	0593	0500	0625	0406	0500	0375	0000	%0598	e14	\$	005704	000004	000537	0625	0500	0531	0375	0600	0468	0000	%0922	e23	\$	
005212	000058	-01064	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$	005212	001347	-00335	0562	0375	0625	0437	0625	0375	0000	%0599	e15	\$	005072	001646	001107	0625	0375	0437	0375	0625	0562	0000	%0923	e24	\$	
004311	000046	-01528	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$	004451	-002053	-00671	0531	0250	0625	0468	0750	0375	0000	%0600	e16	\$	004299	002482	001291	0625	0250	0343	0375	0750	0656	0000	%0924	e25	\$	
003766	000132	-01936	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$	003858	002603	-00853	0500	0125	0625	0500	0875	0375	0000	%0601	e17	\$	003817	00												



See original or copy: <http://web.me.com/klaus.richter/GE52/GE52L0NA.TXT> /PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0



TUB registration: 20091101-GE52/GE52L0NA.TXT /PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta



%BEG GE42 22.TXT, Separation cmy6*, cfi=0.90, D50, not adapted S										%nr. pos \$									
%100 x LAB*																			
1000 x (r g b c m y 0)																			
002110	-00193	000109	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$							
002465	000013	000087	0125	0125	0125	0875	0875	0875	0000	%0871	k02	\$	008425	000007	000173	0866	0866	0866	0133
003451	000025	000047	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$	008714	-00033	000197	0933	0933	0933	0066
004306	000094	000114	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$	009660	-00054	000194	1000	1000	1000	0000
005333	000092	000127	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$	002355	-00196	000029	0000	0000	0000	1000
006497	000065	000135	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$	002271	-00127	000058	0066	0066	0066	0933
007615	000015	000089	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$	002822	000012	000117	0133	0133	0133	0866
008759	-00029	000105	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$	003197	000038	000082	0200	0200	0200	0800
009701	-00051	000180	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$	003961	000037	000105	0266	0266	0266	0733
002083	-00183	000085	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$	004335	000086	000143	0333	0333	0333	0666
002427	000021	000074	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$	004655	000051	000131	0400	0400	0400	0600
003420	000032	000042	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$	005253	000024	000182	0466	0466	0533	0533
004252	000094	000102	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$	005842	000065	000194	0533	0533	0533	0466
005321	000111	000106	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$	006316	-00011	000208	0600	0600	0600	0399
006509	000065	000135	0625	0625	0625	0375	0375	0375	0000	%0986	l06	\$	006690	000011	000237	0666	0666	0666	0333
007610	000015	000093	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$	007351	000033	000110	0733	0733	0733	0266
008614	-00032	000176	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$	007966	-00018	000175	0800	0800	0800	0199
009703	-00056	000179	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$	008378	000019	000183	0866	0866	0866	0133
002060	-00179	000114	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$	008687	-00030	000186	0933	0933	0933	0066
002429	000025	000083	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$	009645	-00054	000181	1000	1000	1000	0000
003401	000036	000037	0250	0250	0250	0750	0750	0750	0000	%0992	m03	\$	002126	-00213	000079	0000	0000	0000	1000
004221	000100	000114	0375	0375	0375	0625	0625	0625	0000	%0993	m04	\$	009645	-00054	000181	1000	1000	1000	0000
005259	000118	000124	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$	002126	-00213	000079	0000	0000	0000	1000
006426	000077	000181	0625	0625	0625	0375	0375	0375	0000	%0995	m06	\$	004721	006564	004492	1000	0000	0000	0000
007598	000020	000107	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$	005170	-04240	-04064	0000	1000	1000	0000
008589	-00033	000193	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$	008649	-00623	007626	1000	1000	0000	0000
009704	-00057	000188	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$	003179	001822	-04020	0000	1000	1000	0000
002058	-00183	000077	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$	005376	-05565	002972	0000	1000	1000	0000
002419	000020	000096	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$	009645	-00054	000181	1000	1000	1000	0000
003465	000033	000048	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$	002126	-00213	000079	0000	0000	0000	1000
004330	000095	000124	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$	009645	-00054	000181	1000	1000	1000	0000
005341	000100	000130	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$	002126	-00213	000079	0000	0000	0000	1000
006485	000071	000154	0625	0625	0625	0375	0375	0375	0000	%1004	n06	\$	005170	-04240	-04064	0000	1000	1000	0000
007610	000028	000106	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$	008649	-00623	007626	1000	1000	0000	0000
008576	-00032	000189	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$	009645	-00054	000181	1000	1000	1000	0000
009700	-00059	000181	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$	002126	-00213	000079	0000	0000	0000	1000
002370	-00204	000034	0000	0000	0000	1000	1000	1000	0000	%1008	k10	\$	009645	-00054	000181	1000	1000	1000	0000
002302	-00140	000048	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$	002126	-00213	000079	0000	0000	0000	1000
002804	000006	000117	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$	009645	-00054	000181	1000	1000	1000	0000
003152	000031	000051	0200	0200	0200	0800	0800	0800	0000	%1011	k13	\$	002126	-00213	000079	0000	0000	0000	1000
003985	000032	000047	0266	0266	0266	0733	0733	0733	0000	%1012	k14	\$	009645	-00054	000181	1000	1000	1000	0000
004382	000086	000112	0333	0333	0333	0666	0666	0666	0000	%1013	k15	\$	002126	-00213	000079	0000	0000	0000	1000
004655	000043	000092	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$	009645	-00054	000181	1000	1000	1000	0000
005294	000017	000144	0466	0466	0466	0533	0533	0533	0000	%1015	k17	\$	002126	-00213	000079	0000	0000	0000	1000
005876	000064	000163	0533	0533	0533	0466	0466	0466	0000	%1016	k18	\$	009645	-00054	000181	1000	1000	1000	0000
006391	-00023	000183	0600	0600	0600	0399	0399	0399	0000	%1017	k19	\$	002126	-00213	000079	0000	0000	0000	1000
006755	000011	000207	0666	0666	0666	0333	0333	0333	0000	%1018	k20	\$	009645	-00054	000181	1000	1000	1000	0000
007386	000027	000112	0733	0733	0733	0266	0266	0266	0000	%1019	k21	\$	002126	-00213	000079	0000	0000	0000	1000
007995	-00021	000170	0800	0800	0800	0199	0199	0199	0000	%1020	k22	\$	009645	-00054	000181	1000	1000	1000	0000
008376	000005	000169	0866	0866	0866	0133	0133	0133	0000	%1021	k23	\$	002126	-00213	000079	0000	0000	0000	1000
008655	-00028	000186	0933	0933	0933	0066	0066	0066	0000	%1022	k24	\$	009645	-00054	000181	1000	1000	1000	0000
009617	-00051	000179	1000	1000	1000	0000	0000	0000	0000	%1023	k25	\$	002126	-00213	000079	0000	0000	0000	1000
002343	-00196	000051	0000	0000	0000	1000	1000	1000	0000	%1024	l10	\$	009645	-00054	000181	1000	1000	1000	0000
002258	-00127	000078	0066	0066	0066	0933	0933	0933	0000	%1025	l11	\$	002126	-00213	000079	0000	0000	0000	1000
002806	000014	000125	0133	0133	0133	0866	0866	0866	0000	%1026	l12	\$	009645	-00054	000181	1000	1000	1000	0000
003128	000040	000081	0200	0200	0200	0800	0800	0800	0000	%1027	l13	\$	002126	-00213	000079	0000	0000	0000	1000
003938	000036	000074	0266	0266	0266	0733	0733	0733	0000	%1028	l14	\$	009645	-00054	000181	1000	1000	1000	0000
004354	000093	000122	0333	0333	0333	0666	0666	0666	0000	%1029	l15	\$	002126	-00213	000079	0000	0000	0000	1000
004589	000059	000090	0400	0400	0400	0600	0600	0600	0000	%1030	l16	\$	009645	-00054	000181	1000	1000	1000	0000
005284	000034	000138</																	

%BEG GE42 22.TXT, Separation cmykn6*, cfi=0.90, D50, adapted S																			
%100 x LAB*a																			
1000 x (r g b c m y o)																			
%nrr. pos \$																			
009658	000004	000088	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008904	-05092	-00822	0875	1000	1000	0125	0000	0000	0000	0000	0001	A01 \$	009706	-00002	-00007	1000	1000	1000	0000
008388	-00772	-01038	0750	1000	1000	0250	0000	0000	0000	0000	0002	A02 \$	008645	000195	-00541	0875	0875	1000	0125
007798	-01213	-01406	0625	1000	1000	0375	0000	0000	0000	0000	0003	A03 \$	008138	000432	-00943	0750	0750	1000	0250
007243	-01579	-01871	0500	1000	1000	0500	0000	0000	0000	0000	0004	A04 \$	007223	000647	-01331	0625	0625	1000	0375
006712	-02082	-02500	0375	1000	1000	0625	0000	0000	0000	0000	0005	A05 \$	006374	001005	-01779	0500	0500	1000	0500
006158	-02608	-03116	0250	1000	1000	0750	0000	0000	0000	0000	0006	A06 \$	005618	001185	-02363	0375	0375	1000	0625
005636	-03032	-03427	0125	1000	1000	0875	0000	0000	0000	0000	0007	A07 \$	004857	001374	-02999	0250	0250	1000	0750
005165	-03626	-04416	0000	1000	1000	1000	0000	0000	0000	0000	0008	A08 \$	004042	001544	-03599	0125	0125	1000	0875
004743	000012	-000466	1000	0875	0875	0000	0125	0125	0000	0000	0009	B01 \$	003366	001096	-04655	0000	1000	1000	0000
004843	000041	000033	0875	0875	0875	0125	0125	0125	0000	0000	0010	B02 \$	004936	000014	-00585	1000	1000	0875	0000
008071	-00576	-00719	0750	0875	0875	0250	0125	0125	0000	0000	0011	B03 \$	008651	000038	-00025	0875	0875	0125	0125
007265	-00773	-01022	0625	0875	0875	0375	0125	0125	0000	0000	0012	B04 \$	007941	000212	-00577	0750	0750	0875	0250
006786	-01197	-01549	0500	0875	0875	0500	0125	0125	0000	0000	0013	B05 \$	006983	000454	-01011	0625	0625	0875	0375
006248	-01595	-02085	0375	0875	0875	0625	0125	0125	0000	0000	0014	B06 \$	006184	000782	-01375	0500	0500	0875	0500
005638	-02083	-02718	0250	0875	0875	0750	0125	0125	0000	0000	0015	B07 \$	005385	001012	-01886	0375	0375	0875	0625
005173	-02564	-03073	0125	0875	0875	0875	0125	0125	0000	0000	0016	B08 \$	004587	001297	-02447	0250	0250	0875	0750
004709	-02726	-03490	0000	0875	0875	1000	0125	0125	0000	0000	0017	B09 \$	003780	001690	-03067	0125	0125	0875	0875
008341	001632	000875	1000	0750	0750	0000	0250	0250	0000	0000	0018	C01 \$	003161	001717	-03430	0000	0000	0750	1000
007928	000766	000350	0875	0750	0750	0125	0250	0250	0000	0000	0019	C02 \$	002927	000146	-00515	1000	1000	0750	0000
007490	0000128	-000050	0750	0750	0750	0250	0250	0250	0000	0000	0020	C03 \$	008606	000015	-00670	0875	0875	0125	0125
006815	-00421	-00611	0625	0750	0750	0375	0250	0250	0000	0000	0021	C04 \$	007650	000098	-00031	0750	0750	0250	0250
006354	-00707	-01047	0500	0750	0750	0500	0250	0250	0000	0000	0022	C05 \$	006721	000223	-00382	0625	0625	0750	0375
005820	-01164	-01591	0375	0750	0750	0625	0250	0250	0000	0000	0023	C06 \$	005945	000566	-01100	0500	0500	0750	0500
005251	-01666	-02189	0250	0750	0750	0750	0250	0250	0000	0000	0024	C07 \$	005176	000850	-01369	0375	0375	0750	0625
004778	-02211	-02580	0125	0750	0750	0875	0250	0250	0000	0000	0025	C08 \$	004384	001143	-01993	0250	0250	0750	0750
004348	-02301	-03080	0000	0750	0750	1000	0250	0250	0000	0000	0026	C09 \$	003663	001341	-02582	0125	0125	0750	0875
007867	002354	001436	1000	0625	0625	0000	0375	0375	0000	0000	0027	D01 \$	002903	001550	-03083	0000	0000	0750	1000
007362	001576	000797	0875	0625	0625	0125	0375	0375	0000	0000	0028	D02 \$	009247	-00041	002613	1000	1000	0625	0000
006848	000918	000457	0750	0625	0625	0250	0375	0375	0000	0000	0029	D03 \$	008593	000008	-001629	0875	0875	0625	0125
006405	000209	000041	0625	0625	0625	0375	0375	0375	0000	0000	0030	D04 \$	007525	-00020	000721	0750	0750	0625	0250
006048	-00457	-00582	0500	0625	0625	0500	0375	0375	0000	0000	0031	D05 \$	006544	000186	-000821	0625	0625	0625	0375
005445	-00861	-01139	0375	0625	0625	0625	0375	0375	0000	0000	0032	D06 \$	005833	000321	-00538	0500	0500	0625	0500
004896	-01295	-01852	0250	0625	0625	0750	0375	0375	0000	0000	0033	D07 \$	004937	000510	-01116	0375	0375	0625	0625
004429	-01633	-02114	0125	0625	0625	0875	0375	0375	0000	0000	0034	D08 \$	004254	000806	-01429	0250	0250	0625	0750
004015	-01954	-02606	0000	0625	0625	1000	0375	0375	0000	0000	0035	D09 \$	003586	000938	-02052	0125	0125	0625	0875
007236	003267	001930	1000	0500	0500	0000	0500	0500	0000	0000	0036	E01 \$	002629	001252	-02705	0000	0000	0625	1000
006741	002339	001405	0875	0500	0500	0125	0500	0500	0000	0000	0037	E02 \$	009228	-00201	003564	1000	1000	0500	0000
006315	001616	001139	0750	0500	0500	0250	0500	0500	0000	0000	0038	E03 \$	008398	-00155	002743	0875	0875	0500	0125
005754	001028	000534	0625	0500	0500	0375	0500	0500	0000	0000	0039	E04 \$	007380	-00013	002040	0750	0750	0500	0250
005404	000242	000041	0500	0500	0500	0500	0500	0500	0000	0000	0040	E05 \$	006447	000063	-000856	0625	0625	0500	0375
005043	-00371	-00718	0375	0500	0500	0625	0500	0500	0000	0000	0041	E06 \$	005447	000252	-000023	0500	0500	0500	0500
004577	-00825	-01133	0250	0500	0500	0750	0500	0500	0000	0000	0042	E07 \$	004957	000351	-00592	0375	0375	0500	0625
004054	-01169	-01746	0125	0500	0500	0875	0500	0500	0000	0000	0043	E08 \$	004293	000578	-01150	0250	0250	0500	0750
003665	-01515	-02025	0000	0500	0500	1000	0500	0500	0000	0000	0044	E09 \$	003466	000847	-01522	0125	0125	0500	0875
006602	004312	002296	1000	0375	0375	0000	0625	0625	0000	0000	0045	F01 \$	002546	001108	-02151	0000	0000	0500	1000
006042	002223	001817	0875	0375	0375	0125	0625	0625	0000	0000	0046	F02 \$	009169	-00308	004681	1000	1000	0375	0000
005677	002473	001568	0750	0375	0375	0250	0625	0625	0000	0000	0047	F03 \$	008297	-00246	003633	0875	0875	0375	0125
005171	001847	001078	0625	0375	0375	0375	0625	0625	0000	0000	0048	F04 \$	007275	-00002	002773	0750	0750	0375	0250
004803	000976	000563	0500	0375	0375	0500	0625	0625	0000	0000	0049	F05 \$	006400	000005	-002122	0625	0625	0375	0375
004518	000256	000005	0375	0375	0375	0625	0625	0625	0000	0000	0050	F06 \$	005429	000065	-001093	0500	0500	0375	0500
004422	-00376	-00719	0250	0375	0375	0750	0625	0625	0000	0000	0051	F07 \$	004548	000265	-000007	0375	0375	0625	0625
003705	-00813	-01244	0125	0375	0375	0875	0625	0625	0000	0000	0052	F08 \$	004189	000396	-00599	0250	0250	0375	0750
003137	-00927	-01397	0000	0375	0375	1000	0625	0625	0000	0000	0053	F09 \$	003447	000768	-01170	0125	0125	0375	0875
005101	004974	003071	1000	0250	0250	0000	0750	0750	0000	0000	0054	G01 \$	002620	000768	-01529	0000	0000	0375	1000
004544	003907	002277	0875	0250	0250	0125	0750	0750	0000	0000	0055	G02 \$	009138	-00435	005868	1000	1000	0250	0000
005027	003301	002074	0750	0250	0250	0250	0750	0750	0000	0000	0056	G03 \$	008185	-00349	004617	0875	0875	0250	0125
004573	002525	001463	0625	0250	0250	0375	0750	0750	0000	0000	0057	G04 \$	007169	-00174	003780	0750	0750	0250	0250
004328	001709	001074	0500	0250	0250	0500	0750	0750	0000	0000	0058	G05 \$	006272	-00058	002883	0625	0625	0250	0375
004101	000994	000605	0375	0250	0250	0625	0750	0750</											

application for evaluation and measurement of printer or monitor systems

See original or copy: <http://web.me.com/klaus.richter/GE52/GE52L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1.1, Cx=0, cfl=0.90, nt=0.18; nx=1.0

[illegible]

```
input: w setgray
output: ->oly* setrgbcolor
```

TUB registration: 20091101-GE52/GE52L0NA.TXT /.PS TUB material application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

TUB-test chart GE52; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE52/GE52L0NA.TXT> / .PS
 Technical information: <http://www.ps.ban.de> V 2.1, io=1,1, Cx=0, cfi=0.90; nt=

009673	00001	00005	1000	1000	1000	0000	0000	0000	0000	00162	S01	2
000583	00139	00051	0875	0937	1000	0125	0062	0000	0000	00163	S02	3
000801	00150	00100	0750	0875	1000	0250	0125	0000	0000	00164	S03	4
007362	00256	01403	0625	0812	1000	0375	0187	0000	0000	00165	S04	5
006727	00202	00189	0500	0750	1000	0500	0250	0000	0000	00166	S05	6
006132	00289	00296	0375	0687	1000	0625	0312	0000	0000	00167	S06	7
005499	00542	002797	0250	0652	1000	0750	0375	0000	0000	00168	S07	8
004857	00609	003374	0125	0562	1000	0875	0437	0000	0000	00169	S08	9
004253	00655	003821	0000	0500	1000	0000	0500	0000	0000	00170	S09	0
008916	000542	0000953	1000	0937	0875	0000	0062	0125	0000	00171	T01	1
008500	000044	0000027	0875	0875	0875	0125	0125	0125	0000	00172	T02	2
007903	00149	000572	0750	0812	0875	0250	0187	0125	0000	00173	T03	3
007051	00115	001051	0625	0750	0875	0375	0250	0125	0000	00174	T04	4
006477	00144	001498	0500	0687	0875	0500	0312	0125	0000	00175	T05	5
005852	00284	001964	0375	0625	0875	0625	0375	0125	0000	00176	T06	6
005203	00521	002409	0250	0562	0875	0750	0437	0125	0000	00177	T07	7
004508	00539	002983	0125	0500	0875	0875	0500	0125	0000	00178	T08	8
003958	00443	003327	0000	0437	0875	1000	0562	0125	0000	00179	T09	9
003707	00004	000280	0000	0875	0000	0000	0125	0250	0000	00180	T10	0
007526	000433	0000383	0875	0750	0750	0125	0187	0000	0000	00181	U01	1
006117	00117	000400	0750	0750	0750	0250	0250	0000	0000	00182	U03	3
006702	00014	000428	0625	0687	0750	0375	0312	0250	0000	00183	U04	4
006158	00140	001078	0500	0625	0750	0500	0375	0250	0000	00184	U05	5
005524	00278	001562	0375	0562	0750	0625	0437	0250	0000	00185	U06	6
004851	00455	002051	0250	0500	0750	0750	0500	0250	0000	00186	U07	7
004307	00490	002529	0125	0437	0750	0875	0562	0250	0000	00187	U08	8
003802	00580	002834	0000	0375	0750	1000	0625	0250	0000	00188	U09	9
008527	001154	002244	1000	0812	0625	0000	0187	0375	0000	00189	V01	1
007786	000826	001282	0875	0750	0562	0125	0250	0375	0000	00190	V02	2
007040	004029	000668	0750	0687	0625	0250	0312	0375	0000	00191	V03	3
006408	000183	000069	0625	0625	0625	0375	0375	0000	0000	00192	V04	4
005897	00012	000601	0500	0562	0625	0500	0437	0375	0000	00193	V05	5
005276	00114	001173	0375	0500	0625	0625	0500	0375	0000	00194	V06	6
004566	00253	001673	0250	0437	06							

[illegible][illegible]

See original or copy: <http://web.me.com/klaus.richter/GE52/GE52L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.00

TUB registration: 20091101-GE52/GE52L0NA.TXT /.PS TUB material: code=rha4ta
- application for evaluation and measurement of printer or monitor systems

009673	000000	000003	1000	1000	1000	0000	0000	0000	0000	\$02423	b01 \$	009695	000000	-000009	1000	1000	1000	0000	0000	0000	0000	\$0567	b10 \$	009677	000000	000006	1000	1000	1000	0000	0000	0000	0000	0000	0000	\$0891	b19 \$
009566	000029	-00530	0875	0906	1000	0125	0093	0000	0000	\$0244	b02 \$	009880	000567	-00627	0908	0875	1000	0031	0125	0000	0000	\$0568	b11 \$	008776	009021	000024	1000	0875	0906	0000	0125	0093	0000	0000	\$0892	b20 \$	
008069	000089	-00983	0750	0812	1000	0250	0187	0000	0000	\$0245	b03 \$	008234	001337	-00446	0937	0750	1000	0062	0250	0000	0000	\$0569	b12 \$	008415	001561	000650	1000	0750	0812	0000	0250	0187	0000	0000	\$0893	b21 \$	
007261	000287	-01401	0625	0718	1000	0375	0281	0000	0000	\$0246	b04 \$	007769	001797	-00634	0906	0625	1000	0093	0375	0000	0000	\$0570	b13 \$	007871	002441	000909	1000	0625	0718	0000	0375	0281	0000	0000	\$0894	b22 \$	
006534	000335	-01823	0500	0625	1000	0500	0375	0000	0000	\$0247	b05 \$	007096	002315	-00921	0875	0500	1000	0125	0500	0000	0000	\$0571	b14 \$	007315	003206	001458	1000	0500	0625	0000	0500	0375	0000	0000	\$0895	b23 \$	
005896	000397	-02287	0375	0531	1000	0625	0468	0000	0000	\$0248	b06 \$	006415	002937	-00993	0843	0375	1000	0156	0625	0000	0000	\$0572	b15 \$	006684	004237	001847	1000	0375	0531	0000	0625	0468	0000	0000	\$0896	b24 \$	
005205	000340	-02864	0250	0437	1000	0750	0562	0000	0000	\$0249	b07 \$	005714	003616	-01226	0812	0250	1000	0187	0750	0000	0000	\$0573	b16 \$	005996	005024	002242	1000	0250	0437	0000	0750	0562	0000	0000	\$0897	b25 \$	
004408	000457	-03543	0125	0434	1000	0875	0656	0000	0000	\$0250	b08 \$	005937	004174	-01432	0811	0125	1000	0218	0875	0000	0000	\$0574	b17 \$	005401	005659	002707	1000	0125	0434	0000	0875	0656	0000	0000	\$0898	b26 \$	
003916	000417	-03714	0100	0250	1000	1000	0750	0000	0000	\$0251	b09 \$	004018	005023	-01810	0750	0000	1000	0250	1000	0000	0000	\$0575	b18 \$	004811	006511	003027	1000	0000	0250	0000	1000	0750	0000	0000	\$0899	b27 \$	
009037	000410	-000668	1000	0968	0875	0000	0031	0125	0000	\$0252	c01 \$	009220	-00520	000311	0906	1000	0875	0093	0000	0125	0000	\$0576	c10 \$	008989	-00644	-00556	0875	1000	0968	0125	0000	0031	0000	0000	\$0900	c19 \$	
008486	000043	-000012	0875	0875	0875	0875	0125	0125	0125	\$0253	c02 \$	008657	000044	000005	0843	0875	0875	0125	0125	0125	0000	\$0577	c11 \$	008583	000048	000013	0875	0875	0875	0125	0125	0125	0000	0000	\$0901	c20 \$	
007893	000003	-00025	0750	0781	0875	0250	0218	0125	0000	\$0254	c03 \$	008113	000045	-00575	0843	0750	0875	0156	0250	0125	0000	\$0578	c12 \$	008													

TUB-test chart GE52; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE52/GE52L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG GE42 22.TXT, Separation cmyn6*, cfi=0.90, D50, adapted S
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr.   pos $
%z004773 006678 004054 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008786 -00601 007052 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z005539 -05107 002593 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005165 -03626 -04416 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z003368 001906 -04066 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z004756 006712 -00840 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z002420 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009678 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%z004773 006678 004054 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008786 -00601 007052 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z005539 -05107 002593 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005165 -03626 -04416 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z003368 001906 -04066 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z004756 006712 -00840 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z002420 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009678 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%z004773 006678 004054 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008786 -00601 007052 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z005539 -05107 002593 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005165 -03626 -04416 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z003368 001906 -04066 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z004756 006712 -00840 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z002420 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009678 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%z005645 004730 004567 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z007823 -02092 006363 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z005422 -04652 000219 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z004573 -01862 -03925 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003460 003068 -03506 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z004844 006525 000657 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z002464 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009678 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%z006617 003447 005649 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z007019 -03313 005151 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z005506 -04322 -00948 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z004253 -00655 -03821 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z003849 003731 -02706 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z004850 006480 001897 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z002438 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009684 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%z007547 001680 006369 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z006385 -04539 004046 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005291 -04103 -02349 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z003916 000417 -03714 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z004218 005023 -01810 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z004811 006511 003027 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z002327 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009679 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE52/GE52L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

%BEG GE42.22.TXT, Separation cmyn6*, cfi=0.90, D50, adapted S
%100 x LAB*a 1000 x (r g b c m y o) %nrr. pos \$
002110 000020 000029 0000 0000 0000 1000 1000 1000 0000 %0972 k01 \$
002465 000219 000002 0125 0125 0125 0875 0875 0875 0000 %0973 k02 \$
003451 000210 -00051 0250 0250 0250 0750 0750 0750 0000 %0974 k03 \$
004306 000261 000003 0375 0375 0375 0625 0625 0625 0000 %0975 k04 \$
005333 000237 -000003 0500 0500 0500 0500 0500 0500 0000 %0976 k05 \$
006497 000184 -000005 0625 0625 0625 0375 0375 0375 0000 %0977 k06 \$
007615 000118 -000006 0750 0750 0750 0250 0250 0250 0000 %0978 k07 \$
008779 000044 -000004 0875 0875 0875 0125 0125 0125 0000 %0979 k08 \$
009701 000001 000004 1000 1000 1000 0000 0000 0000 0000 %0980 k09 \$
002083 000030 000006 0000 0000 0000 1000 1000 1000 0000 %0981 l01 \$
002427 000228 -00009 0125 0125 0125 0875 0875 0875 0000 %0982 l02 \$
003420 000217 -00055 0250 0250 0250 0750 0750 0750 0000 %0983 l03 \$
004252 000262 -00007 0375 0375 0375 0625 0625 0625 0000 %0984 l04 \$
005321 000255 -00017 0500 0500 0500 0500 0500 0500 0000 %0985 l05 \$
006509 000184 -00005 0625 0625 0625 0375 0375 0375 0000 %0986 l06 \$
007618 000110 -00003 0750 0750 0750 0250 0250 0250 0000 %0987 l07 \$
008614 000040 000006 0875 0875 0875 0125 0125 0125 0000 %0988 l08 \$
009703 -00006 -00005 1000 1000 1000 0000 0000 0000 0000 %0989 l09 \$
002060 000035 000035 0000 0000 0000 1000 1000 1000 0000 %0990 m01 \$
002429 000232 000000 0125 0125 0125 0875 0875 0875 0000 %0991 m02 \$
003401 000222 -00059 0250 0250 0250 0750 0750 0750 0000 %0992 m03 \$
004221 000268 000005 0375 0375 0375 0625 0625 0625 0000 %0993 m04 \$
005259 000264 000000 0500 0500 0500 0500 0500 0500 0000 %0994 m05 \$
006426 000198 000041 0625 0625 0625 0375 0375 0375 0000 %0995 m06 \$
007598 000116 -00048 0750 0750 0750 0250 0250 0250 0000 %0996 m07 \$
008589 000040 000023 0875 0875 0875 0125 0125 0125 0000 %0997 m08 \$
009704 -00006 000003 1000 1000 1000 0000 0000 0000 0000 %0998 m09 \$
002058 000031 -00001 0000 0000 0000 1000 1000 1000 0000 %0999 n01 \$
002419 000227 000012 0125 0125 0125 0875 0875 0875 0000 %1000 n02 \$
003465 000217 -00050 0250 0250 0250 0750 0750 0750 0000 %1001 n03 \$
004338 000260 000013 0375 0375 0375 0625 0625 0625 0000 %1002 n04 \$
005341 000245 000006 0500 0500 0500 0500 0500 0500 0000 %1003 n05 \$
006485 000190 000023 0625 0625 0625 0375 0375 0375 0000 %1004 n06 \$
007610 000124 00049 0750 0750 0750 0250 0250 0250 0000 %1005 n07 \$
008576 000041 000019 0875 0875 0875 0125 0125 0125 0000 %1006 n08 \$
009700 -00008 -00004 1000 1000 1000 0000 0000 0000 0000 %1007 n09 \$
002370 000063 -00049 0000 0000 0000 1000 1000 1000 0000 %1008 k10 \$
002302 000068 -00034 0066 0066 0066 0933 0933 0933 0000 %1009 k11 \$
002804 000205 000028 0133 0133 0133 0866 0866 0866 0000 %1010 k12 \$
003152 000222 -00042 0200 0200 0200 0800 0800 0800 0000 %1011 k13 \$
003985 000205 -00057 0266 0266 0266 0733 0733 0733 0000 %1012 k14 \$
004382 000250 000001 0333 0333 0333 0666 0666 0666 0000 %1013 k15 \$
004655 000202 -00022 0400 0400 0400 0600 0600 0600 0000 %1014 k16 \$
005294 000162 000020 0466 0466 0466 0533 0533 0533 0000 %1015 k17 \$
005876 000197 000031 0533 0533 0533 0466 0466 0466 0000 %1016 k18 \$
006391 000098 000044 0600 0600 0600 0399 0399 0399 0000 %1017 k19 \$
006755 000124 000062 0666 0666 0666 0333 0333 0333 0000 %1018 k20 \$
007386 000128 -00041 0733 0733 0733 0266 0266 0266 0000 %1019 k21 \$
007995 000065 000008 0800 0800 0800 0199 0199 0199 0000 %1020 k22 \$
008376 000084 000002 0866 0866 0866 0133 0133 0133 0000 %1021 k23 \$
008655 000043 000015 0933 0933 0933 0066 0066 0066 0000 %1022 k24 \$
009617 000001 -00004 1000 1000 1000 0000 0000 0000 0000 %1023 k25 \$
002343 000012 -00031 0000 0000 0000 1000 1000 1000 0000 %1024 l10 \$
002258 000083 -00003 0066 0066 0066 0933 0933 0933 0000 %1025 l11 \$
002806 000213 000035 0133 0133 0133 0866 0866 0866 0000 %1026 l12 \$
003128 000231 -00012 0200 0200 0200 0800 0800 0800 0000 %1027 l13 \$
003938 000211 -00030 0266 0266 0266 0733 0733 0733 0000 %1028 l14 \$
004354 000203 000011 0333 0333 0333 0666 0666 0666 0000 %1029 l15 \$
004589 000219 00023 0400 0400 0400 0600 0600 0600 0000 %1030 l16 \$
005284 000180 000014 0466 0466 0466 0533 0533 0533 0000 %1031 l17 \$
005848 000217 000000 0533 0533 0533 0466 0466 0466 0000 %1032 l18 \$
006350 000121 -00010 0600 0600 0600 0399 0399 0399 0000 %1033 l19 \$
006726 000134 000025 0666 0666 0666 0333 0333 0333 0000 %1034 l20 \$
007394 000134 -00054 0733 0733 0733 0266 0266 0266 0000 %1035 l21 \$
008007 000069 -00001 0800 0800 0800 0199 0199 0199 0000 %1036 l22 \$
008418 000077 -00005 0866 0866 0866 0133 0133 0133 0000 %1037 l23 \$
008715 000041 000010 0933 0933 0933 0066 0066 0066 0000 %1038 l24 \$
009652 000000 -00003 1000 1000 1000 0000 0000 0000 0000 %1039 l25 \$
002305 000012 -00039 0000 0000 0000 1000 1000 1000 0000 %1040 m10 \$
002234 000085 -00001 0066 0066 0066 0933 0933 0933 0000 %1041 m11 \$
002768 000212 000041 0133 0133 0133 0866 0866 0866 0000 %1042 m12 \$
003136 000242 -00009 0200 0200 0200 0800 0800 0800 0000 %1043 m13 \$
003910 000214 -00023 0266 0266 0266 0733 0733 0733 0000 %1044 m14 \$
004317 000263 000039 0333 0333 0333 0666 0666 0666 0000 %1045 m15 \$
004583 000214 -00008 0400 0400 0400 0600 0600 0600 0000 %1046 m16 \$
005255 000177 000053 0466 0466 0466 0533 0533 0533 0000 %1047 m17 \$
005831 000216 000035 0533 0533 0533 0466 0466 0466 0000 %1048 m18 \$
006296 000114 000056 0600 0600 0600 0399 0399 0399 0000 %1049 m19 \$
006710 000137 000043 0666 0666 0666 0333 0333 0333 0000 %1050 m20 \$
007364 000134 -00037 0733 0733 0733 0266 0266 0266 0000 %1051 m21 \$
007983 000072 000000 0800 0800 0800 0199 0199 0199 0000 %1052 m22 \$

TUB-test chart GE52; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: ->olv* setrgbcolor

TUB registration: 20091101-GE52/GE52L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta