

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

%BEG	GE46	22.TXT	Separation	cmyn62*	cf1=0.90	D65	not adapted	\$	%nrr.	pos	\$	%BEG	GE46	22.TXT	Separation	cmyn62*	cf1=0.90	D65	not adapted	\$	%nrr.	pos	\$	
%100 x	LAB*		1000 x	(r g b	c m y	0)						%100 x	LAB*		1000 x	(r g b	c m y	0)						
009306	-00084	000213	1000	1000	1000	0000	0000	0000	0000	0000	A01	\$	009430	-00085	000200	1000	1000	1000	0000	0000	0000	0000	A10	\$
009019	-00508	-00515	0875	1000	1000	0125	0000	0000	0000	0000	A01	\$	008676	000201	-00436	0875	0875	1000	0125	0000	0000	0000	A11	\$
008308	-00871	-00959	0750	1000	1000	0250	0000	0000	0000	0000	A02	\$	008011	000378	-00822	0750	0750	1000	0250	0000	0000	0000	A12	\$
007858	-01163	-01216	0625	1000	1000	0375	0000	0000	0000	0000	A03	\$	007079	000715	-01270	0625	0625	1000	0375	0000	0000	0000	A13	\$
007383	-01611	-01686	0500	1000	1000	0500	0000	0000	0000	0000	A04	\$	006380	001074	-01671	0500	0500	1000	0500	0000	0000	0000	A14	\$
006878	-01964	-02178	0375	1000	1000	0625	0000	0000	0000	0000	A05	\$	005517	001270	-02210	0375	0375	1000	0625	0000	0000	0000	A15	\$
006222	-02376	-02748	0250	1000	1000	0750	0000	0000	0000	0000	A06	\$	004753	001626	-02861	0250	0250	1000	0750	0000	0000	0000	A16	\$
005783	-02708	-03092	0125	1000	1000	0875	0000	0000	0000	0000	A07	\$	004026	001950	-03502	0125	0125	1000	0875	0000	0000	0000	A17	\$
005666	-03204	-03572	0000	1000	1000	1000	0000	0000	0000	0000	A08	\$	003221	002337	-04112	0000	0000	1000	1000	0000	0000	0000	A18	\$
008820	000546	000814	1000	0875	0875	0000	0125	0125	0000	0000	B01	\$	009577	-00326	001125	1000	1000	0875	0000	0000	0125	0000	B10	\$
008443	-00968	000216	0875	0875	0875	0125	0125	0125	0000	0000	B02	\$	008644	-00061	000184	0875	0875	0125	0125	0125	0000	0000	B11	\$
007868	-00630	-00416	0750	0875	0875	0250	0125	0125	0000	0000	B03	\$	007726	000164	-00413	0750	0750	0875	0250	0250	0125	0000	B12	\$
007319	-00815	-00756	0625	0875	0875	0375	0125	0125	0000	0000	B04	\$	007033	000389	-00732	0625	0625	0875	0375	0125	0000	0000	B13	\$
006942	-01133	-01342	0500	0875	0875	0500	0125	0125	0000	0000	B05	\$	006280	000774	-01313	0500	0500	0875	0500	0500	0125	0000	B14	\$
006429	-01625	-01884	0375	0875	0875	0625	0125	0125	0000	0000	B06	\$	005447	001087	-01743	0375	0375	0875	0625	0625	0125	0000	B15	\$
005784	-01888	-02456	0250	0875	0875	0750	0125	0125	0000	0000	B07	\$	004487	001338	-02549	0250	0250	0875	0750	0750	0125	0000	B16	\$
005354	-02274	-02817	0125	0875	0875	0875	0125	0125	0000	0000	B08	\$	003800	001773	-03043	0125	0125	0875	0875	0875	0125	0000	B17	\$
004789	-02645	-03175	0000	0875	0875	1000	0125	0125	0000	0000	B09	\$	003069	002270	-03701	0000	0000	0875	1000	1000	0125	0000	B18	\$
003837	-001272	-001019	1000	0750	0750	0000	0250	0250	0000	0000	B10	\$	009265	-00220	001877	1000	1000	0750	0000	0000	0250	0000	B19	\$
007875	000587	000691	0875	0750	0750	0125	0250	0250	0000	0000	C02	\$	008590	-00287	001053	0875	0875	0750	0125	0125	0250	0000	C03	\$
007464	-00053	000149	0750	0750	0750	0250	0250	0250	0000	0000	C03	\$	007583	-00059	001145	0750	0750	0250	0250	0250	0000	0000	C12	\$
007031	-00478	-00577	0625	0750	0750	0375	0250	0250	0000	0000	C04	\$	006889	-00093	-00424	0625	0625	0750	0375	0375	0250	0000	C13	\$
006522	-00891	-00818	0500	0750	0750	0500	0250	0250	0000	0000	C05	\$	006077	000490	-00888	0500	0500	0750	0500	0500	0250	0000	C14	\$
006062	-01278	-01254	0375	0750	0750	0625	0250	0250	0000	0000	C06	\$	005263	000720	-01359	0375	0375	0750	0625	0625	0250	0000	C15	\$
005504	-01618	-01805	0250	0750	0750	0750	0250	0250	0000	0000	C07	\$	004382	001084	-02009	0250	0250	0750	0750	0250	0250	0000	C16	\$
004936	-01790	-02509	0125	0750	0750	0875	0250	0250	0000	0000	C08	\$	003653	001319	-02554	0125	0125	0750	0875	0875	0250	0000	C17	\$
004528	-02090	-02650	0000	0750	0750	1000	0250	0250	0000	0000	C09	\$	003113	001766	-03032	0000	0000	0750	1000	1000	0250	0000	C18	\$
007793	000243	001341	1000	0625	0625	0000	0375	0375	0000	0000	C10	\$	009264	-00468	002743	1000	1000	0625	0000	0000	0375	0000	C19	\$
007385	-001203	-000991	0875	0625	0625	0125	0375	0375	0000	0000	D01	\$	008475	-00359	001944	0875	0875	0625	0125	0125	0375	0000	D10	\$
006870	-000662	-000597	0750	0625	0625	0250	0375	0375	0000	0000	D02	\$	007542	-00226	000954	0750	0750	0625	0250	0250	0375	0000	D11	\$
006577	000012	000076	0625	0625	0625	0375	0375	0375	0000	0000	D03	\$	006693	-00009	000061	0625	0625	0625	0375	0375	0375	0000	D12	\$
006194	-00505	-00498	0500	0625	0625	0500	0375	0375	0000	0000	D04	\$	006058	000228	-00474	0500	0500	0625	0500	0500	0375	0000	D13	\$
005701	-00959	-01042	0375	0625	0625	0625	0375	0375	0000	0000	D05	\$	005170	000447	-00943	0375	0375	0625	0625	0625	0375	0000	D14	\$
005116	-01321	-01296	0250	0625	0625	0750	0375	0375	0000	0000	D06	\$	004412	000758	-01378	0250	0250	0625	0750	0750	0375	0000	D15	\$
004706	-01506	-02032	0125	0625	0625	0875	0375	0375	0000	0000	D07	\$	003548	000892	-02048	0125	0125	0625	0875	0875	0375	0000	D16	\$
004273	-01730	-02349	0000	0625	0625	1000	0375	0375	0000	0000	D08	\$	002923	001301	-02670	0000	0000	0625	1000	1000	0375	0000	D17	\$
007222	002709	001898	1000	0500	0500	0000	0500	0500	0000	0000	E01	\$	009248	-00710	003657	1000	1000	0500	0000	0000	0500	0000	E10	\$
006825	-001799	-001483	0875	0500	0500	0125	0500	0500	0000	0000	E02	\$	008420	-00581	-002899	0875	0875	0500	0125	0125	0500	0000	E11	\$
006218	-001301	-001231	0750	0500	0500	0500	0250	0500	0000	0000	E03	\$	007502	-00432	002200	0750	0750	0500	0250	0250	0500	0000	E12	\$
005863	000801	000564	0625	0500	0500	0375	0500	0500	0000	0000	E04	\$	006647	-00166	000996	0625	0625	0500	0375	0375	0500	0000	E13	\$
005655	-00048	-000199	0500	0500	0500	0500	0500	0500	0000	0000	E05	\$	005759	-00040	000094	0500	0500	0500	0500	0500	0500	0000	E14	\$
005439	-00563	-00456	0375	0500	0500	0625	0500	0500	0000	0000	E06	\$	005180	000184	-00522	0375	0375	0500	0625	0625	0500	0000	E15	\$
004803	-01006	-01257	0250	0500	0500	0500	0750	0500	0000	0000	E07	\$	004388	000344	-01197	0250	0250	0500	0750	0750	0500	0000	E16	\$
004114	-01242	-01443	0125	0500	0500	0875	0500	0500	0000	0000	E08	\$	003586	000701	-01534	0125	0125	0500	0875	0875	0500	0000	E17	\$
003991	-01435	-01967	0000	0500	0500	1000	0500	0500	0000	0000	E09	\$	002715	001129	-02307	0000	0000	0500	1000	1000	0500	0000	E18	\$
003605	003322	002309	1000	0375	0375	0000	0625	0625	0000	0000	F01	\$	009135	-00944	004802	1000	1000	0375	0000	0000	0625	0000	F10	\$
003129	002564	001965	0875	0375	0375	0125	0625	0625	0000	0000	F02	\$	008307	-00795	003981	0875	0875	0375	0125	0125	0625	0000	F11	\$
005579	002059	001651	0750	0375	0375	0250	0625	0625	0000	0000	F03	\$	007371	-00542	003140	0750	0750	0375	0250	0250	0625	0000	F12	\$
005209	001354	001213	0625	0375	0375	0375	0625	0625	0000	0000	F04	\$	006578	-00447	002281	0625	0625	0375	0375	0375	0625	0000	F13	\$
004901	000636	000588	0500	0375	0375	0500	0625	0625	0000	0000	F05	\$	005504	-00249	001065	0500	0500	0375	0500	0500	0625	0000	F14	\$
004806	000009	000050	0375	0375	0375	0625	0625	0625	0000	0000	F06	\$	004845	000017	000050	0375	0375	0375	0625	0625	0625	0000	F15	\$
004412	-00505	-00572	0250	0375	0375	0750	0625	0625	0000	0000	F07	\$	004245	000132	-00565	0250	0250	0375	0750	0750	0625	0000	F16	\$
003841	-01070	-01227	0125	0375																				

```
input: w setgray
output: ->oly* setrgbcolor
```

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009311	-00808	000199	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
008685	-00208	-00362	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
007996	-00233	-00891	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
007302	-00209	-01278	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
006762	-00166	-01622	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
006266	-00265	-02025	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
005533	-00418	-02641	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
004843	-00424	-03136	0125	0562	1000	0875	0500	0000	0000	%0169	S08	\$
004265	-00467	-03924	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$
003895	-00624	-00938	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
008405	-00600	-00193	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
007695	-00260	-00364	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
007086	-00151	-00874	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
006591	-00224	-01308	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
005928	-00212	-01779	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
005294	-00391	-02245	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
004606	-00366	-02829	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
004046	-00349	-03219	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
003824	-00605	-001327	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
003135	-00013	-000879	0750	0812	0750	0125	0187	0250	0000	%0181	U02	\$
007467	-00059	-000147	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$
006883	-00127	-00385	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
006323	-00297	-00944	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
005690	-00275	-01482	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
005012	-00414	-01954	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
004489	-00317	-02359	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
003926	-00455	-02756	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
008537	-00708	-002251	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
007867	-000435	-001556	0875	0750	0625	0125	0250	0375	0000	%0190	V02	\$
007139	-000163	-000860	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
006552	-000006	-000061	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
006089	-00009	-00414	0500	0562	0625	0500	0437	0375	0000	%0193	V05	\$
005527	-00246	-01046	0375	0500	0625	0625	0625	0375	0000	%0194	V06	\$
004845	-00342	-01544	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
004163	-00414	-02082	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
003650	-00424	-02227	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
008908	-00129	-02829	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
007548	-00652	-002183	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
006723	-000309	-001733	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
006111	-00058	-000735	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
005615	-00047	-000099	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
005204	-00106	-00514	0375	0437	0500	0625	0560	0500	0000	%0203	W06	\$
004454	-00326	-01272	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
003888	-00227	-01609	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
003472	-00324	-01946	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
007716	-001515	-003465	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
007096	-001021	-002738	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
006340	-000818	-002351	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
005707	-000557	-001658	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
005171	-000184	-000772	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
004839	-000015	-000039	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
004286	-00128	-00656	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
003645	-00178	-01256	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
003077	-00263	-01599	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
007362	-001951	-004100	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
006664	-001438	-003443	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
005876	-001191	-002796	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
005309	-00004	-002169	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$
004853	-000556	-001466	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
004473	-000196	-000687	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
003900	-00005	-000019	0250	0250	0250	0750	0750	0750	0000	%0222	Y07	\$
003506	-00053	-00717	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
002709	-00203	-01419	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
006870	-001743	-004661	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
006262	-001924	-003934	0875	0500	0125	0125	0500	0875	0000	%0226	Z02	\$
005554	-001479	-003281	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
004935	-001239	-002758	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
004384	-000933	-002114	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
004089	-000522	-001390	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
003707	-000218	-000805	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
003080	-000018	-000096	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
002600	-000458	-01107	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$
004606	-002353	-005321	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$
005716	-002104	-004925	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$
005148	-001944	-004454	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$
004615	-001589	-003763	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
004184	-001135	-003141	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
003844	-000783	-002443	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
003591	-000497	-002022	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$
003150	-000014	-001374	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$
002244	-000485	-000353	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
009409	-000995	-000229	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
008808	-000435	-00206	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$
008085	-000891	-00683	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
007549	-001163	-00723	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
006767	-001787	-01120	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
005928	-002220	-01435	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
005239	-002773	-01829	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
004538	-003532	-02233	0562	0250	1000	0437	0875	0000	0000	%0493	S17	\$
003869	-00457	-02583	0000	1000	0500	1000	0000	0000	0000	%0494	S18	\$
009131	-00500	-000758	0937	1000	0875	0062	0000	0125	0000	%0495	T10	\$
008605	-00062	-000181	0875	0875	0125	0125	0125	0125	0000	%0496	T11	\$
008024	-000407	-00400	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
007141	-000946	-00542	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
006531	-001359	-00824	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
005727	-001929	-01220	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
004858	-002617	-01658	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
004224	-002953	-02031	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
003389	-003778	-02565	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
008900	-00947	-001132	0875	1000	0750	0125	0000	0250	0000	%0504	T19	\$
008239	-00573	-000719	0812	0875	0750	0187	0125	0250	0000			

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-GE56/GE56L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

IOB material: code=rha4ta

TUB-test chart GE56; Relative Device Colour System
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE56/GE56L0NP.PDF> / .PS
 Technical information: <http://www.ps.ban.de> V 2.1, io=1,1, Cx=0, cfl=0.90; nt=0.01; nx=1.3

090827	-00066	000218	1000	1000	1000	0000	0000	0000	0000	%0243	b01 \$
090887	-00024	-00363	0875	0906	1000	0125	0093	0000	0000	%0244	b02 \$
007966	000020	-00855	0750	0812	1000	0250	0187	0000	0000	%0245	b03 \$
007159	000305	-1265	0625	0718	1000	0375	0281	0000	0000	%0246	b04 \$
006644	000330	-01617	0500	0625	1000	0500	0375	0000	0000	%0247	b05 \$
006030	000354	-02071	0375	0531	1000	0625	0468	0000	0000	%0248	b06 \$
005302	000392	-02628	0250	0437	1000	0750	0562	0000	0000	%0249	b07 \$
004549	000574	-03319	0125	0343	1000	0875	0656	0000	0000	%0250	b08 \$
003928	000873	-03879	0000	0250	1000	1000	0750	0000	0000	%0251	b09 \$
009053	000921	-00199	1000	0968	0875	0900	0031	0125	0000	%0252	c01 \$
008394	-00066	000198	0875	0875	0875	0125	0125	0125	0000	%0253	c02 \$
007569	-00093	-00371	0750	0781	0875	0250	0218	0125	0000	%0254	c03 \$
007015	000075	-00741	0625	0687	0875	0375	0312	0125	0000	%0255	c04 \$
006441	000209	-01302	0500	0593	0875	0500	0486	0125	0000	%0256	c05 \$
006057	000230	-01372	0437	0500	0875	0625	0437	0125	0000	%0257	c06 \$
005017	000387	-02350	0250	0406	0875	0750	0593	0125	0000	%0258	c07 \$
004533	000536	-02835	0125	0312	0875	0875	0687	0125	0000	%0259	c08 \$
003842	000504	-03138	0000	0218	0875	1000	0781	0125	0000	%0260	c09 \$
009041	000164	-00165	1000	0937	0875	0900	0662	0250	0000	%0261	d01 \$
008289	-00024	000893	0875	0843	0750	0125	0156	0250	0000	%0262	d02 \$
007581	-00051	000117	0750	0750	0750	0250	0250	0250	0000	%0263	d03 \$
006873	-00031	-00350	0256	0656	0750	0375	0343	0250	0000	%0264	d04 \$
006209	-00012	-00920	0500	0562	0750	0500	0437	0250	0000	%0265	d05 \$
005468	000234	-01390	0375	0468	0750	0625	0531	0250	0000	%0266	d06 \$
004712	000221	-01951	0250	0375	0750	0750	0625	0250	0000	%0267	d07 \$
004163	000332	-02321	0125	0281	0750	0875	0718	0250	0000	%0268	d08 \$
003635	000328	-02661	0000	0187	0750	1000	0812	0250	0000	%0269	d09 \$
008850	000165	-00260	0500	0906	0625	0000	0093	0375	0000	%0270	e01 \$
008057	-00006	00168	0875	0812	0625	0125	0187	0375	0000	%0271	e02 \$
007651	-000021	-00089	0750	0718	0625	0250	0281	0375	0000	%0272	e03 \$
007257	000001	000067	0625	0625	0625	0375	0371	0375	0000	%0273	e04 \$
006035	000094	-00351	0500	0531	0625	0500	0468	0375	0000	%0274	e05 \$
005284	000108	-01057	0375	0437	0625	0625	0562	0375	0000	%0275	e06 \$
004492	000094	-01564	0250	0343	0625	0750	0566	0375	0000	%0276	e07 \$
003800	000206	-02054	0125	0250	0625	0875	0750	0375	0000	%0277	e08 \$
003125	000351	-02272	000								

See original or copy: <http://web.me.com/klaus.richter/GE56/GE56L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.01; nx=1.3

```
%BEG GE46.22.TXT, Separation cmyn62*, cfi=0.90, D65, not adapted $
%100 x LAB*      %#1000 x (r g b c m y o)      %nr.      pos $
%z004550 005995 003801 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008906 -01350 007837 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z005761 -06125 003573 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005666 -03304 -03572 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z003221 002637 -04112 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z004579 006403 -00907 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z002133 000514 000365 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009378 -00085 000207 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%z004550 005995 003801 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008906 -01350 007837 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z005761 -06125 003573 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005666 -03304 -03572 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z003221 002637 -04112 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z004579 006403 -00907 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z002133 000514 000365 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009378 -00085 000207 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%z004550 005995 003801 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008906 -01350 007837 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z005761 -06125 003573 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005666 -03304 -03572 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z003221 002637 -04112 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z004579 006403 -00907 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z002133 000514 000365 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009378 -00085 000207 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%z005558 003759 004523 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z007857 -02604 006704 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z005563 -05135 000992 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z004686 -01474 -03663 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003398 003390 -03519 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z004526 006103 000500 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z002171 000506 000371 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009365 -00090 000224 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%z006406 002353 005321 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z007048 -03989 005799 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z005461 -04299 -00726 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z004265 -00467 -03934 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z003869 003666 -02588 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z004572 005941 001563 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z002200 000499 000368 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009372 -00086 000209 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%z007349 000949 006262 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z006576 -05166 004916 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005719 -04389 -02123 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z003928 000873 -03879 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z004011 005224 -02020 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z004552 005762 002662 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z002087 000515 000354 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009360 -00087 000213 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE56/GE56L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.01; nx=1.3

```
%BEG GE46.22.TXT, Separation cmyn62*, cfi=0.90, D65, not adapted $
%100 x LAB*          1000 x (r g b c m y 0)          %nr. pos $
001893 000532 000349 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002668 000000 000148 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003567 -00006 000042 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004521 000012 000083 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005445 -00037 000120 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006554 000000 000091 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
007500 -00046 000139 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008565 -00059 000182 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009414 -00083 000202 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
001944 000535 000337 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002705 000006 000135 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003547 -00082 000209 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004572 000021 000055 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005527 -00030 000091 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006605 000000 000068 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
007533 -00045 000128 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
008540 -00056 000174 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009389 -00090 000214 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
001936 000527 000319 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002736 000007 000133 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003622 -00005 000024 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004642 000024 000040 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
005590 -00032 000077 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006592 -00002 000071 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
007571 -00049 000127 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
008565 -00063 000190 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009412 -00087 000202 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
001935 000521 000331 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002730 -00002 000160 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003616 -00008 000038 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004640 000011 000054 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005574 -00035 000096 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006605 -00016 000077 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
007563 -00048 000123 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008586 -00055 000183 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009427 -00084 000200 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
002206 000502 000329 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
003282 000161 000262 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
004293 000022 000062 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
005368 000006 000033 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
006388 000005 000043 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
007418 000000 000062 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
008506 000001 000131 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
009537 000022 000113 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
001091 000026 000089 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
002142 000010 000144 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
003184 -00042 000140 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
004238 000000 000195 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
005261 -00034 000146 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
006288 -00049 000189 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
007311 -00062 000194 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
008344 -00072 000195 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
009374 000511 000327 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
010406 000171 000266 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
011439 000026 000068 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
012487 000009 000028 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
013544 000004 000040 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
014609 000003 000061 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
015684 000001 000114 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
016769 000025 000087 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
017854 000027 000054 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
018949 000024 000084 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
019995 000029 000110 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
021043 000000 000156 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
022094 000034 000137 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
023146 000047 000172 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
024203 000065 000196 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
025266 000073 000195 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
026322 000530 000299 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
027387 000186 000246 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
028458 000033 000044 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
029534 000005 000028 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
030615 000007 000033 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
031696 000008 000061 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
032777 000006 000089 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
033858 000011 000091 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
034939 000026 000047 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
036020 000008 000097 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
037101 000032 000096 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
038182 000007 000148 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
039263 -00036 000136 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart GE56; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: -> olv* setrgbcolor

TUB registration: 20091101-GE56/GE56L0NP.PDF /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart GE56; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

TUB registration: 20091101-GE56/GE56LONP.PDF /.PS
application for evaluation and measurement of printer on

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/GE56/GE56L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.01; nx=1.3

See original or copy: <http://web.me.com/klaus.richter/GE56/GE56L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.01; nx=1.3

```
%BEG GE46.22.TXT, Separation cmyn62*, cfi=0.90, D65, adapted $
%100 x LAB*a      %1000 x (r g b c m y o)      %nr.      pos $
%Z004550 005681 003489 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008906 -01304 007619 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005761 -06339 003287 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005666 -03527 -03860 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003221 002212 -04454 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004579 006091 -01219 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z002133 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009378 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W1 7 $
%$
%Z004550 005681 003489 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008906 -01304 007619 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005761 -06339 003287 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005666 -03527 -03860 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003221 002212 -04454 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004579 006091 -01219 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z002133 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009378 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W2 7 $
%$
%Z004550 005681 003489 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008906 -01304 007619 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005761 -06339 003287 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005666 -03527 -03860 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003221 002212 -04454 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004579 006091 -01219 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z002133 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009378 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W001 7 $
%$
%Z005558 003534 004221 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z007857 -02639 006449 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005563 -05360 000690 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004686 -01771 -03983 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003398 002985 -03865 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004526 005792 000176 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z002171 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009365 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %W251 7 $
%$
%Z006406 002197 005046 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007048 -04092 005538 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005461 -04532 -01022 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004265 -00798 -04256 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003869 003303 -02919 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004572 005635 001247 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z002200 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009372 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %W501 7 $
%$
%Z007349 000870 006009 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006576 -05309 004648 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005719 -04603 -02407 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003928 000510 -04198 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004011 004868 -02338 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004552 005451 002355 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z002087 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009360 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %W751 7 $
%$
```

See original or copy: <http://web.me.com/klaus.richter/GE56/GE56L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.01; nx=1.3

```
%BEG GE46.22.TXT, Separation cmyn62*, cfi=0.90, D65, adapted $
%100 x LAB*a      1000 x (r g b c m y 0)      %nr. pos $
001893 000020 -00046 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002668 -00447 -00228 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003567 -00382 -00312 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004521 -00286 -00248 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005445 -00262 -00187 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006554 -00134 -00189 0625 0625 0625 0625 0375 0375 0000 %0977 k06 $
007500 -00104 -00118 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008565 -00031 -00048 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009414 -00012 -00097 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
001944 -00026 -00058 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002705 -00439 -00240 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003547 -00380 -00326 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004572 -00273 -00274 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005527 -00247 -00215 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006605 -00130 -00211 0625 0625 0625 0625 0375 0375 0000 %0986 l06 $
007533 -00101 -00128 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
008540 -00031 -00057 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009389 -00003 -00003 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
001936 -00019 -00076 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002736 -00436 -00242 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003622 -00377 -00329 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004642 -00265 -00288 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
005590 -00244 -00227 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006592 -00134 -00208 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
007571 -00102 -00128 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
008565 -00035 -00041 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009412 -00008 -00007 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
001935 -00014 -00064 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002730 -00446 -00215 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003616 -00381 -00315 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004640 -00277 -00274 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005574 -00249 -00209 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006605 -00147 -00201 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
007563 -00101 -00132 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008586 -00026 -00046 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009427 -00012 -00009 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
002206 -00016 -00059 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
002382 -00310 -00121 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002983 -00409 -00306 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
003368 -00385 -00326 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
003838 -00349 -00305 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
004410 -00308 -00271 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
005056 -00254 -00187 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005357 -00209 -00197 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
005991 -00153 -00205 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006442 -00132 -00139 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
006884 -00150 -00132 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007358 -00070 -00065 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
007561 -00088 -00109 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
008308 -00042 -00048 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
008944 -00004 -00027 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009244 -00009 -00019 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
002234 -00028 -00061 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
002416 -00297 -00117 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
003003 -00394 -00300 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
003407 -00379 -00330 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
003804 -00345 -00306 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
004429 -00304 -00259 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
005103 -00253 -00202 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005404 -00201 -00222 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
006083 -00145 -00237 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006456 -00118 -00198 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
006895 -00136 -00162 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007343 -00070 -00104 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
007564 -00087 -00118 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
008340 -00038 -00064 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
008935 -00007 -00025 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009266 -00010 -00018 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
002222 -00046 -00088 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
002397 -00283 -00137 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
003058 -00383 -00323 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
003462 -00378 -00329 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
003887 -00342 -00313 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
004535 -00306 -00269 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
005144 -00242 -00226 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005450 -00212 -00217 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
006050 -00148 -00246 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006503 -00129 -00184 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
006919 -00137 -00175 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007384 -00060 -00112 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
007620 -00085 -00118 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart GE56; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w *setgray*
output: -> *olv* setrgbcolor*

TUB registration: 20091101-GE56/GE56L0NP.PDF /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE56/GE56L0NP.PDF> / <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfl=0.90, nt=

TUB registration: 20091101-GE56/GE56LONP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rh4ta

[illegible]

TUB-test chart GE56; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009304	-00057	000228	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
008882	-00308	-00518	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008124	-00579	-00895	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
007462	-00658	-01295	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
006945	-00869	-01727	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
006441	-01165	-02195	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
005786	-01598	-02886	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
005208	-01797	-03255	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
004568	-02076	-03801	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
003863	-02441	-040873	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
003081	-000629	-000183	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
007692	-03667	-00571	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
007128	-02540	-00906	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
006704	-00732	-01367	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
006135	-01014	-01814	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
005473	-01312	-02378	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
004864	-01496	-02981	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
004310	-01799	-03385	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
003715	-001089	-001155	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
003060	-004045	-006098	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
0027451	-00030	-000128	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
006975	-00335	-00606	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
006394	-00629	-01029	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
005835	-00845	-01557	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
005263	-01153	-01994	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
004683	-01268	-02421	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
004139	-01494	-02813	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
003265	-001595	-001870	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
002704	-001008	-001364	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
002057	-000478	-000810	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
001608	-000018	-000087	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
001186	-00316	-00540	0500	0593	0593	0625	0500	0406	0375	00112	M05	\$
000821	-00682	-01033	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
000501	-00945	-01500	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
004436	-01110	-02102	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
003891	-01368	-02280	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
002774	-002217	-002449	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
002173	-001545	-001962	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
001659	-001050	-001616	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
001205	-000675	-000702	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
000844	-00031	-000104	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
000531	-00385	-00571	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
004662	-00760	-01320	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
003955	-01028	-01672	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
003552	-01197	-02126	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
002739	-002814	-003060	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
002718	-002136	-002410	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
002045	-001731	-001989	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
001521	-001133	-001479	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
001028	-000588	-000663	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
0004820	-000027	-000056	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
004355	-00361	-00639	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
003683	-00764	-01281	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
003212	-00956	-01679	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
002673	-003401	-003547	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
002126	-002779	-003037	0875	0406	0500	0125	0593	0750	0000	00136	P02	\$
001572	-002157	-002601	0750	0375	0250	0250	0625	0750	0000	00137	P03	\$
001021	-001767	-001961	0625	0343	0250	0375	0656	0750	0000	00138	P04	\$
0004637	-001178	-001320	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
004356	-004039	-000563	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
003904	-000804	-000022	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
003613	-00337	-00721	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
002994	-00472	-01293	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
0026128	-003828	-004083	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
0025638	-003226	-003458	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
0025051	-002773	-002940	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
0024540	-002259	-002414	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
0024155	-001674	-001942	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
0023835	-001194	-001195	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
0023615	-000632	-000700	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
0023081	-000033	-000099	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
0022703	-000164	-01105	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
0021686	-004238	-004645	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
0021566	-003718	-004304	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
00214612	-003336	-003686	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
00214112	-002795	-003025	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
0021357	-002178	-002700	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
0021358	-001613	-002223	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
0021282	-001281	-001723	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
0021284	-000601	-001260	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
0020604	-000564	-000375	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
009409	-00057	000200	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
008703	-000318	-00319	0800	0875	1000	0093	0125	0000	0000	00406	J11	\$
008102	-000590	-00705	0812	0750	1000	0818	0250	0000	0000	00407	J12	\$
007303	-000949	-01013	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
006472	-001401	-01363	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
005777	-001759	-01715	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
004949	-002088	-02288	0347	0250	1000	0562	0750	0000	0000	00411	J16	\$
004201	-002459	-03435	0250	0100	0875	0875	0500	0000	0000	00412	J17	\$
003400	-003091	-03470	0250	0000	1000	0750	1000	0000	0000	00413	J18	\$
003188	-002400	-000857	0968	1000	0875	0031	0000	0125	0000	00414	K01	\$
008593	-00037	000192	0875	0875	0875	0125	0125	0125	0000	00415	K11	\$
008745	-000271	-00398	0781	0750	0875	0218	0250	0125	0000	00416	K12	\$
007983	-000625	-00660	0625	0875	0312	0375	0125	0000	0000	00417	K13	\$
006382	-000998	-01079	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
005570	-0001524	-01466	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
004702	-001831	-01986	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
003914	-002157	-02656	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
003027	-003062	-03229	0128	0000	0875	0781	1000	0125	0000	00422	K18	\$
009110	-00474	-001431	0937	1000	0750	0062	0000	0250	0000			

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009312	-00051	000193	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$	009411	-00063	000222	1000	1000	1000	0000	0000	0000	%0486	S10 \$	009395	-00054	000192	1000	1000	1000	0000	0000	0000	0000	%0810	S19 \$		
008674	-00236	-00388	0875	0937	1000	0125	0062	0000	0000	%0163	S02 \$	008813	000448	-00196	0937	0875	1000	0062	0125	0000	0000	%0487	S11 \$	008789	000726	000522	1000	0875	0937	0000	0125	0062	0000	%0811	S20 \$	
007975	-00314	-00932	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$	008092	000878	-00662	0875	0750	1000	0125	0250	0000	0000	%0488	S12 \$	008389	001569	000606	1000	0750	0875	0000	0250	0125	0000	%0812	S21 \$	
007773	-00330	-01331	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$	007561	001157	-00689	0812	0625	1000	0187	0375	0000	0000	%0489	S13 \$	007893	002314	000651	1000	0625	0812	0000	0375	0187	0000	%0813	S22 \$	
006728	-00324	-01684	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$	006786	001770	-01066	0750	0500	1000	0250	0500	0000	0000	%0490	S14 \$	007114	003082	000724	1000	0500	0750	0000	0500	0250	0000	%0814	S23 \$	
006221	-00479	-02107	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$	005951	002185	-01367	0687	0375	1000	0312	0625	0000	0000	%0491	S15 \$	006495	003088	001166	1000	0375	0687	0000	0625	0312	0000	%0815	S24 \$	
005469	-00732	-02758	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$	005267	002712	-01745	0625	0250	1000	0375	0750	0000	0000	%0492	S16 \$	005952	004451	001434	1000	0250	0625	0000	0750	0375	0000	%0816	S25 \$	
004864	-00827	-03279	0125	0625	1000	0875	0507	0000	0000	%0169	S08 \$	004818	000932	-02143	0625	0125	1000	0507	0875	0000	0000	%0493	S17 \$	005351	005228	001732	1000	0125	0625	0000	0875	0437	0000	%0817	S26 \$	
004158	-01057	-04127	0000	0625	1000	1000	0500	0000	0000	%0170	S09 \$	003904	003521	-02479	0500	0000	1000	0500	1000	0000	0000	%0494	S18 \$	004739	000437	001873	1000	0000	0500	0000	1000	0500	0000	%0818	S27 \$	
003983	-00405	000941	1000	0937	0875	0000	0062	0125	0000	%0171	T01 \$	009131	-00400	000729	0937	1000	0875	0062	0000	0125	0000	%0495	T10 \$	005891	-00060	-00124	0875	1000	0937	0125	0000	0062	0000	%0819	T10 \$	
008407	-00903	000188	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$	008606	-00036	000177	0875	0875	0875	0125	0125	0125	0000	%0496	T11 \$	008544	-00030	000176	0875	0875	0875	0125	0125	0125	0000	%0820	T10 \$	
007683	-00293	-00391	0750	0812	0875	0250	0187	0125	0000	%0173	T03 \$	008026	000399	-00395	0812	0750	0875	0187	0250	0125	0000	%0497	T12 \$	007966	000741	000354	0875	0750	0812	0125	0250	0187	0000	%0821	T21 \$	
007067	-00238	-00909	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$	007152	000945	-00513	0750	0625	0875	0250	0375	0125	0000	%0498	T13 \$	007434	001479	000666	0875	0625	0750	0125	0375	0250	0000	%0822	T22 \$	
006562	-00352	-01362	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$	006545	001349	-00781	0687	0500	0875	0312	0500	0125	0000	%0499	T14 \$	006837	002920	000718	0875	0500	0687	0125	0500	0312	0000	%0823	T23 \$	
005889	-00395	-01849	0375	0625	0875	0625	0375	0125	0000	%0176	T06 \$	005747	001905	-01161	0625	0375	0875	0375	0625	0125	0000	%0500	T15 \$	006163	003015	001008	0875	0375	0625	0125	0625	0375	0000	%0824	T24 \$	
005240	-00651	-02344	0250	0562	0875	0750	0437	0125	0000	%0177	T07 \$	004886	002567	-01576	0562	0250	0875	0437	0750	0125	0000	%0501	T16 \$	005486	003917	001257	0875	0250	0562	0125	0750	0437	0000	%0825	T25 \$	
004536	-00721	-02956	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$	004253	002869	-01944	0500	0125	0875	0500	0875	0125	0000	%0502	T17 \$	004870	004495	001574	0875	0125	0500	0125	0875	0500	0000	%0826	T26 \$	
003963	-00787	-03368	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$	003429	003626	-02447	0437	0000	0875	0562	1000	0125	0000	%0503	T18 \$	004205	005733	001939	0875	0000	0437	0125	1000	0562	0000	%0827	T27 \$	
008854	000830	001346	1000	0875	1000	0000	0125	0250	0000	%0180	T01 \$	008895	-00800	001877	0875	1000	0750	0125	0000	0250	0000	%0504	T19 \$	008362	-01294	000100	0750	1000	0875	0250	0000	0125	0000	%0828	T19 \$	
008150	000735	000880	0875	0812	0750	0125	0187	0250	0000	%0181	T02 \$	008237	-00478	000685	0812	0875	0750	0187	0125	0250	0000	%0505	T11 \$	007857	-00576	000000	0750	0875	0812	0250	0125	0187	0000	%0829	T20 \$	
007468	-00038	000143	0750	0750	0750	0250	0250	0250	0000	%0182	T03 \$	007632	-00037	000128	0750	0750	0250	0250	0250	0250	0000	%0506	T12 \$	007530	-00030	000148	0750	0750	0750	0250	0250	0250	0000	%0830	T21 \$	
006874	-00160	-00404	0625	0687	0750	0375	0312	0250	0000	%0183	T04 \$	007003	000292	-00346	0687	0625	0750	0312	0375	0250	0000	%0507	T13 \$	006893	000879	000499	0750	0625	0687	0250	0375	0312	0000	%0831	T22 \$	
006299	-00387	-00990	0500	0625	0750	0500	0375	0250	0000	%0184	T05 \$	006268	000918	-00560	0625	0500	0750	0375	0500	0250	0000	%0508	T14 \$	006253	001632	000609	0750	0500	0625	0250	0500	0375	0000	%0832	T23 \$	
005656	-00427	-01545	0375	0562	0750	0625	0437	0250	0000	%0185	T06 \$	005523	001418	-00929	0562	0375	0750	0437	0625	0250	0000	%0509	T15 \$	005568	002382	000969	0750	0375	0562	0250	0625	0437	0000	%0833	T24 \$	
004964	-00637	-02042	0250	0500	0750	0750	0500	0250	0000	%0186	T07 \$	004725	001889	-01265	0500	0250	0750	0500	0750	0250	0000	%0510	T16 \$	004787	003192	001183	0750	0375	0500	0500	0250	0750	0500	0000	%0834	T25 \$
004432	-00509	-02460	0125	0437	0750	0875	0562	0250	0000	%0187	T08 \$	004029	002433	-01603	0437	0125	0750	0562	0875	0250	0000	%0511	T17 \$	004208	003856	001383	0750	0125	0437	0250	0875	0562	0000	%0835	T26 \$	
003855	-00822	-02866	0000	0375	0750	1000	0625	0250	0000	%0188	T09 \$	003267	003126	-02126	0375	0000	0750	0625	1000	0250	0000	%0512	T18 \$	003595	004794	001710	0750	0000	0375	0250	1000	0625	0000	%0836	T27 \$	
008508	001041	002271	1000	0812	0625	0000	0187	0375	0000	%0189	T01 \$	008573	-01174	001900	0812	1000	0625	0187	0000	0375	0000	%0513	T19 \$	007756	-01522	-00161	0625	1000	0812	0375	0000	0187	0000	%0837	T19 \$	
007896	000675	001568	0875	0750	0625	0125	0250	0375	0000	%0190	T02 \$	007862	-00789	001275	0750	0875	0625	0250	0125	0375	0000	%0514	T11 \$	007391	-01187	-00025	0625	0875	0750	0375	0125	0250	0000	%0838	T20 \$	
007153	000299	000864	0750	0687	0625	0250	0312	0375	0000	%0191	T03 \$	007397	-00489	000608	0687	0750	0625	0312	0250	0375	0000	%0515	T12 \$	007044	-00537	-00191	0625	0750	0687	0375	0250	0312	0000	%0839	T21 \$	
006553	000019	000061	0625	0625	0625	0375	0375	0375	0000	%0192	T04 \$	006706	-00013	000064	0625	0625	0625	0375	0375	0375	0000	%0516	T13 \$	006586	000024	000085	0625	0625	0625	0375	0375	0375	0000	%0840	T22 \$	
006090	-00135	-00432	0500	0562	0625	0500	0437	0375	0000	%0193	T05 \$	006072	-00096	-00423	0562	0500	0625	0437	0500	0375	0000	%0517	T14 \$	005901	000932	000396	0625	0500	0562	0375	0500	0437	0000	%0841	T23 \$	
005502	-00342	-01094	0375	0500	0625	0625	0625	0375	0000	%0194	T06 \$	005218	-00097	-00561	0500	0375	0625	0500	0625	0375	0000	%0518	T15 \$	005121	001671	000723	0625	0375	0500	0375	0625	0500	0000	%0842	T24 \$	
004807	-00503	-01614	0250	0437	0625	0750	0562	0375	0000	%0195	T07 \$	004497	001432	-00983	0437	0250	0625	0562	0750	0375	0000	%0519	T16 \$	004355	002457	000976	0625	0500	0437	0375	0750	0562	0000	%0843	T25 \$	
004112	-00650	-02094	0125	0375	0625	0875	0625	0375	0000	%0196	T08 \$	003911	001882	-01330	0375	0125	0625	0625	0875	0375	0000	%0520	T17 \$	003802	003071	001198	0625	0125	0375	0375	0875	0625	0000	%0844	T26 \$	
003593	-00706	-02331	0000	0312	0625	1000	0687	0375	0000	%0197	T09 \$	003107	002563	-01815	0312	0000	0625	0687	1000	0375	0000	%0521	T18 \$	003271	003957	001375	0625	0000	03							

TUB-test chart GE56; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

TUB registration: 20091101-GE56/GE56L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

IUB material: code=rha4ta

```
%BEG GE46.22.TXT, Separation cmyn62*, cfi=0.90, D50, not adapted $
%100 x LAB*      %#1000 x (r g b c m y o)      %nr.      pos $
%z004736 006345 004078 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008953 -00709 007666 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z005684 -05677 003188 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005515 -03956 -03897 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z003181 002186 -04143 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z004727 006444 -00576 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z002149 000590 000388 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009379 -00055 000201 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%$
%z004736 006345 004078 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008953 -00709 007666 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z005684 -05677 003188 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005515 -03956 -03897 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z003181 002186 -04143 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z004727 006444 -00576 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z002149 000590 000388 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009379 -00055 000201 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%$
%z004736 006345 004078 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008953 -00709 007666 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z005684 -05677 003188 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005515 -03956 -03897 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z003181 002186 -04143 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z004727 006444 -00576 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z002149 000590 000388 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009379 -00055 000201 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%$
%z005686 004238 004645 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z007870 -02029 006473 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z005473 -04970 000684 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z004568 -02076 -03891 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003400 003091 -03470 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z004686 006267 000824 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z002186 000582 000394 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009366 -00058 000218 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%$
%z006508 002899 005354 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z007026 -03424 005493 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z005358 -04396 -01008 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z004159 -01057 -04127 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z003904 003521 -02479 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z004739 006187 001873 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z002216 000574 000391 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009373 -00056 000202 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%$
%z007428 001546 006212 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z006526 -04628 004557 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005584 -04763 -02448 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z003854 000391 -03997 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z004105 005158 -01792 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z004723 006073 002950 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z002102 000588 000378 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009361 -00057 000207 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%$
```

See original or copy: <http://web.me.com/klaus.richter/GE56/GE56L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.01; nx=1.3

```
%BEG GE46.22.TXT, Separation cmyn62*, cfi=0.90, D50, not adapted $
%100 x LAB*          1000 x (r g b c m y 0)          %nr. pos $
001909 000004 000375 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002670 000022 000149 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003567 000000 000043 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004522 000026 000084 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005446 -000020 000119 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006558 000016 000090 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
007501 -000026 000136 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008566 -000033 000178 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009415 -000054 000196 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
001960 000006 000362 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002707 000026 00137 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003547 000001 000030 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004573 000031 000056 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005528 -00017 000090 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006606 000012 000067 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
007534 -000027 000125 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
008541 -000031 000170 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009390 -000060 000207 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
001952 000056 000344 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002738 000027 000135 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003622 -00001 000025 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004643 000032 000041 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
005591 -00021 000075 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006593 000010 000070 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
007572 -00031 000124 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
008567 -00036 000185 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009414 -00059 000196 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
001951 000591 000355 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002732 000020 000161 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003616 -00002 000038 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004641 000021 000055 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005575 -00021 000094 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006606 000063 000076 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
007563 -00030 000120 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008587 -00029 000179 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009428 -00056 000194 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
002221 000572 000353 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
003289 000208 000270 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002985 000033 000065 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
003369 000011 000034 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
003838 000011 000044 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
004411 000009 000063 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
005058 000022 000131 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005359 000041 000114 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
005993 000042 000090 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006445 000034 000144 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
006886 -00023 000138 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007361 000031 000194 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
007563 -00013 000144 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
008310 -00022 000185 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
008946 -00034 000189 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009245 -00045 000189 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
002250 000582 000351 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
002424 000219 000274 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
003004 000038 000070 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
003408 000014 000029 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
003805 000011 000042 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
004530 000032 000062 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
005105 000016 000114 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005406 000041 000088 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
006085 000038 000055 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006458 000040 000085 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
006896 -00013 000108 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007345 000026 000155 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
007565 -00014 000135 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
008342 -00022 000169 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
008937 -00037 000191 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009267 -00046 000190 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
002237 000598 000325 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
002405 000232 000255 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
003059 000042 000046 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
003463 000010 000029 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
003887 000013 000034 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
004536 000000 000061 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
005145 000021 000089 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005452 000026 000091 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
006051 000037 000048 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006505 000026 000097 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
006919 -00018 000094 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007386 000032 000147 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
007621 -00016 000133 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart GE56; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: ->olv* setrgbcolor

TUB registration: 20091101-GE56/GE56L0NP.PDF /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

%BEG	GE46	22.TXT	Separation	cmyn62*	cf1=0.90	D50	adapted	\$	%LAB*	1000	x	(r	g	b	c	m	y	0	%nr.	pos	\$
009307	-00005	000004	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	A01	\$
008998	-00529	-00775	0875	1000	1000	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	A02	\$
008272	-01030	-01264	0750	1000	1000	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	A03	\$
007811	-01395	-01560	0625	1000	1000	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	A04	\$
007317	-01951	-02087	0500	1000	1000	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	A05	\$
006793	-02432	-02631	0375	1000	1000	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	A06	\$
006114	-03023	-03266	0250	1000	1000	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	A07	\$
005657	-03563	-03658	0125	1000	1000	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	A08	\$
005515	-04245	-04198	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	A09	\$
008842	000710	0006314	1000	0875	0875	0000	0125	0125	0000	0000	0000	0125	0125	0000	0000	0000	0000	0000	0000	B01	\$
008444	-00066	-00014	0875	0875	0875	0125	0125	0125	0000	0000	0000	0125	0125	0000	0000	0000	0000	0000	0000	B02	\$
007846	-00743	-00712	0750	0875	0875	0250	0125	0125	0000	0000	0000	0250	0125	0000	0000	0000	0000	0000	0000	B03	\$
007288	-01027	-01082	0625	0875	0875	0375	0125	0125	0000	0000	0000	0375	0125	0000	0000	0000	0000	0000	0000	B04	\$
006893	-01463	-01712	0500	0875	0875	0500	0125	0125	0000	0000	0000	0500	0125	0000	0000	0000	0000	0000	0000	B05	\$
006358	-02088	-02317	0375	0875	0875	0625	0125	0125	0000	0000	0000	0625	0125	0000	0000	0000	0000	0000	0000	B06	\$
005692	-02523	-02942	0250	0875	0875	0750	0125	0125	0000	0000	0000	0750	0125	0000	0000	0000	0000	0000	0000	B07	\$
005245	-03035	-03355	0125	0875	0875	0875	0125	0125	0000	0000	0000	0875	0125	0000	0000	0000	0000	0000	0000	B08	\$
004661	-03574	-03769	0000	0875	0875	1000	0125	0125	0000	0000	0000	1000	0125	0000	0000	0000	0000	0000	0000	B09	\$
004247	001459	000842	1000	0750	0750	0000	0250	0250	0000	0000	0000	0250	0250	0000	0000	0000	0000	0000	0000	B10	\$
007897	000649	000471	0875	0750	0750	0125	0250	0250	0000	0000	0000	0250	0250	0000	0000	0000	0000	0000	0000	C02	\$
007465	-00147	-00105	0750	0750	0750	0250	0250	0250	0000	0000	0000	0250	0250	0000	0000	0000	0000	0000	0000	C03	\$
007011	-00685	-00888	0625	0750	0750	0375	0250	0250	0000	0000	0000	0375	0250	0000	0000	0000	0000	0000	0000	C04	\$
006488	-01183	-01171	0500	0750	0750	0500	0250	0250	0000	0000	0000	0500	0250	0000	0000	0000	0000	0000	0000	C05	\$
006011	-01675	-01655	0375	0750	0750	0625	0250	0250	0000	0000	0000	0625	0250	0000	0000	0000	0000	0000	0000	C06	\$
005434	-02151	-02262	0250	0750	0750	0750	0250	0250	0000	0000	0000	0750	0250	0000	0000	0000	0000	0000	0000	C07	\$
004845	-02520	-03016	0125	0750	0750	0875	0250	0250	0000	0000	0000	0875	0250	0000	0000	0000	0000	0000	0000	C08	\$
004425	-02910	-03193	0000	0750	0750	1000	0250	0250	0000	0000	0000	1000	0250	0000	0000	0000	0000	0000	0000	C09	\$
007854	002244	001187	1000	0625	0625	0000	0375	0375	0000	0000	0000	0375	0375	0000	0000	0000	0000	0000	0000	D01	\$
007423	001290	000788	0875	0625	0625	0125	0375	0375	0000	0000	0000	0625	0375	0000	0000	0000	0000	0000	0000	D02	\$
006892	000623	000357	0750	0625	0625	0250	0375	0375	0000	0000	0000	0375	0375	0000	0000	0000	0000	0000	0000	D03	\$
006578	-00167	-00198	0625	0625	0625	0375	0375	0375	0000	0000	0000	0375	0375	0000	0000	0000	0000	0000	0000	D04	\$
006174	-00778	-00829	0500	0625	0625	0500	0375	0375	0000	0000	0000	0500	0375	0000	0000	0000	0000	0000	0000	D05	\$
005661	-01349	-01428	0375	0625	0625	0625	0375	0375	0000	0000	0000	0625	0375	0000	0000	0000	0000	0000	0000	D06	\$
005063	-01808	-01727	0250	0625	0625	0750	0375	0375	0000	0000	0000	0750	0375	0000	0000	0000	0000	0000	0000	D07	\$
004632	-02156	-02512	0125	0625	0625	0875	0375	0375	0000	0000	0000	0875	0375	0000	0000	0000	0000	0000	0000	D08	\$
004185	-02496	-02867	0000	0625	0625	1000	0375	0375	0000	0000	0000	1000	0375	0000	0000	0000	0000	0000	0000	D09	\$
007305	002930	001761	1000	0500	0500	0000	0500	0500	0000	0000	0000	0500	0500	0000	0000	0000	0000	0000	0000	E01	\$
006882	001909	001293	0875	0500	0500	0125	0500	0500	0000	0000	0000	0125	0500	0000	0000	0000	0000	0000	0000	E02	\$
006261	001308	001004	0750	0500	0500	0250	0500	0500	0000	0000	0000	0250	0500	0000	0000	0000	0000	0000	0000	E03	\$
005887	000673	000305	0625	0500	0500	0375	0500	0500	0000	0000	0000	0375	0500	0000	0000	0000	0000	0000	0000	E04	\$
005566	-00310	-00190	0500	0500	0500	0500	0500	0500	0000	0000	0000	0500	0500	0000	0000	0000	0000	0000	0000	E05	\$
005419	-00898	-00810	0375	0500	0500	0625	0500	0500	0000	0000	0000	0625	0500	0000	0000	0000	0000	0000	0000	E06	\$
004757	-01504	-01678	0250	0500	0500	0750	0500	0500	0000	0000	0000	0750	0500	0000	0000	0000	0000	0000	0000	E07	\$
004058	-01845	-01901	0125	0500	0500	0875	0500	0500	0000	0000	0000	0875	0500	0000	0000	0000	0000	0000	0000	E08	\$
003919	-02149	-02459	0000	0500	0500	1000	0500	0500	0000	0000	0000	1000	0500	0000	0000	0000	0000	0000	0000	E09	\$
006606	003513	002182	1000	0375	0375	0000	0625	0625	0000	0000	0000	0625	0625	0000	0000	0000	0000	0000	0000	F01	\$
006209	002671	001791	0875	0375	0375	0125	0625	0625	0000	0000	0000	0375	0625	0000	0000	0000	0000	0000	0000	F02	\$
005643	002018	001444	0750	0375	0375	0250	0625	0625	0000	0000	0000	0375	0625	0000	0000	0000	0000	0000	0000	F03	\$
005254	001264	000963	0625	0375	0375	0375	0625	0625	0000	0000	0000	0375	0625	0000	0000	0000	0000	0000	0000	F04	\$
004922	000414	000298	0500	0375	0375	0500	0625	0625	0000	0000	0000	0375	0625	0000	0000	0000	0000	0000	0000	F05	\$
004807	-00334	-00268	0375	0375	0375	0625	0625	0625	0000	0000	0000	0375	0625	0000	0000	0000	0000	0000	0000	F06	\$
004390	-00940	-00953	0250	0375	0375	0750	0625	0625	0000	0000	0000	0375	0625	0000	0000	0000	0000	0000	0000	F07	\$
003794	-01652	-01678	0125	0375	0375	0875	0625	0625	0000	0000	0000	0375	0625	0000	0000	0000	0000	0000	0000	F08	\$
003491	-01904	-02035	0000	0375	0375	1000	0625	0625	0000	0000	0000	1000	0625	0000	0000	0000	0000	0000	0000	F09	\$
005909	004193	002611	1000	0250	0250	0000	0750	0750	0000	0000	0000	0250	0750	0000	0000	0000	0000	0000	0000	G01	\$
005564	003363	002248	0875	0250	0250	0125	0750	0750	0000	0000	0000	0250	0750	0000	0000	0000	0000	0000	0000	G02	\$
005015	002826	001883	0750	0250	0250	0250	0750	0750	0000	0000	0000	0250	0750	0000	0000	0000	0000	0000	0000	G03	\$
004678	001960	001329	0625	0250	0250	0375	0750	0750	0000	0000	0000	0375	0750	0000	0000	0000	0000	0000	0000	G04	\$
004393	001084	000850	0500	0250	0250	0500	0750	0750	0000	0000	0000	0500	0750	0000	0000	0000	0000	0000	0000	G05	\$
004234	000255	000140	0375	0250	0250	0625	0750	0750	0000	0000	0000	0375	0750	0000	0000	0000					

009304	-00004	000009	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
008882	-00292	-00748	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008124	-00631	-01143	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
007462	-00769	-01560	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
006945	-01026	-02005	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
006441	-01367	-02475	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
005785	-01859	-03192	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
005200	-02140	-03576	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
004568	-02445	-04227	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
003863	-02655	-04642	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
003831	-00658	-00959	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
007692	-00457	-00838	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
007128	-00681	-01179	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
006704	-00911	-01651	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
006135	-01244	-02111	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
005473	-01601	-02692	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
004864	-01839	-03310	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
004310	-02192	-03728	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
003715	-00109	-00921	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
003060	-00347	-00448	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
007451	-01042	-00136	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
006975	-00489	-00883	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
006394	-00835	-01320	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
005835	-01101	-01862	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
005263	-01460	-02313	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
004683	-01627	-02754	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
004139	-01902	-03160	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
003625	-00156	-001624	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
007704	-00918	-01105	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
007057	-00323	-00635	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
006608	-00177	-00198	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
006186	-00541	-00837	0500	0593	0625	0500	0406	0375	0000	00112	M05	\$
005621	-00954	-01343	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
005061	-01270	-01824	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
004436	-01491	-02441	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
003891	-01798	-02632	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007774	-00213	-002183	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
007273	-00147	-001692	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
006549	-00857	-001328	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
006055	-00439	-004043	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
005644	-00364	-00204	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
005361	-00603	-00887	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
004662	-01121	-01654	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
003955	-01452	-02023	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
003552	-01657	-02487	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
007339	-002692	-002737	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
006718	-001959	-002127	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
006045	-001493	-001690	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
005521	-000848	-001166	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
005028	-00260	-00339	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
004820	-00319	-00273	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
004355	-00750	-00980	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
003683	-01213	-01638	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
003212	-01447	-02048	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
006673	-00329	-003263	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
006126	-002549	-002739	0875	0406	0500	0125	0593	0750	0000	00136	P02	\$
005572	-001917	-002289	0750	0375	0250	0250	0625	0750	0000	00137	P03	\$
005021	-001428	-001636	0625	0343	0250	0375	0656	0750	0000	00138	P04	\$
004637	-000814	-000997	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
004356	-000051	-000221	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
003904	-00433	-00329	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
003613	-00792	-01081	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
002994	-00982	-01668	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
006128	-003598	-003785	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
005638	-002952	-003148	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
005051	-002447	-002616	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
004540	-001887	-002077	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
004015	-001268	-001595	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
003835	-000760	-000841	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
003615	-000177	-000341	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
003081	-00468	-00272	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
002703	-00371	-01487	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
005686	-003969	-004336	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
005166	-003402	-003982	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
004612	-002970	-003550	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
004112	-002385	-002678	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
003757	-001737	-002344	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
003588	-001156	-001863	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
003282	-000797	-001355	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
002864	-000082	-000083	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
002284	-00011	-000016	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
009409	000005	-00017	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
008703	000318	-00054	0800	0875	1000	0093	0125	0000	0000	00406	J11	\$
008102	000536	-00054	0812	0750	1000	0812	0250	0000	0000	00407	J12	\$
007303	000824	-01282	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
006472	001202	-01653	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
005777	001497	-02021	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
004949	001753	-02615	0437	0250	1000	0562	0750	0000	0000	00411	J16	\$
004201	001818	-03202	0343	0250	1000	0687	0875	0000	0000	00412	J17	\$
003400	002618	-03834	0218	0000	1000	0750	1000	0000	0000	00413	J18	\$
009188	-00197	-00635	0968	1000	0875	0031	0000	0125	0000	00414	K10	\$
008593	-00047	-00045	0875	0875	0875	0125	0125	0125	0000	00415	K11	\$
008745	-000194	-00653	0781	0750	0875	0218	0250	0125	0000	00416	K12	\$
007983	000480	-00934	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
006382	000791	-01371	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
005570	001244	-01777	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
004702	001474	-02318	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
003914	001729	-03008	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
003027	002555	-03603	0218	0000	0875	0781	1000	0125	0000	00422	K18	\$
009110	-00438	-001207	0937	1000	0750	0062	0000	0250	0000	00423	L10	\$
008427	-00335	-000538										

See original or copy: <http://web.me.com/klaus.richter/GE56/GE56L0NP.PDF> / .PS
 Technical information: <http://www.ps.ban.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.01; nx=1.33

TUB registration: 20091101-GE56/GE56L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

```
input: w setgray
output: -> oly* setrgbcolor
```

TUB-test chart GE56; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

See original or copy: <http://web.me.com/klaus.richter/GE56/GE56L.0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.01; nx=1.33

[illegible]

See original or copy: <http://web.me.com/klaus.richter/GE56/GE56L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.01; nx=1.3

```
%BEG GE46.22.TXT, Separation cmyn62*, cfi=0.90, D50, adapted $
%100 x LAB*a      %1000 x (r g b c m y o)      %nr.      pos $
%Z004736 005986 003756 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008953 -00692 007453 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005684 -05952 002890 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005515 -04245 -04198 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003181 001688 -04505 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004727 006084 -00898 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z002149 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009379 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%$
%Z004736 005986 003756 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008953 -00692 007453 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005684 -05952 002890 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005515 -04245 -04198 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003181 001688 -04505 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004727 006084 -00898 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z002149 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009379 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%$
%Z004736 005986 003756 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008953 -00692 007453 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005684 -05952 002890 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005515 -04245 -04198 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003181 001688 -04505 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004727 006084 -00898 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z002149 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009379 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%$
%Z005686 003969 004336 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z007870 -02095 006218 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005473 -05258 000370 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004568 -02445 -04227 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003400 002618 -03834 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004686 005909 000490 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z002186 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009366 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%$
%Z006508 002703 005076 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007026 -03574 005228 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005358 -04694 -01317 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004159 -01460 -04468 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003904 003096 -02826 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004739 005835 001548 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z002216 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009373 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%$
%Z007428 001432 005959 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006526 -04823 004283 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005584 -05041 -02745 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003854 -00041 -04334 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004105 004748 -02124 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004723 005717 002633 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z002102 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009361 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%$
```

See original or copy: <http://web.me.com/klaus.richter/GE56/GE56L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.01; nx=1.3

```
%BEG GE46.22.TXT, Separation cmyn62*, cfi=0.90, D50, adapted $
%100 x LAB*a      1000 x (r g b c m y 0)      %nr. pos $
001909 000016 -00045 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002670 -00499 -00249 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003567 -00443 -00329 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004522 -00333 -00261 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005446 -00300 -00199 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006558 -00166 -00195 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
007501 -00126 -00122 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008566 -00039 -00049 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009415 000012 -00087 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
0101960 000023 -00057 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
0207707 -00491 -00260 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
0303547 -00443 -00343 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
0404573 -00323 -00286 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
0505528 -00289 -00225 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
0606606 -00165 -00217 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
0707534 -00124 -00132 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
0808541 -00040 -00058 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
0909390 000005 000003 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
1001952 000012 -00075 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
1102738 -00488 -00261 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
1203622 -00440 -00346 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
1304643 -00316 -00300 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
1405591 -00287 -00238 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
1506593 -00168 -00214 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
1607572 -00124 -00132 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
1708567 -00043 -00042 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
1809414 000008 -00007 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
1901951 000007 -00064 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
2002732 -00495 -00235 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
2103616 -00442 -00332 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
2204641 -00328 -00286 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
2305575 -00289 -00220 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
2406606 -00181 -00208 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
2507563 -00124 -00136 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
2608587 -00034 -00047 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
2709428 000012 -00009 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
2802221 000011 -00058 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
2902389 -00337 -00136 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
3002985 -00460 -00324 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
3103369 -00449 -00344 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
3203838 -00407 -00320 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
3304411 -00360 -00285 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
3405058 -00290 -00198 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
3505359 -00245 -00206 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
3605993 -00189 -00212 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
3706445 -00157 -00145 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
3806886 -00176 -00138 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
3907361 -00080 -00068 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
4007563 -00107 -00113 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
4108310 -00051 -00049 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
4208946 -00008 -00027 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
4309245 000007 -00019 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
4402250 000024 -00059 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
4502424 -00323 -00131 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
4603004 -00454 -00318 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
4703408 -00442 -00347 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
4803805 -00404 -00321 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
4904530 -00363 -00282 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
5005105 -00292 -00214 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
5105406 -00241 -00231 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
5206085 -00184 -00244 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
5306458 -00150 -00204 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
5406896 -00165 -00168 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
5507345 -00086 -00108 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
5607565 -00108 -00122 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
5708342 -00049 -00065 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
5808937 -00011 -00026 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
5909267 000008 -00017 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
6002237 000039 -00086 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
6102405 -00312 -00150 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
6203059 -00445 -00341 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
6303463 -00442 -00346 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
6403887 -00402 -00329 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
6504536 -00358 -00283 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
6605145 -00284 -00237 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
6705452 -00251 -00226 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
6806051 -00189 -00252 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
6906505 -00160 -00190 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
7006919 -00168 -00181 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
7107386 -00077 -00115 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
7207621 -00106 -00122 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```