

See original or copy: <http://web.me.com/klaus.richter/HE73/HE73L0NA.TXT> /PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

TUB registration: 20091101-HE73/HE73L0NA.TXT /PS
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

%BEG LAB22.TXT, Separation cmyk, cfi=0.90, D65, not adapted S																			
%100 x LAB*																			
1000 x (r g b c m y o)																			
000119 0000 0000 0000 0000 0000 0000 0000 0000 0000																			
000122 000148 -00142 0000 0000 0125 0000 1000 0875 0000																			
0002532 000256 -00456 0000 0000 0250 0000 1000 0750 0000																			
0003193 000331 -01260 0000 0000 0375 0000 1000 0625 0000																			
0003318 000275 -01232 0000 0000 0500 0000 1000 0500 0000																			
0003704 000352 -01902 0000 0000 0625 0000 1000 0375 0000																			
0003821 000562 -02114 0000 0000 0750 0000 1000 0250 0000																			
0004374 000643 -03391 0000 0000 0875 0000 1000 0125 0000																			
0004536 000821 -04291 0000 0000 1000 0000 1000 0000 0000																			
0004242 -00104 000419 0000 0125 0000 1000 0875 1000 0000 0000																			
0002071 000013 000082 0000 0125 0125 0000 0875 0875 0000 0000																			
0002568 -00096 -00304 0000 0125 0250 0000 0875 0750 0000 0000																			
0003430 -00144 -01112 0000 0125 0375 0000 0875 0625 0000 0000																			
0003550 -00175 -01238 0000 0125 0500 0000 0875 0500 0000 0000																			
0003999 -00124 -01747 0000 0125 0625 0000 0875 0375 0000 0000																			
0004335 000016 -02279 0000 0125 0750 0000 0875 0250 0000 0000																			
0004677 -00181 -03252 0000 0125 0875 0000 0875 0125 0000 0000																			
0004703 -00204 -03227 0000 0125 1000 0000 0875 0000 0000 0000																			
0002596 -00194 000275 0000 0250 0000 0000 0750 1000 0000 0000																			
0002578 -00225 000266 0000 0250 0125 0000 0750 0875 0000 0000																			
0002606 -00104 -03037 0000 0250 0250 0000 0750 0750 0000 0000																			
0003706 -00611 -00973 0000 0250 0375 0000 0750 0625 0000 0000																			
0003915 -00602 -01064 0000 0250 0500 0000 0750 0500 0000 0000																			
0004022 -00134 -01770 0000 0250 0625 0000 0750 0375 0000 0000																			
0004654 -00520 -02199 0000 0250 0750 0000 0750 0250 0000 0000																			
0004667 -00230 -03267 0000 0250 0875 0000 0750 0125 0000 0000																			
0004576 -00756 -04432 0000 0250 1000 0000 0750 0000 0000 0000																			
0004233 -01528 000644 0000 0375 0000 0000 0625 1000 0000 0000																			
0003609 -00783 000322 0000 0375 0125 0000 0625 0875 0000 0000																			
0003744 -00711 -00227 0000 0375 0250 0000 0625 0750 0000 0000																			
0003744 -00604 -01006 0000 0375 0375 0000 0625 0625 0000 0000																			
0004232 -00718 -01567 0000 0375 0500 0000 0625 0500 0000 0000																			
0004629 -01133 -01597 0000 0375 0625 0000 0625 0375 0000 0000																			
0004933 -01005 -02064 0000 0375 0750 0000 0625 0250 0000 0000																			
0004974 -00847 -03124 0000 0375 0875 0000 0625 0125 0000 0000																			
0004942 -01408 -04164 0000 0375 1000 0000 0625 0000 0000 0000																			
0004680 -02556 001170 0000 0500 0000 0000 0500 1000 0000 0000																			
0004184 -01479 -00066 0000 0500 0125 0000 0500 0875 0000 0000																			
0004243 -01483 -00076 0000 0500 0250 0000 0500 0750 0000 0000																			
0004142 -01326 -00087 0000 0500 0375 0000 0500 0625 0000 0000																			
0004197 -01174 -00097 0000 0500 0500 0000 0500 0500 0000 0000																			
0004582 -01145 -01596 0000 0500 0625 0000 0500 0375 0000 0000																			
0005220 -01404 -02574 0000 0500 0750 0000 0500 0250 0000 0000																			
0005239 -01342 -03092 0000 0500 0875 0000 0500 0125 0000 0000																			
0004950 -01414 -04192 0000 0500 1000 0000 0500 0000 0000 0000																			
0004662 -02559 001159 0000 0625 0000 0000 0375 1000 0000 0000																			
0004714 -02344 000378 0000 0625 0125 0000 0375 0875 0000 0000																			
0004765 -02336 000390 0000 0625 0250 0000 0375 0750 0000 0000																			
0004708 -01884 -00643 0000 0625 0375 0000 0375 0625 0000 0000																			
0004606 -01694 -00753 0000 0625 0500 0000 0375 0500 0000 0000																			
0004708 -01269 -01600 0000 0625 0625 0000 0375 0375 0000 0000																			
0005112 -01523 -01942 0000 0625 0750 0000 0375 0250 0000 0000																			
0005473 -02827 -03529 0000 0625 0875 0000 0375 0125 0000 0000																			
0005242 -01992 -03980 0000 0625 1000 0000 0375 0000 0000 0000																			
0005110 -03236 001689 0000 0750 0000 0000 0250 1000 0000 0000																			
0005123 -03277 000922 0000 0750 0125 0000 0250 0875 0000 0000																			
0005305 -02980 000176 0000 0750 0250 0000 0250 0750 0000 0000																			
0004999 -02304 -00259 0000 0750 0375 0000 0250 0625 0000 0000																			
0005391 -02564 -00767 0000 0750 0500 0000 0250 0500 0000 0000																			
0005099 -01864 -01188 0000 0750 0625 0000 0250 0375 0000 0000																			
0005079 -01790 -01331 0000 0750 0750 0000 0250 0250 0000 0000																			
0005722 -02988 -02691 0000 0750 0875 0000 0250 0125 0000 0000																			
0005484 -02827 -03494 0000 0750 1000 0000 0250 0000 0000 0000																			
0005550 -04217 001647 0000 0875 0000 0000 0125 1000 0000 0000																			
0005588 -03973 000683 0000 0875 0125 0000 0125 0875 0000 0000																			
0005607 -03956 000672 0000 0875 0250 0000 0125 0750 0000 0000																			
0005759 -03646 -00252 0000 0875 0375 0000 0125 0625 0000 0000																			
0005761 -03615 -00338 0000 0875 0500 0000 0125 0500 0000 0000																			
0005623 -01516 -01078 0000 0875 0725 0000 0125 0250 0000 0000																			
0005767 -02845 -02133 0000 0875 0750 0000 0125 0000 0000 0000																			
0005625 -02339 -02210 0000 0875 0875 0000 0125 0125 0000 0000																			
0005719 -03416 -03317 0000 0875 1000 0000 0125 0000 0000 0000																			
0005673 -04543 001848 0000 1000 0000 0000 0000 0000 0000 0000																			
0005893 -05641 001471 0000 1000 0125 0000 0000 0875 0000 0000																			
0005952 -05208 000469 0000 1000 0250 0000 0000 0750 0000 0000																			
0005938 -05144 000256 0000 1000 0375 0000 0000 0625 0000 0000																			
0005980 -04688 -00536 0000 1000 0500 0000 0000 0500 0000 0000																			
0005958 -04553 -00908 0000 1000 0625 0000 0000 0375 0000 0000																			
0005703 -04535 -01698 0000 1000 0750 0000 0000 0250 0000 0000																			
0005899 -03947 -02171 0000 1000 0875 0000 0000 0125 0000 0000																			
0005589 -04190 -02487 0000 1000 1000 0000 0000 0000 0000 0000																			
0002240 000142 000337 0125 0000 0000 0875 1000 1000 0000 0000																			
0002329 000331 -00157 0125 0000 0125 0875 1000 0875 0000 0000																			
0002525 000206 -00458 0125 0000 0250 0875 1000 0750 0000 0000																			
0003145 000300 -01290 0125 0000 0375 0875 1000 0625 0000 0000																			
0003279 000290 -01268 0125 0000 0500 0875 1000 0500 0000 0000																			
0003674 000380 -02017 0125 0000 0625 0875 1000 0375 0000 0000																			
0003805 000593 -02290 0125 0000 0750 0875 1000 0250 0000 0000																			
0004349 000636 -03450 0125 0000 0875 0875 1000 0125 0000 0000																			
0004242 001090 -04189 0125 0000 1000 0875 1000 0000 0000 0000																			
0002765 -00087 000469 0125 0125 0000 0875 0875 1000 0000 0000																			
0002471 000009 000083 0125 0125 0125 0875 0875 0875 0000 0000																			
0002940 000034 -00330 0125 0125 0250 0875 0875 0750 0000 0000																			
0003200 000000 -00934 0125 0125 0375 0875 0875 0625 0000 0000																			
0003442 000117 -01419 0125 0125 0500 0875 0875 0500 0000 0000																			
0003786 000195 -01879 0125 0125 0625 0875 0875 0375 0000 0000																			
0004221 000004 -02175 0125 0125 0750 0875 0875 0250 0000 0000																			
0004478 000332 -02590 0125 0125 0875 0875 0875 0125 0000 0000																			
0004713 000085 -03232 0125 0125 1000 0875 0875 0000 0000 0000																			
0003682 -00353 000929 0125 0250 0000 0875 0750 1000 0000 0000																			
0002981 -00206 000250 0125 0250 0125 0875 0750 0875 0000 0000																			
0002999 000147 -00226 0125 0250 0250 0875 0750 0750 0000 0000																			
0003307 -00319 -00600 0125 0250 0375 0875 0750 0625 0000 0000																			
0003796 -00267 -01308 0125 0250 0500 0875 0750 0500 0000 0000																			
0003984 -00113 -01764 0125 0250 0625 0875 0750 0375 0000 0000																			
0004289 -00066 -02119 0125 0250 0750 0875 0750 0250 0000 0000																			
0004676 -00332 -02698 0125 0250 0875 0875 0750 0125 0000 0000																			
0004855 -00358 -03158 0125 0250 1000 0875 0750 0000 0000 0000																			
0004216 -01527 000658 0125 0375 0000 0875 0625 1000 0000 0000																			
0003813 -01000 000462 0125 0375 0125 0875 0625 0875 0000 0000																			
0003771 -00715 -00177 0125 0375 0250 0875 0625 0750 0000 0000																			
0003794 -00722 -00296 0125 0375 0375 0875 0625 0625 0000 0000																			
0003971 -00773 -01136 0125 0375 0500 0875 0625 0500 0000 0000																			
0004322 -00720 -01615 0125 0375 0625 0875 0625 0375 0000 0000																			
0004603 -00517 -02081 0125 0375 0750 0875 0625 0250 0000 0000																			
0004844 -00657 -02624 0125 0375 0875 0875 0625 0125 0000 0000																			
0004983 -00764 -03167 0125 0375 1000 0875 0625 0000 0000 0000																			
0004602 -02533 001125 0250 0500 0000 0875 0500 1000 0000 0000																			
0004215 -01531 000708 0125 0500 0125 0875 0500 0875 0000 0000																			
0004274 -01474 -00050 0125 0500 0250 0875 0500 0750 0000 0000																			
0004095 -01193 -00237 0125 0500 0375 0875 0500 0625 0000 0000																			
0004213 -01211 -01015 0125 0500 0500 0875 0500 0500 0000 0000																			
0004671 -01135 -01605 0125 0500 0625 0875 0500 0375 0000 0000																			
0004924 -01087 -02067 0125 0500 0750 0875 0500 0250 0000 0000																			
0005238 -01406 -02611 0125 0500 0875 0875 0500 0125 0000 0000																			
0005145 -01777 -03125 0125 0500 1000 0875 0500 0000 0000 0000																			
0005135 -03348 001703 0125 0625 0000 0875 0375 1000 0000 0000																			
0004662 -02515 000201 0125 0625 0125 0875 0375 0875 0000 0000																			
0004647 -02105 000481 0125 0625 0250 0875 0375 0750 0000 0000																			
0004557 -01939 -00171 0125 0625 0375 0875 0375 0625 0000 0000																			
0004693 -01664 -00808 0125 0625 0500 0875 0375 0500 0000 0000																			
0004717 -01524 -01083 0125 0625 0625 0875 0375 0375 0000 0000																			
0005155 -01515 -01967 0125 0625 0750 0875 0375 0250 0000 0000																			
0005427 -01711 -02434 0125 0625 0875 0875 0375 0125 0000 0000																			
0005406 -01762 -03115 0125 0625 1000 0875 0375 0000 0000 0000																			
0005528 -04352 0002567 0125 0750 0000 0875 0250 1000 0000 0000																			
0005177 -03253 000959 0125 0750 0125 0875 0250 0875 0000 0000																			
0005092 -02832 000652 0125 0750 0250 0875 0250 0750 0000 0000																			
0005136 -02452 -00115 0125 0750 0375 0875 0250 0625 0000 0000																			
0005105 -02192 -00444 0125 0750 0500 0875 0250 0500 0000 0000																			
0005192 -01945 -01149 0125 0750 0625 0875 0250 0375 0000 0000																			
0005167 -01861 -01272 0125 0750 0750 0875 0250 0250 0000 0000																			
0005566 -02077 -02243 0125 0750 0875 0875 0250 0125 0000 0000																			
0005644 -02348 -03033 0125 0750 1000 0875 0250 0000 0000 0000																			
0005925 -05896 0002663 0125 0875 0000 0875 0125 1000 0000 0000																			
0005491 -03919 001402 0125 0875 0125 0875 0125 0875 0000 0000																			
0005517 -03490 000793 0125 0875 0250 0875 0125 0750 0000 0000																			
0005502 -03195 000165 0125 0875 0375 0875 0125 0625 0000 0000																			
0005520 -02883 -00369 0125 0875 0500 0875 0125 0500 0000 0000																			
0005578 -05702 000782 0125 0875 1000 0875 0125 0000 0000 0000																			
0005691 -02845 -02133 0125 0875 0750 0875 0125 0000 0000 0000																			
0005612 -02234 -01698 0125 0875 0875 0875 0125 0125 0000 0000																			
0005840 -02634 -02673 0125 0875 1000 0875 0125 0000 0000 0000																			
0005																			

004016	001247	000499	0375	0000	0000	0625	1000	1000	0000	%0243	A10	\$
003830	001024	000145	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$
003157	001472	-00175	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$
004067	000492	-00719	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$
004074	001152	-01083	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$
004484	001202	-02085	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$
004017	001816	-02709	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$
003711	002257	-04054	0375	0000	0875	0625	1000	0125	0000	%0250	A17	\$
003403	001778	-04350	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$
003914	000781	000868	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$
003888	000855	000781	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$
003809	000992	000114	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$
003294	000485	-00390	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$
003836	000583	-01067	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$
004081	001159	-02051	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$
004035	001211	-02088	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$
004041	001314	-02823	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$
004189	001204	-03421	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$
004505	001502	-001713	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$
003996	000758	000917	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$
004048	000738	000369	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$
004103	000463	-00210	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$
004210	000392	-00849	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$
004363	000424	-01387	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$
004572	000498	-01910	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$
004749	000582	-02446	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$
005166	000538	-02751	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$
004913	-00211	001693	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$
004686	-00343	001380	0375	0375	0125	0625	0625	0875	0000	%0271	D11	\$
004475	-00121	000949	0375	0375	0250	0625	0625	0750	0000	%0272	D12	\$
004496	-00003	000120	0375	0375	0375	0625	0625	0625	0000	%0273	D13	\$
004832	-00005	-00263	0375	0375	0500	0625	0625	0500	0000	%0274	D14	\$
005302	-00010	-00011	0375	0375	0625	0625	0625	0375	0000	%0275	D15	\$
005394	-00104	-01402	0375	0375	0750	0625	0625	0250	0000	%0276	D16	\$
005715	-00003	-01282	0375	0375	0875	0625	0625	0125	0000	%0277	D17	\$
006048	-00035	-02102	0375	0375	1000	0625	0625	0000	0000	%0278	D18	\$
005706	-01670	002063	0375	0500	0000	0625	0500	1000	0000	%0279	D19	\$
005237	-01066	001594	0375	0500	0125	0625	0500	0875	0000	%0280	E11	\$
005186	-01040	001138	0375	0500	0250	0625	0500	0750	0000	%0281	E12	\$
005154	-00712	000189	0375	0500	0375	0625	0500	0625	0000	%0282	E13	\$
005065	-00435	-00260	0375	0500	0500	0625	0500	0500	0000	%0283	E14	\$
005402	-00565	-00862	0375	0500	0625	0625	0500	0375	0000	%0284	E15	\$
005621	-00492	-01380	0375	0500	0750	0625	0500	0250	0000	%0285	E16	\$
005861	-00417	-01791	0375	0500	0875	0625	0500	0125	0000	%0286	E17	\$
006171	-00313	-02087	0375	0500	1000	0625	0500	0000	0000	%0287	E18	\$
006050	-02378	002694	0375	0625	0000	0625	0375	1000	0000	%0288	F10	\$
005724	-01634	002081	0375	0625	0125	0625	0375	0875	0000	%0289	F11	\$
005495	-01796	001439	0375	0625	0250	0625	0375	0750	0000	%0290	F12	\$
005500	-01320	000387	0375	0625	0375	0625	0375	0625	0000	%0291	F13	\$
005670	-01032	-00219	0375	0625	0500	0625	0375	0500	0000	%0292	F14	\$
005559	-00955	-00496	0375	0625	0625	0625	0375	0375	0000	%0293	F15	\$
005709	-00951	-01459	0375	0625	0750	0625	0375	0250	0000	%0294	F16	\$
006042	-00889	-01714	0375	0625	0875	0625	0375	0125	0000	%0295	F17	\$
006318	-00845	-02142	0375	0625	1000	0625	0375	0000	0000	%0296	F18	\$
006405	-03292	003250	0375	0750	0000	0625	0250	1000	0000	%0297	G10	\$
005764	-02774	002138	0375	0750	0125	0625	0250	0875	0000	%0298	G11	\$
005777	-02770	001671	0375	0750	0250	0625	0250	0750	0000	%0299	G12	\$
006049	-02020	000816	0375	0750	0375	0625	0250	0625	0000	%0300	G13	\$
005960	-01734	00012	0375	0750	0500	0625	0250	0500	0000	%0301	G14	\$
005889	-01542	-00563	0375	0750	0625	0250	0250	0375	0000	%0302	G15	\$
005882	-01463	-00946	0375	0750	0750	0625	0250	0250	0000	%0303	G16	\$
006258	-01601	-01662	0375	0750	0875	0625	0250	0125	0000	%0304	G17	\$
006514	-01407	-02235	0375	0750	1000	0625	0250	0000	0000	%0305	G18	\$
006423	-03240	003208	0375	0875	0000	0625	0125	1000	0000	%0306	H10	\$
006144	-03562	002782	0375	0875	0125	0625	0125	0875	0000	%0307	H11	\$
006133	-03516	001957	0375	0875	0250	0625	0125	0750	0000	%0308	H12	\$
006439	-02637	000678	0375	0875	0375	0625	0125	0625	0000	%0309	H13	\$
006427	-02463	000132	0375	0875	0500	0625	0125	0500	0000	%0310	H14	\$
006443	-03222	-00238	0375	0875	0625	0625	0125	0375	0000	%0311	H15	\$
006347	-02066	-00876	0375	0875	0750	0625	0125	0250	0000	%0312	H16	\$
006325	-01838	-01263	0375	0875	0875	0625	0125	0125	0000	%0313	H17	\$
006832	-02032	-01872	0375	0875	1000	0625	0125	0000	0000	%0314	H18	\$
006689	-04895	-004708	0375	1000	0000	0625	0000	1000	0000	%0315	I10	\$
006481	-04476	003194	0375	1000	0125	0625	0000	0875	0000	%0316	I11	\$
006472	-04463	002274	0375	1000	0250	0625	0000	0750	0000	%0317	I12	\$
006907	-03321	001059	0375	1000	0375	0625	0000	0625	0000	%0318	I13	\$
006846	-03060	000405	0375	1000	0500	0625	0000	0500	0000	%0319	I14	\$
006792	-02769	-00091	0375	1000	0625	0000	0000	0375	0000	%0320	I15	\$
006747	-02626	-00460	0375	1000	0750	0625	0000	0250	0000	%0321	I16	\$
006688	-02321	-01150	0375	1000	0875	0625	0000	0125	0000	%0322	I17	\$
006753	-02241	-01419	0375	1000	1000	0625	0000	0000	0000	%0323	I18	\$
004691	002709	000988	0500	0000	0000	0500	1000	1000	0000	%0324	J10	\$
004759	002664	000964	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$
004818	003018	000215	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$
004503	001959	-01278	0500	0000	0375	0500	1000	0625	0000	%0327	J13	\$
004106	001126	-01069	0500	0000	0500	0500	1000	0500	0000	%0328	J14	\$
004163	002161	-02268	0500	0000	0625	0500	1000	0375	0000	%0329	J15	\$
003971	002231	-03250	0500	0000	0750	0500	1000	0250	0000	%0330	J16	\$
003978	002240	-03250	0500	0000	1000	0500	1000	0125	0000	%0331	J17	\$
003360	002560	-04205	0500	0000	1000	0500	1000	0000	0000	%0332	J18	\$
004689	002387	002328	0500	0125	0000	0500	0875	1000	0000	%0333	K10	\$
004365	001490	000790	0500	0125	0125	0500	0875	0875	0000	%0334	K11	\$
004496	001962	000288	0500	0125	0250	0500	0875	0750	0000	%0335	K12	\$
004307	001638	-00650	0500	0125	0375	0500	0875	0625	0000	%0336	K13	\$
004093	001217	-01017	0500	0125	0500	0500	0875	0500	0000	%0337	K14	\$
004130	001261	-01223	0500	0125	0625	0500	0875	0375	0000	%0338	K15	\$
004048	001207	-02087	0500	0125	0750	0500	0875	0250	0000	%0339	K16	\$
004058	001799	-02638	0500	0125	0875	0500	0875	0125	0000	%0340	K17	\$
004019	001758	-03416	0500	0125	1000	0500	0875	0000	0000	%0341	K18	\$
004719	002327	002329	0500	0250	0000	0500	0750	1000	0000	%0342	L10	\$
004502	001516	001733	0500	0250	0125	0500	0750	0875	0000	%0343	L11	\$
004378	0013											

004778	003772	001731	0750	0000	0000	0250	0000	1000	1000	0000	0000	%0486	A19	\$
004742	003983	000974	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$		
004755	004211	000368	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$		
004674	004537	-00365	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$		
004589	004722	-01296	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$		
004909	003854	-02048	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$		
003879	002854	-01938	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$		
003836	003228	-02477	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$		
003807	003659	-03381	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$		
004829	003470	003076	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$		
004716	003803	001777	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$		
004668	003972	001066	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$		
004686	004181	000394	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$		
004579	004539	-00371	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$		
004076	003249	-01586	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$		
003821	002915	-01986	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$		
003778	002577	-02325	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$		
004049	002634	-02939	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$		
004855	003450	003150	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$		
004740	002944	002805	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$		
004940	002890	001616	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$		
004910	002990	000884	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$		
004843	003271	-00028	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$		
004512	002762	-00806	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$		
004186	002141	-01245	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$		
004393	002142	-01878	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$		
004709	002072	-02460	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$		
005409	002524	003402	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$		
005020	002468	002892	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$		
005157	002374	002396	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$		
005564	002119	001332	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$		
005462	002144	000431	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$		
005343	002282	-00272	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$		
004867	001558	-00927	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$		
005007	001652	-01563	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$		
005304	001412	-02117	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$		
005899	001644	003816	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$		
005486	001651	003302	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$		
005623	001665	002765	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$		
005831	001555	002013	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$		
006106	001394	001026	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$		
006101	001511	002026	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$		
005525	000980	-00607	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$		
005821	000988	-01217	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$		
005926	001006	-01704	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$		
006448	000869	004454	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$		
006410	000890	004419	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$		
006096	000769	003357	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$		
006273	000683	002546	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$		
006470	000667	001697	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$		
006648	000722	000627	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$		
006317	000446	-00154	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$		
006467	000495	-00892	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$		
006750	000534	-01255	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$		
007022	000123	005157	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$		
006727	-00306	004275	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$		
006722	-00211	003891	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$		
006852	-00192	003045	0750	0750	0375	0250	0250	0500	0000	%0543	G22	\$		
007024	-00198	002282	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$		
007095	-00184	001064	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$		
007215	000908	002091	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$		
007625	-00224	-00310	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$		
007827	-00141	-00901	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$		
008095	-01112	006225	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$		
007728	-01582	005553	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$		
007585	-01305	004713	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$		
007613	-01275	003821	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$		
007625	-01269	002786	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$		
007599	-01105	001492	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$		
007776	-00710	000368	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$		
007793	-00682	-00292	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$		
007991	-00562	-00902	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$		
007986	-02426	006880	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$		
007963	-02350	005696	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$		
007925	-02278	004769	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$		
007971	-02235	003910	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$		
007944	-02122	002965	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$		
008023	-01957	002054	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$		
008199	-01511	000620	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$		
008154	-01286	000920	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$		
008154	-01090	-00478	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$		
004677	005540	002545	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$		
004613	005708	001862	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$		
004568	005948	001078	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$		
004571	006229	001519	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$		
004615	005122	-01009	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$		
004545	004722	-01284	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$		
004177	004269	-01661	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$		
003977	004068	-02069	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$		
003964	003372	-02579	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$		
004673	005447	003271	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$		
004851	004110	002051	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$		
004882	004299	001277	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$		
004843	004374	000667	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$		
004796	004673	-00093	0875	0125										

0069653	-008088	000198	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$	
0089886	-005076	-003075	0875	1000	1000	1000	0125	0000	0000	0000	%0730	b02	\$
0083347	-009077	-004664	0750	1000	1000	0000	0250	0000	0000	0000	%0731	b03	\$
007756	-012022	-006693	0625	1000	1000	0000	0375	0000	0000	0000	%0732	b04	\$
007285	-017122	-010336	0500	1000	1000	0000	0500	0000	0000	0000	%0733	b05	\$
006785	-021442	-015093	0375	1000	1000	0000	0625	0000	0000	0000	%0734	b06	\$
006219	-026466	-019511	0250	1000	1000	0000	0750	0000	0000	0000	%0735	b07	\$
005830	-028684	-022446	0125	1000	1000	0000	0875	0000	0000	0000	%0736	b08	\$
005596	-041164	-024870	0000	1000	1000	0000	1000	0000	0000	0000	%0737	b09	\$
008707	000650	000483	1000	0875	0875	0000	0125	0125	0000	0000	%0738	c01	\$
008339	-000662	000193	0875	0875	0875	0000	0125	0125	0125	0000	%0739	c02	\$
008014	-005668	-002910	0750	0875	0875	0250	0125	0125	0000	0000	%0740	c03	\$
007285	-009117	-005010	0625	0875	0875	0375	0125	0125	0000	0000	%0741	c04	\$
006833	-012822	-008443	0500	0875	0875	0500	0125	0125	0000	0000	%0742	c05	\$
006308	-017338	-012822	0375	0875	0875	0625	0125	0125	0000	0000	%0743	c06	\$
005791	-020911	-016765	0250	0875	0875	0750	0125	0125	0000	0000	%0744	c07	\$
005565	-022110	-017440	0125	0875	0875	0875	0125	0125	0000	0000	%0745	c08	\$
005694	-022884	-021844	0000	0875	0875	1000	0125	0125	0000	0000	%0746	c09	\$
008321	001237	000927	1000	0750	0750	0000	0250	0250	0000	0000	%0747	d01	\$
007865	000581	000432	0875	0750	0750	0125	0250	0250	0000	0000	%0748	d02	\$
007429	000006	000140	0750	0750	0750	0250	0250	0250	0000	0000	%0749	d03	\$
006821	-003544	-000564	0625	0750	0750	0375	0250	0250	0000	0000	%0750	d04	\$
006343	-008611	-005711	0500	0750	0750	0500	0250	0250	0000	0000	%0751	d05	\$
005899	-013377	-009330	0375	0750	0750	0625	0250	0250	0000	0000	%0752	d06	\$
005415	-017122	-012999	0250	0750	0750	0750	0250	0250	0000	0000	%0753	d07	\$
005183	-018133	-012229	0125	0750	0750	0875	0250	0250	0000	0000	%0754	d08	\$
005139	-017119	-012720	0000	0750	0750	1000	0250	0250	0000	0000	%0755	d09	\$
007776	002071	001170	1000	0625	0625	0000	0375	0375	0000	0000	%0756	e01	\$
007252	001279	000798	0875	0625	0625	0125	0375	0375	0000	0000	%0757	e02	\$
006828	000675	000543	0750	0625	0625	0250	0375	0375	0000	0000	%0758	e03	\$
006301	-000111	-000125	0625	0625	0625	0375	0375	0375	0000	0000	%0759	e04	\$
005886	-003395	-001196	0500	0625	0625	0500	0375	0375	0000	0000	%0760	e05	\$
005567	-009117	-004611	0375	0625	0625	0625	0375	0375	0000	0000	%0761	e06	\$
005034	-013611	-009880	0250	0625	0625	0750	0375	0375	0000	0000	%0762	e07	\$
004748	-015093	-010102	0125	0625	0625	0875	0375	0375	0000	0000	%0763	e08	\$
004790	-012244	-015580	0000	0625	0625	1000	0375	0375	0000	0000	%0764	e09	\$
007227	002881	001621	1000	0500	0500	0000	0500	0500	0000	0000	%0765	f01	\$
006690	001918	001244	0875	0500	0500	0125	0500	0500	0000	0000	%0766	f02	\$
006231	001337	000849	0750	0500	0500	0250	0500	0500	0000	0000	%0767	f03	\$
005681	000715	000533	0625	0500	0500	0375	0500	0500	0000	0000	%0768	f04	\$
005233	-000909	-000097	0500	0500	0500	0500	0500	0500	0000	0000	%0769	f05	\$
005055	-004115	-002088	0375	0500	0500	0625	0500	0500	0000	0000	%0770	f06	\$
004601	-009022	-006322	0250	0500	0500	0750	0500	0500	0000	0000	%0771	f07	\$
004293	-011611	-010408	0125	0500	0500	0875	0500	0500	0000	0000	%0772	f08	\$
004331	-011339	-009777	0000	0500	0500	1000	0500	0500	0000	0000	%0773	f09	\$
006600	003678	002044	1000	0375	0375	0000	0625	0625	0000	0000	%0774	g01	\$
005972	002702	001480	0875	0375	0375	0125	0625	0625	0000	0000	%0775	g02	\$
005533	002015	001372	0750	0375	0375	0250	0625	0625	0000	0000	%0776	g03	\$
005102	001413	001064	0625	0375	0375	0375	0625	0625	0000	0000	%0777	g04	\$
004744	000665	000468	0500	0375	0375	0500	0625	0625	0000	0000	%0778	g05	\$
004377	-000144	-000123	0375	0375	0375	0625	0625	0625	0000	0000	%0779	g06	\$
004127	-003099	-003333	0250	0375	0375	0750	0625	0625	0000	0000	%0780	g07	\$
003887	-006822	-003662	0125	0375	0375	0875	0625	0625	0000	0000	%0781	g08	\$
003872	-006244	-010105	0000	0375	0375	1000	0625	0625	0000	0000	%0782	g09	\$
005976	004448	002391	1000	0250	0250	0000	0750	0750	0000	0000	%0783	h01	\$
005299	003481	001851	0875	0250	0250	0500	0125	0750	0000	0000	%0784	h02	\$
004811	002854	001663	0750	0250	0250	0500	0250	0750	0000	0000	%0785	h03	\$
004386	002244	001264	0625	0250	0250	0750	0375	0750	0000	0000	%0786	h04	\$
004109	001417	000945	0500	0250	0250	0800	0750	0750	0000	0000	%0787	h05	\$
003878	000771	000386	0375	0250	0250	0625	0750	0750	0000	0000	%0788	h06	\$
003494	000910	000102	0250	0250	0250	0750	0750	0750	0000	0000	%0789	h07	\$
003088	-002677	-002880	0125	0250	0250	0875	0750	0750	0000	0000	%0790	h08	\$
002738	-001005	-003338	0000	0250	0250	1000	0750	0750	0000	0000	%0791	h09	\$
005294	005158	002868	1000	0125	0125	0000	0875	0875	0000	0000	%0792	i01	\$
004738	004011	002140	0875	0125	0125	0125	0875	0875	0000	0000	%0793	i02	\$
004612	003754	001807	0750	0125	0125	0250	0875	0875	0000	0000	%0794	i03	\$
004470	002524	001821	0625	0125	0125	0375	0875	0875	0000	0000	%0795	i04	\$
004130	001523	000833	0500	0125	0125	0500	0875	0875	0000	0000	%0796	i05	\$
003727	000884	000813	0375	0125	0125	0625	0875	0875	0000	0000	%0797	i06	\$
003171	000454	000327	0250	0125	0125	0750	0875	0875	0000	0000	%0798	i07	\$
002711	000012	000059	0125	0125	0125	0875	0875	0875	0000	0000	%0799	i08	\$
002250	000017	000056	0000	0125	0125	1000	0875	0875	0000	0000	%0800	i09	\$
004526	006314	003172	1000	0000	0000	0000	1000	1000	0000	0000	%0801	j01	\$
004576	005495	002747	0875	0000	0000	0125	1000	1000	0000	0000	%0802	j02	\$
004588	003778	001816	0750	0000	0000	0250	1000	1000	0000	0000	%0803	j03	\$
004591	003791	001768	0625	0000	0000	0375	1000	1000	0000	0000	%0804	j04	\$
004553	002711	000975	0500	0000	0000	0500	1000	1000	0000	0000	%0805	j05	\$
003916	001238	000489	0375	0000	0000	0625	1000	1000	0000	0000	%0806	j06	\$
002962	000361	000383	0250	0000	0000	0750	1000	1000	0000	0000	%0807	j07	\$
002341	000179	000262	0125	0000	0000	0875	1000	1000	0000	0000	%0808	j08	\$
001147	000047	000134	0000	0000	0000	1000	1000	1000	0000	0000	%0809	j09	\$
0009690	-000886	000190	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$	
0008680	-000888	-003211	0875	0875	1000	0125	0125	0000	0000	0000	%0811	b11	\$
0008154	-000703	-007090	0750	0750	1000	0250	0250	0000	0000	0000	%0812	b12	\$
0074333	-000626	-011448	0625	0625	1000	0375	0375	0000	0000	0000	%0813	b13	\$
0066681	000073	-016511	0500	0500	1000	0500	0500	0000	0000	0000	%0814	b14	\$
0060995	-000611	-020665	0375	0375	1000	0625	0625	0000	0000	0000	%0815	b15	\$
0053441	000000	-026701	0250	0250	1000	0750	0750	0000	0000	0000	%0816	b16	\$
004668	000093	-012320	0125	0125	1000	0875	0875	0000	0000	0000	%0817	b17	\$
0045322	000147	-043598	0000	1000	1000	1000	1000	0000	0000	0000	%0818	b18	\$
0092770	000000	000783	1000	1000	0875	0000	0125	0000	0000	0000	%0819	c10	\$
008485	-000506	000182	0875	0875	0125	0125	0125	0200	0000	0000	%0820	c11	\$
0079199	-001722	-002228	0750	0750	0250	0250	0125	0000	0000	0000	%0821	c12	\$
0071445	-000821												

%BEG HE63_22.TXT, Separation cmyn4*, cfi=0.90, D65, not adapted \$
%100 x LAB* %1000 x (r g b c m y 0) %nr. pos \$
%z004571 006362 002994 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008176 -00379 007435 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005673 -04543 001848 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005589 -04190 -02487 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z004536 000281 -04291 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003956 003810 -02190 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z001313 000032 000119 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009616 -00081 000201 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004526 006314 003172 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008174 -00387 007533 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005769 -04534 001578 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005596 -04164 -02487 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z004532 000147 -04308 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003982 003849 -02204 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z001142 000056 000133 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009675 -00088 000197 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/HE73/HE73L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

%BEG HE63 22.TXT, Separation cmy4* cfi=0.90, D65, not adapted \$																											
%100 x LAB*	%1000 x (r g b c m y 0)	%nrr.	pos \$																								
0001105	000032	000112	0000	0000	0000	0000	1000	1000	0000	0000	%0972	k01	\$	008318	-00050	000189	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$	
002421	000015	000086	0125	0125	0125	0875	0875	0875	0000	0000	%0973	k02	\$	008646	-00057	000201	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$	
003325	000012	000107	0250	0250	0250	0750	0750	0750	0000	0000	%0974	k03	\$	009641	-00083	000202	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$	
004165	-00004	000136	0375	0375	0375	0625	0625	0625	0000	0000	%0975	k04	\$	001116	000045	000121	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$	
005114	-00012	000109	0500	0500	0500	0500	0500	0500	0000	0000	%0976	k05	\$	002422	000026	000053	0066	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$
006328	-00008	000091	0625	0625	0625	0375	0375	0375	0000	0000	%0977	k06	\$	002667	000016	000068	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$	
007446	000000	000143	0750	0750	0750	0250	0250	0250	0000	0000	%0978	k07	\$	003054	000028	000077	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$	
008421	-00055	000186	0875	0875	0875	0125	0125	0125	0000	0000	%0979	k08	\$	003794	-00015	000120	0266	0266	0266	0333	0333	0333	0000	%1060	n14	\$	
009676	-00078	000187	1000	1000	1000	0000	0000	0000	0000	0000	%0980	k09	\$	004206	000025	000093	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$	
001090	000031	000112	0000	0000	0000	1000	1000	1000	0000	0000	%0981	l01	\$	004483	-00004	000225	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$	
002443	000012	000080	0125	0125	0125	0875	0875	0875	0000	0000	%0982	l02	\$	005170	000015	000098	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$	
003370	000008	000097	0250	0250	0250	0750	0750	0750	0000	0000	%0983	l03	\$	005408	-00003	000223	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$	
004225	-00005	000118	0375	0375	0375	0625	0625	0625	0000	0000	%0984	l04	\$	006128	-00025	000118	0600	0600	0600	0400	0400	0400	0000	%1065	n19	\$	
005178	-00007	000076	0500	0500	0500	0500	0500	0500	0000	0000	%0985	l05	\$	006530	-00025	000264	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$	
006336	-00013	000074	0625	0625	0625	0375	0375	0375	0000	0000	%0986	l06	\$	007177	-00032	000130	0734	0734	0734	0266	0266	0266	0000	%1067	n21	\$	
007472	-00002	000130	0750	0750	0750	0250	0250	0250	0000	0000	%0987	l07	\$	007820	-00038	000168	0800	0800	0800	0200	0200	0200	0000	%1068	n22	\$	
008432	-00057	000186	0875	0875	0875	0125	0125	0125	0000	0000	%0988	l08	\$	008280	-00048	000196	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$	
009694	-00085	000200	1000	1000	1000	0000	0000	0000	0000	0000	%0989	l09	\$	008588	-00053	000194	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$	
001078	000039	000111	0000	0000	0000	1000	1000	1000	0000	0000	%0990	m01	\$	009630	-00081	000185	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$	
002452	000021	000072	0125	0125	0125	0875	0875	0875	0000	0000	%0991	m02	\$	001078	000052	000090	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$	
003385	000014	000097	0250	0250	0250	0750	0750	0750	0000	0000	%0992	m03	\$	009565	-00079	000188	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$	
004231	-00008	000127	0375	0375	0375	0625	0625	0625	0000	0000	%0993	m04	\$	004452	0006274	003357	1000	0000	0000	0000	0000	0000	0000	%1074	l26	\$	
005161	-00006	000092	0500	0500	0500	0500	0500	0500	0000	0000	%0994	m05	\$	005595	-04600	-02877	0000	1000	1000	1000	0000	0000	0000	%1075	l27	\$	
006335	-00014	000092	0625	0625	0625	0375	0375	0375	0000	0000	%0995	m06	\$	008019	-00305	007659	1000	1000	0000	0000	0000	0000	0000	%1076	m26	\$	
007494	000003	000128	0750	0750	0750	0250	0250	0250	0000	0000	%0996	m07	\$	003440	0000305	-04342	0000	1000	1000	1000	0000	0000	0000	%1077	m27	\$	
008486	-00060	000191	0875	0875	0875	0125	0125	0125	0000	0000	%0997	m08	\$	005051	-04755	001852	1000	0000	0000	0000	0000	0000	0000	%1078	n26	\$	
009698	-00085	000196	1000	1000	1000	0000	0000	0000	0000	0000	%0998	m09	\$	003838	003899	-02295	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$	
001089	000039	000119	0000	0000	0000	1000	1000	1000	0000	0000	%0999	n01	\$	%\$	%004452	006274	003357	%#1000	0000	0000	0000	1000	1000	0000	%1074	l26	%\$03 0 \$
002411	000016	000087	0125	0125	0125	0875	0875	0875	0000	0000	%1000	n02	\$	%\$	%008019	-00305	007659	%#1000	1000	0000	0000	0000	1000	0000	%1076	m26	%\$03 1 \$
003358	000009	000112	0250	0250	0250	0750	0750	0750	0000	0000	%1001	n03	\$	%\$	%005501	-04755	001852	%#0000	1000	0000	0000	1000	0000	0000	%1078	n26	%\$03 2 \$
004179	-00006	000155	0375	0375	0375	0625	0625	0625	0000	0000	%1002	n04	\$	%\$	%005595	-04600	-02877	%#0000	1000	1000	1000	0000	0000	0000	%1075	l27	%\$03 3 \$
005095	-00018	000114	0500	0500	0500	0500	0500	0500	0000	0000	%1003	n05	\$	%\$	%004439	000305	-04342	%#0000	1000	1000	1000	0000	0000	0000	%1077	m27	%\$03 4 \$
006304	-00018	000195	0625	0625	0625	0375	0375	0375	0000	0000	%1004	n06	\$	%\$	%003838	003899	-02295	%#1000	0000	1000	0000	1000	0000	0000	%1079	n27	%\$03 5 \$
007451	-00007	000135	0750	0750	0750	0250	0250	0250	0000	0000	%1005	n07	\$	%\$	%001078	000052	000090	%#0000	0000	0000	1000	1000	0000	0000	%1072	k26	%\$03 6 \$
008470	-00057	000192	0875	0875	0875	0125	0125	0125	0000	0000	%1006	n08	\$	%\$	%009565	-00079	000188	%#1000	1000	1000	0000	0000	0000	0000	%1073	k27	%\$03 7 \$
009698	-00083	000187	1000	1000	1000	0000	0000	0000	0000	0000	%1007	n09	\$	%\$	%001122	000035	000114	%#0000	0000	0000	1000	1000	0000	0000	%0981	l01	%\$03 6 \$
001142	000039	000110	0000	0000	0000	1000	1000	1000	0000	0000	%1008	k10	\$	%\$	%001122	000035	000114	%#0000	0000	0000	1000	1000	0000	0000	%0981	l01	%\$03 6 \$
002409	000019	000041	0066	0066	0066	0933	0933	0933	0000	0000	%1009	k11	\$	%\$	%009653	-00080	000190	%#1000	1000	1000	0000	0000	0000	0000	%0989	l09	%\$03 7 \$
002657	000023	000043	0133	0133	0133	0866	0866	0866	0000	0000	%1010	k12	\$	%\$	%001135	000043	000118	%#0000	0000	0000	1000	1000	0000	0000	%0990	m01	%\$03 6 \$
003016	000021	000063	0200	0200	0200	0800	0800	0800	0000	0000	%1011	k13	\$	%\$	%009670	-00084	000199	%#1000	1000	1000	0000	0000	0000	0000	%0998	m09	%\$03 7 \$
003779	-00011	000088	0266	0266	0266	0333	0333	0333	0000	0000	%1012	k14	\$	%\$	%001135	000043	000118	%#0000	0000	0000	1000	1000	0000	0000	%0990	m01	%\$03 6 \$
004221	000025	000063	0333	0333	0333	0666	0666	0666	0000	0000	%1013	k15	\$	%\$	%009670	-00084	000199	%#1000	1000	1000	0000	0000	0000	0000	%0998	m09	%\$03 7 \$
004492	-00016	000187	0400	0400	0400	0600	0600	0600	0000	0000	%1014	k16	\$	%\$	%001135	000043	000118	%#0000	0000	0000	1000	1000	0000	0000	%0990	m01	%\$03 6 \$
005149</																											

%BEG HE63.22.TXT, Separation cmydn*, cfi=0.90, D65, adapted S																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																															
%100 x LAB*a										%100 x (r g b c m y o)																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																					
nmr. pos \$										nmr. pos \$																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																					
000133	000000	000000	0000	0000	0000	0000	0000	0000	0000	A01	\$	002240	000122	000209	0125	0000	0000	0875	1000	1000	0000	0000	0001	J01	\$	002819	000281	000346	0250	0000	0000	0750	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000

004016 001252 000353 0375 0000 0000 0025 1000 1000 0000 %0243 A10 \$
003830 001026 000001 0375 0000 0125 0625 1000 0875 0000 %0244 A11 \$
004157 001478 -00322 0375 0000 0250 0625 1000 0750 0000 %0245 A12 \$
003677 000492 -00862 0375 0000 0375 0625 1000 0625 0000 %0246 A13 \$
004074 001158 -01230 0375 0000 0500 0625 1000 0500 0000 %0247 A14 \$
004404 001207 -02231 0375 0000 0625 0625 1000 0375 0000 %0248 A15 \$
004017 001821 -02855 0375 0000 0750 0625 1000 0250 0000 %0249 A16 \$
003711 002257 -04197 0375 0000 0875 0625 1000 0000 0000 %0250 A17 \$
003403 001775 -04492 0375 0000 0975 0625 1000 0000 0000 %0251 A18 \$
003914 000784 000723 0375 0125 0000 0625 0875 1000 0000 %0252 B10 \$
003888 000858 000636 0375 0125 0125 0625 0875 0875 0000 %0253 B11 \$
003809 000994 -00029 0375 0125 0250 0625 0875 0750 0000 %0254 B12 \$
003294 000480 -00529 0375 0125 0375 0625 0875 0625 0000 %0255 B13 \$
003836 000585 -01211 0375 0125 0500 0625 0875 0500 0000 %0256 B14 \$
004081 001165 -02198 0375 0125 0625 0625 0875 0375 0000 %0257 B15 \$
004035 001216 -02234 0375 0125 0750 0625 0875 0250 0000 %0258 B16 \$
004041 001319 -02970 0375 0125 0875 0625 0875 0125 0000 %0259 B17 \$
004189 001211 -03569 0375 0125 1000 0625 0875 0000 0000 %0260 B18 \$
004505 001513 001562 0375 0250 0000 0625 0750 1000 0000 %0261 C10 \$
003996 000762 000771 0375 0250 0125 0625 0750 0875 0000 %0262 C11 \$
004048 000743 000223 0375 0250 0250 0625 0750 0750 0000 %0263 C12 \$
004103 000469 -00356 0375 0250 0375 0625 0750 0625 0000 %0264 C13 \$
004210 000399 -00997 0375 0250 0500 0625 0750 0500 0000 %0265 C14 \$
004363 000433 -01536 0375 0250 0625 0625 0750 0375 0000 %0266 C15 \$
004572 000510 -02061 0375 0250 0750 0625 0750 0250 0000 %0267 C16 \$
004749 000597 -02599 0375 0250 0875 0625 0750 0125 0000 %0268 C17 \$
005166 000558 -02908 0375 0250 1000 0625 0750 0000 0000 %0269 C18 \$
004913 -00194 001538 0375 0375 0000 0625 0625 1000 0000 %0270 D10 \$
004686 -00329 001227 0375 0375 0125 0625 0625 0875 0000 %0271 D11 \$
004475 -00118 000798 0375 0375 0250 0625 0625 0750 0000 %0272 D12 \$
004496 000807 -00930 0375 0375 0375 0625 0625 0625 0000 %0273 D13 \$
004832 000071 -00417 0375 0375 0500 0625 0625 0500 0000 %0274 D14 \$
005302 000011 -01069 0375 0375 0625 0625 0625 0375 0000 %0275 D15 \$
005394 -00080 -01561 0375 0375 0750 0625 0625 0250 0000 %0276 D16 \$
005715 000023 -01991 0375 0375 0875 0625 0625 0125 0000 %0277 D17 \$
006048 000803 -02268 0375 0375 1000 0625 0625 0000 0000 %0278 D18 \$
005706 -01642 001906 0375 0500 0000 0625 0500 1000 0000 %0279 D19 \$
005237 -01045 001436 0375 0500 0125 0625 0500 0875 0000 %0280 E11 \$
005186 -01019 000981 0375 0500 0250 0625 0500 0750 0000 %0281 E12 \$
005154 -00692 000032 0375 0500 0375 0625 0500 0625 0000 %0282 E13 \$
005065 -00416 -00416 0375 0500 0500 0625 0500 0500 0000 %0283 E14 \$
005402 -00541 -01022 0375 0500 0625 0625 0500 0375 0000 %0284 E15 \$
005621 -00466 -01542 0375 0500 0750 0625 0500 0250 0000 %0285 E16 \$
005861 -00387 -01955 0375 0500 0875 0625 0500 0125 0000 %0286 E17 \$
006171 -00279 -02254 0375 0500 1000 0625 0500 0000 0000 %0287 E18 \$
006050 -02345 002528 0375 0625 0000 0625 0375 1000 0000 %0288 F10 \$
005724 -01606 001918 0375 0625 0125 0625 0375 0875 0000 %0289 F11 \$
005495 -01771 001278 0375 0625 0250 0625 0375 0750 0000 %0290 F12 \$
005600 -01294 000226 0375 0625 0375 0625 0375 0625 0000 %0291 F13 \$
005570 -01006 -00381 0375 0625 0500 0625 0375 0500 0000 %0292 F14 \$
005559 -00929 -00657 0375 0625 0625 0625 0375 0375 0000 %0293 F15 \$
005709 -00923 -01622 0375 0625 0750 0625 0375 0250 0000 %0294 F16 \$
006042 -00857 -01880 0375 0625 0875 0625 0375 0125 0000 %0295 F17 \$
006318 -00809 -02311 0375 0625 1000 0625 0375 0000 0000 %0296 F18 \$
006405 -03255 003908 0375 0750 0000 0625 0250 1000 0000 %0297 G10 \$
005764 -02742 001508 0375 0750 0125 0625 0250 0875 0000 %0298 G11 \$
005777 -02742 001508 0375 0750 0250 0625 0250 0750 0000 %0299 G12 \$
006049 -01987 000423 0375 0750 0375 0625 0250 0500 0000 %0300 G13 \$
005960 -01703 -00178 0375 0750 0500 0625 0250 0500 0000 %0301 G14 \$
005889 -01512 -00727 0375 0750 0625 0250 0250 0375 0000 %0302 G15 \$
005882 -01433 -01110 0375 0750 0750 0625 0250 0250 0000 %0303 G16 \$
006258 -01566 -01839 0375 0750 0875 0625 0250 0125 0000 %0304 G17 \$
006514 -01369 -02405 0375 0750 1000 0625 0250 0000 0000 %0305 G18 \$
006423 -03202 003038 0375 0875 0000 0625 0125 1000 0000 %0306 H10 \$
006144 -03528 002615 0375 0875 0125 0625 0125 0875 0000 %0307 H11 \$
006133 -03483 001790 0375 0875 0250 0625 0125 0750 0000 %0308 H12 \$
006439 -02599 005058 0375 0875 0375 0625 0125 0625 0000 %0309 H13 \$
006427 -02425 -00037 0375 0875 0500 0625 0125 0500 0000 %0310 H14 \$
006443 -02284 -00407 0375 0875 0625 0625 0125 0375 0000 %0311 H15 \$
006347 -02029 -01045 0375 0875 0750 0625 0125 0250 0000 %0312 H16 \$
006325 -01802 -01432 0375 0875 0875 0625 0125 0125 0000 %0313 H17 \$
006832 -01989 -02046 0375 0875 1000 0625 0125 0000 0000 %0314 H18 \$
006689 -04854 004536 0375 1000 0000 0625 0000 1000 0000 %0315 I10 \$
006481 -04438 003024 0375 1000 0125 0625 0000 0875 0000 %0316 I11 \$
006472 -04425 002104 0375 1000 0250 0625 0000 0750 0000 %0317 I12 \$
006907 -03277 000885 0375 1000 0375 0625 0000 0625 0000 %0318 I13 \$
006846 -03017 000231 0375 1000 0500 0625 0000 0500 0000 %0319 I14 \$
006792 -02727 -00265 0375 1000 0625 0000 0375 0000 %0320 I15 \$
006747 -02584 -00633 0375 1000 0750 0625 0000 0250 0000 %0321 I16 \$
006688 -02280 -01322 0375 1000 0875 0625 0000 0125 0000 %0322 I17 \$
006753 -02199 -01592 0375 1000 1000 0625 0000 0000 %0323 I18 \$

004691 002722 000835 0500 0000 0000 0500 1000 1000 0000 %0324 J10 \$
004759 002679 000811 0500 0000 0125 0500 1000 0875 0000 %0325 J11 \$
004818 003033 000862 0500 0000 0250 0500 1000 0750 0000 %0326 J12 \$
004503 001970 -01429 0500 0000 0375 0500 1000 0625 0000 %0327 J13 \$
004106 001132 -01216 0500 0000 0500 0500 1000 0500 0000 %0328 J14 \$
004163 002167 -02415 0500 0000 0625 0500 1000 0375 0000 %0329 J15 \$
003971 002235 -03395 0500 0000 0750 0500 1000 0250 0000 %0330 J16 \$
003978 002253 -03371 0500 0000 0875 0500 1000 0125 0000 %0331 J17 \$
003360 002556 -04355 0500 0000 1000 0500 1000 0000 0000 %0332 J18 \$
004689 002401 002175 0500 0125 0000 0500 0875 1000 0000 %0333 K10 \$
004365 001500 000640 0500 0125 0125 0500 0875 0000 %0334 K11 \$
004496 001973 000137 0500 0125 0250 0500 0875 0750 0000 %0335 K12 \$
004307 001647 -00798 0500 0125 0375 0500 0875 0625 0000 %0336 K13 \$
004093 001222 -01164 0500 0125 0500 0500 0875 0500 0000 %0337 K14 \$
004130 001267 -01370 0500 0125 0625 0500 0875 0375 0000 %0338 K15 \$
004048 001212 -02233 0500 0125 0750 0500 0875 0250 0000 %0339 K16 \$
004058 001804 -02784 0500 0125 0875 0500 0875 0125 0000 %0340 K17 \$
004019 001763 -03562 0500 0125 1000 0500 0875 0000 0000 %0341 K18 \$
004719 002341 002176 0500 0250 0000 0500 0750 1000 0000 %0342 L10 \$
004502 001527 000152 0500 0250 0125 0500 0750 0875 0000 %0343 L11 \$
004378 001369 000704 0500 0250 0250 0500 0750 0750 0000 %0344 L12 \$
004337 001580 -00083 0500 0250 0375 0500 0750 0625 0000 %0345 L13 \$
004110 000923 -00708 0500 0250 0500 0500 0750 0500 0000 %0346 L14 \$
004310 001023 -01380 0500 0250 0625 0500 0750 0375 0000 %0347 L15 \$
004317 001262 -01215 0500 0250 0750 0500 0750 0250 0000 %0348 L16 \$
004532 001150 -02632 0500 0250 0875 0500 0750 0125 0000 %0349 L17 \$
004996 001091 -02987 0500 0250 1000 0500 0750 0000 0000 %0350 L18 \$
005248 001492 002602 0500 0375 0000 0500 0625 1000 0000 %0351 M10 \$
004914 000892 001921 0500 0375 0125 0500 0875 0000 %0352 M11 \$
004630 000886 001253 0500 0375 0250 0500 0625 0750 0000 %0353 M12 \$
004876 000667 000313 0500 0375 0375 0500 0625 0250 0000 %0354 M13 \$
004825 000667 -00358 0500 0375 0500 0500 0625 0500 0000 %0355 M14 \$
004966 000570 -00047 0500 0375 0625 0500 0625 0375 0000 %0356 M15 \$
005265 000518 -01504 0500 0375 0750 0500 0625 0250 0000 %0357 M16 \$
005505 000523 -01978 0500 0375 0875 0500 0625 0125 0000 %0358 M17 \$
005869 000507 -02288 0500 0375 1000 0500 0625 0000 0000 %0359 M18 \$
005932 -00341 002760 0500 0500 0000 0500 0500 1000 0000 %0360 N10 \$
005479 000195 002295 0500 0500 0125 0500 0875 0000 %0361 N11 \$
005164 -00057 001795 0500 0500 0250 0500 0500 0750 0000 %0362 N12 \$
005324 -00087 000928 0500 0500 0375 0500 0500 0625 0000 %0363 N13 \$
005319 000015 -00053 0500 0500 0500 0500 0500 0000 %0364 N14 \$
005778 000019 -00420 0500 0500 0625 0500 0375 0000 %0365 N15 \$
006196 -00090 -00988 0500 0500 0750 0500 0500 0250 0000 %0366 N16 \$
006400 000049 -01451 0500 0500 0875 0500 0500 0125 0000 %0367 N17 \$
006652 000130 -01836 0500 0500 1000 0500 0500 0000 0000 %0368 N18 \$
006891 -01373 003797 0500 0625 0000 0500 0375 1000 0000 %0369 O10 \$
006290 -00888 003004 0500 0625 0125 0500 0375 0875 0000 %0370 O11 \$
005737 -01067 002210 0500 0625 0250 0500 0375 0750 0000 %0371 O12 \$
005748 -00935 001138 0500 0625 0375 0500 0375 0625 0000 %0372 O13 \$
005957 -00697 000150 0500 0625 0500 0500 0375 0500 0000 %0373 O14 \$
005918 -00371 -00386 0500 0625 0625 0500 0375 0375 0000 %0374 O15 \$
006282 -00508 -01030 0500 0625 0750 0500 0375 0250 0000 %0375 O16 \$
006569 -00358 -01388 0500 0625 0875 0500 0375 0125 0000 %0376 O17 \$
006770 -00324 -01867 0500 0625 1000 0500 0375 0000 0000 %0377 O18 \$
006869 -02487 003957 0500 0750 0000 0500 0250 1000 0000 %0378 P10 \$
006237 -02153 002728 0500 0750 0125 0500 0250 0875 0000 %0379 P11 \$
006213 -02001 002396 0500 0750 0250 0500 0250 0750 0000 %0380 P12 \$
006283 -01756 001357 0500 0750 0375 0500 0250 0625 0000 %0381 P13 \$
006448 -01325 000385 0500 0750 0500 0500 0250 0500 0000 %0382 P14 \$
006427 -01082 -00223 0500 0750 0625 0500 0250 0375 0000 %0383 P15 \$
006355 -00887 -00770 0500 0750 0750 0500 0250 0250 0000 %0384 P16 \$
006747 -00861 -01427 0500 0750 0875 0500 0250 0125 0000 %0385 P17 \$
006928 -00784 -01918 0500 0750 1000 0500 0250 0000 0000 %0386 P18 \$
006949 -02745 004224 0500 0875 0000 0500 0125 1000 0000 %0387 Q10 \$
006635 -02932 003395 0500 0875 0125 0500 0125 0875 0000 %0388 Q11 \$
006661 -02817 002744 0500 0875 0250 0500 0125 0750 0000 %0389 Q12 \$
006676 -02692 001767 0500 0875 0375 0500 0125 0625 0000 %0390 Q13 \$
006958 -02007 000693 0500 0875 0500 0500 0125 0500 0000 %0391 Q14 \$
006895 -01696 -00152 0500 0875 0625 0500 0125 0375 0000 %0392 Q15 \$
006841 -01468 -00622 0500 0875 0750 0500 0125 0250 0000 %0393 Q16 \$
006849 -01307 -01003 0500 0875 0875 0500 0125 0125 0000 %0394 Q17 \$
007314 -01562 -01672 0500 0875 1000 0500 0125 0000 0000 %0395 Q18 \$
006887 -04029 005037 0500 1000 0000 0500 0000 1000 0000 %0396 R10 \$
006960 -03770 003783 0500 1000 0125 0500 0000 0875 0000 %0397 R11 \$
006951 -03721 002999 0500 1000 0250 0500 0000 0750 0000 %0398 R12 \$
007080 -03626 002099 0500 1000 0375 0500 0000 0625 0000 %0399 R13 \$
007395 -02567 000749 0500 1000 0500 0500 0000 0500 0000 %0400 R14 \$
007402 -02336 000183 0500 1000 0625 0500 0000 0375 0000 %0401 R15 \$
007290 -02136 -00324 0500 1000 0750 0500 0000 0250 0000 %0402 R16 \$
007284 -01877 -00873 0500 1000 0875 0500 0000 0125 0000 %0403 R17 \$
007306 -01736 -01209 0500 1000 1000 0500 0000 0000 %0404 R18 \$

004800 003703 001565 0625 0000 0000 0375 1000 1000 0000 %0405 S10 \$
004861 003864 000782 0625 0000 0125 0375 1000 0875 0000 %0406 S11 \$
004937 004130 000057 0625 0000 0250 0375 1000 0750 0000 %0407 S12 \$
004866 004379 -00570 0625 0000 0375 0375 1000 0625 0000 %0408 S13 \$
004489 003170 -01632 0625 0000 0500 0375 1000 0500 0000 %0409 S14 \$
004245 002852 -02930 0625 0000 0625 0375 1000 0375 0000 %0410 S15 \$
003974 002873 -03059 0625 0000 0750 0375 1000 0250 0000 %0411 S16 \$
003981 002867 -03064 0625 0000 0875 0375 1000 0125 0000 %0412 S17 \$
003899 002897 -03215 0625 0000 1000 0375 1000 0000 0000 %0413 S18 \$
004830 003494 002171 0625 0125 0000 0375 0875 1000 0000 %0414 T10 \$
004746 002498 001544 0625 0125 0125 0375 0875 0875 0000 %0415 T11 \$
004715 002731 000751 0625 0125 0250 0375 0875 0750 0000 %0416 T12 \$
004796 002994 000933 0625 0125 0375 0375 0875 0625 0000 %0417 T13 \$
004668 002448 -01184 0625 0125 0500 0375 0875 0500 0000 %0418 T14 \$
004450 002044 -01457 0625 0125 0625 0375 0875 0375 0000 %0419 T15 \$
004089 002318 -02476 0625 0125 0750 0375 0875 0250 0000 %0420 T16 \$
004089 002438 -02536 0625 0125 0875 0375 0875 0125 0000 %0421 T17 \$
004060 002326 -03388 0625 0125 1000 0375 0875 0000 0000 %0422 T18 \$
004744 002335 002240 0625 0250 0000 0375 0750 1000 0000 %0423 U10 \$
004731 002325 002221 0625 0250 0125 0375 0750 0875 0000 %0424 U11 \$
004666 002186 000967 0625 0250 0250 0375 0750 0750 0000 %0425 U12 \$
004720 002191 000277 0625 0250 0375 0375

004778	003787	001577	0750	0000	0000	0250	0000	1000	1000	0000	0000	%0486	A19	\$
004742	003997	000821	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$		
004755	004226	000518	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$		
004674	004551	-000518	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$		
004509	004734	-014448	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$		
004909	003858	-02194	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$		
003879	002857	-02082	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$		
003836	003231	-02621	0750	0000	0875	0250	1000	0000	0000	%0493	A26	\$		
003807	003661	-03525	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$		
004829	003485	-02922	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$		
004716	003818	-016124	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$		
004668	003986	-000913	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$		
004686	004195	-000242	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$		
004579	004552	-00523	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$		
004076	003255	-01732	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$		
003821	002917	-02139	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$		
003778	002578	-02469	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$		
004049	002639	-03085	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$		
004855	003466	-002996	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$		
004740	002958	-002652	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$		
004948	002907	-001461	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$		
004910	003006	-000729	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$		
004843	003287	-001082	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$		
004512	002773	-00957	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$		
004862	002148	-01392	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$		
004393	002151	-02028	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$		
004709	002086	-02613	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$		
005409	002547	-003242	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$		
005020	002486	-002736	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$		
005157	002394	-002239	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$		
005564	002145	-001170	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$		
005462	002368	-000271	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$		
005343	002314	-000431	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$		
004867	001574	-01080	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$		
005007	001670	-01719	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$		
005304	001434	-02275	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$		
005899	001674	-003651	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$		
005486	001675	-003142	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$		
005623	001692	-002603	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$		
005831	001584	-001849	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$		
006106	001427	-000860	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$		
006101	001544	-000161	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$		
005525	001005	-00767	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$		
005821	001017	-01380	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$		
005926	001037	-01869	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$		
006448	000906	-004284	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$		
006410	000928	-004250	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$		
006096	000802	-003190	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$		
006273	000719	-002378	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$		
006470	000705	-001527	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$		
006648	000763	-000455	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$		
006317	000483	-003222	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$		
006467	000533	-01062	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$		
006750	000576	-01428	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$		
007002	000168	-004981	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$		
006727	-000264	-004102	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$		
006722	-00169	-003718	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$		
006652	-00075	-002871	0750	0750	0375	0250	0250	0625	0000	%0543	G22	\$		
007024	-00152	-002116	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$		
007095	-00137	-000888	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$		
007215	-000956	-000823	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$		
007625	-00170	-00492	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$		
007827	-00084	-01084	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$		
008095	-01052	-006039	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$		
007728	-01526	-005371	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$		
007585	-01251	-004532	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$		
007613	-01222	-003640	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$		
007625	-01215	-002605	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$		
007599	-01051	-001311	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$		
007776	-00654	-000185	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$		
007793	-00625	-00475	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$		
007991	-00503	-01088	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$		
007986	-02367	-006695	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$		
007963	-02292	-005511	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$		
007925	-02220	-004585	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$		
007971	-02176	-003725	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$		
007944	-02064	-002780	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$		
008023	-01898	-001868	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$		
008199	-01449	-000433	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$		
008154	-01225	-00166	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$		
008154	-01029	-00665	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$		
004677	005554	002392	0750	0000	0000	0125	1000	1000	0000	%0567	J19	\$		
004613	005721	001710	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$		
004568	005960	000926	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$		
004571	006241	000908	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$		
004615	005135	-01161	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$		
004545	004734	-01435	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$		
004177	004275	-01808	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$		
003977	003820	-0222	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$		
003964	003774	-02715	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$		
004673	005460	003118	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$		
004851	004126	-001897	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$		
004883	004315	-001122	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$		
004842	004390	000513	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$		
004796	004688	-00247	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$		
004667	004509	-000982	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$		
004255	003586	-01576	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$		
003965	003051	-01988	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$		
004242	002882	-02589	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$		
004871	003738	003146	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$		
004959	003714	002714	0875	0250	0125	0125	0750	0875	0000	%058				

See original or copy: <http://web.me.com/klaus.richter/HE73/HE73L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

009653	-00001	000001	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009896	-00500	-00567	0875	1000	1000	0000	0125	0000	0000	%0730	b02	\$
008347	-00911	-00652	0750	1000	1000	0000	0250	0000	0000	%0731	b03	\$
007756	-01146	-00877	0625	1000	1000	0000	0375	0000	0000	%0732	b04	\$
007285	-01665	-01216	0500	1000	1000	0000	0500	0000	0000	%0733	b05	\$
006785	-02103	-01679	0375	1000	1000	0000	0625	0000	0000	%0734	b06	\$
006219	-02617	-02123	0250	1000	1000	0000	0750	0000	0000	%0735	b07	\$
005830	-02841	-02415	0125	1000	1000	0000	0875	0000	0000	%0736	b08	\$
005596	-04146	-02654	0000	1000	1000	0000	1000	0000	0000	%0737	b09	\$
008707	-00722	-000292	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
008339	-000002	-000006	0875	0875	0875	0000	0125	0125	0000	%0739	c02	\$
008014	-05008	-00476	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
007285	-00870	-00690	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
006833	-01242	-01019	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
006308	-01707	-01454	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
005791	-02069	-01843	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005565	-02192	-01907	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
005694	-02264	-02352	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
008321	001302	000739	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
007865	000638	000248	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
007429	000056	-00039	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
006821	-00314	-00230	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
006343	-00829	-00743	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
005899	-01313	-01099	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
005415	-01696	-01465	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005183	-01801	-01393	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
005139	-01708	-01436	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007776	002127	000987	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007252	001326	000619	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
006828	000715	000367	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006301	000019	-00046	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
005805	-00374	-00305	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
005567	-00899	-00628	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
005034	-01352	-01151	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
004748	-01499	-01173	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
004790	-01219	-01719	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
007227	002848	001442	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006690	001955	001069	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006231	001367	000677	0750	0500	0500	0250	0500	0500	0000	%0767	f03	\$
005681	000735	000365	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005233	000002	-00066	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005055	-00406	-00451	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
004601	-00900	-00791	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004293	-01164	-01205	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
004331	-01142	-01134	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
006600	003714	001870	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
005972	002727	001310	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005533	002033	001205	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
005102	001423	000901	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
004744	000670	000307	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
004377	-00016	-00034	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
004127	-00405	-00489	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
003887	-00692	-00516	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003872	-00634	-01169	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
005976	004473	002221	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005299	003495	001686	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
004811	002859	001502	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
004386	002242	001107	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
004109	001410	000789	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
003878	000760	000232	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
003494	-00905	-00048	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
003088	-00291	-00428	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
002738	-00134	-00484	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
005294	005171	002703	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004738	004015	001980	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
004612	003757	001647	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
004470	002524	001663	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
004130	001517	000677	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
003727	000871	000660	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
003171	000431	000179	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
002711	-00018	-00085	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
002250	-00020	-00085	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
004526	006315	003013	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
004576	005496	002588	0750	0000	0000	0125	1000	1000	0000	%0802	j02	\$
004588	003780	001657	0875	0000	0000	0250	1000	1000	0000	%0803	j03	\$
004591	003793	001609	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
004553	002712	000816	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
003916	001228	000335	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
002962	000335	000236	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
002341	000142	000120	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
001147	-00008	000000	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009690	000001	-00007	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
008680	-00017	-00511	0875	0875	0875	0100	0125	0125	0000	%0811	b11	\$
008154	-00010	-00376	0750	0750	0750	0250	0250	0250	0000	%0812	b12	\$
007433	-00023	-01329	0625	1000	0375	0375	0000	0000	0000	%0813	b13	\$
006681	-00110	-01826	0500	0500	0500	0500	0000	0000	0000	%0814	b14	\$
006095	-00033	-02237	0375	0375	1000	0625	0625	0625	0000	%0815	b15	\$
005341	-00013	-02835	0250	0250	0750	0750	0000	0000	0000	%0816	b16	\$
004668	-00016	-03408	0125	0100	0875	0875	0000	0000	0000	%0817	b17	\$
004532	-00147	-04467	0000	1000	1000	1000	0000	0000	0000	%0818	b18	\$
002970	-00081	-00508	1000	1000	0875	0000	0125	0000	0000	%0819	c10	\$
008485	-00011	-00005	0875	0875	0875	0125	0125	0125	0000	%0820	c11	\$
007999	-00112	-00413	0750	0750	0750	0250	0250	0125	0000	%0821	c12	\$
007145	-00036	-00999	0625	0625	0875	0375	0375	0125	0000	%0822	c13	\$
006395	-00046	-01431	0500	0500	0875	0500	0500	0125	0000	%0823	c14	\$
005682	-00014	-01994	0375	0375	0875	0625	0625	0125	0000	%0824	c15	\$
004952	-00044	-02581	0250	0250	0875	0750	0750	0125	0000	%0825	c16	\$
004389	-00038	-02840	0125	0125	0875	0875	0125	0000	0000	%0826	c17	\$
004253	-00076	-03617	0000	0000	0750	1000	1000	0125	0000	%0827	c18	\$
009157	-00010	-00149	1000	1000	0750	0000	0250	0000	0000	%0828	d10	\$
008471	-00066	-00709	0875	0875	0750	0125	0125	0250	0000			

%BEG HE63_22.TXT, Separation cmyn4*, cfi=0.90, D65, adapted S
%100 x LAB*a %1000 x (r g b c m y 0) %nr. pos S
%z004571 006374 002843 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008176 -00317 007248 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005673 -04516 001686 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005589 -04164 -02648 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z004536 000293 -04442 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003956 003814 -02335 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z001313 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009616 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%S
%z004526 006315 003013 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008174 -00325 007347 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005769 -04513 001409 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005596 -04146 -02654 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z004532 000147 -04467 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003982 003841 -02359 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z001142 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009675 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%S

See original or copy: <http://web.me.com/klaus.richter/HE73/HE73L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG HE63.22.TXT, Separation cmy4*, cfi=0.90, D65, adapted S
%100 x LAB*a      1000 x (r g b   c m y 0)   %nrr. pos $
001105 -00019 000021 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002421 -00016 -00018 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003325 -00005 -00008 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004165 -00009 000010 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005114 -00002 -00027 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006328 -00020 -00059 0625 0625 0625 0625 0375 0375 0000 %0977 k06 $
007446 000045 -00020 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008421 000006 000011 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009475 000002 -00002 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
010100 -00021 000021 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
024443 -00019 00025 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003370 -00008 -00019 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
044225 -00009 -00008 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005178 -00003 -00061 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006336 000015 -00076 0625 0625 0625 0625 0375 0375 0000 %0986 l06 $
007472 000044 -00033 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
008432 000004 000010 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009694 -00004 000010 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
010178 -00012 000020 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
02452 -00009 -00033 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003385 -00002 -00019 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004231 -00012 000000 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
005161 000004 -00044 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006335 000014 -00058 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
007494 000050 -00036 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
008486 000001 000015 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009698 -00004 000006 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
010189 -00012 000029 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
024111 -00015 -00018 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003358 -00007 -00004 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
041479 -00018 000029 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005095 000008 -00022 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006304 000010 -00055 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
007451 000053 -00028 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008470 000004 000016 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009698 -00002 -00002 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
011142 -00012 000019 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
02409 -00012 -00063 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
02657 -00004 -00065 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
003016 -00001 -00048 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
003779 -00022 -00033 0266 0266 0266 0333 0333 0333 0000 %1012 k14 $
042221 -00021 -00063 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
004492 -00016 -00057 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005149 000023 -00060 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
005458 000006 000066 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006177 -00007 -00046 0600 0600 0600 0400 0400 0400 0000 %1017 k19 $
006621 -00007 000109 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007209 000006 -00043 0734 0734 0734 0266 0266 0266 0000 %1019 k21 $
007857 000010 -00007 0800 0800 0800 0200 0200 0200 0000 %1020 k22 $
008266 000014 000003 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
008609 000010 000012 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009596 000007 -00010 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
011154 -00011 000024 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
024711 -00012 -00043 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
027775 -00011 -00060 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
003127 000001 -00051 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
003878 -00026 -00033 0266 0266 0266 0333 0333 0333 0000 %1028 l14 $
04290 000017 -00067 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
004560 -00004 000039 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005207 000029 -00091 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
005511 000007 000028 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006196 000008 -00071 0600 0600 0600 0400 0400 0400 0000 %1033 l19 $
006671 000000 000062 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007217 000013 -00050 0734 0734 0734 0266 0266 0266 0000 %1035 l21 $
007842 000013 -00009 0800 0800 0800 0200 0200 0200 0000 %1036 l22 $
008291 000015 000000 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
008662 000008 000008 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009613 000004 -00008 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
001192 -00004 000034 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
02458 -00003 -00066 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
02722 -00003 -00070 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
003070 000008 -00041 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
003831 -00013 -00034 0266 0266 0266 0333 0333 0333 0000 %1044 m14 $
04229 000018 -00051 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
004557 000003 000052 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005210 000033 -00066 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
005499 000026 000027 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006179 000006 -00050 0600 0600 0600 0400 0400 0400 0000 %1049 m19 $
006614 000016 000062 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007212 000011 -00035 0734 0734 0734 0266 0266 0266 0000 %1051 m21 $
007870 000011 -00002 0800 0800 0800 0200 0200 0200 0000 %1052 m22 $
```

%BEG HE63 22.TXT, Separation cmydn4*, cfi=0.90, D50, not adapted S																			
%100 x LAB*																			
1000 x (r g b c m y o)																			
nmr. pos \$																			
000135	000049	000122	0000	0000	0000	0000	0000	0000	0000	000247	000197	000345	0125	0000	0000	0000	0000	0000	0000
000226	000146	000139	0000	0000	0125	0000	1000	0875	0000	002333	000339	000147	0125	0000	0125	0875	1000	0875	0000
000259	000231	000458	0000	0000	0250	0000	1000	0750	0000	002521	000178	000461	0125	0000	0250	0875	1000	0750	0000
0003175	000232	0001287	0000	0000	0375	0000	1000	0625	0000	003126	000200	0001321	0125	0000	0375	0875	1000	0625	0000
0003300	0000175	0001261	0000	0000	0500	0000	1000	0500	0000	003260	000191	0001298	0125	0000	0500	0875	1000	0500	0000
0003672	000173	0001952	0000	0000	0625	0000	1000	0375	0000	003640	000192	0002073	0125	0000	0625	0875	1000	0375	0000
0003789	000364	0002160	0000	0000	0750	0000	1000	0250	0000	003769	000381	0002345	0125	0000	0750	0875	1000	0250	0000
0004311	000256	000492	0000	0000	0875	0000	1000	0125	0000	004284	000240	0003555	0125	0000	0875	0875	1000	0125	0000
0004437	000300	0004461	0000	0000	1000	0000	1000	0000	0000	004164	000279	0004310	0125	0000	1000	0875	1000	0000	0000
0004246	000050	0004166	0000	0125	0000	0000	0875	1000	0000	002769	000022	0004665	0125	0125	0000	0875	0875	1000	0000
0002073	000025	0000084	0000	0125	0125	0000	0875	0875	0000	002472	000022	0000084	0125	0125	0125	0875	0875	0000	0000
0002560	000117	000319	0000	0125	0250	0000	0875	0750	0000	002935	0000009	000337	0125	0125	0250	0875	0875	0000	0000
0003405	000240	0001160	0000	0125	0375	0000	0875	0625	0000	003182	000077	000967	0125	0125	0375	0875	0875	0000	0000
0003522	000289	0001293	0000	0125	0500	0000	0875	0500	0000	003416	000005	0001465	0125	0125	0500	0875	0875	0000	0000
0003960	000306	0001815	0000	0125	0625	0000	0875	0375	0000	003752	000013	0001936	0125	0125	0625	0875	0875	0000	0000
0004288	000233	0002360	0000	0125	0750	0000	0875	0250	0000	004176	000228	0002253	0125	0125	0750	0875	0875	0000	0000
0004600	000595	0003388	0000	0125	0875	0000	0875	0125	0000	004430	000058	0002668	0125	0125	0875	0875	0875	0000	0000
0004627	000615	0003663	0000	0125	1000	0000	0875	0000	0000	004643	000302	0003353	0125	0125	1000	0875	0875	0000	0000
0002596	000157	0000265	0000	0250	0000	0000	0750	1000	0000	003687	000238	0000911	0125	0250	0000	0875	0750	1000	0000
0002577	000188	0000253	0000	0250	0125	0000	0750	0875	0000	002979	000250	000234	0125	0250	0125	0875	0750	0875	0000
0002598	000126	000234	0000	0250	0250	0000	0750	0750	0000	002989	000260	000249	0125	0250	0250	0875	0750	0750	0000
0003673	000704	0001044	0000	0250	0375	0000	0750	0625	0000	003287	000375	000737	0125	0250	0375	0875	0750	0625	0000
0003882	000708	0001135	0000	0250	0500	0000	0750	0500	0000	003764	000394	0001369	0125	0250	0500	0875	0750	0500	0000
0003983	000321	0001840	0000	0250	0625	0000	0750	0375	0000	003946	000297	0001832	0125	0250	0625	0875	0750	0375	0000
0004598	000789	0002303	0000	0250	0750	0000	0750	0250	0000	004244	000298	0002198	0125	0250	0750	0875	0750	0250	0000
0004588	000649	0003408	0000	0250	0875	0000	0750	0125	0000	004610	000661	0002816	0125	0250	0875	0750	0125	0000	0000
0004448	000469	0004668	0000	0250	1000	0000	0750	0000	0000	004777	000760	0003299	0125	0250	1000	0875	0750	0000	0000
0004208	000424	0000547	0000	0375	0000	0000	0625	1000	0000	004192	000142	0000562	0125	0375	0000	0875	0625	1000	0000
0003596	000729	0000272	0000	0375	0125	0000	0625	0875	0000	003798	000926	0000399	0125	0375	0125	0875	0625	0875	0000
0003724	000724	0000208	0000	0375	0250	0000	0625	0750	0000	003752	000722	0000229	0125	0375	0250	0875	0625	0750	0000
0003712	000701	0001076	0000	0375	0375	0000	0625	0625	0000	003773	000741	0000352	0125	0375	0375	0875	0625	0000	0000
0004105	000898	0001691	0000	0375	0500	0000	0625	0500	0000	003932	000895	0001219	0125	0375	0500	0875	0625	0500	0000
0004573	001335	0001713	0000	0375	0500	0000	0625	0375	0000	004274	000908	0001710	0125	0375	0625	0875	0625	0375	0000
0004870	001272	0001900	0000	0375	0750	0000	0625	0250	0000	004550	000769	0002180	0125	0375	0750	0875	0625	0250	0000
0004887	001282	0003287	0000	0375	0875	0000	0625	0125	0000	004774	000995	0002754	0125	0375	0875	0875	0625	0125	0000
0004811	002105	0004414	0000	0375	1000	0000	0625	0000	0000	004896	001197	0003329	0125	0375	1000	0875	0625	0000	0000
0004642	002377	0001010	0000	0500	0000	0000	0500	1000	0000	004563	002359	0000966	0125	0500	0000	0875	0500	1000	0000
0004150	001465	0001666	0000	0500	0125	0000	0500	0875	0000	004192	001420	0000612	0125	0500	0125	0875	0500	0875	0000
0004208	001470	0001777	0000	0500	0250	0000	0500	0750	0000	004241	001457	0001505	0125	0500	0250	0875	0500	0750	0000
0004094	001436	0001099	0000	0500	0375	0000	0500	0625	0000	004605	001205	0003222	0125	0500	0375	0875	0500	0625	0000
0004153	001284	0001100	0000	0500	0500	0000	0500	0500	0000	004167	001324	0001120	0125	0500	0500	0875	0500	0500	0000
0004526	001346	0001713	0000	0500	0625	0000	0500	0375	0000	004615	001340	0001722	0125	0500	0625	0875	0500	0375	0000
0005136	001770	0002743	0000	0500	0750	0000	0500	0250	0000	004860	001297	0002194	0125	0500	0750	0875	0500	0250	0000
0005143	001803	0003279	0000	0500	0875	0000	0500	0125	0000	005133	001779	0002781	0125	0500	0875	0875	0500	0125	0000
0004818	002117	0004445	0000	0500	1000	0000	0500	0000	0000	005051	001634	0003306	0125	0500	1000	0875	0500	0000	0000
0004623	002381	0000999	0000	0625	0000	0000	0375	1000	0000	005087	003102	0001495	0125	0625	0000	0875	0375	1000	0000
0004669	002262	0000227	0000	0625	0125	0000	0375	0875	0000	004623	002350	0000884	0125	0625	0125	0875	0375	0875	0000
0004720	002252	0000240	0000	0625	0250	0000	0375	0750	0000	004604	002049	0000063	0125	0625	0250	0875	0375	0750	0000
0004655	001949	000781	0000	0625	0375	0000	0375	0625	0000	004511	001934	0003033	0125	0625	0375	0875	0375	0625	0000
0004555	001775	0000880	0000	0625	0500	0000	0375	0500	0000	004642	001754	0003930	0125	0625	0500	0875	0375	0500	0000
0004649	001477	0001724	0000	0625	0625	0000	0375	0375	0000	004604	001656	0001207	0125	0625	0625	0875	0375	0000	0000
0005040	001781	0002094	0000	0625	0750	0000	0375	0250	0000	005083	001777	0002120	0125	0625	0750	0875	0375	0250	0000
0005333	003448	0003824	0000	0625	0875	0000	0375	0125	0000	005340	002069	0002612	0125	0625	0875	0875	0375	0125	0000
0005106	002682	0004250	0000	0625	1000	0000	0375	0000	0000	005301	002242	0003328	0125	0625	1000	0875	0375	0000	0000
0005065	002993	0001488	0000	0750	0000	0000	0250	1000	0000	005472	004008	0002295	0125	0750	0000	0875	0250	1000	0000
0005067	003120	0000718	0000	0750	0125	0000	0250	0875	0000	005122	003091	0000875	0125	0750	0125	0875	0250	0875	0000
0005243	002922	0000118	0000	0750	0250	0000	0250	0750	0000	005040	002712	0000474	0125	0750	0250	0875	0250	0750	0000

See original or copy: <http://web.me.com/klaus.richter/HE73/HE73L0NA.TXT> /PS
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

004049	001378	000555	0375	0000	0000	0000	00625	1000	1000	0000	0000	%0243	A10	\$
003854	001101	000190	0375	0000	0125	0625	1000	0875	0000	0000	0000	%0244	A11	\$
004186	001535	-00113	0375	0000	0250	0625	1000	0750	0000	0000	0000	%0245	A12	\$
003675	000448	-00715	0375	0000	0375	0625	1000	0625	0000	0000	0000	%0246	A13	\$
004079	001103	-01058	0375	0000	0500	0625	1000	0500	0000	0000	0000	%0247	A14	\$
004024	001845	-02097	0375	0000	0625	0625	1000	0375	0000	0000	0000	%0248	A15	\$
004000	001607	-02715	0375	0000	0750	0625	1000	0250	0000	0000	0000	%0249	A16	\$
003665	001823	-04102	0375	0000	0875	0625	1000	0125	0000	0000	0000	%0250	A17	\$
003534	001241	-04445	0375	0000	1000	0625	1000	0000	0000	0000	0000	%0251	A18	\$
003941	000936	-00092	0375	0125	0000	0625	0875	1000	0000	0000	0000	%0252	B10	\$
003916	001003	-00819	0375	0125	0125	0625	0875	0875	0000	0000	0000	%0253	B11	\$
003831	001064	-00615	0375	0125	0250	0625	0875	0750	0000	0000	0000	%0254	B12	\$
003297	000476	-00378	0375	0125	0375	0625	0875	0625	0000	0000	0000	%0255	B13	\$
003829	000509	-01070	0375	0125	0500	0625	0875	0500	0000	0000	0000	%0256	B14	\$
004065	001001	-02063	0375	0125	0625	0625	0875	0375	0000	0000	0000	%0257	B15	\$
004019	001052	-02099	0375	0125	0750	0625	0875	0250	0000	0000	0000	%0258	B16	\$
004009	001059	-02862	0375	0125	0875	0625	0875	0125	0000	0000	0000	%0259	B17	\$
004138	000847	-03495	0375	0125	1000	0625	0875	0000	0000	0000	0000	%0260	B18	\$
004558	001767	-001775	0375	0250	0000	0625	0750	1000	0000	0000	0000	%0261	C10	\$
004024	000918	-000950	0375	0250	0125	0625	0750	0875	0000	0000	0000	%0262	C11	\$
004068	000833	-000401	0375	0250	0250	0625	0750	0750	0000	0000	0000	%0263	C12	\$
004109	000473	-00195	0375	0250	0375	0625	0750	0625	0000	0000	0000	%0264	C13	\$
004202	000333	-00855	0375	0250	0500	0625	0750	0500	0000	0000	0000	%0265	C14	\$
004346	000312	-01411	0375	0250	0625	0625	0750	0375	0000	0000	0000	%0266	C15	\$
004544	000332	-01951	0375	0250	0750	0625	0750	0250	0000	0000	0000	%0267	C16	\$
004711	000354	-02505	0375	0250	0875	0625	0750	0125	0000	0000	0000	%0268	C17	\$
005120	000268	-02825	0375	0250	1000	0625	0750	0000	0000	0000	0000	%0269	C18	\$
004929	000000	-001678	0375	0375	0000	0625	0625	1000	0000	0000	0000	%0270	D10	\$
004696	-00170	-001359	0375	0375	0125	0625	0625	0875	0000	0000	0000	%0271	D11	\$
004485	000008	-000941	0375	0375	0250	0625	0625	0750	0000	0000	0000	%0272	D12	\$
004497	000014	-000120	0375	0375	0375	0625	0625	0625	0000	0000	0000	%0273	D13	\$
004829	000038	-00268	0375	0375	0500	0625	0625	0500	0000	0000	0000	%0274	D14	\$
005285	000090	-00439	0375	0375	0625	0625	0625	0375	0000	0000	0000	%0275	D15	\$
005365	-00235	-01454	0375	0375	0750	0625	0625	0250	0000	0000	0000	%0276	D16	\$
005679	-00181	-01890	0375	0375	0875	0625	0625	0125	0000	0000	0000	%0277	D17	\$
006006	-00247	-02176	0375	0375	1000	0625	0625	0000	0000	0000	0000	%0278	D18	\$
005697	-01419	-001961	0375	0500	0000	0625	0500	1000	0000	0000	0000	%0279	D19	\$
005235	-00874	-001533	0375	0500	0125	0625	0500	0875	0000	0000	0000	%0280	E10	\$
005178	-00893	-001078	0375	0500	0250	0625	0500	0750	0000	0000	0000	%0281	E12	\$
005140	-00677	-000143	0375	0500	0375	0625	0500	0625	0000	0000	0000	%0282	E13	\$
005051	-00456	-00294	0375	0500	0500	0625	0500	0500	0000	0000	0000	%0283	E14	\$
005374	-00645	-00924	0375	0500	0625	0625	0500	0375	0000	0000	0000	%0284	E15	\$
005585	-00641	-01451	0375	0500	0750	0625	0500	0250	0000	0000	0000	%0285	E16	\$
005817	-00614	-01872	0375	0500	0875	0625	0500	0125	0000	0000	0000	%0286	E17	\$
006123	-00538	-02174	0375	0500	1000	0625	0500	0000	0000	0000	0000	%0287	E18	\$
006033	-02054	-002543	0375	0625	0000	0625	0375	1000	0000	0000	0000	%0288	F10	\$
005715	-01381	-001981	0375	0625	0125	0625	0375	0875	0000	0000	0000	%0289	F11	\$
005475	-01601	-001328	0375	0625	0250	0625	0375	0750	0000	0000	0000	%0290	F12	\$
005576	-01249	-000301	0375	0625	0375	0625	0375	0625	0000	0000	0000	%0291	F13	\$
005543	-01042	-00294	0375	0625	0500	0625	0375	0500	0000	0000	0000	%0292	F14	\$
005529	-01000	-000571	0375	0625	0625	0625	0375	0375	0000	0000	0000	%0293	F15	\$
005661	-01126	-01558	0375	0625	0750	0625	0375	0250	0000	0000	0000	%0294	F16	\$
005990	-01095	-01817	0375	0625	0875	0625	0375	0125	0000	0000	0000	%0295	F17	\$
006250	-01107	-02259	0375	0625	1000	0625	0375	0000	0000	0000	0000	%0296	F18	\$
006375	-02902	-003036	0375	0750	0000	0625	0250	1000	0000	0000	0000	%0297	G10	\$
005733	-02486	-002009	0375	0750	0125	0625	0250	0875	0000	0000	0000	%0298	G11	\$
005748	-02533	-001499	0375	0750	0250	0625	0250	0750	0000	0000	0000	%0299	G12	\$
006014	-01911	-004086	0375	0750	0375	0625	0250	0500	0000	0000	0000	%0300	G13	\$
005921	-01708	-00131	0375	0750	0500	0625	0250	0500	0000	0000	0000	%0301	G14	\$
005844	-01593	-00678	0375	0750	0625	0625	0250	0375	0000	0000	0000	%0302	G15	\$
005832	-01570	-01063	0375	0750	0750	0625	0250	0250	0000	0000	0000	%0303	G16	\$
006191	-01811	-01898	0375	0750	0875	0625	0250	0125	0000	0000	0000	%0304	G17	\$
006440	-01708	-02385	0375	0750	1000	0625	0250	0000	0000	0000	0000	%0305	G18	\$
006394	-02854	-002999	0375	0875	0000	0625	0125	0000	0000	0000	0000	%0306	H10	\$
006105	-03204	-002555	0375	0875	0125	0625	0125	0875	0000	0000	0000	%0307	H11	\$
006085	-03238	-001739	0375	0875	0250	0625	0125	0750	0000	0000	0000	%0308	H12	\$
006391	-02512	-000509	0375	0875	0375	0625	0125	0625	0000	0000	0000	%0309	H13	\$
006375	-02409	-00031	0375	0875	0500	0625	0125	0500	0000	0000	0000	%0310	H14	\$
006387	-02320	-00038	0375	0875	0625	0625	0125	0375	0000	0000	0000	%0311	H15	\$
006286	-02159	-01031	0375	0875	0750	0625	0125	0250	0000	0000	0000	%0312	H16	\$
006261	-01992	-01412	0375	0875	0875	0625	0125	0125	0000	0000	0000	%0313	H17	\$
006752	-02274	-02052	0375	0875	1000	0625	0125	0000	0000	0000	0000	%0314	H18	\$
006642	-04370	-004372	0375	1000	0000	0625	0000	1000	0000	0000	0000	%0315	I10	\$
006428	-04066	-002909	0375	1000	0125	0625	0000	0875	0000	0000	0000	%0316	I11	\$
006410	-04138	-001998	0375	1000	0250	0625	0000	0750	0000	0000	0000	%0317	I12	\$
006851	-03140	-000850	0375	1000	0375	0625	0000	0625	0000	0000	0000	%0318	I13	\$
006785	-02963	-000295	0375	1000	0500	0625	0000	0500	0000	0000	0000	%0319	I14	\$
006679	-02742	-00279	0375	1000	0625	0000	0000	0375	0000	0000	0000	%0320	I15	\$
006821	-02652	-00644	0375	1000	0750	0625	0000	0250	0000	0000	0000	%0321	I16	\$
006616	-02451	-01329	0375	1000	0875	0625	0000	0125	0000	0000	0000	%0322	I17	\$
006678	-02414	-01599	0375	1000	1000	0625	0000	0000	0000	0000	0000	%0323	I18	\$
004764	002934	001114	0500	0000	0000	0500	1000	1000	0000	0000	0000	%0324	J10	\$
004830	002888	001086	0500	0000	0125	0500	1000	0875	0000	0000	0000	%0325	J11	\$
004889	003173	003036	0500	0000	0250	0500	1000	0750	0000	0000	0000	%0326	J12	\$
004523	001919	-01216	0500	0000	0375	0500	1000	0625	0000	0000	0000	%0327	J13	\$
004111	001078	-01845	0500	0000	0500	0500	1000	0500	0000	0000	0000	%0328	J14	\$
004166	002020	-02234	0500	0000	0625	0500	1000	0375	0000	0000	0000	%0329	J15	\$
003950	001949	-03255	0500	0000	0750	0500	1000	0250	0000					

See original or copy: <http://web.me.com/klaus.richter/HE73/HE73L0NA.TXT> /PS
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

004886	004068	001908	0750	0000	0000	0250	1000	1000	0000	0000	%0486	A19	\$	004841	005859	002817	0875	0000	0000	0125	1000	1000	0000	0000	%0567	J19	\$	004763	006672	003317	1000	0000	0000	0000	1000	1000	0000	0000	%0648	S19	\$	
004847	004218	001167	0750	0000	0125	0250	1000	0875	0000	0000	%0487	A20	\$	004775	005981	002154	0875	0000	0125	0125	1000	0875	0000	0000	0000	%0568	J20	\$	004814	006844	002746	1000	0000	0125	0000	1000	0875	0000	0000	%0649	S20	\$
004859	004392	000575	0750	0000	0250	0250	1000	0750	0000	0000	%0488	A21	\$	004730	006162	001389	0875	0000	0250	0125	1000	0750	0000	0000	0000	%0569	J21	\$	004858	006883	001755	1000	0000	0250	0000	1000	0750	0000	0000	%0650	S21	\$
004776	004646	-00144	0750	0000	0375	0250	1000	0625	0000	0000	%0489	A22	\$	004730	006365	000490	0875	0000	0375	0125	1000	0625	0000	0000	0000	%0570	J22	\$	004776	006755	000989	1000	0000	0375	0000	1000	0625	0000	0000	%0651	S22	\$
004681	004737	-01079	0750	0000	0500	0250	1000	0500	0000	0000	%0490	A23	\$	004724	005166	-00762	0875	0000	0500	0125	1000	0500	0000	0000	0000	%0571	J23	\$	004729	006629	000219	1000	0000	0500	0000	1000	0500	0000	0000	%0652	S23	\$
004062	003783	-01908	0750	0000	0625	0250	1000	0375	0000	0000	%0491	A24	\$	004638	004735	-01066	0875	0000	0625	0125	1000	0375	0000	0000	0000	%0572	J24	\$	004683	006527	-00734	1000	0000	0625	0000	1000	0375	0000	0000	%0653	S24	\$
003908	002776	-01852	0750	0000	0750	0250	1000	0250	0000	0000	%0492	A25	\$	004397	005267	-01240	1000	0000	0750	0125	1000	0250	0000	0000	0000	%0573	J25	\$	004397	005267	-01240	1000	0000	0750	0000	1000	0250	0000	0000	%0654	S25	\$
003862	003004	-02397	0750	0000	0875	0250	1000	0000	0000	0000	%0483	A26	\$	004401	004178	-01809	1000	0000	0875	0000	1000	0125	0000	0000	0000	%0574	J26	\$	004401	004178	-01809	1000	0000	0875	0000	1000	0125	0000	0000	%0655	S26	\$
003821	003405	-03407	0750	0000	1000	0250	1000	0000	0000	0000	%0493	A27	\$	003892	003225	-02479	0875	0000	1000	0125	1000	0000	0000	0000	0000	%0575	J27	\$	004005	003771	-02055	1000	0000	1000	0000	1000	0000	0000	0000	%0656	S27	\$
004941	003852	003219	0750	0125	0000	0250	0875	1000	0000	0000	%0495	B10	\$	004839	005801	003524	0875	0125	0000	0125	0875	1000	0000	0000	0000	%0576	K19	\$	004835	005834	004060	1000	0125	0000	0000	0875	1000	0000	0000	%0657	T10	\$
004825	004101	001956	0750	0125	0125	0250	0875	0875	0000	0000	%0496	B20	\$	004971	004429	002243	0875	0125	0125	0125	0875	0875	0000	0000	0000	%0577	K20	\$	005481	005585	002937	1000	0125	0125	0000	0875	0875	0000	0000	%0658	T20	\$
004774	004213	001258	0750	0125	0250	0250	0875	0750	0000	0000	%0497	B21	\$	005000	004563	001485	0875	0125	0250	0125	0875	0750	0000	0000	0000	%0578	K21	\$	005405	005689	001974	1000	0125	0250	0000	0875	0750	0000	0000	%0659	T21	\$
004790	004363	000600	0750	0125	0375	0250	0875	0625	0000	0000	%0498	B22	\$	004954	004559	000882	0875	0125	0375	0125	0875	0625	0000	0000	0000	%0579	K22	\$	005444	005621	001281	1000	0125	0375	0000	0875	0625	0000	0000	%0660	T22	\$
004682	004646	-00149	0750	0125	0500	0250	0875	0500	0000	0000	%0499	B23	\$	004906	004810	000137	0875	0125	0500	0125	0875	0500	0000	0000	0000	%0580	K23	\$	005437	005558	000567	1000	0125	0500	0000	0875	0500	0000	0000	%0661	T23	\$
004123	003216	-01464	0750	0125	0625	0250	0875	0375	0000	0000	%0500	B24	\$	004761	004559	-00618	0875	0125	0625	0125	0875	0375	0000	0000	0000	%0581	K24	\$	005362	005643	-00320	1000	0125	0625	0000	0875	0375	0000	0000	%0662	T24	\$
003850	002833	-01899	0750	0125	0750	0250	0875	0250	0000	0000	%0501	B25	\$	004313	003565	-01282	0875	0125	0750	0125	0875	0250	0000	0000	0000	%0582	K25	\$	005094	004528	-00951	1000	0125	0750	0000	0875	0250	0000	0000	%0663	T25	\$
003790	002443	-02272	0750	0125	0875	0250	0875	0125	0000	0000	%0502	B26	\$	004001	002983	-01742	0875	0125	0875	0125	0875	0125	0000	0000	0000	%0583	K26	\$	004681	003814	-01482	1000	0125	0875	0000	0875	0125	0000	0000	%0664	T26	\$
004047	002424	-02908	0750	0125	1000	0250	0875	0000	0000	0000	%0503	B27	\$	004260	002740	-02374	0875	0125	1000	0125	0875	0000	0000	0000	0000	%0584	K27	\$	004566	003086	-01799	1000	0125	1000	0000	0875	0000	0000	0000	%0665	T27	\$
004967	003838	003288	0750	0250	0000	0250	0750	1000	0000	0000	%0504	C19	\$	004990	004115	003451	0875	0250	0000	0125	0750	1000	0000	0000	0000	%0585	L19	\$	005360	005206	004750	1000	0250	0000	0000	0750	1000	0000	0000	%0666	T29	\$
004837	003309	002923	0750	0250	0125	0250	0750	0875	0000	0000	%0505	C20	\$	005075	004072	003026	0875	0250	0125	0125	0750	0875	0000	0000	0000	%0586	L20	\$	005559	005385	003953	1000	0250	0125	0000	0750	0875	0000	0000	%0667	U20	\$
005024	003178	001746	0750	0250	0250	0250	0750	0750	0000	0000	%0506	C21	\$	005488	003888	001926	0875	0250	0250	0125	0750	0750	0000	0000	0000	%0587	L21	\$	006138	004825	002496	1000	0250	0250	0000	0750	0750	0000	0000	%0668	U21	\$
004988	003213	001023	0750	0250	0375	0250	0750	0625	0000	0000	%0507	C22	\$	005468	003892	001224	0875	0250	0375	0125	0750	0625	0000	0000	0000	%0588	L22	\$	006126	004851	001691	1000	0250	0375	0000	0750	0625	0000	0000	%0669	U22	\$
004916	003404	000124	0750	0250	0500	0250	0750	0500	0000	0000	%0508	C23	\$	005471	003945	000470	0875	0250	0500	0125	0750	0500	0000	0000	0000	%0589	L23	\$	006063	004791	000997	1000	0250	0500	0000	0750	0500	0000	0000	%0670	U23	\$
004561	002798	-00690	0750	0250	0625	0250	0750	0375	0000	0000	%0509	C24	\$	005462	003983	-00143	0875	0250	0625	0125	0750	0375	0000	0000	0000	%0590	L24	\$	006050	004690	000277	1000	0250	0625	0000	0750	0375	0000	0000	%0671	U24	\$
004211	002118	-01175	0750	0250	0750	0250	0750	0250	0000	0000	%0510	C25	\$	004837	003412	-01021	0875	0250	0750	0125	0750	0250	0000	0000	0000	%0591	L25	\$	005783	004481	-00680	1000	0250	0750	0000	0750	0250	0000	0000	%0672	U25	\$
004405	002053	-01832	0750	0250	0875	0250	0750	0125	0000	0000	%0511	C26	\$	004577	002727	-01470	0875	0250	0875	0125	0750	0125	0000	0000	0000	%0592	L26	\$	005461	003483	-01139	1000	0250	0875	0000	0750	0125	0000	0000	%0673	U26	\$
004706	001912	-02440	0750	0250	1000	0250	0750	0000	0000	0000	%0513	C27	\$	004883	002555	-01957	0875	0250	1000	0125	0750	0000	0000	0000	0000	%0593	L27	\$	005035	002780	-01611	1000	0250	1000	0000	0750	0000	0000	0000	%0674	U27	\$
005500	002943	003489	0750	0375	0000	0250	0625	1000	0000	0000	%0513	D19	\$	005517	003192	003731	0875	0375	0000	0125	0625	1000	0000	0000	0000	%0594	M19	\$	005748	004437	005245	1000	0375	0000	0000	0625	1000	0000	0000	%0675	V19	\$
005106	002844	002985	0750	0375	0125	0250	0625	0875	0000	0000	%0514	D20	\$	005528	003347	003437	0875	0375	0125	0125	0625	0875	0000	0000	0000	%0595	M20	\$	006085	004592	004476	1000	0375	0125	0000	0625	0875	0000	0000	%0676	V20	\$
005236	002728	002492	0750	0375	0250	0250	0625	0750	0000	0000	%0515	D21	\$	005641	003430	002689	0875	0375	0250	0125	0625	0750	0000	0000	0000	%0596	M21	\$	006274	004524	003469	1000	0375	0250	0000	0625	0750	0000	0000	%0677	V21	\$
005627	002379	-001424	0750	0375	0375	0250	0625	0625	0000	0000	%0516	D22	\$	006036	003053	001638	0875	0375	0375	0125	0625	0625	0000	0000	0000	%0597	M22	\$	006701	004070	002108	1000	0375	0375	0000	0625	0625	0000	0000	%0678	V22	\$
00551																																										

See original or copy: <http://web.me.com/klaus.richter/HE73/HE73L0NA.TXT> /.PS
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.0

009654	-00060	000192	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$	
009866	-00599	-00427	0875	1000	1000	0000	0125	0000	0000	0000	%0730	b02	\$
008317	-01021	-00540	0750	1000	1000	0000	0250	0000	0000	0000	%0731	b03	\$
007717	-01274	-00788	0625	1000	1000	0000	0375	0000	0000	0000	%0732	b04	\$
007228	-01228	-01172	0500	1000	1000	0000	0500	0000	0000	0000	%0733	b05	\$
006710	-02327	-01679	0375	1000	1000	0000	0625	0000	0000	0000	%0734	b06	\$
006124	-02917	-02172	0250	1000	1000	0000	0750	0000	0000	0000	%0735	b07	\$
005723	-03204	-02480	0125	1000	1000	0000	0875	0000	0000	0000	%0736	b08	\$
005456	-04608	-02815	0000	1000	1000	0000	1000	0000	0000	0000	%0737	b09	\$
008726	000766	000505	1000	0875	0875	0000	0125	0125	0000	0000	%0738	c01	\$
008340	-000305	000189	0875	0875	0875	0000	0125	0125	0125	0000	%0739	c02	\$
007996	-00588	-00337	0750	0875	0875	0000	0250	0125	0125	0000	%0740	c03	\$
007255	-00968	-00582	0625	0875	0875	0000	0375	0125	0125	0000	%0741	c04	\$
006749	-01374	-00946	0500	0875	0875	0000	0500	0125	0125	0000	%0742	c05	\$
006297	-01893	-01425	0375	0875	0875	0000	0625	0125	0125	0000	%0743	c06	\$
005713	-02313	-01851	0250	0875	0875	0000	0750	0125	0125	0000	%0744	c07	\$
005483	-02448	-01927	0125	0875	0875	0000	0875	0125	0125	0000	%0745	c08	\$
005601	-02603	-02389	0000	0875	0875	0000	1000	0125	0125	0000	%0746	c09	\$
008359	001441	000375	1000	0750	0750	0000	0250	0250	0000	0000	%0747	d01	\$
007883	000684	000452	0875	0750	0750	0000	0125	0250	0250	0000	%0748	d02	\$
007431	000031	000139	0750	0750	0750	0000	0250	0250	0000	0000	%0749	d03	\$
006812	-03055	-00079	0625	0750	0750	0000	0375	0250	0250	0000	%0750	d04	\$
006314	-00915	-00641	0500	0750	0750	0000	0500	0250	0250	0000	%0751	d05	\$
005853	-01442	-01039	0375	0750	0750	0000	0625	0250	0250	0000	%0752	d06	\$
005353	-01874	-01442	0250	0750	0750	0000	0750	0250	0250	0000	%0753	d07	\$
005120	-01965	-01376	0125	0750	0750	0000	0875	0250	0250	0000	%0754	d08	\$
005078	-01879	-01414	0000	0750	0750	0000	1000	0250	0250	0000	%0755	d09	\$
007836	002336	001257	1000	0625	0625	0000	0375	0375	0000	0000	%0756	e01	\$
007290	001464	000850	0875	0625	0625	0000	0125	0375	0375	0000	%0757	e02	\$
006849	000797	000569	0750	0625	0625	0000	0250	0375	0375	0000	%0758	e03	\$
006303	000009	000124	0625	0625	0625	0000	0375	0375	0375	0000	%0759	e04	\$
005874	-00414	-00225	0500	0625	0625	0000	0500	0375	0375	0000	%0760	e05	\$
005493	-00950	-00532	0375	0625	0625	0000	0625	0375	0375	0000	%0761	e06	\$
004986	-01473	-01102	0250	0625	0625	0000	0750	0375	0375	0000	%0762	e07	\$
004696	-01624	-01133	0125	0625	0625	0000	0875	0375	0375	0000	%0763	e08	\$
004734	-01424	-01678	0000	0625	0625	0000	1000	0375	0375	0000	%0764	e09	\$
007308	003130	001743	1000	0500	0500	0000	0500	0500	0000	0000	%0765	f01	\$
006748	002176	001326	0875	0500	0500	0000	0125	0500	0500	0000	%0766	f02	\$
006271	001526	000905	0750	0500	0500	0000	0250	0500	0500	0000	%0767	f03	\$
005703	000835	000562	0625	0500	0500	0000	0375	0500	0500	0000	%0768	f04	\$
005234	000005	000097	0500	0500	0500	0000	0500	0500	0000	0000	%0769	f05	\$
005040	-00440	-00323	0375	0500	0500	0000	0625	0500	0500	0000	%0770	f06	\$
004570	-00964	-00706	0250	0500	0500	0000	0750	0500	0500	0000	%0771	f07	\$
004248	-01278	-01151	0125	0500	0500	0000	0875	0500	0500	0000	%0772	f08	\$
004288	-01246	-01076	0000	0500	0500	0000	1000	0500	0500	0000	%0773	f09	\$
006707	004049	002209	1000	0375	0375	0000	0625	0625	0000	0000	%0774	g01	\$
006050	002996	001599	0875	0375	0375	0000	0125	0625	0625	0000	%0775	g02	\$
005594	002276	001460	0750	0375	0375	0000	0250	0625	0625	0000	%0776	g03	\$
005146	001621	001125	0625	0375	0375	0000	0375	0625	0625	0000	%0777	g04	\$
004764	000772	000496	0500	0375	0375	0000	0500	0625	0625	0000	%0778	g05	\$
004378	000004	000123	0375	0375	0375	0000	0625	0625	0625	0000	%0779	g06	\$
004112	-00426	-00368	0250	0375	0375	0000	0750	0625	0625	0000	%0780	g07	\$
003865	-00710	-00416	0125	0375	0375	0000	0875	0625	0625	0000	%0781	g08	\$
003839	-00725	-01086	0000	0375	0375	0000	1000	0625	0625	0000	%0782	g09	\$
006106	004831	002594	1000	0250	0250	0000	0750	0750	0000	0000	%0783	h01	\$
005400	003802	002008	0875	0250	0250	0000	0125	0750	0750	0000	%0784	h02	\$
004895	003143	001701	0750	0250	0250	0000	0250	0750	0750	0000	%0785	h03	\$
004403	002403	001365	0625	0250	0250	0000	0375	0750	0750	0000	%0786	h04	\$
004152	001603	001007	0500	0250	0250	0000	0500	0750	0750	0000	%0787	h05	\$
003900	000868	000420	0375	0250	0250	0000	0625	0750	0750	0000	%0788	h06	\$
003496	000027	000104	0250	0250	0250	0000	0750	0750	0750	0000	%0789	h07	\$
003077	-00287	-00306	0125	0250	0250	0000	0875	0750	0750	0000	%0790	h08	\$
002730	-00130	-00355	0000	0250	0250	0000	1000	0750	0750	0000	%0791	h09	\$
005458	005535	003108	1000	0125	0125	0000	0875	0875	0000	0000	%0792	i01	\$
004484	004334	002325	0875	0125	0125	0000	0125	0875	0875	0000	%0793	i02	\$
004721	004951	001982	0750	0125	0125	0000	0250	0875	0875	0000	%0794	i03	\$
004548	002814	001931	0625	0125	0125	0000	0375	0875	0875	0000	%0795	i04	\$
004173	001701	000901	0500	0125	0125	0000	0500	0875	0875	0000	%0796	i05	\$
003756	001035	000852	0375	0125	0125	0000	0625	0875	0875	0000	%0797	i06	\$
003185	000527	000347	0250	0125	0125	0000	0750	0875	0875	0000	%0798	i07	\$
002713	000021	000060	0125	0125	0125	0000	0875	0875	0875	0000	%0799	i08	\$
002251	000025	000058	0000	0125	0125	0000	1000	0875	0875	0000	%0800	i09	\$
004718	006630	003488	1000	0000	0000	0000	1000	1000	0000	0000	%0801	j01	\$
004740	005819	003014	0875	0000	0000	0000	0125	1000	1000	0000	%0802	j02	\$
004697	004074	001993	0750	0000	0000	0000	0250	1000	1000	0000	%0803	j03	\$
004700	004085	001946	0625	0000	0000	0000	0375	1000	1000	0000	%0804	j04	\$
004626	002934	001100	0500	0000	0000	0000	0500	1000	1000	0000	%0805	j05	\$
003949	001367	000544	0375	0000	0000	0000	0625	1000	1000	0000	%0806	j06	\$
002974	000435	000399	0250	0000	0000	0000	0750	1000	1000	0000	%0807	j07	\$
002148	000227	000271	0125	0000	0000	0000	0875	1000	1000	0000	%0808	j08	\$
001350	000066	000138	0000	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009691	-00058	000183	1000	1000	1000	0000	0000	0000	0000	0000	%0810	b10	\$
008673	-00107	-00340	0875	0875	0875	0000	0125	0125	0000	0000	%0811	b11	\$
008139	-00137	-00820	0750	0750	0750	0000	0250	0250	0000	0000	%0812	b12	\$
007412	-00125	-01187	0625	0625	0625	0000	0375	0375	0000	0000	%0813	b13	\$
006652	-00075	-01702	0500	0500	0500	0000	0500	0500	0000	0000	%0814	b14	\$
006053	-00266	-02141	0375	0375	0375	0000	0625	0625	0000	0000	%0815	b15	\$
005285	-00287	-02769	0250	0250	0250	0000	0750	0750	0000	0000	%0816	b16	\$
004616	-00447	-03451	0125	0125	0125	0000	0875	0875	0000	0000	%0817	b17	\$
004423	-00452	-04487	0000	0000	0000	0000	1000	1000	0000	0000	%0818	b18	\$
002981	000120	000777	1000	1000	1000	0000	0000	0125	0000	0000	%0819	c10	\$
008487	-000209	000178	0875	0875	0875	0000	0125	0125	0250	0000	%0820	c11	\$
007991	-00188	-00247	0750	0750	0750	0000	0250	0250	0125	0000	%0821	c12	\$
007128	-00152	-00851	0625	0625	0625	0000	0375	0					

%BEG HE63_22.TXT, Separation cmyn4*, cfi=0.90, D50, not adapted \$
%100 x LAB*
%#1000 x (r g b c m y 0) %nr. pos \$
%z004763 006672 003317 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008237 000254 007303 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005605 -04269 001571 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005449 -04635 -02816 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z004437 -00300 -04461 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z004095 003714 -02055 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z001315 000049 000122 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009618 -00051 000194 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004718 006630 003488 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008235 000249 007397 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005697 -04290 001301 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005456 -04608 -02815 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z004429 -00452 -04487 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z004032 003755 -02068 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z001145 000076 000137 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009676 -00059 000190 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

ABBE	HAB3	22.TXT,	Separation (cm g b	c1=0.90,	D50,	not	adp.	\$
*100 x	LE63		1000 x	c m y 0	c m y 0		shr.	pos
001107	000048	000115	0000	0800	1000	1000	0000	%0972 k01
002423	000028	000088	0125	0125	0875	0875	0875	%0973 k02
003327	000030	000109	0250	0250	0750	0750	0750	%0974 k03
004167	000016	000136	0375	0375	0625	0625	0625	%0975 k04
005115	000004	000108	0500	0500	0500	0500	0500	%0976 k05
006329	000007	000090	0625	0625	0375	0375	0375	%0977 k06
007448	000023	000142	0750	0750	0250	0250	0250	%0978 k07
008423	-00028	000182	0875	0875	0125	0125	0125	%0979 k08
009677	-00050	000180	1000	1000	0000	0000	0000	%0980 k09
010192	000047	000115	0000	0000	1000	1000	1000	%0981 l01
024444	000024	000082	0125	0125	0875	0875	0875	%0982 l02
033772	000024	000098	0250	0250	0750	0750	0750	%0983 l03
042226	000012	000118	0375	0375	0625	0625	0625	%0984 l04
050179	000004	000075	0500	0500	0500	0500	0500	%0985 l05
060337	000000	000073	0625	0625	0375	0375	0375	%0986 l06
074774	000019	000129	0750	0750	0250	0250	0250	%0987 l07
084333	-00030	000182	0875	0875	0125	0125	0125	%0988 l08
090695	-00056	000193	1000	1000	0000	0000	0000	%0989 l09
010101	000055	000115	0000	0000	1000	1000	1000	%0990 m01
024543	000032	000074	0125	0125	0875	0875	0875	%0991 m02
030387	000030	000090	0250	0250	0750	0750	0750	%0992 m03
040167	000004	000092	0500	0500	0500	0500	0500	%0993 m04
050162	000003	000092	0500	0500	0500	0500	0500	%0994 m05
060336	000000	000091	0625	0625	0375	0375	0375	%0995 m06
074906	000025	000127	0750	0750	0250	0250	0250	%0996 m07
084847	-00033	000186	0875	0875	0125	0125	0125	%0997 m08
090699	000057	000190	1000	1000	0000	0000	0000	%0998 m09
010192	000056	000100	0000	0000	1000	1000	1000	%0999 m10
024213	000029	000089	0125	0125	0875	0875	0875	%1000 n02
030360	000027	000113	0250	0250	0750	0750	0750	%1001 n03
040181	000017	000155	0375	0375	0625	0625	0625	%1002 n04
050908	000007	000113	0500	0500	0500	0500	0500	%1003 n05
060305	-00003	000094	0625	0625	0375	0375	0375	%1004 n06
074573	000031	000134	0750	0750	0250	0250	0250	%1005 n07
084772	-00030	000188	0875	0875	0125	0125	0125	%1006 n08
090699	-00056	000181	1000	1000	0000	0000	0000	%1007 n09
010145	000055	000114	0000	0000	1000	1000	1000	%1008 k10
024210	000026	000043	0066	0666	0933	0933	0933	%1009 k11
030268	000030	000045	0133	0133	0866	0866	0866	%1010 k12
030317	000032	000065	0200	0200	0800	0800	0800	%1011 k13
037800	000001	000088	0266	0266	0333	0333	0333	%1012 k14
042423	000036	000064	0333	0333	0666	0666	0666	%1013 k15
044995								

008319	-00023	000185	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$
008648	-00029	000197	0933	0933	0933	0666	0666	0666	0000	%1054	m24	\$
009642	-00054	000196	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$
001119	000063	000125	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$
002424	000035	000056	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$
002668	000027	000070	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$
003056	000041	000079	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$
003796	000001	000120	0266	0266	0266	0333	0333	0333	0000	%1060	n14	\$
004208	000041	000095	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$
004486	000028	000225	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$
005172	000032	000099	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$
005411	000030	000222	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$
006129	-00008	000117	0600	0600	0600	0400	0400	0400	0000	%1065	n19	\$
006533	000014	000262	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$
007179	-00014	000129	0734	0734	0734	0266	0266	0266	0000	%1067	n21	\$
007821	-00014	000165	0800	0800	0800	0200	0200	0200	0000	%1068	n22	\$
008282	-00020	000193	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$
008509	-00025	000190	0933	0933	0933	0666	0666	0666	0000	%1070	n24	\$
009631	-00054	000179	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$
001081	000066	000094	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$
009566	-00051	000182	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$
004644	006592	003670	1000	0000	0000	0000	1000	1000	0000	%1074	L26	\$
005457	-04977	-02412	0000	1000	1000	1000	0000	0000	0000	%1075	L27	\$
008082	009332	007516	1000	1000	0000	0000	0000	1000	0000	%1076	m26	\$
004329	-00299	-04513	0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$
005429	-04480	001562	0000	1000	0000	1000	0000	1000	0000	%1078	n26	\$
008387	003792	-02160	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$
%\$												
%z004644	0006592	003670	##1000	0000	0000	0000	1000	1000	0000	%1074	L26	%03 0 5
%z008082	000332	007516	##1000	1000	0000	0000	0000	1000	0000	%1076	m26	%Y3 1 3
%z005429	-04480	001562	##0000	1000	0000	1000	0000	1000	0000	%1078	n26	%L3 2 3
%z005457	-04977	-02412	##0000	1000	1000	1000	0000	0000	0000	%1075	L27	%C3 3 3
%z004329	-00299	-04513	##0000	0000	1000	1000	1000	0000	0000	%1077	m27	%V3 4 3
%z003887	003792	-02160	##1000	0000	1000	0000	1000	0000	0000	%1079	n27	%M3 5 3
%z001081												

TUB registration: 20091101-HE73/HE73L0NA.TXT /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

TUB-test chart HE73; Relative Elementary Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```


110B registration: 20091101-HE/3/HE/3L0NÄ.1X1/.pS 110B material: code=rha4a
application for evaluation and measurement of printer or monitor systems

TUB-test chart HE73; Relative Elementary Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

input: w *setgray*
output: → *olv** *setrgbcolor*

004049	001362	000409	0375	0000	0000	0625	1000	1000	0000	%0243	A10	\$
003854	001083	000046	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$
004186	001520	-00261	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$
003675	000428	-00858	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$
004079	001087	-01205	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$
004024	001028	-02243	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$
004000	001590	-02861	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$
003665	001002	-04244	0375	0000	0875	0625	1000	0100	0000	%0250	A17	\$
003534	001219	-04587	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$
003941	000918	-00067	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$
003916	000985	000673	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$
003831	001046	000013	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$
003297	000450	-00517	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$
003829	000490	-01215	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$
004065	000985	-02209	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$
004019	001036	-02245	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$
004009	001043	-03008	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$
004138	000832	-03642	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$
004558	001757	-05162	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$
004024	000902	000804	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$
004068	000817	001255	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$
004109	000458	-00341	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$
004202	000319	-01003	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$
004346	000300	-01560	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$
004544	000322	-02102	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$
004711	000346	-02657	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$
005120	000265	-02981	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$
004929	-000006	001524	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$
004696	-001178	001208	0375	0375	0125	0625	0625	0875	0000	%0271	D11	\$
004447	-000602	000791	0375	0375	0250	0625	0625	0750	0000	%0272	D12	\$
004497	000003	-00629	0375	0375	0375	0625	0625	0625	0000	%0273	D13	\$
004829	000031	-00421	0375	0375	0500	0625	0625	0500	0000	%0274	D14	\$
005285	000091	-01097	0375	0375	0625	0625	0625	0375	0000	%0275	D15	\$
005365	-00235	-01611	0375	0375	0750	0625	0625	0250	0000	%0276	D16	\$
005679	-00178	-02050	0375	0375	0875	0625	0625	0125	0000	%0277	D17	\$
006006	-00239	-02348	0375	0375	1000	0625	0625	0000	0000	%0278	D18	\$
005697	-01415	-00180	0375	0500	0000	0625	0500	1000	0000	%0279	D19	\$
005235	-00875	001377	0375	0500	0125	0625	0500	0875	0000	%0280	E10	\$
005178	-00895	000921	0375	0500	0250	0625	0500	0750	0000	%0281	E12	\$
005140	-00680	-00011	0375	0500	0375	0625	0500	0625	0000	%0282	E13	\$
005051	-00460	-00449	0375	0500	0500	0625	0500	0500	0000	%0283	E14	\$
005374	-00645	-01081	0375	0500	0625	0625	0500	0375	0000	%0284	E15	\$
005585	-00638	-01611	0375	0500	0750	0625	0500	0250	0000	%0285	E16	\$
005817	-00609	-02033	0375	0500	0875	0625	0500	0125	0000	%0286	E17	\$
006123	-00529	-02338	0375	0500	1000	0625	0500	0000	0000	%0287	E18	\$
006033	-02046	-002379	0375	0625	0000	0625	0375	1000	0000	%0288	F10	\$
005715	-01377	-001820	0375	0625	0125	0625	0375	0875	0000	%0289	F11	\$
005475	-01600	-001169	0375	0625	0250	0625	0375	0750	0000	%0290	F12	\$
005576	-01247	-000142	0375	0625	0375	0625	0375	0625	0000	%0291	F13	\$
005543	-01040	-00453	0375	0625	0500	0625	0375	0500	0000	%0292	F14	\$
005529	-00998	-00730	0375	0625	0625	0625	0375	0375	0000	%0293	F15	\$
005661	-01123	-01718	0375	0625	0750	0625	0375	0250	0000	%0294	F16	\$
005990	-01087	-01981	0375	0625	0875	0625	0375	0125	0000	%0295	F17	\$
006259	-01096	-02424	0375	0625	1000	0625	0375	0000	0000	%0296	F18	\$
006375	-02889	-002870	0375	0750	0000	0625	0250	1000	0000	%0297	G10	\$
005733	-02482	-001848	0375	0750	0125	0625	0250	0875	0000	%0298	G11	\$
005748	-02528	-001338	0375	0750	0250	0625	0250	0750	0000	%0299	G12	\$
006014	-01903	-00023	0375	0750	0375	0625	0250	0500	0000	%0300	G13	\$
005921	-01702	-00293	0375	0750	0500	0625	0250	0500	0000	%0301	G14	\$
005844	-01587	-00840	0375	0750	0625	0250	0250	0375	0000	%0302	G15	\$
005832	-01565	-01224	0375	0750	0750	0625	0250	0250	0000	%0303	G16	\$
006191	-01802	-01972	0375	0750	0875	0625	0250	0125	0000	%0304	G17	\$
006440	-01695	-02552	0375	0750	1000	0625	0250	0000	0000	%0305	G18	\$
006394	-02842	-002832	0375	0875	0000	0625	0125	1000	0000	%0306	H10	\$
006105	-03195	-002390	0375	0875	0125	0625	0125	0875	0000	%0307	H11	\$
006085	-03229	-001575	0375	0875	0250	0625	0125	0750	0000	%0308	H12	\$
006391	-02500	-000343	0375	0875	0375	0625	0125	0625	0000	%0309	H13	\$
006375	-02397	-00197	0375	0875	0500	0625	0125	0500	0000	%0310	H14	\$
006387	-02308	-00564	0375	0875	0625	0625	0125	0375	0000	%0311	H15	\$
006286	-02148	-01197	0375	0875	0750	0625	0125	0250	0000	%0312	H16	\$
006261	-01981	-01577	0375	0875	0875	0625	0125	0125	0000	%0313	H17	\$
006752	-02257	-02222	0375	0875	1000	0625	0125	0000	0000	%0314	H18	\$
006642	-04354	-004203	0375	1000	0000	0625	0000	1000	0000	%0315	I10	\$
006428	-04054	-002742	0375	1000	0125	0625	0000	0875	0000	%0316	I11	\$
006410	-04125	-001831	0375	1000	0250	0625	0000	0750	0000	%0317	I12	\$
006851	-03122	-000679	0375	1000	0375	0625	0000	0625	0000	%0318	I13	\$
006785	-02946	-000935	0375	1000	0500	0625	0000	0500	0000	%0319	I14	\$
006729	-02725	-00448	0375	1000	0625	0000	0000	0375	0000	%0320	I15	\$
006681	-02636	-00813	0375	1000	0750	0625	0000	0250	0000	%0321	I16	\$
006616	-02436	-01498	0375	1000	0875	0625	0000	0125	0000	%0322	I17	\$
006678	-02398	-01768	0375	1000	1000	0625	0000	0000	0000	%0323	I18	\$
004764	002927	000961	0500	0000	0000	0500	1000	1000	0000	%0324	J10	\$
004830	002881	000933	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$
004889	003167	002022	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$
004523	001908	-01367	0500	0000	0375	0500	1000	0625	0000	%0327	J13	\$
004111	001062	-01191	0500	0000	0500	0500	1000	0500	0000	%0328	J14	\$
004166	002095	-02381	0500	0000	0625	0500	1000	0375	0000	%0329	J15	\$
003950	001932	-03401	0500	0000	0750	0500	1000	0250	0000	%0330	J16	\$
003958	001953	-03341	0500	0000	0875	0500	1000	0125	0000	%0331	J17	\$
003315	002080	-04385	0500	0000	1000	0500	1000	0000	0000	%0332	J18	\$
004768	002710	002274	0500	0125	0000	0500	0875	1000	0000	%0333	K10	\$
004408	001653	000707	0500	0125	0125	0500	0875	0875	0000	%0334	K11	\$
004542	002086	000226	0500	0125	0250	0500	0875	0750	0000	%0335	K12	\$
004332	001639	-00735	0500	0125	0375	0500	0875	0625	0000	%0336	K13	\$
004101	001161	-01133	0500	0125	0500	0500	0875	0500	0000	%0337	K14	\$
004135	001186	-01344	0500	0125	0625	0500	0875	0375	0000	%0338	K15	\$
004032	001630	-02243	0500	0125	0750	0500	0875	0250	0000	%0339	K16	\$
004043	001578	-02787	0500	0125	0875	0500	0875	0125	0000	%0340	K17	\$
003981	001408	-03603	0500	0125	1000	0500	0875	0000	0000	%0341	K18	\$
004797	002650	002272	0500	0250	0000	0500	0750	1000	0000	%0342	L10	\$
004555	001773	001645	0500	0250	0125	0500	0750	0875	0000	%0343	L11	\$
004418	0015											

004886	004062	001755	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
004847	004212	001014	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
004859	004386	000421	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
004776	004639	-002696	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
004681	004728	-01231	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
004062	003767	-02054	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
003908	002758	-01997	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
003862	003087	-02536	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$
003821	003387	-03452	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$
004941	003846	003064	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$
004825	004094	001803	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
004774	004206	001105	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
004790	004356	000447	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
004682	004637	-00301	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
004123	003201	-01611	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
003850	002814	-02044	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
003790	002423	-02416	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
004047	002407	-03054	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
004967	003833	003134	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
004837	003302	002770	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
005024	003174	001591	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
004988	003209	000868	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
004916	003398	-00029	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
004561	002789	-00841	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
004211	002104	-01322	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
004405	002042	-01981	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
004706	001903	-02591	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
005500	002944	003330	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
005106	002841	002829	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005236	002719	002335	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
005627	002382	001264	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
005519	002378	003078	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
005389	002273	003029	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
004885	001541	-01031	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$
005014	001578	-01685	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$
005293	001271	-02274	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$
005974	002097	003693	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
005557	002057	003191	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
005689	002041	002662	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
005889	001874	-001911	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006149	001615	-000920	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
006137	001644	-000167	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
005535	000981	-00738	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
005820	000932	-01368	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
005915	000904	-01873	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
006512	001363	-004280	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
006474	001381	-004248	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
006149	001180	-003202	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
006317	001034	-002396	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
006505	000939	-001551	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
006671	000873	-000485	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
006324	000478	-00308	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
006461	000456	-01063	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$
006738	000466	-01439	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
007057	000657	-004933	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
006766	000152	-004054	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
007671	000225	-003680	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
006889	000276	-002650	0750	0750	0375	0250	0250	0500	0000	%0543	G22	\$
007048	000109	-002099	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007105	-00012	-000876	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$
007218	000063	-000026	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$
007615	-00223	-00511	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$
007808	-00188	-01117	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$
008134	-00522	-005923	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$
007754	-01049	-005246	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$
007610	-00819	-004356	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$
007631	-00851	-003459	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$
007633	-00930	-002534	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$
007595	-00890	-001251	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$
007765	-00624	-000144	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$
007773	-00671	-00525	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$
007963	-00619	-01143	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$
008003	-01806	-006478	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$
007974	-01784	-005334	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$
007931	-01766	-004431	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$
007970	-01778	-003585	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$
007935	-01741	-002654	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$
008008	-01661	-001753	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$
008104	-01377	-000340	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$
008126	-01230	-00250	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$
008122	-01102	-00742	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$
004841	005852	002664	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$
004775	005973	002001	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$
004730	006154	001237	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$
004730	006358	000337	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$
004724	006158	-00914	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$
004638	004726	-01217	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$
004250	004227	-01629	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$
003862	003725	-02078	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$
003902	003298	-02524	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$
004839	005794	003371	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$
004971	004424	002089	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$
005000	004558	001331	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$
004954	004580	000728	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$
004906	004804	-00016	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$
004761	004552	-00771	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$
004313	003552	-01430	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$
004001	002966	-01888	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$
004260	002726	-02522	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$
004990	004111	003297	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$
005075	004068	002871	0875	0250	0125	0125	0750	0875	0000	%0586	L20	\$

009654	000000	000001	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009866	-00551	-00613	0875	1000	1000	0000	0125	0000	0000	%0730	b02	\$
0083317	-00983	-00722	0750	1000	1000	0000	0250	0000	0000	%0731	b03	\$
007717	-01245	-00967	0625	1000	1000	0000	0375	0000	0000	%0732	b04	\$
007228	-01807	-01348	0500	1000	1000	0000	0500	0000	0000	%0733	b05	\$
006710	-02315	-01852	0375	1000	1000	0000	0625	0000	0000	%0734	b06	\$
006124	-02914	-02341	0250	1000	1000	0000	0750	0000	0000	%0735	b07	\$
005723	-03207	-02655	0125	1000	1000	0000	0875	0000	0000	%0736	b08	\$
005456	-04615	-02979	0000	1000	1000	0000	1000	0000	0000	%0737	b09	\$
008726	000810	000320	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
008340	000003	000006	0875	0875	0875	0000	0125	0125	0000	%0739	c02	\$
007996	-00555	-00518	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
007255	-00946	-00758	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
006297	-01360	-01119	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
006740	-01887	-01595	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
005713	-02317	-02018	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005483	-02455	-02091	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
005601	-02608	-02554	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
008359	001480	000272	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
007883	000715	000272	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
007431	000055	-00037	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
006812	-00341	-00252	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
006314	-00909	-00811	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
005853	-01443	-01206	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
005353	-01883	-01606	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005120	-01978	-01538	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
005078	-01892	-01576	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007836	002366	001078	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007290	001486	000674	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
006849	000812	000396	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006303	000015	-00045	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
005874	-00414	-00392	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
005954	-00965	-00697	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
004986	-01488	-01262	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
004696	-01643	-01293	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
004734	-01443	-01838	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
007308	003152	001567	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006748	002189	001154	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006271	001532	000736	0750	0500	0500	0000	0250	0500	0000	%0767	f03	\$
005703	000832	000396	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005234	-00005	-00065	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005040	-00454	-00485	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
004570	-00985	-00865	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004248	-01305	-01308	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
004288	-01272	-01234	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
006707	004061	002037	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
006050	002998	001431	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005594	002271	001294	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
005146	001609	000962	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
004764	000753	000335	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
004378	-00020	-00034	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
004112	-00454	-00524	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
003865	-00743	-00571	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003839	-00758	-01241	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
006106	004834	002426	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005400	003793	001844	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
004895	003126	001629	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
004455	002450	001207	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
004152	001575	000851	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
003900	000836	000265	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
003496	-00011	-00048	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
003077	-00332	-00455	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
002730	-00180	-00503	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
005458	005527	002943	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004846	004317	002164	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
004721	004032	001822	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
004548	002792	001772	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
004173	001673	000745	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
003756	001001	000698	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
003185	000483	000197	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
002713	-00029	-00086	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
002251	-00032	-00085	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
004718	006611	003328	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
004740	005800	002854	0875	0000	0000	0125	1000	1000	0000	%0802	j02	\$
004697	004055	001833	0750	0000	0000	0250	1000	1000	0000	%0803	j03	\$
004700	004065	001786	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
004626	002913	000940	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
003949	001336	000389	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
002974	000389	000250	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
002140	000170	000126	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
001358	-00009	000000	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009691	000000	-00007	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
008673	-00064	-00524	0875	0875	0875	0100	0125	0125	0000	%0811	b11	\$
008139	-00102	-01002	0750	0750	0750	0250	0250	0250	0000	%0812	b12	\$
007412	-01010	-01364	0625	1000	0375	0375	0000	0000	0000	%0813	b13	\$
006652	-00064	-01874	0500	0500	0500	0500	0000	0000	0000	%0814	b14	\$
006053	-00264	-02309	0375	0375	1000	0625	0625	0625	0000	%0815	b15	\$
005285	-00298	-02933	0250	0250	0750	0750	0000	0000	0000	%0816	b16	\$
004616	-00310	-03571	0125	0250	1000	0875	0000	0000	0000	%0817	b17	\$
004423	-00476	-04655	0000	0000	1000	1000	0000	0000	0000	%0818	b18	\$
009281	000174	000589	1000	1000	0875	0000	0125	0000	0000	%0819	c10	\$
008487	000010	-00004	0875	0875	0125	0125	0125	0000	0000	%0820	c11	\$
007991	-00155	-00428	0750	0750	0875	0250	0250	0125	0000	%0821	c12	\$
007128	-00133	-01026	0625	0625	0875	0375	0375	0125	0000	%0822	c13	\$
006372	-00089	-01468	0500	0500	0875	0500	0500	0125	0000	%0823	c14	\$
005646	-00184	-02055	0375	0375	0875	0625	0625	0125	0000	%0824	c15	\$
004902	-00231	-02667	0250	0250	0875	0750	0750	0125	0000	%0825	c16	\$
004339	000090	-02922	0125	0125	0875	0875	0875	0125	0000	%0826	c17	\$
004138	000292	-03720	0000	0000	0750	1000	1000	0125	0000	%0827	c18	\$
009179	000286	-001487	1000	1000	1000	0000	0000	0250	0000	%0828	d10	\$
008480	000034	-000703	0875	0875	0750	0125	0125	0250	0000	%0829	d11	\$


```
%BEG HE63_22.TXT, Separation cmyn4*, cfi=0.90, D50, adapted $
%100 x LAB*a      %#1000 x (r g b c m y 0)      %nr.   pos $
%z004763 006664 003165 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 $
%z008237 000289 007120 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 $
%z005605 -04266 001411 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 $
%z005449 -04634 -02974 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 $
%z004437 -00311 -04611 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 $
%z004095 003698 -02201 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 $
%z001315 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 $
%z009618 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 $
%S
%z004718 006611 003328 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 $
%z008235 000285 007215 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 $
%z005697 -04293 001135 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 $
%z005456 -04616 -02979 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 $
%z004429 -00476 -04645 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 $
%z004032 003725 -02224 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 $
%z001145 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 $
%z009676 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/HE73/HE73L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG HE63.22.TXT, Separation cmyn4*, cfi=0.90, D50, adapted S
%100 x LAB*a      1000 x (r g b   c m y 0)   %nrr.   pos $
001107 -00018 000021 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002423 -00019 -00019 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003327 -00005 -00008 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004167 -00006 000010 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005115 -00005 -00027 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006329 000013 -00057 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
007448 000045 -00018 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008423 000006 000012 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009477 000002 -00002 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
010092 -00019 000020 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
020444 -00022 -00026 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
030372 -00010 -00019 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
040226 -00009 -00008 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
050179 -00004 -00060 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
060337 000005 -00075 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
070474 000042 -00031 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
080433 000004 000011 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
090695 -00003 000010 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
100101 -00011 000020 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
020453 -00014 -00034 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
030387 -00003 -00018 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
040232 -00011 000000 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
050162 -00001 -00044 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
060336 000007 -00057 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
070496 000048 -00033 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
080487 000002 000015 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
090699 -00003 000006 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
100192 -00009 000028 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
020413 -00018 -00018 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
030369 -00007 -00004 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
040181 -00006 000029 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
050808 -00003 -00022 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
060605 000003 -00054 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
070453 000053 -00025 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
080472 000005 000017 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
090699 -00002 -00002 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
100145 -00010 000019 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
020410 -00021 -00064 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
030268 -00013 -00065 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
0403017 -00007 -00048 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
0503780 -00027 -00033 0266 0266 0266 0333 0333 0333 0000 %1012 k14 $
0604223 000013 -00062 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
0704495 -00008 000057 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
0805150 000016 -00058 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
0905460 000017 000067 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
1006177 -00015 -00046 0600 0600 0600 0400 0400 0400 0000 %1017 k19 $
0206624 000009 000109 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
0307210 000000 -00042 0734 0734 0734 0266 0266 0266 0000 %1019 k21 $
0407858 000008 -00006 0800 0800 0800 0200 0200 0200 0000 %1020 k22 $
0508268 000014 000005 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
0608611 000011 000013 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
0709597 000006 -00010 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
0801157 -00008 000024 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
0902472 -00018 -00043 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
1002776 -00019 -00060 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
0203128 -00005 -00051 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
0303879 -00032 -00033 0266 0266 0266 0333 0333 0333 0000 %1028 l14 $
0404292 000003 000066 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
0504562 000000 000039 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
0605208 000017 -00089 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
0705513 000012 000029 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
0806197 -00002 -00070 0600 0600 0600 0400 0400 0400 0000 %1033 l19 $
0906673 000010 000062 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
1007218 000005 -00049 0734 0734 0734 0266 0266 0266 0000 %1035 l21 $
0207844 000011 -00008 0800 0800 0800 0200 0200 0200 0000 %1036 l22 $
0308292 000015 000001 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
0408663 000009 000009 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
0509614 000003 -00007 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
0601195 000000 000034 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
0702459 -00013 -00066 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
0802724 -00013 -00070 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
0903072 000003 -00040 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
1003832 -00019 -00034 0266 0266 0266 0333 0333 0333 0000 %1044 m14 $
0204231 000012 -00050 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
0304560 000011 000052 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
0405211 000026 -00064 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
0505502 000032 000028 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
0606180 -00001 -00049 0600 0600 0600 0400 0400 0400 0000 %1049 m19 $
0706617 000026 000062 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
0807213 000005 -00033 0734 0734 0734 0266 0266 0266 0000 %1051 m21 $
0907871 000010 -00001 0800 0800 0800 0200 0200 0200 0000 %1052 m22 $
```