See original or other formats: http://www.uni-ulm.de/~klaus.richter/GE72/GE72L0N1.TXT /.PS
Technical information: http://www.ps.bam.de V 2.1, io=1.1, Cx=0; cf1=0.90; nt=0.18; nx=1.0

TUB registration: 20091101-GE72/GE72L0N1.TXT /.PS
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

```
%BEG GE72.txt, Separation cmyn6*, cf1=0.95, D65, not adapted $
%100 x LAB*          1000 x (r g b c m y 0)          nr*   pos $
002192 -00211 000112 0000 0000 0000 1000 1000 0000 \0000 A01 $
002318 000519 -00856 0000 0000 0125 1000 1000 0875 0000 \a001 A02 $
002413 000717 -01132 0000 0000 0250 1000 1000 0750 0000 \a002 A03 $
002447 000665 -01387 0000 0000 0375 1000 1000 0625 0000 \a003 A04 $
002515 001017 -01999 0000 0000 0500 1000 1000 0500 0000 \a004 A05 $
002708 001252 -02501 0000 0000 0625 1000 1000 0375 0000 \a005 A06 $
002922 001620 -02875 0000 0000 0750 1000 1000 0250 0000 \a006 A07 $
003218 001845 -03294 0000 0000 0875 1000 1000 0125 0000 \a007 A08 $
003438 002196 -03934 0000 0000 1000 1000 1000 0000 0000 \a008 A09 $
002650 -00568 -00614 0000 0125 0000 0875 0875 0000 0000 \0001 B01 $
002459 -00354 -00295 0000 0125 0125 1000 0875 0875 0000 \0010 B02 $
002460 000000 -00354 0000 0125 0250 1000 0875 0750 0000 \0011 B03 $
002461 000294 -01484 0000 0125 0375 1000 0875 0625 0000 \0012 B04 $
002745 000324 -02014 0000 0125 0500 1000 0875 0500 0000 \0013 B05 $
002947 000453 -02447 0000 0125 0625 1000 0875 0375 0000 \0020 A02 $
003241 000847 -02781 0000 0125 0750 1000 0875 0250 0000 \0015 B07 $
003245 001146 -03166 0000 0125 0875 1000 0875 0125 0000 \0016 B08 $
003703 001387 -03623 0000 0125 1000 1000 0875 0000 0000 \0017 B09 $
003177 -00137 -00192 0000 0250 0000 1000 0750 0000 0000 \0021 C01 $
002831 -00813 000392 0000 0250 0125 1000 0750 0875 0000 \0022 C02 $
002830 -00422 -00178 0000 0250 0250 1000 0750 0750 0000 \0023 C03 $
002828 -00469 -01582 0000 0250 0375 1000 0750 0625 0000 \0021 C04 $
002662 -00202 -01955 0000 0250 0500 1000 0750 0500 0000 \0025 C05 $
003286 -00336 -02335 0000 0250 0625 1000 0750 0375 0000 \0023 C06 $
003570 001164 -02695 0000 0250 0750 1000 0750 0250 0000 \0024 C07 $
003777 001414 -03027 0000 0250 0875 1000 0750 0125 0000 \0025 C08 $
004012 000620 -03570 0000 0250 1000 1000 0750 0000 0000 \0026 C09 $
003592 -00330 000916 0000 0375 0000 1000 0625 0000 0000 \0031 D01 $
003256 -02074 -00231 0000 0375 0125 1000 0625 0875 0000 \0028 D02 $
003071 -01575 -00502 0000 0375 0250 1000 0625 0750 0000 \0029 D03 $
002968 -01051 -01242 0000 0375 0375 1000 0625 0625 0000 \0030 D04 $
003358 -01003 -01758 0000 0375 0500 1000 0625 0500 0000 \0031 D05 $
003579 -00675 -02354 0000 0375 0625 1000 0625 0375 0000 \0032 D06 $
003781 -00439 -02930 0000 0375 0750 1000 0625 0250 0000 \0033 D07 $
003906 -00069 -03118 0000 0375 0875 1000 0625 0125 0000 \0034 D08 $
004161 000236 -03620 0000 0375 1000 1000 0625 0000 0000 \0035 D09 $
004031 -00374 000147 0000 0500 0000 1000 0500 0000 0000 \0037 E01 $
003546 -02496 000413 0000 0500 0125 1000 0500 0875 0000 \0037 E02 $
003467 -02205 -00246 0000 0500 0250 1000 0500 0750 0000 \0038 E03 $
003352 -02017 -01107 0000 0500 0375 1000 0500 0625 0000 \0039 E04 $
003660 -01561 -01662 0000 0500 0500 1000 0500 0500 0000 \0040 E05 $
003765 -01244 -02263 0000 0500 0625 1000 0500 0375 0000 \0041 E06 $
003913 -00943 -02743 0000 0500 0750 1000 0500 0250 0000 \0042 E07 $
004068 -00551 -03147 0000 0500 0875 1000 0500 0125 0000 \0043 E08 $
004259 -00311 -03665 0000 0500 1000 1000 0500 0000 0000 \0044 E09 $
003932 -02467 -01739 0000 0625 0000 1000 0375 0000 0000 \0046 F01 $
004003 -02901 000767 0000 0625 0125 1000 0375 0875 0000 \0046 F02 $
003930 -02627 -00402 0000 0625 0250 1000 0375 0750 0000 \0047 F03 $
003847 -02514 -00802 0000 0625 0375 1000 0375 0625 0000 \0048 F04 $
003910 -02377 -01176 0000 0625 0500 1000 0375 0500 0000 \0049 F05 $
004086 -01761 -02330 0000 0625 0625 1000 0375 0375 0000 \0050 F06 $
004156 -01432 -02651 0000 0625 0750 1000 0375 0250 0000 \0051 F07 $
004351 -01161 -03175 0000 0625 0875 1000 0375 0125 0000 \0052 F08 $
004509 -00910 -03634 0000 0625 1000 1000 0375 0000 0000 \0053 F09 $
004782 -03876 002419 0000 0750 0000 1000 0250 1000 0000 \0054 G01 $
004486 -03515 001159 0000 0750 0125 1000 0250 0875 0000 \0055 G02 $
004393 -03270 000876 0000 0750 0250 1000 0250 0750 0000 \0056 G03 $
004396 -03046 -00405 0000 0750 0375 1000 0250 0625 0000 \0057 G04 $
004377 -02889 -00819 0000 0750 0500 1000 0250 0500 0000 \0058 G05 $
004368 -02589 -01756 0000 0750 0625 1000 0250 0375 0000 \0059 G06 $
004464 -02244 -02735 0000 0750 0750 1000 0250 0250 0000 \0060 G07 $
004615 -01698 -03183 0000 0750 0875 1000 0250 0125 0000 \0061 G08 $
004850 -01153 -03632 0000 0750 1000 1000 0250 0000 0000 \0062 G09 $
005157 -00506 003022 0000 0875 0000 1000 0125 0000 0000 \0063 H01 $
004900 -03187 000811 0000 0875 0125 1000 0125 0875 0000 \0064 H02 $
004892 -04017 000656 0000 0875 0250 1000 0125 0750 0000 \0065 H03 $
004856 -03658 -00184 0000 0875 0375 1000 0125 0625 0000 \0066 H04 $
004843 -03401 -00901 0000 0875 0500 1000 0125 0500 0000 \0067 H05 $
004871 -03087 -01489 0000 0875 0625 1000 0125 0375 0000 \0068 H06 $
005021 -02672 -02088 0000 0875 0750 1000 0125 0250 0000 \0069 H07 $
004782 -02424 -03672 0000 0875 0875 1000 0125 0125 0000 \0070 H08 $
005343 -03910 -01978 0000 1000 0000 1000 0000 0000 0000 \0071 H09 $
005641 -05738 003352 0000 1000 0000 1000 0000 1000 0000 \0072 I01 $
005588 -05395 002803 0000 1000 0125 1000 0000 0875 0000 \0073 I02 $
005554 -05113 001002 0000 1000 0250 1000 0000 0750 0000 \0074 I03 $
005465 -04821 000194 0000 1000 0375 1000 0000 0625 0000 \0075 I04 $
005403 -04548 -00428 0000 1000 0500 1000 0000 0500 0000 \0076 I05 $
005691 -04332 -01072 0000 1000 0625 1000 0000 0375 0000 \0077 I06 $
005802 -04093 -01718 0000 1000 0750 1000 0000 0250 0000 \0078 I07 $
005520 -03242 -03176 0000 1000 0875 1000 0000 0125 0000 \0079 I08 $
005360 -02269 -03888 0000 1000 1000 1000 0000 0000 0000 \0080 I09 $
002170 000734 000769 0125 0000 0000 0875 1000 1000 0000 \0081 J01 $
002217 000827 -00032 0125 0000 0125 0875 1000 0875 0000 \0082 J02 $
002353 000800 -00353 0125 0000 0250 0875 1000 0750 0000 \0083 J03 $
002576 001481 -01308 0125 0000 0375 0875 1000 0625 0000 \0084 J04 $
002676 001528 -01685 0125 0000 0500 0875 1000 0500 0000 \0085 J05 $
002811 001602 -02196 0125 0000 0625 0875 1000 0375 0000 \0086 J06 $
003108 001990 -02585 0125 0000 0750 0875 1000 0250 0000 \0087 J07 $
003220 002366 -02237 0125 0000 0875 0875 1000 0125 0000 \0088 J08 $
003281 003328 -03760 0125 0000 1000 0875 1000 0000 0000 \0089 J09 $
002710 -00128 000693 0125 0125 0000 0875 0875 0000 0000 \0090 K01 $
002519 000010 000993 0125 0125 0125 0875 0875 0875 0000 \0091 K02 $
003037 000552 -00186 0125 0125 0250 0875 0875 0750 0000 \0092 K03 $
003137 000652 -01106 0125 0125 0375 0875 0875 0625 0000 \0093 K04 $
003338 000739 -01435 0125 0125 0500 0875 0875 0500 0000 \0094 K05 $
003523 000793 -01903 0125 0125 0625 0875 0875 0375 0000 \0095 K06 $
003604 001355 -02491 0125 0125 0750 0875 0875 0250 0000 \0096 K07 $
003741 001420 -02897 0125 0125 0875 0875 0875 0125 0000 \0097 K08 $
004028 001987 -03470 0125 0125 1000 0875 0875 0000 0000 \0098 K09 $
002831 -00813 000392 0250 0125 0000 0750 0750 0000 0000 \0100 L02 $
003503 -00816 000643 0250 0125 0125 0750 0750 0875 0000 \0100 L02 $
003218 -00519 000342 0250 0125 0250 0750 0750 0750 0000 \0101 L03 $
003405 -00154 -01082 0250 0125 0375 0750 0750 0625 0000 \0102 L04 $
003500 000137 -01097 0250 0125 0500 0750 0750 0500 0000 \0103 L05 $
003788 000334 -01903 0125 0250 0625 0875 0750 0375 0000 \0104 L06 $
003967 000576 -02335 0125 0250 0750 0875 0750 0250 0000 \0105 L07 $
004080 000800 -02636 0125 0250 0875 0875 0750 0125 0000 \0106 L08 $
004286 001241 -03325 0125 0250 1000 0875 0750 0000 0000 \0107 L09 $
003795 -01242 000147 0250 0375 0000 0750 0625 0000 0000 \0109 M02 $
003719 -01591 000814 0125 0375 0125 0875 0625 0875 0000 \0109 M02 $
003562 -01184 -00010 0125 0375 0250 0875 0625 0750 0000 \0110 M03 $
003532 -00908 -01090 0125 0375 0375 0875 0625 0625 0000 \0111 M04 $
003524 -00633 -01488 0125 0375 0500 0875 0625 0500 0000 \0112 M05 $
004095 -00326 -01835 0125 0375 0625 0875 0625 0375 0000 \0113 M05 $
004234 -00119 -02164 0125 0375 0750 0875 0625 0250 0000 \0114 M06 $
004366 000345 -02857 0125 0375 0875 0875 0625 0125 0000 \0115 M08 $
004603 000541 -03291 0125 0375 1000 0875 0625 0000 0000 \0116 M09 $
003970 -02148 -00113 0125 0500 0000 0875 0500 0000 0000 \0117 N01 $
004092 -02289 001105 0125 0500 0125 0875 0500 0875 0000 \0118 N02 $
003980 -02353 000600 0125 0500 0250 0875 0500 0750 0000 \0119 N03 $
003998 -01672 -00671 0125 0500 0375 0875 0500 0625 0000 \0120 N04 $
004000 -01320 -01180 0125 0500 0500 0875 0500 0500 0000 \0121 N05 $
004284 -00914 -01936 0125 0500 0625 0875 0500 0375 0000 \0122 N05 $
004453 -00618 -02312 0125 0500 0750 0875 0500 0250 0000 \0123 N06 $
004568 -00367 -02793 0125 0500 0875 0875 0500 0125 0000 \0124 N08 $
004831 -00060 -03188 0125 0500 1000 0875 0500 0000 0000 \0125 N09 $
004072 -02103 000147 0125 0625 0000 0875 0375 0000 0000 \0126 O01 $
004508 -03009 001596 0125 0625 0125 0875 0375 0875 0000 \0127 O02 $
004511 -03113 001000 0125 0625 0250 0875 0375 0750 0000 \0128 O03 $
004468 -02843 -00207 0125 0625 0375 0875 0375 0625 0000 \0129 O04 $
004471 -02575 -00600 0125 0625 0500 0875 0375 0500 0000 \0130 O05 $
004501 -01513 -01876 0125 0625 0875 0875 0375 0000 0000 \0131 O06 $
004554 -01432 -02051 0125 0625 1000 0875 0375 0000 0000 \0132 O08 $
004854 -00928 -02722 0125 0625 0875 0875 0375 0000 0000 \0133 O08 $
005045 -00626 -03119 0125 0625 1000 0875 0375 0000 0000 \0134 O09 $
005013 -04012 003121 0125 0750 0000 0875 0250 1000 0000 \0135 P01 $
005030 -03926 002105 0125 0750 0125 0875 0250 0875 0000 \0136 P02 $
004930 -03827 000676 0125 0750 0250 0875 0250 0750 0000 \0137 P03 $
004922 -03838 000045 0125 0750 0375 0875 0250 0625 0000 \0138 P04 $
004938 -03850 -00588 0125 0750 0500 0875 0250 0500 0000 \0139 P05 $
004938 -03291 -01492 0125 0750 0625 0875 0250 0375 0000 \0140 P06 $
005000 -02733 -02396 0125 0750 0750 0875 0250 0250 0000 \0141 P07 $
005042 -01509 -02752 0125 0750 0875 0875 0250 0125 0000 \0142 P08 $
005210 -01000 -03188 0125 0750 1000 0875 0250 0000 0000 \0143 P09 $
005501 -05446 004051 0125 0875 0000 0875 0125 1000 0000 \0144 Q01 $
005510 -05326 003129 0125 0875 0125 0875 0125 0875 0000 \0145 Q02 $
005437 -04887 001243 0125 0875 0250 0875 0125 0750 0000 \0146 Q03 $
005398 -03639 000242 0125 0875 0375 0875 0125 0625 0000 \0147 Q04 $
005410 -03125 -00546 0125 0875 0500 0875 0125 0500 0000 \0148 Q05 $
005421 -02971 -01234 0125 0875 0625 0875 0125 0375 0000 \0149 Q05 $
005439 -02802 -01921 0125 0875 0750 0875 0125 0250 0000 \0150 Q06 $
005301 -02286 -02694 0125 0875 0875 0875 0125 0000 0000 \0151 Q08 $
005449 -01907 -03147 0125 0875 1000 0875 0125 0000 0000 \0152 Q09 $
006026 -05812 004004 0125 1000 0000 0875 0000 1000 0000 \0153 R01 $
006014 -05802 -00418 0125 1000 0125 0875 0000 0875 0000 \0154 R02 $
005954 -04656 001506 0125 1000 0250 0875 0000 0750 0000 \0155 R03 $
005881 -04184 000562 0125 1000 0375 0875 0000 0625 0000 \0156 R04 $
005836 -03902 -00418 0125 1000 0500 0875 0000 0500 0000 \0157 R05 $
005875 -03693 -00947 0125 1000 0625 0875 0000 0375 0000 \0158 R05 $
005810 -03384 -01506 0125 1000 0750 0875 0000 0250 0000 \0159 R07 $
005746 -02980 -02358 0125 1000 0875 0875 0000 0125 0000 \0160 R08 $
005791 -02722 -02961 0125 1000 1000 0875 0000 0000 0000 \0161 R09 $
002419 001348 000976 0250 0000 0000 0750 1000 1000 0000 \0162 S01 $
002260 001443 000507 0250 0000 0125 0750 1000 0875 0000 \0163 S02 $
002444 001387 000000 0250 0000 0250 0750 1000 0750 0000 \0164 S03 $
002667 001837 -00971 0250 0000 0375 0750 1000 0625 0000 \0165 S04 $
002918 002013 -01284 0250 0000 0500 0750 1000 0500 0000 \0166 S05 $
002807 002297 -01884 0250 0000 0625 0750 1000 0375 0000 \0167 S07 $
003177 002395 -02307 0250 0000 0750 0750 1000 0250 0000 \0168 S07 $
003429 002396 -02720 0250 0000 0875 0750 1000 0125 0000 \0169 S08 $
003529 003172 -03393 0250 0000 1000 0750 1000 0000 0000 \0170 S09 $
002969 000000 -00354 0250 0125 0000 0750 0875 1000 0000 \0171 T01 $
002977 000790 000629 0250 0125 0125 0750 0875 0875 0000 \0172 T02 $
003090 000790 000000 0250 0125 0250 0750 0875 0750 0000 \0173 T03 $
003282 001059 -00829 0250 0125 0375 0750 0875 0625 0000 \0174 T04 $
003489 001172 -01185 0250 0125 0500 0750 0875 0500 0000 \0175 T05 $
003688 001172 -01540 0250 0125 0625 0750 0875 0375 0000 \0176 T05 $
003795 001830 -02179 0250 0125 0750 0750 0875 0250 0000 \0177 T07 $
003934 001830 -02593 0250 0125 0875 0750 0875 0125 0000 \0178 T08 $
004246 002306 -03058 0250 0125 1000 0750 0875 0000 0000 \0179 T09 $
003458 -00221 000171 0250 0250 0000 0750 0750 0000 0000 \0181 U01 $
003559 -00239 001143 0250 0250 0125 0750 0750 0875 0000 \0181 U02 $
003532 000000 000000 0250 0250 0250 0750 0750 0750 0000 \0182 U03 $
004042 000250 -00487 0250 0250 0375 0750 0750 0625 0000 \0183 U04 $
004158 000521 -01033 0250 0250 0500 0750 0750 0500 0000 \0184 U05 $
004221 000797 -01310 0250 0250 0625 0750 0750 0375 0000 \0185 U06 $
004373 001142 -01858 0250 0250 0750 0750 0750 0250 0000 \0186 U07 $
004500 001142 -02278 0250 0250 0875 0750 0750 0125 0000 \0187 U08 $
004934 001539 -02735 0250 0250 1000 0750 0750 0000 0000 \0188 U09 $
003751 -00985 000349 0250 0375 0000 0750 0625 0000 0000 \0189 V01 $
003956 -00893 001471 0250 0375 0125 0750 0625 0875 0000 \0190 V02 $
004156 -00700 001471 0250 0375 0250 0750 0625 0750 0000 \0191 V03 $
004253 -00471 -00537 0250 0375 0375 0750 0625 0625 0000 \0192 V04 $
004387 -00239 -00921 0250 0375 0500 0750 0625 0500 0000 \0193 V05 $
004441 000041 -01472 0250 0375 0625 0750 0625 0375 0000 \0194 V06 $
004640 000276 -01753 0250 0375 0750 0750 0625 0250 0000 \0195 V07 $
004874 000681 -02373 0250 0375 0875 0750 0625 0125 0000 \0196 V08 $
005175 000801 -02651 0250 0375 1000 0750 0625 0000 0000 \0197 V09 $
004521 -01699 001857 0250 0500 0125 0750 0500 0875 0000 \0198 W02 $
004521 -01699 001857 0250 0500 0125 0750 0500 0875 0000 \0199 W02 $
004576 -01699 001857 0250 0500 0250 0750 0500 0750 0000 \0200 W03 $
004583 -01038 -00206 0250 0500 0375 0750 0500 0625 0000 \0201 W04 $
004583 -00377 -00206 0250 0500 0500 0750 0500 0500 0000 \0202 W05 $
004810 -00431 -01449 0250 0500 0625 0750 0500 0375 0000 \0203 W06 $
004810 -00431 -01449 0250 0500 0750 0750 0500 0250 0000 \0204 W07 $
005110 -00136 -02127 0250 0500 0875 0750 0500 0125 0000 \0205 W08 $
005290 000277 -02680 0250 0500 1000 0750 0500 0000 0000 \0206 W09 $
004491 -02645 000000 0250 0625 0000 0750 0375 0000 0000 \0207 X01 $
004992 -02497 002211 0250 0625 0125 0750 0375 0875 0000 \0208 X02 $
005021 -02497 001277 0250 0625 0250 0750 0375 0750 0000 \0209 X03 $
004990 -01895 000063 0250 0625 0375 0750 0375 0625 0000 \0210 X04 $
005014 -01895 -00421 0250 0625 0500 0750 0375 0500 0000 \0211 X05 $
005022 -01159 -01548 0250 0625 0625 0750 0375 0375 0000 \0212 X06 $
005171 -00875 -01859 0250 0625 0750 0750 0375 0250 0000 \0213 X07 $
005295 -00587 -02208 0250 0625 0875 0750 0375 0125 0000 \0214 X08 $
005440 -00299 -02557 0250 0625 1000 0750 0375 0000 0000 \0215 X09 $
005340 -03570 003607 0250 0750 0000 0750 0250 1000 0000 \0216 Y01 $
005406 -03247 002489 0250 0750 0125 0750 0250 0875 0000 \0217 Y02 $
005515 -03247 001371 0250 0750 0250 0750 0250 0750 0000 \0218 Y03 $
005456 -02580 000416 0250 0750 0375 0750 0250 0625 0000 \0219 Y04 $
005453 -02580 -00207 0250 0750 0500 0750 0250 0500 0000 \0220 Y05 $
005451 -01860 -01156 0250 0750 0625 0750 0250 0375 0000 \0221 Y06 $
005349 -01860 -01571 0250 0750 0750 0750 0250 0250 0000 \0222 Y07 $
005559 -01227 -02168 0250 0750 0875 0750 0250 0125 0000 \0223 Y08 $
005719 -00853 -02611 0250 0750 1000 0750 0250 0000 0000 \0224 Y09 $
005858 -04908 004544 0250 0875 0000 0750 0125 1000 0000 \0225 Z01 $
005868 -04908 003610 0250 0875 0125 0750 0125 0875 0000 \0226 Z02 $
005908 -03803 002004 0250 0875 0250 0750 0125 0750 0000 \0227 Z03 $
005925 -03349 000849 0250 0875 0375 0750 0125 0625 0000 \0228 Z04 $
005950 -03349 000000 0250 0875 0500 0750 0125 0500 0000 \0229 Z05 $
005897 -02536 -00800 0250 0875 0625 0750 0125 0375 0000 \0230 Z06 $
005882 -02196 -01571 0250 0875 0750 0750 0125 0250 0000 \0231 Z07 $
005728 -01884 -02391 0250 0875 0875 0750 0125 0125 0000 \0232 Z08 $
005658 -01414 -02754 0250 0875 1000 0750 0125 0000 0000 \0233 Z09 $
006380 -05381 004725 0250 1000 0000 0750 0000 1000 0000 \0234 a01 $
006317 -04793 003610 0250 1000 0125 0750 0000 0875 0000 \0235 a02 $
006493 -04619 002485 0250 1000 0250 0750 0000 0750 0000 \0236 a03 $
006397 -03965 001102 0250 1000 0375 0750 0000 0625 0000 \0237 a04 $
006203 -03501 000170 0250 1000 0500 0750 0000 0500 0000 \0238 a05 $
006295 -03143 -00481 0250 1000 0625 0750 0000 0375 0000 \0239 a06 $
006202 -02939 -01212 0250 1000 0750 0750 0000 0250 0000 \0240 a07 $
006288 -02692 -01931 0250 1000 0875 0750 0000 0125 0000 \0241 a08 $
006267 -02392 -02694 0250 1000 1000 0750 0000 0000 0000 \0242 a09 $
```