





Picture B1: Flower motif, 14 CIE-test colours and 2 + 16 grey steps (sf); PS operators *settransfer*, 4 *colorimage*




Picture D2: Radial gratings **W-O**, **W-L**, **W-V**, **W-N**, and **W-Z**; Use of PS operator *LAB** setcolor




Picture B3: 14 CIE-test colours and 2 + 16 grey steps; Use of PS operator *LAB* setcolor*

Fig. B1 to B7 of ISO/IEC-test chart 2;


Picture B7: Landolt-Rings $W\text{-I}$ and $W\text{-IV}$, Use ISO/IEC 15775 and input: LAB^* setcolor DIS ISO/IEC 19839-X; output: w^* setgray




picture B4: 16 equidistant steps $\mathbf{W}\text{-}\mathbf{C}$, $\mathbf{W}\text{-}\mathbf{M}$, $\mathbf{W}\text{-}\mathbf{Y}$ and $\mathbf{W}\text{-}\mathbf{N}$; PS operator LAB^* setcolor



picture B6: Landolt-rings **W-C** and **W-M**; Use of PS operator *LAB** *setcolor*



picture B7: Landolt-rings $W-Y$ and $W-N$; Use of PS operator $LAB^* \underline{setcolor}$



— 20030101-EE92/10L/L92E07FP.PS/.PDF BAM 1
application for monitors (Yr=2.5) and printers

ode=rha4ta